


Quick Start Guide for FRDM-TWRPI

Contents:

- Quick Start Package Overview
- Get to Know the FRDM-TWRPI
- Getting Started Out of the Box
- Explore Further



www.freescale.com/FRDM-TWRPI


Quick Start Package Overview

These documents are available as part of the Quick Start Package:

Name	Type	Description
Quick Start Guide	PPT	This document

Additional reference documents are available on freescale.com/FRDM-TWRPI:

Name	Description
FRDM-TWRPI Schematics	PDF schematics for the FRDM-TWRPI hardware
FRDM-TWRPI Design Package	Zip file containing all design source files for the FRDM-TWRPI hardware.



Get to Know the FRDM-TWRPI

2 of 3

The Freescale Freedom development platform is a set of software and hardware tools for evaluation and development. It is ideal for rapid prototyping of microcontroller-based applications. The Freescale Freedom TWRPI adapter module, FRDM-TWRPI, allow Tower Plug In (TWRPI) modules featuring a variety of sensors and radios to be easily incorporated into the Freescale Freedom development platform.

Features:

- General Purpose Tower Plug-in socket for use with TWRPI-based sensor and radio modules
- Pass-thru of all Freedom Development Platform signals to allow additional expansion
- Thru-hole test points of key interface signals:
 - SPI and I2C



Fig A: FRDM-TWRPI top



Fig B: FRDM-TWRPI shown affixed to a FRDM-K64F Freedom development platform


		TWRPI Socket				Freedom Header	
		J5 - Power / Analog	J6 - Digital Signals	J1 - GPIO/UART	J2 - I2C/SPI	J3 - Power	J4 - Analog
I2C	SCL		Pin 3		Pin 20		
	SDA		Pin 4		Pin 18		
SPI	MISO		Pin 9		Pin 10		
	MOSI		Pin 10		Pin 8		
	SS		Pin 11		Pin 6		
	CLK		Pin 12		Pin 12		
UART	RX		Pin 17	Pin 4			
	TX		Pin 18	Pin 2			
GPIO	GPIO0		Pin 15	Pin 1			
	GPIO1		Pin 16	Pin 3			
	GPIO4		Pin 19	Pin 10			
	GPIO5		Pin 20	Pin 12			
Analog	ADC0	Pin 8					Pin 2
	ADC1	Pin 9					Pin 4
	ADC2	Pin 10					Pin 6
Power	5V	Pin 1				Pin 10	
	3.3V	Pin 2				Pins 4 & 8	
	GND	Pin 3				Pins 12 & 14	
	Reset	Pin 20				Pin 6	

Getting Started Out of the Box

Assembling the Hardware

- 1 Insert your selected Freescale Tower Plug In (TWRPI) module in to the socket of the FRDM-TWRPI.

The FRDM-TWRPI module can accept general purpose TWRPI modules. Each TWRPI module is keyed and uniquely spaced to enforce the correct module type and orientation.



- 2 Attach the FRDM-TWRPI board (with TWRPI module attached) to the desired Freescale Freedom Development Platform.

The headers on the Freedom board are uniquely spaced to ensure correct orientation with compatible peripheral modules.

- 3 The FRDM-TWRPI adapter module provides a high degree of flexibility and potential combinations. Please refer to reference code provided with either the selected Freescale Freedom Development Platform or Tower Plug In module as a baseline for interfacing the two selected components.

Explore Further



Now that you are familiar with the FRDM-TWRPI, it's time to explore additional detailed design documents, such as schematics and layout files, available on www.freescale.com/FRDM-TWRPI. Select your next path from the links in the **Jump Start Your Design** section.

How to Reach Us:

Home Page:
freescale.com

Web Support:
freescale.com/support

Information in this document is provided solely to enable system and software implementers to use Freescale products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. “Typical” parameters that may be provided in Freescale data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including “Typicals”, must be validated for each customer application by customer’s technical experts. Freescale does not convey any license under its patent rights nor the rights of others. Freescale sells products pursuant to standard terms and conditions of sale, which can be found at the following address: <http://www.reg.net/v2/webservices/Freescale/Docs/TermsandConditions.htm>

Freescale, the Freescale logo, Altivec, C-5, CodeTest, CodeWarrior, ColdFire, C_Ware, Energy Efficient Solutions logo, Kinetis, mobileGT, PowerQUICC, Processor Expert, QorIQ, Qorriva, StarCore, Symphony, and VortiQa are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. Airfast, BeeKit, BeeStack, ColdFire+, CoreNet, Flexis, MadniV, MXC, Platform in a Package, QorIQ Qonverge, QUICC Engine, Ready Play, SafeAssure, SMARTMOS, TurboLink, Vybrid, and Xtrinsic are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© Freescale Semiconductor, Inc. 2012.
All rights reserved.