

P1025RDB-PA Quick Start Guide

1.1 Introduction

This quick start guide applies to boards with assembly rev "700-26826 Rev A". Please check the top side of the board to see the revision number.

1.2 P1025RDB-PA Board Details

Figure 1 shows the P1025RDB-PA board interface.




Figure 1: P1025RDB-PA Board Interface

1.2.1 High Level Block Diagram

Figure 2 shows the high level block diagram of P1025RDB-PA.




Figure 2: High Level Block Diagram

1.2.2 Key Features of the P1025RDB-PA

- Freescale QorIQ architecture CPU
 - QorIQ P1025E, 533 MHz
- Memory Sub-system
 - SDRAM
 - The 1Gbyte (8 bit x 4 chip) DDR3 SDRAM
 - NOR Flash
 - 16MB 16 bit NOR Flash
 - NAND Flash:

- 32MB SLC NAND Flash
 - 256 Kbit M24256 I2C EEPROM
 - 128 Mbit SPI flash
 - I2C Board 128x8 bit memory
 - SD/MMC connector to interface with the SD memory card
- PCI-E
 - PCI-E lane 0: mini-PCI-E X1 connector with USB 2.0 signal
 - PCI-E lane 1: One PCI-E X1 connector
- USB 2.0
 - Dual Type A USB slot, connected to USB PHY via USB HUB
- Ethernet
 - eTSEC1: Connected to RGMII PHY –AR8021
 - eTSEC2: Connected to SGMII PHY –VSC8221
 - eTSEC3: Connected to RGMII PHY –AR8021
- UART
 - DUART interface: supports two UARTs up to 115200 bps for console display; Dual RJ45 slot are used for these 2 UART ports.
- QUICC Engine
 - X4 PMC connectors to support QE TDM function with T1/E1 daughtercard and SLIC card.
 - UEC1: Connect to MII PHY –KSZ8041NL
 - UEC5: Connect to RMII PHY –KSZ8041NL
 - Full duplex serial RS-485 port
- MISC
 - LED
 - Power LED (Green)
 - Link LED (Green) on each RJ45 ethernet connector
 - Activities LED (Yellow) on each RJ45 ethernet connector
 - JTAG/COP for debugging
 - Reset: Manual Reset and software reset function will be used on the design
 - I2C
 - Serial EEPROM – Board identification (System ID and DDR SPD)
 - Real-time clock
- POR (Power On Reset Configurations)
 - Supports critical POR setting changed via switches on board
- PCB

- Power/reset button are located at the rear of the casing
- Power LED and Ethernet LED are located at the front of the casing
- Power
 - Internal open frame power supply, which converts 220V AC to 12V DC and 5V DC.
- Schematics – OrCad; PCB - Allegro

1.2.3 Known Hardware Issues with 700-26826 Revision A

None.

1.3 Default Booting Method

By default, the boot loader executes from NOR flash.

1.4 Switch Settings

Table 1 shows the default switch setting.

Table 1: Board Default Switch Setting

Switch	1	2	3	4	5	6	7	8
SW4	ON	ON	OFF	OFF	OFF	OFF	ON	ON
SW3	OFF	ON	OFF	ON	OFF	ON	ON	ON

Table 2 shows the dual core switch settings for frequency and boot location.

Table 2: Switch Setting for Frequency and Boot Location, dual Core

Switch Settings SW4[1:6]	Switch Settings SW3[2:3]	Core0 Freq (MHz)	Core1 Freq (MHz)	Platform (MHz)	DDR Freq(MHz)	Boot Location	Boot Hold-off
11 0000	10	533	533	267	667	NOR	Core0 boot; Core1 hold-off
11 0001	10	533	533	267	667	SD/MMC	
11 0010	10	533	533	267	667	SPI	
11 0011	10	533	533	267	667	NAND	
11 0100	10	400	400	267	667	NOR	
11 0101	10	400	400	267	667	SD/MMC	
11 0110	10	400	400	267	667	SPI	

11 0111	10	400	400	267	667	NAND	
---------	----	-----	-----	-----	-----	------	--

Table 3 shows the single core switch settings for frequency and boot location.

Table 3: Switch Setting for Frequency and Boot Location, Single Core

Switch Settings SW4[1:6]	Switch Settings SW3[2:3]	Core0 Freq(MHz)	Core1 Freq(MHz)	Platform (MHz)	DDR Freq(MHz)	Boot Location	Boot Hold-off
110000	01	533	N/A	267	667	NOR	Core0 boot
110001	01	533	N/A	267	667	SD/MMC	
110010	01	533	N/A	267	667	SPI	
110011	01	533	N/A	267	667	NAND	
110100	01	400	N/A	267	667	NOR	
110101	01	400	N/A	267	667	SD/MMC	
110110	01	400	N/A	267	667	SPI	
110111	01	400	N/A	267	667	NAND	
100000	01	667	N/A	333	667	NOR	
100001	01	667	N/A	333	667	SD/MMC	
100010	01	667	N/A	333	667	SPI	
100011	01	667	N/A	333	667	NAND	

Note: 1=ON; 0=OFF;

Table 4 shows the all configuration options that are available on the board.

Table 4: Configuration options of all switches

Switch	Signal name	Signal Meaning	Setting
SW4[1:6]	SWITCH[1:6]	Frequency and boot ROM setting	For more details, refer to Table 2
SW4[7]	LGPL5 (cfg_boot_seq[1])	Indicates whether the boot sequencer is enabled during boot-up	OFF: Enables boot sequencer and configuration information loaded from I2C ROM. A valid ROM must be present. If not, the card will hang.

			ON: Disables boot sequer
SW4[8]	FBANK_SELECT	Indicates which NOR flash bank is selected	OFF: Uses upper 4 sectors for booting ON: Uses middle 4 sectors for booting
SW3[1]	CFG_SDWIDTH	Configs the width of the SD/MMC bus, 4-bit or 8-bit	OFF: Width = 4bits, SPI interface active ON: Width = 8bits Software can read the status of this bit by reading the I2C 8-bit register.
SW3[2]	TEST_SEL	Personality selection	OFF: Single e500 Core Device (P1016) ON: Dual e500 Core Device (P1025)
SW3[3]	DMA1_DACK_N	Freescale use only	Must be set OFF for P1025E
SW3[4]	LA19 (cfg_host_agt[2])	Controls the setting of the cfg_host_agt[2] pin	ON: cfg_host_agt[2] = 1 OFF: cfg_host_agt[2] = 0
SW3[5]	USB1_STP	Freescale use only	Must be set OFF for P1025E
SW3[6]	SWITCH7	Reserved	Default ON
SW3[7]	LA18 (cfg_host_agt[1])	Controls the setting of the cfg_host_agt[1] pin	ON: cfg_host_agt[1] = 1 OFF: cfg_host_agt[1] = 0
SW3[8]	LWE1_N (cfg_host_agt[0])	Controls the setting of the cfg_host_agt[0] pin	ON: cfg_host_agt[0] = 1 OFF: cfg_host_agt[0] = 0

1.5 Jumper Default Setting

J20: 2-3

1.6 Ethernet Port Settings

Figure 3 shows the ethernet ports on P1025RDB-PA.



Figure 3: Ethernet Ports on P1025RDB-PA

Table 5 lists all ethernet ports on P1025RDB-PA.

Table 5: Ethernet ports on P1025RDB-PA

Marking on board	P1025 Interface	In uboot	In Linux	Mode of operation
eTSEC1	eTSEC1	eTSEC1	eth0	RGMII
eTSEC2	eTSEC2	eTSEC2	eth1	SGMII
eTSEC3	eTSEC3	eTSEC3	eth2	RGMII
UEC1	QE UEC1	/	eth3	MII
UEC5	QE UEC5	/	eth4	RMII

1.7 USB Ports on P1025RDB-PA

Figure 4 shows the two USB ports on P1025RDB-PA.



Figure 4: Dual USB Ports on P1025RDB-PA

Table 6 lists USB ports on P1025RDB-PA.

Table 6: USB Ports on P1025RDB-PA

Marking on board	P1025 Interface	In uboot	In Linux	Mode of operation
USB	external PHY(ULPI)+HUB	USB1	USB1	ULPI(external PHY)

1.8 UART Ports on P1025RDB-PA

P1025RDB-PA has two UART connectors marked as **UART0** and **UART1** on the back side of the board as shown in Figure 5 below. By default the control display port is **UART0**.




Figure 5: UART Ports on P1025RDB-PA

Table 7 lists UART ports on P1025RDB-PA.

Table 7: UART Ports on P1025RDB-PA

Marking on board	P1025 Interface	In uboot	In Linux	Mode of operation
TOP UART1	UART1	eserial1/ttyS1	ttyS1	
BOT UART0	UART0	eserial0/ttyS0	ttyS0	Default control display port

1.9 RS485 ports on P1025RDB-PA

P1025RDB have two RS485 connectors marked as RS485_1&RS485_2 on the back side of the board as shown in [Figure 6](#) below.




Figure 6: RS485 ports on P1025RDB-PA

[Table 8](#) lists RS485 ports on P1025RDB-PA

Table 7: RS485 ports on P1025RDB-PA

Marking on board	P1025 Interface	In uboot	In Linux
RS485_1	QE UEC7	/	ttyQE0
RS485_2	QE UEC3	/	ttyQE1

1.10 Getting off the Enclosure

When set the switch or jumpers, follow these 3 steps to open the enclosure:

Step1: Disassemble 2 screws on bottom chassis



Figure 7

Step2: Disassemble 2 screws on both side of the bottom chassis



Figure 8

Step 3: Slip the top cover away lightly



Figure 9

1.11 TDM Function on P1025RDB-PA

P1025RDB-PA support PMC card to achieve QE TDM function. [Figure 10](#) shows connection for TDM function.



Figure 10: PMC card on P1025RDB-PA

Hardware requirements:

- P1025RDB-PA;
- FSL T1/E1 PMC card: PQ-MDS-T1
- Zarlink SLIC module: Le71HR8820G

Prepare steps:

- Get off the top cover of enclosure. Refer to section [1.10 Getting off the Enclosure](#)
- Get off the board from the enclosure by disassembly all of 4pcs stews on board.
- Insert T1/E1 PMC card and Voice card. Refer to [Figure 11](#)
- Insert two telephone lines into two RJ11 connectors of SLIC module respectively.

- Power on the board and run the software which can support TDM. Refer to [QUICC ENGINE TDM User Manual](#) for more software operation steps.
- Pick up the telephones and speak each other.



Figure 11 Insert T1/E1 PMC card and Voice card

1.12 Preparing the Board

1. Ensure that board is not connected to the power.
2. Ensure that the power switch is OFF.

NOTE: It is recommended to wear a wrist strap while preparing the P1025RDB-PA board to get protection from electrical charges.

3. Set switches and jumper header settings, as mentioned in the [Table 1: Board Default Switch Setting](#).
4. Plug the power cable into the receptacle on the back of the chassis.
5. Attach an RS-232 cable between the P1025RDB-PA UART0 port and a host PC.
6. Open a serial console emulator on your PC, such as TeraTerm or HyperTerminal, in order to communicating with P1025RDB-PA.
7. Configure the host PC's serial port with the following settings:

- Data rate: 115200 bps
 - Number of data bits: 8
 - Parity: None
 - Number of Stop bits: 1
 - Flow Control: Hardware/None
8. Switch ON the power button given on the back of the chassis. The board should boot and show the u-boot console messages. An example u-boot log is given in Section [1.12.1 Example U-boot log](#).
9. A mini Root File System (mini.rootfs.ext2.gz.uboot) with limited application are preloaded in the Nor flash. However a larger Root File System (max.rootfs.ext2.gz.uboot) offered both in USB stick and BSP DVD are recommended to use, refer to the [User_Manual_QorIQ_SDK_20110709.doc](#) document for bring up.

1.12.1 Example U-boot log

```
U-Boot 2010.12-00063-g8669298-dirty (Jul 09 2011 - 14:37:56)
```

```
CPU0: P1025E, Version: 1.1, (0x80ec0311)
```

```
Core: E500, Version: 5.1, (0x80212051)
```

```
Clock Configuration:
```

```
CPU0:533.333 MHz, CPU1:533.333 MHz,
```

```
CCB:266.667 MHz,
```

```
DDR:333.333 MHz (666.667 MT/s data rate) (Asynchronous), LBC:16.667 MHz
```

```
QE:266.667 MHz
```

```
L1: D-cache 32 kB enabled
```

```
I-cache 32 kB enabled
```

```
Board: P1025RDB CPLD: V2.6 PCBA: V2.0
```

```
rom_loc: nor lower bank
```

```
SD/MMC : 4-bit Mode
```

```
eSPI : Enabled
```

```
I2C: ready
```

```
SPI: ready
```

```
DRAM: Detected UDIMM(s)
```

```
DDR: 1 GiB (DDR3, 32-bit, CL=5, ECC off)
```

```
FLASH: 16 MiB
```

```
L2:      256 KB enabled
NAND:    32 MiB
MMC:     FSL_ESDHC: 0
Firmware 'Microcode version 0.0.1 for P1021 r1.0' for 1021 V1.0
QE: uploading microcode 'Microcode for P1021 r1.0' version 0.0.1
PCIE1: Root Complex of mini PCIE SLOT, no link, regs @ 0xffe0a000
PCIE1: Bus 00 - 00
PCIE2: Root Complex of PCIE SLOT, no link, regs @ 0xffe09000
PCIE2: Bus 01 - 01
Video: No radeon video card found!
In:      serial
Out:     serial
Err:     serial
Net:     eTSEC2 is in sgmi mode.
eTSEC1, eTSEC2, eTSEC3
Hit any key to stop autoboot:  0
=>NOTE: Linux login: root, Password: root
```

1.13 CAUTION

Avoid touching any area of open frame power circuitry inside the chassis. High Voltage in the power circuitry can prove fatal and hazardous.

Avoid touching areas of integrated circuitry and connectors; static discharge can damage circuits.

How to Reach Us:

Home Page:

www.freescale.com

E-mail:

support@freescale.com

USA/Europe or Locations Not Listed:

Freescale Semiconductor
 Technical Information Center,
 CH370
 1300 N. Alma School Road
 Chandler, Arizona 85224
 +1-800-521-6274 or +1-480-768-
 2130
 support@freescale.com

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland
 GmbH
 Technical Information Center
 Schatzbogen 7
 81829 Muenchen, Germany
 +44 1296 380 456 (English)
 +46 8 52200080 (English)
 +49 89 92103 559 (German)
 +33 1 69 35 48 48 (French)
 support@freescale.com

Japan:

Freescale Semiconductor Japan Ltd.
 Headquarters
 ARCO Tower 15F
 1-8-1, Shimo-Meguro, Meguro-ku,
 Tokyo 153-0064, Japan
 0120 191014 or +81 3 5437 9125
 support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd.
 Technical Information Center
 2 Dai King Street
 Tai Po Industrial Estate
 Tai Po, N.T., Hong Kong
 +800 2666 8080
 support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor Literature
 Distribution Center
 P.O. Box 5405
 Denver, Colorado 80217
 1-800-521-6274 or 303-675-2140
 Fax: 303-675-2150
 LDCForFreescaleSemiconductor@hibbert
 group.com

P1025RDB-PA QSG
 Document number: 926-26826

16 September 2011

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc. Reg. U.S. Pat. & Tm. Off. All other product or service names are the property of their respective owners.

© 2011 Freescale Semiconductor, Inc. All rights reserved.