



MOUNTING OPTIONS

Wall mounting



Ceiling mounting



TECHNICAL SPECIFICATIONS

Model Number	Input Voltage	Charge Duration	Discharge Duration	Battery	Power
PrimEvo XT200	220-240V~ 50/60Hz	24h	3 h	Ni-cad or Ni-Mh 3.6V 0.9Ah	NM: 1W M: 3W



PrimEvo XT200

instruction Leaflet

ABB B.V.
Bruntcliffe Lane
Morley, Leeds.
W.Yorkshire LS279LL,UK

Telephone +44 (0) 113 281 0600
Sales +44 (0) 113 281 0610
Fax +44 (0) 113 281 0601
Email LV.enquiries@gb.abb.com

The content of this ABB B.V publication has been carefully checked for accuracy at the time of print. However, ABB B.V doesn't give any warranty of any kind, express or implied, in this respect and shall not be liable for any loss or damage that may result from any use or as a consequence of any inaccuracies in or any omissions from the information which it may contain. © Copyright ABB B.V. Copyright in these pages is owned by ABB B.V except where otherwise indicated. No part of this publication may be reproduced, copied or transmitted in any form or by any means, without our prior written permission. Images, trade marks, brands, designs and technology are also protected by other intellectual property rights and may not be reproduced or appropriated in any manner without written permission of their respective owners. ABB B.V reserves the right to change and improve any product specifications or other mentions in this publication at its own discretion and at any time. These conditions of use are governed by laws of the UK and the courts of London shall have exclusive jurisdiction in any dispute.

Explanations

	Maintained	Non-maintained	Switched maintained	
				OK
				Emergency mode
				Failure - Battery Charge

Technical Specifications

Power Supply	: 220-240VAC, 50/60 Hz	Emergency Duration	: 3 Hours
Power Consumption	: Max. 3.5W	Protection Class	: II
Ambient Operating Temp	: -5°C...+45°C	IP Rating	: IP20
Charge Time	: 24 Hours	Function	: Manual test
Operation	: Maintained and Non maintained	Installation	: Wall mount or Ceiling mount
		Viewing distance	: 24m

Carefully read this instruction leaflet before installing or using the luminaire. This leaflet provides important information about the correct installation, use, maintenance and disposal of this product.

Please observe the following guidelines:

1. The luminaire should only be installed by qualified personnel and installation must be in accordance with European installation requirements HD 60364 and additional local regulations.
2. This product may not be modified in any way what so ever or used for a purpose or in an environment other than for which it is designed. Failing to observe these guidelines will invalidate the warranty and the CE-compliance of this product.
3. The luminaire is suitable for indoors use only
4. Before installing the luminaire, the supply must be isolated.
5. The lightsource in this luminaire is non-replaceable.

INSTALLING AND CONNECTING

The luminaire should be connected to the voltage equivalent to that indicated on the type label. The surface mounted luminaire is fitted with a terminal block suitable for loop-in-loop-out connection. For further information on the different connection possibilities, see the instructions in this instruction leaflet.

SERVICE AND OPERATION

Normal Operation: The green indicator light on the front of the unit stays on. The indicator will go out if the mains supply fails, the internal charger malfunctions, or the unit in test mode.

Battery: Sealed Ni-Cad or Ni-Mh rechargeable battery pack. Battery should be replaced when the required duration is no longer achieved. To avoid any damage to the fixture and ensure its performance, the battery should be replaced with same brand and type.

Test Switch: Press the test switch button, LED indicator will go out and the sign will be illuminate from its battery pack.







PLEASE NOTE!

Constant voltage is required and the batteries must be sufficiently charged for emergency lighting to function properly. Failure to observe this requirement can damage the batteries, the light source or in worst-cast scenario. the luminaires electronics.



INSPECTION AND MAINTENANCE

The company strongly advises annual inspection of your emergency lighting installation.

MOUNTING INSTRUCTIONS

<p>① Dispart mounting plate</p>  <p>③ Insert flat screwdriver into slot on side of unit, pry off and remove the mounting plate from unit. ④ Disconnect AC connector from PCBA.</p>	<p>② Wall mounting or Ceiling mounting</p>  <p>⑤ Knock out appropriate center cable entry hole and mounting screw hole on the mounting plate. ⑥ Route AC supply wire through center hole of mounting plate. ⑦ Fix mounting plate on the mount surface with screws and anchor nuts.</p>
<p>③ Wiring connection Suitable cable 0.75- 2.5mm²</p>  <p>Connect the AC supply wire to terminal block. Refer to wiring instruction showed below.</p>	<p>④ Battery connect</p>  <p>Connect battery male and female connector inside of mounting bracket.</p>
<p>⑤ Change pictogram when necessary</p>  <p>Remove the pictogram on the unit, select other pictogram you need then insert into slot of panel.</p>	<p>⑥ Finish installation</p>  <p>Snap AC supply on PCBA and then snap fixture to mounting plate.</p>

WIRING INSTRUCTIONS

<p>Maintained Wiring</p>  <p>Maintained (default operation): Connect L,N and leave jumper cable connected.</p>	<p>Non-Maintained Wiring</p>  <p>Non-maintained: Connect L,N and remove jumper cable.</p>
---	--