



G320X SERVO DRIVE

REV 10: May 13, 2010

GECKODRIVE, INC.
14662 FRANKLIN AVE
SUITE E
TUSTIN, CA 92780
(714) 832-8874

Thank you for purchasing the G320X drive. The G320X DC servo drive is warranted to be free of manufacturing defects for 1 year from the date of purchase. Any customer who is dissatisfied with it or is unable to make it work will be cheerfully refunded the purchase price if the G320X is returned within 15 days of the purchase date.

PLEASE READ FIRST BEFORE USING THE G320X:

If you are not familiar with DC servo drives please do the following setup instructions with the motor on the bench before mounting it on the mechanism it will eventually run. This will allow you to get a baseline motor behavior of what to expect.

Before you start, you must have a suitable encoder mounted and properly aligned on the motor. Follow the manufacturer's instructions on mounting and aligning the encoder if the motor doesn't already come with one.

Next you must have a DC power supply suitable for the motor. The power supply current rating must equal the maximum current you expect to run the motor at.

Finally, have a STEP and DIRECTION pulse source available.

Before going on, turn the "P", "I", "D", and LIMIT trimpots to the 11 o'clock position. The trimpots are single-turn so be careful not to over-torque them.

G320X PINOUT

TERMINAL 1	Power Ground Connect the negative (black) lead of your power supply to this terminal.
TERMINAL 2	Power (+) Connect the positive (red) lead of your power supply to this terminal. It must be between +18VDC to +80VDC.
TERMINAL 3	Armature (-) Connect the black lead of your motor to this terminal.
TERMINAL 4	Armature (+) Connect the red lead of your motor to this terminal.
TERMINAL 5	ERR/RES This is the ERROR and RESET pin. For a full explanation read the section titled "ERROR/RESET PIN" on page 6.
TERMINAL 6	Encoder Ground Connect the encoder power supply ground to this terminal.
TERMINAL 7	Encoder +5VDC Connect the encoder +5VDC pin to this terminal.
TERMINAL 8	Channel A Connect the Channel A pin of your encoder to this terminal.
TERMINAL 9	Channel B Connect the Channel B pin of your encoder to this terminal.
TERMINAL 10	Direction Connect the DIRECTION signal to this terminal.
TERMINAL 11	Step Connect the STEP signal to this terminal.
TERMINAL 12	S/D Common Connect this terminal to either +5VDC or signal ground.



G320X SERVO DRIVE

REV 10: May 13, 2010

GECKODRIVE, INC.
14662 FRANKLIN AVE
SUITE E
TUSTIN, CA 92780
(714) 832-8874

DIP SWITCH SETTINGS

The G320X has a 10 position DIP switch that is accessible when the cover is removed. These switch settings control many of the features of the G320X and are labeled SW1 through SW10.

REMOVING THE COVER:

- 1.) Remove the two 2-56 Phillips-head screws on the bottom of the drive.
- 2.) Slide the cover backwards while still lifting until it clears the drive.

REPLACING THE COVER:

- 1.) Slide the cover forward over the drive until the holes in the cover line up with the holes in the bottom plate.
- 2.) Replace the screws on the bottom of the drive.

EXPLANATION OF SWITCH FUNCTIONS

SW1 Not used

SW2, SW3 MUL1 and MUL0 respectively
Sets the G320X pulse multiplier
SW2 "ON" and SW3 "ON" = Step pulse times 1 (default)
SW2 "ON" and SW3 "OFF" = Step pulse times 2
SW2 "OFF" and SW3 "ON" = Step pulse times 5
SW2 "OFF" and SW3 "OFF" = Step pulse times 10

SW4, SW5 SR1 and SR0 respectively
Sets the G320X following error limit
SW4 "ON" and SW5 "ON" = +/- 256 count following error limit (default)
SW4 "OFF" and SW5 "ON" = +/- 512 count following error limit
SW4 "ON" and SW5 "OFF" = +/- 1024 count following error limit
SW4 "OFF" and SW5 "OFF" = +/- 2048 count following error limit

SW6 HEDS
SW6 "OFF" = Default
SW6 "ON" = Turned on if using encoders with HEDS optical heads or open collector encoders. Disables encoder failure detection allowing user to run encoders that don't have line drivers or active pullup.

SW7 TORQ
SW7 "OFF" = Use LIMIT trimpot setting only (default)
SW7 "ON" = Allow 20A for 1 second, then use LIMIT trimpot setting

SW8, SW9, SW10 GAIN2, GAIN1, and GAIN0 respectively
Current mode servo gain
SW8 "ON", SW9 "ON", SW10 "ON" = Lowest gain
SW8 "ON", SW9 "OFF", SW10 "ON" = Low gain
SW8 "ON", SW9 "ON", SW10 "OFF" = Medium-low gain
SW8 "ON", SW9 "OFF", SW10 "OFF" = Medium gain 1 (default)
SW8 "OFF", SW9 "ON", SW10 "ON" = Medium gain 2
SW8 "OFF", SW9 "OFF", SW10 "ON" = Medium-high gain
SW8 "OFF", SW9 "ON", SW10 "OFF" = High gain
SW8 "OFF", SW9 "OFF", SW10 "OFF" = Highest gain

G320X TERMINAL WIRING:

IMPORTANT: When first testing the G320X, connect ERR/RES (Terminal 5) to ENC+ (Terminal 7).

IMPORTANT: Do not connect the motor to the G320X until STEP 6.

IMPORTANT: Please follow the next steps in the sequence they are given.



G320X SERVO DRIVE

REV 10: May 13, 2010

GECKODRIVE, INC.
14662 FRANKLIN AVE
SUITE E
TUSTIN, CA 92780
(714) 832-8874

STEP 1: CONNECTING THE ENCODER

The encoder must be at minimum a 25 line-count digital quadrature encoder and must operate on a single +5VDC power supply. If the encoder supply current is more than 50 mA, use an external +5VDC supply. It may have an INDEX output, which will not be used. If it has differential outputs, use only the "+" phase outputs.

TERMINAL 6 Encoder Ground
Connect the encoder power supply ground to this terminal.

TERMINAL 7 Encoder +5VDC
Connect the encoder +5VDC to this terminal

TERMINAL 8 CH A
Connect the encoder channel "A" to this terminal

TERMINAL 9 CH B
Connect the encoder channel "B" to this terminal

To determine the optimal encoder line count, please follow the instructions below.

- 1.) Determine motors no load RPM
- 2.) Calculate rated RPM as 80% of no load RPM
- 3.) Divide (#2) by 60 to get revolutions per second
- 4.) Determine the CNC program's maximum step pulse frequency (in Hz)
- 5.) Divide (#4) by (#3), which will give you the maximum counts per revolution
- 6.) Divide (#5) by 4, which will give you the max line count
- 7.) Pick the first standard line count below (#6)

An example of using that formula with a 45kHz step pulse frequency and a maximum motor RPM of 3000:

$$(45\text{kHz} / 40) / 4 = 281.25$$

STEP 2: CONNECTING THE POWER SUPPLY

IMPORTANT: Never put a switch on the DC side of the power supply! This will damage, if not destroy, your drive!

Keep the power supply leads short and use the largest wire gauge that will easily fit in the terminals. If the lead length is more than 18" use a 1000 uF capacitor across the G320X power supply terminals. Make sure your power supply can provide the peak current the motor may draw. The power supply voltage must be between 18 VDC and 80 VDC.

TERMINAL 1 POWER GROUND
Connect the power supply (-) to this terminal.

TERMINAL 2 +18 TO 80 VDC
Connect the power supply (+) to this terminal

STEP 3: TESTING THE ENCODER

At this point the encoder should be tested for functionality. You can test the encoder on the G320X by watching the indicator LEDs on the board.

Turn on the power supply. The FAULT indicator (red LED) should be on for 1 second and then turn off. The IN-POSITION indicator (green LED) should turn on and remain on. The POWER indicator (green LED) should always be on. Turn the motor shaft VERY slowly by hand. The IN-POSITION indicator (green LED) will turn off when you turn the motor more than two encoder counts. The Warn indicator (yellow LED) will turn on when you have turned the motor more than 128 encoder counts. The FAULT indicator (red LED) will turn on when you turn the motor past the following error limit (see option switch section). After 1 second the FAULT light will turn off and the IN-POSITION LED will come back on.



G320X SERVO DRIVE

REV 10: May 13, 2010

GECKODRIVE, INC.
14662 FRANKLIN AVE
SUITE E
TUSTIN, CA 92780
(714) 832-8874

STEP 4: CONNECTING CONTROL INPUTS

The STEP and DIRECTION signal drivers must be 3.3V or 5V TTL signals and have edge transition times of 100 ns or faster. The COMMON input can be connected to signal ground or a +5VDC supply. The G320X default motor direction is CW when the DIRECTION pin is left unconnected.

- TERMINAL 10** Direction
 Connect the DIRECTION line to this terminal.
- TERMINAL 11** Step
 Connect the STEP line to this terminal.
- TERMINAL 12** Common
 Connect this terminal to the signal ground or +5VDC.

STEP 5: TESTING THE STEP AND DIRECTION INPUTS

Set the STEP pulse generator to 40 pulses per second. If you are using a CNC program, use the "JOG" command. Turn on the power supply; the FAULT indicator (red) will turn off after 1 second and the IN-POSITION indicator (green) will turn on. Start sending step pulses (JOG). The IN-POSITION indicator (green) will turn off almost immediately, the WARN indicator (yellow) will turn on 3 seconds later and the FAULT indicator (red) will turn on 3 seconds after that. Once the FAULT indicator (red) turns on, stop sending step pulses. Send step pulses in the opposite DIRECTION and the above process should repeat.

STEP 6: CONNECTING THE MOTOR

Turn the power supply and the step pulse source off. Verify that the "P", "I", "D", and LIMIT trim pots are in the 11 o'clock position.

- TERMINAL 3** Armature (-)
 Connect the BLACK motor lead to this terminal.
- TERMINAL 4** Armature (+)
 Connect the RED motor lead to this terminal.

STEP 7: TUNING THE SERVO

Turn on the power supply. The FAULT indicator should turn off and the IN-POSITION indicator should turn on after 1 second. If everything is correct you may hear faint sounds coming from the motor. This is normal. The motor is "dithering", or bouncing between adjacent encoder counts. The integral term in a PID loop has infinite DC gain over time and will amplify even the smallest position error. Because encoder feedback can only occur on count edges, the loop is "blind" until it encounters an encoder count edge. It then reverses the motor direction until another edge is found, then the process repeats.


If the motor jumps slightly and the FAULT indicator immediately turns back on, then either the motor is wired backwards or the trim pots are misadjusted. Check the trim pot settings. If they are correct then switch exchange CH A and CH B. If it still doesn't work and you followed all the previous steps, call Geckodrive at the number at the end of this document.

Now try turning the motor gently by hand. The motor should resist being turned and the IN-POSITION indicator may flicker.

CAUTION: Do not move the motor manually for more than several seconds at a time; motor overheating will occur if you do.

Now turn on the power supply and step pulse source and ramp the speed up to see if the motor turns.

The default PID trim pot settings should work in most applications. The PID settings do not in any way affect the positioning accuracy of the G320X and only affects the settling time of the servo. If you use an oscilloscope (probe on TP1) an optimally tuned servo will display the "Critically Damped" graph below.



The manner in which the motor returns to its command position is called damping. At one extreme, called over damped response, the motor returns to position after a long, drawn out delay. At the other extreme, called under damped response, the motor returns to its position too rapidly, overshoots, returns and undershoots and so on until it finally settles at its command position. This is also called ringing; when extreme, the over/undershoot builds in amplitude until the motor enters violent oscillation. Between the two extremes is the optimal response called critical damping. Here the motor rapidly returns to its position with little or no overshoot in the minimal amount of time.

SETTING THE “P”, “I”, “D” TRIMPOTS

“P” and “D” settings generally track each other. If you increase “P” for greater stiffness, an increase in “D” is needed as well to restore critical damping. Be careful, increasing “P” without increasing “D” may cause the motor to break out into violent oscillation.

The higher “P” is set, the noisier the motor will be when stopped. This is because higher gain causes more vigorous dithering between encoder counts at rest. There is a trade-off between high gain (high stiffness) on one hand and excessive dithering (noise and motor heating) on the other.

The “I” setting takes out the remaining following error. Increasing the “I” setting will increase the servo stiffness; if it is increased too much the servo will oscillate.

To see how a servo is compensated it is first necessary to induce a disturbance. The easiest way is to switch the DIRECTION input while commanding a constant speed via the STEP input. The abrupt direction change puts a momentary load on the motor while the oscilloscope shows how it responds (see oscilloscope traces above).

If you are using an oscilloscope, use channel 1 on TP1 and channel 2 on the DIRECTION input. Set the trigger to “normal”, trigger source to channel 2 and trigger edge to “+”. You should see a single sweep for every clockwise change in direction.

CURRENT LIMIT

The current LIMIT trimpot sets maximum continuous current the motor is permitted to have. It is adjustable from 0 amps to 20 amps. The trimpot setting is proportional to current; if it is set to full scale it will be outputting 20A, half scale will output 10A, quarter scale will output 5A, and so on. The behavior of the trimpot is controlled by DIP SW 10. If SW 10 is on (default), the G320X will limit the current to the trimpot setting until it runs into an excessive load. It will then start a 1 second timer and limit the current draw to 20A; if it does not overcome the load it will limit at the trimpot set current. The load must drop below the trimpot setting to reset the timer. If SW 10 is off (G320 compatibility mode), the G320X will constantly output what the LIMIT trimpot is set to. Normally the LIMIT trimpot is set to the motor’s continuous rated current.

INDICATOR LEDs

The G320X has four indicator LEDs. These are:

- IN-POSITION indicator (IN POS Green LED)
- WARN indicator (WARN Yellow LED)
- FAULT indicator (FAULT Red LED)
- POWER indicator (POWER Green LED)

The FAULT indicator (red LED) is on while the drive is in power-on reset, the DISABLE input is held “low” or if the protection circuit is tripped due to a FAULT condition. All output switching stops are reset. The FAULT condition lasts for 1 second, and then self-resets to try again. If the G320X enters a FAULT condition it will dynamically brake the motor. This means if a FAULT occurs while the motor is moving the motor will very rapidly decelerate to a stop.



G320X SERVO DRIVE

REV 10: May 13, 2010

GECKODRIVE, INC.
14662 FRANKLIN AVE
SUITE E
TUSTIN, CA 92780
(714) 832-8874

There are three conditions that will trip the protection circuit. One condition is if there is a short-circuit. The second condition is if there is no encoder attached; the G320X detects if one or more encoder wires are not connected. The third condition is if the POSITION ERROR exceeds the set following error limit. This condition can have several causes:

- 1) The loop settings are severely under-damped and the motor breaks out into oscillation.
- 2) Excessive motor load due to acceleration or workload.
- 3) The speed command in excess of what the motor can deliver.
- 4) The current LIMIT is set too low.
- 5) The power supply current is insufficient for the demand.
- 6) The power supply voltage is below 18 VDC.
- 7) The motor is wired backwards, is broken or disconnected.
- 8) Encoder failure.

The IN-POSITION indicator (green LED) is lit when the motor is within 2 increments of motion of the commanded position. If the motor is out of position by more than two increments of motion the indicator will not be lit.

The Warn indicator (yellow LED) is lit whenever the motor is more than 128 counts off of the commanded position. Its purpose is to give warning that a large following error is probably developing and will result in the drive going into FAULT (red LED) if measures are not taken to arrest the increasing following error.

The Power indicator (green LED) is lit whenever there is power applied to the G320X.

ERROR / RESET PIN

This terminal functions as an ERROR output and as a RESET input. Because this terminal functions as both an input and an output, some detailed description is necessary.

When first testing the G320X, ERR/RES (Terminal 5) was connected to ENC+ (term. 7). It can be left that way if it is not necessary to read the state of the ERROR output. Otherwise, the following details are important.

The ERROR output is latched in the "ERROR" state (Terminal 5 = "0") by the power-on reset circuitry in the G320X. It will stay in this state indefinitely until it is cleared by applying +5V to this terminal for at least 1 second.

The voltage on this terminal is +5VDC when the G320X is functioning normally. The voltage on this terminal goes to 0VDC whenever the FAULT indicator is lit. This output can be used to signal your controller that an error has occurred.

Normally when the G320X is first powered up, it will be necessary to push the momentary switch to START for 1 second. This will clear the power-on reset condition and extinguish the FAULT LED. The motor will then be enabled and the drive will begin to operate. If at any time after that a condition occurs that causes the G320X to "FAULT out", such as not being able to complete a step command, the ERR/RES terminal will go to "0", signaling to the controller an error has occurred. This will require the operator to correct the problem that caused the FAULT and then push the switch to "START" for 1 second to re-enable the G320X.





At anytime the operator can push the switch to the "STOP" position to immediately halt the G320X drive. Anytime the G320X is in the "FAULT" state (FAULT LED lit), all switching action stops, the motor freewheels and is unpowered.

DISCLAIMER

CERTAIN APPLICATIONS USING POWER PRODUCTS MAY INVOLVE POTENTIAL RISKS OF DEATH, PERSONAL INJURY OR SEVERE DAMAGE TO PROPERTY. GECKODRIVE INC. PRODUCTS ARE NOT DESIGNED, AUTHORIZED OR WARRANTED TO BE SUITABLE FOR USE IN LIFE-SUPPORT DEVICES OR OTHER CRITICAL APPLICATIONS. INCLUSION OF GECKODRIVE INC. PRODUCTS IN SUCH APPLICATIONS IS UNDERSTOOD TO BE FULLY AT THE PURCHASER'S OWN RISK

In order to minimize risks associated with the purchaser's application, adequate design and operating safeguards must be provided by the purchaser to minimize inherent or procedural hazards. GECKODRIVE INC. assumes no liability for applications assistance or the purchaser's product design. GECKODRIVE INC. does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright or other intellectual property right of GECKODRIVE INC.

G320X Servodrive



0.1250

G320X SPECIFICATIONS

Power Supply:	+18VDC to +80VDC
Quiescent Current:	30mA
Motor Current:	0 to 20 Amps
Motor Inductance:	At least 1mH
Short Circuit Protect:	22A trip
Lock Range:	+/- 256, 512, 1024, or 2048
Feedback:	Quadrature TTL Encoder 5V Compatible
Feedback Resolution:	X4 Encoder Line Count
Feedback Voltages:	<1V for Logic 0 and >4V for Logic 1
Switching Frequency:	20kHz
Current Limit:	0 to 20 Amps Trimpot Adjustable
Analog PID:	Proportional, Derivative, Integral Coefficient Trimpots
Step Pulse Frequency:	0 to 500kHz
Step Pulse "0" Time:	0.5uS
Step Pulse "1" Time:	1.5uS
Size:	2.5" x 2.5" x 0.8375"
Package:	Blue aluminum anodized cover, black aluminum hard anodized bottom heatsink
Weight:	3.6 oz. (100g)
Encoder Supply:	+5VDC 50mA maximum
Pulse Multiplier:	1, 2, 5, or 10 times input step rate