

XCSRC10M12

Safety RFID contactless switch - Single model -
Unique pairing



Main

| | |
|---------------------------|-----------------------------|
| Range of product | Preventa Safety detection |
| Product or component type | Preventa RFID safety switch |
| Component name | XCSRC |

Complementary

| | |
|--|---|
| Design | Rectangular, standard |
| Size | 50 x 15 x 15 mm transponder 108.3 x 30 x 15 mm reader |
| Material | Valox |
| Electrical connection | 1 male connector |
| Connector type | M12 male |
| Type of output stage | Solid-state, PNP |
| Safety outputs | 2 NO |
| Number of poles | 5 |
| Local signalling | 2 multi-colour LEDs green, orange and red |
| [Sa] assured operating distance | 10 mm face to face |
| [Sar] assured tripping distance | 35 mm face to face |
| Approach directions | 3 directions-transponder with rotary sensing face |
| [Ue] rated operational voltage | 24 V DC (- 20...10 %) SELV or PELV conforming to EN/IEC 60204-1 |
| [Ie] rated operational current | 60 mA |
| [Ui] rated insulation voltage | 30 V DC |
| [Uimp] rated impulse withstand voltage | 0.8 kV IEC 60947-5-2 |
| Protection type | Short-circuit protection |
| Maximum switching voltage | 26.4 V DC |
| Switching capacity in mA | 200 mA |
| Switching frequency | <= 0.5 Hz |
| Discordance time | <= 120 ms |
| Response time | 120 ms typical |
| Delay first up | 5 s |
| Tightening torque | < 1.5 N.m |
| Standards | EN/IEC 60947-5-2 EN/IEC 60947-5-3 ISO 14119 |
| Product certifications | CSA 22-2 FCC IC TÜV Ecolab RCM EAC E2 |
| Marking | CE TÜV EAC RCM CULus |


The information provided in this documentation contains general descriptions and/or technical characteristics of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric Industries SAS nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein.

FCC
IC

| | |
|---------------------------------------|--|
| Safety level | SIL 3 EN/IEC 61508 SILCL 3 EN/IEC 62061 PL = e EN/ISO 13849-1 Category 4 EN/ISO 13849-1 |
| Safety reliability data | PFH _D = 5E-10/h EN/IEC 62061 PFH _D = 5E-10/h EN/ISO 13849-1 |
| Service life | 20 yr |
| Ambient air temperature for operation | -25...70 °C |
| Ambient air temperature for storage | -40...85 °C |
| Vibration resistance | 10 gn 10...150 Hz EN/IEC 60068-2-6 |
| Shock resistance | 30 gn 11 ms EN/IEC 60068-2-27 |
| Electrical shock protection class | Class III EN/IEC 61140 |
| IP degree of protection | IP65 EN/IEC 60529 IP66 EN/IEC 60529 IP67 EN/IEC 60529 IP69K DIN 40050 |


Environment

Dimensions



Connections

M12 Connector, 5-pin




- (1) + 24 VDC
- (2) OSSD2
- (3) 0 VDC
- (4) OSSD1
- (5) NC (Not connected)

Connections

Wiring Diagram: Connection to a Safety Relay

Cat. 4 / PL=e (EN/ISO 13849-1) / SIL3 (IEC 61508) / SILCL3 IEC 62061), if combined with an appropriate Preventa XPS Safety unit PL=e / SIL3




- (1) Transponder
- (2) Reader
- (3) Logic
- (4) Start
- (5) ESC: External start conditions
- (6) H1: indicator light deactivated
- (7) Fuse. Operating status of internal electronic fuse
- (8) To PLC
- (9) Power circuit

NOTE: KM1 and KM2 contactors must have force-guided contacts.

Connections

Wiring Diagram: Connection to a Safety Controller

Cat. 4 / PL=e (EN/ISO 13849-1) / SIL3 (IEC 61508) / SILCL3 IEC 62061), if combined with an appropriate Preventa XPS Safety controller PL=e / SIL3



- (1) Power supply
- (2) 1 A max.
- (3) Safety controller
- (4) Feedback
- (5) Restart
- (6) Reader



- (7) Transponder
- (8) Power circuit

NOTE: KM1 and KM2 contactors must have force-guided contacts.

Mounting and Clearance



Face to Face Mounting (Preferred Configuration)

Example n°1



e: Recommended minimum mounting distance between transponder and reader.



Example n°2



e: Recommended minimum mounting distance between transponder and reader.

Face to Face Mounting (Preferred Configuration)

Example n°3





$e > 2$ mm. (e: recommended minimum mounting distance between transponder and reader)
min.
d : Detection limit

Mounting and Clearance

Side by Side Mounting



Correct Mounting Configuration



e: Recommended minimum mounting distance between transponder and reader.

Mounting and Clearance

Minimum Mounting Clearances between Safety Switches



Dimensions in mm

| E1 min. | E2 min. | E3 min. |
|---------|---------|---------|
|---------|---------|---------|

| | | |
|----|-----|----|
| 45 | 150 | 65 |
|----|-----|----|


Dimensions in in.

| E1 min. | E2 min. | E3 min. |
|---------|---------|---------|
| 1.77 | 5.91 | 2.56 |

Detection Curves

Face to Face Mounting (Preferred Configuration)

Sao and Sar sensing distances along Y axis as function of Z (longitudinal misalignment for X=0)




Sar: Assured release distance

Sao: Assured operating distance

(1) Recommended minimum mounting distance between transponder and reader.

Sao and Sar sensing distances along X axis as function of Z (transverse misalignment for Y=0)



Sar: Assured release distance


Sao: Assured operating distance

(1) Recommended minimum mounting distance between transponder and reader.

Detection Curves

Side by Side Mounting

Sao and Sar sensing distances along Y axis as function of X (longitudinal misalignment for Z=0mm)



Sar: Assured release distance


Sao: Assured operating distance

(1) X=0 for X<0

(2) X=0 for X>0

(3) Recommended minimum mounting distance between transponder and reader.

Sao and Sar sensing distances along Z axis as function of X (transverse misalignment for Y=0mm)



Sar: Assured release distance

Sao: Assured operating distance

- (1) $X=0$ for $X<0$
- (2) $X=0$ for $X>0$
- (3) Recommended minimum mounting distance between transponder and reader.