

Bench Digital Multimeter

User Manual



Part Number: 72-1015

Overview

This Operating Manual covers information on safety and cautions. Please read the relevant information carefully and strictly observe all warnings.

Warning

To avoid electric shock or personal injury, read the “Safety Information” and “Rules for Safety Operation” carefully before using the Meter.

Digital Bench-Type True RMS Multimeter **Model 72-1015** (hereafter referred to as “the Meter”) has auto and manual range options with maximum reading of 5999 counts and 3-5/6 digits which has a unique outlook design.

In addition to all the conventional features including DC/AC voltage, current, resistance, diode, continuity test, capacitance, temperature °C and °F, transistor, max/min, there is a data hold, low battery display, sleep mode, RS232C serial port for easy connection with computer to realize macro recording, monitoring and capture of transient dynamic data, displaying change of waveform during the measurement, providing data and evidence to engineering technicians for scientific research.

Inspection

Open the package case and take out the Meter. Check the following items carefully for missing or damaged parts:

Item	Description	Qty
1	Operating Manual	1 piece
2	Test Lead	1 pair
3	Alligator Clip	1 pair
4	Multi-Purpose Socket	1 piece
5	Point Contact Temperature Probe (to be used under 230°C temperature measurement)	1 piece
6	Power Cord	1 piece
7	RS232C Interface Cable	1 piece
8	Installation guide and computer interface software (CD-ROM)	1 piece

In the event that items are found missing or damaged, contact your Tenma dealer immediately.

Safety Information

This Meter complies with the standards IEC61010: in pollution degree 2, over voltage category (CAT. I 1000V, CAT.II 600V) and double insulation.

CAT III: Distribution level, fixed installation, with smaller transient over voltages than CAT. IV

CAT IV: Primary supply level, overhead lines, cable systems etc.

Use the Meter only as specified in this operating manual, otherwise the protection provided by the Meter may be impaired.

In this manual, a **Warning** identifies conditions and actions that pose hazards to the user, or may damage the Meter or the equipment under test.


A Note identifies the information that user should pay special attention to.

International electrical symbols used on the Meter and in this Operating Manual are explained on page 8.











Rules For Safe Operation

Warning


To avoid possible electric shock or personal injury, and to avoid possible damage to the Meter or to the equipment under test, adhere to the following rules:

- Before using the Meter inspect the case. Do not use the Meter if it is damaged or the case (or part of the case) is removed. Look for cracks or missing plastic.
- Pay attention to the insulation around the connectors.
- Inspect the test leads for damaged insulation or exposed metal. Check the test leads for continuity. Replace damaged test leads with identical model number or electrical specifications before using the Meter.
- Do not apply more than the rated voltage, as marked on the Meter, between the terminals or between any terminal and ground.
- Prior to measurement, ensure the rotary selector switch is in the proper position. To prevent potential damage to the meter, do not change range or mode during measurement.
- When the Meter working at an effective voltage over 60V DC, or 30V RMS AC, special care should be taken for there is danger of electric shock.
- Use the proper terminals, function, and range for your measurements.
- If the value to be measured is unknown, use the maximum measurement position and reduce the range step by step until a satisfactory reading is obtained.
- Do not use or store the Meter in an environment of high temperature, humidity, explosive, flammable gas or strong magnetic field. Do not use the meter if allowed to get wet. Even after complete drying, incorrect readings could occur, causing a potentially hazardous condition.
- When using the test leads, keep your fingers behind the finger guards.
- Disconnect circuit power and discharge all high-voltage capacitors before testing resistance, continuity, diodes, current, or capacitance.
- Before measuring current, check the Meter's fuses and turn off power to the circuit before connecting the Meter to the circuit.
- Replace the battery as soon as the battery indicator  appears. With a low battery, the Meter might produce false readings that can lead to electric shock and personal injury.
- Remove test leads, temperature probe, RS232C interface cable, and alligator clip from the Meter and turn the Meter power off before opening the Meter case.
- When servicing the Meter, use only the same model number or identical electrical specifications replacement parts.
- The internal circuit of the Meter shall not be altered at will to avoid damage of the Meter and any accident.
- Soft cloth and mild detergent should be used to clean the surface of the Meter when servicing. No abrasive and solvent should be used to prevent the surface of the Meter from corrosion, damage and accident.
- The Meter is suitable for indoor use only.
- Turn the Meter power off when it is not in use. Remove batteries from meter if use of battery power is not anticipated for long periods of time.
- Routinely check installed batteries for leaking. Remove immediately if evidence of leaks exist.

International Electrical Symbols

	AC or DC
	Ground
	Double Insulated
	Warning. Refer to the Operating Manual
	Low Battery
	Continuity Test
	Diode
	Capacitance Test
	Fuse
	Conforms to Standards of European Union

The Meter Structure (see figure 1)



(Figure 1)

- 1. LCD Display
- 2. Rotary Switch
- 3. Input Terminals
- 4. Functional Buttons

Rotary Switch

Below table indicated for information about the rotary switch positions:


Rotary Switch Position	Function
$V \sim$	AC and DC voltage measurement
$\bullet \parallel \rightarrow \Omega$	$\bullet \parallel$:Continuity test.
	\rightarrow :Diode test.
	Ω :Resistance measurement.
$\text{—} \text{—}$	Capacitance test
Hz	Frequency measurement.
$^{\circ}\text{F}$	Temperature in Fahrenheit
$^{\circ}\text{C}$	Temperature in celsius
hFE	Transistor test
$\mu\text{A} \sim$	AC or DC current measurement range from 0.1uA to 5999uA.
$\text{mA} \sim$	AC or DC current measurement range from 0.01mA to 599.9mA.
$\text{A} \sim$	AC or DC current measurement range from 0.01A to 10.00A.

Functional Buttons

Below table indicated for information about the functional button operations.

Button	Operation Performed
POWER	Turn the power on and off.
LIGHT	Turn the display backlight on and off.
SELECT	<ul style="list-style-type: none"> • Switches between AC and DC measurement. • Switches between continuity, diode and resistance measurements • Switches between frequency and Fahrenheit temperature.
HOLD	Press HOLD to enter and exit the Hold mode in any mode.
RANGE	Press RANGE to switch between manual and auto ranging.
RS232C	Turn on or off the serial port interface without changing the original setting.
MAX MIN	Starts recording of maximum and minimum values. Steps the display through high (MAX) and low (MIN).
AC AC+DC	To select AC or AC+DC measurement.

Display Symbols (see figure 2)




(Figure 2)

Number	Symbol	Meaning
1	True RMS	Indicator for true rms value.
2	HOLD	Data hold is active.
3		Sleep Mode feature is enabled.
4		Indicates negative reading.
5	AC	Indicator for AC voltage or current.
6	DC	Indicator for DC voltage or current
7	AC+DC	Indicator for AC+DC measurement
8	OL	The input value is too large for the selected range.
9	Ω, kΩ, MΩ	Ω : Ohm. The unit of resistance.
		kΩ : kilohm. 1×10^3 or 1000 ohms.
		MΩ : Megaohm. 1×10^6 or 1,000,000 ohms.
	A, mA, μA	A : Amperes (amps).The unit of current.
		mA : Milliamp. 1×10^{-3} or 0.001 amperes.
		μA : Microamp. 1×10^{-6} or 0.000001 amperes.
	V, mV	V : Volts. The unit of voltage.
		mV : Millivolt. 1×10^{-3} or 0.001 volts.
	F, mF, μF, nF	F : Farad.The unit of capacitance.
		mF : Millifarad. 1×10^{-3} or 0.001 farads
		μF : Microfarad. 1×10^{-6} or 0.000001 farads.
		nF : Nanofarad. 1×10^{-9} or 0.000000001 farads.
	°C, °F	Centigrade temperature
Fahrenheit temperature		
Hz, kHz, MHz	Hz : Hertz. The unit of frequency in cycles/second.	
	kHz : Kilohertz. 1×10^3 or 1,000 hertz.	
	MHz: Megahertz. 1×10^6 or 1,000,000 hertz.	
β	Unit of transistor.	

Number	Symbol	Meaning
10		Test of diode
11		The continuity buzzer is on.
12	Auto Range Manual	Indicator of Auto or manual range
13		Display of maximum or minimum value.
14		Data output is in progress.
15		The battery is low. ⚠ Warning: To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator appears.
16		Transistor test is on

Measurement Operation

A. DC or AC Voltage Measurement (See figure 3)



(Figure 3)

⚠ Warning

To avoid personal injury, or damage to the Meter from electric shock, please do not attempt to measure voltages higher than 1000V although readings may be obtained.


To measure DC/AC voltage, connect the Meter as follows:

1. Insert the red test lead into the **V** terminal and the black test lead into the **COM** terminal. If the measured value is less than 600mV, insert the red test lead into **mV** terminal instead and press **RANGE** button to select manual range 600.0mV mode, the LCD displays "**MANUAL**" and "**mV**".
2. Set the rotary switch to **V** ; press **SELECT** button to select DC or AC measurement mode.
3. Connect the test leads across with the object being measured. The measured value shows on the display. AC measurement displays True RMS value.
4. Press **AC/AC+DC** button to measure AC+DC voltage's true RMS.

Note

- In each range, the Meter has an input impedance of 10MΩ except 600mV range has 3000MΩ . This loading effect can cause measurement errors in high impedance circuits. If the circuit impedance is less than or equal to 10kΩ , the error is negligible (0.1% or less).
- When DC/AC voltage measurement has been completed, disconnect the connection between the test leads and the circuit under test, and remove the test leads from the input terminals of the Meter.

B. DC or AC Current Measurement (See figure 4)



(Figure 4)

⚠ Warning

Before connecting the meter in series with the circuit under test, be sure power to the circuit is off to avoid the possibility of arcing.

If the fuse burns out during measurement, the Meter may be damaged and there is risk of personal injury to the operator. Use proper terminals, function, and range for the measurement. When the test leads are connected to the current terminals, do not parallel them across any circuit.


To measure current, do the following:

1. Insert the red test lead into the μA mA terminal and the black test lead into the COM terminal.
2. Set the rotary switch to an appropriate measurement position in μA \sim , mA \sim or A \sim , press SELECT button to select AC or DC measurement mode.
3. Connect the test leads in series with the object being measured. The measured value shows on the display. AC measurement displays True RMS value.
4. Press **AC/AC+DC** button to measure AC+DC current's true RMS

Note

- If the value of current to be measured is unknown, use the maximum measurement position, and reduce the range step by step until a satisfactory reading is obtained.
- For safety sake, each measurement time of high current (>5A) should be less than 10 seconds and the interval time between 2 measurements should be greater than 15 minutes.
- When current measurement is complete, disconnect the test leads from the circuit under test. Disconnect the test leads from the input terminals on the meter.

Measuring Resistance (see figure 5)



(Figure 5)

⚠ Warning

To avoid damage to the Meter or to the devices under test, disconnect circuit power and discharge all the high-voltage capacitors before measuring resistance. To avoid possible injury, please do not attempt to input voltages higher than 60V DC or 30V AC.


To measure resistance, connect the Meter as follows:

1. Insert the red test lead into the Ω terminal and the black test lead into the **COM** terminal.
2. Set the rotary switch to Ω \rightarrow \rightarrow , press **SELECT** button to select Ω measurement mode.
3. Connect the test leads across with the object being measured. The measured value shows on the display

Note

- When measuring low resistances, the test leads and internal wiring will add approximately 0.2 Ω to 0.5 Ω of error. To obtain accurate readings in low-resistance, short-circuit the test lead beforehand and record the reading obtained, call this reading as X. Then use the equation:
measured resistance value (Y) – (X) = accurate readings of resistance.
- If Ω reading with shorted test leads is not < 0.5 Ω , check for loose test leads or possible incorrect function selection.
- When measuring high resistance (>1M Ω), it is normal to take several seconds to obtain a stable reading. In order to obtain stable reading, choose shorter test lead to carrying out measurement.
- The LCD displays **OL** indicating open-circuit for the tested resistor or the resistor value is higher than the maximum range of the Meter.
- When resistance measurement has been completed, disconnect the connection between the test leads and the circuit under test, and remove the test leads from the input terminals if the meter.

D. Testing Continuity (See figure 6)



(Figure 6)

⚠ Warning

To avoid damage to the Meter or to the devices under test, disconnect circuit power and discharge all the high-voltage capacitors before testing for continuity. To avoid personal injury, please do not attempt to input voltages higher than 60V DC or 30V AC.


To test for continuity, connect the Meter as below:

1. Insert the red test lead into the Ω terminal and the black test lead into the **COM** terminal.
2. Set the rotary switch to Ω \rightarrow \rightarrow , and press **SELECT** button to select \rightarrow measurement mode.
3. Connect the test lead across with the object being measured. The buzzer sounds if the resistance of a circuit under test is < 70 , the circuit is in good condition. The buzzer does not sound if the resistance of a circuit under test is > 70 , the circuit is broken.
4. The measured value shows on the display and the unit is Ω .

Note

- In continuity mode, the resistance range is 600 Ω , and the open circuit voltage is approximately 1.2V.
- When continuity testing has been completed, disconnect the connection between the test leads and the circuit under test, and remove the test leads from the input terminals of the Meter.

E. Testing Diodes (See figure 7)



(Figure 7)

⚠ Warning

To avoid possible damage to the Meter and to the device under test, disconnect circuit power and discharge all high-voltage capacitors before testing diodes.

To avoid personal injury, please do not attempt to input voltages higher than 60V DC or 30V AC.

Use the diode test to check diodes, transistors, and other semiconductor devices. The diode test sends a current through the semiconductor junction, and then measures the voltage drop across the junction. A good silicon junction drops between 0.5V and 0.8V.


To test a diode out of a circuit, connect the Meter as follows:

1. Insert the red test lead into Ω terminal and the black test lead into the **COM** terminal.
2. Set the rotary switch to Ω \rightarrow and press **SELECT** button to select \rightarrow measurement mode.
3. For forward voltage drop readings on any semiconductor component, place the red test lead on the component's anode and place the black test lead on the component's cathode. The measured value shows on the display.

Note

- Connect the test leads to the proper terminals as said above to avoid error display. The LCD will display **OL** indicating diode being tested is open or polarity is reversed. The unit of diode is Volt (V), displaying the forward voltage drop readings.
- Open circuit voltage is around 2.7V.
- When diode testing is completed, disconnect the test leads from the device under test, and remove the test leads from the input terminals of the meter.

F. Capacitance Measurement (See figure 8)



(Figure 8)

⚠ Warning

To avoid damage to the Meter or to the equipment under test, disconnect circuit power and discharge all high-voltage capacitors before measuring capacitance. Use the DC Voltage function to confirm that the capacitor is discharged.


To measure capacitance, connect the Meter as follows:

1. Insert the red test lead into the **HzΩmV** terminal and the black test lead into the **COM** terminal.
2. Set the rotary switch to **⌚**.
3. Connect the test leads across with the object being measured. The measured value shows on the display.

Note

- The Meter displays a fixed value which is the distributed capacitor's value of the inside Meter. To ensure accuracy, it is necessary to subtract this value from the measured value when measuring small capacitor.
- Multi-purpose socket can be used instead of test leads. Insert the capacitor being tested into the corresponding input terminal of the multi-purpose socket. This socket will provide a more accurate reading when measuring small capacitor values.
- When measuring capacitance values larger than 600uF, it is normal for the meter to require some time to stabilize.
- The LCD displays **OL** indicating the tested capacitor is shorted or it exceeds the maximum range.
- When capacitance measurement has been completed, disconnect the test leads from the device under test and remove the leads from the input terminals of the meter.

G. Frequency Measurement (see figure 9)



(Figure 9)

⚠ Warning

To avoid the risk of personal injury, do not attempt to measure frequency with voltage higher than 30V RMS.


To measure frequency, connect the Meter as follows:

1. Insert the red test lead into the **Hz** terminal and the black test lead into the **COM** terminal.
2. Set the rotary switch to **Hz⁰F** and press **SELECT** button to select **Hz** measurement mode
3. Connect the test leads across with the object being measured. The measured value shows on the display.

Note

- When making frequency measurements, the measured signal “a”, must fall within the following voltage level:
 - When 10Hz to 1MHz : $150\text{m} \leq a \leq 30 \text{ rms}$
 - When > 1MHz to 10MHz : $300\text{m} \leq a \leq 30 \text{ rms}$
 - When > 10MHz to 50MHz : $600\text{m} \leq a \leq 30 \text{ rms}$
 - When > 50MHz : Unspecified
- When frequency measurement is complete, disconnect the test leads from the circuit under test, and remove from the input terminals of the meter.

H. Temperature Measurement (see figure 10)



(Figure 10)


To measure temperature, connect the Meter as follows:

1. Set the rotary switch to $^{\circ}\text{C}$ to measure degree celsius temperature or $\text{Hz}^{\circ}\text{F}$ and press **SELECT** button to select $^{\circ}\text{F}$ measurement mode to measure Fahrenheit.
2. Insert the multi-purpose socket into the corresponding **Hz** and **COM** terminal.
3. Insert the temperature probe to the corresponding input terminal of the multi-purpose socket. Take care to ensure that proper polarity is observed when connecting to this socket.
4. Place the temperature probe to the object being measured. The measured value shows on the display after few seconds.

Note

- The testing environment must be between 18°C to 28°C to ensure accuracy especially when measuring low temperature.
- Different readings may be obtained when testing room environment under short or open circuit situation, then short-circuited reading shall be considered as the correct reading.
- The included point contact temperature probe can only be used under 230°C . For any measurement higher than that, the rod type temperature probe must be used instead.
- When temperature measurement has been completed, disconnect the connection between the temperature probe, multi-purpose socket and the circuit under test, and remove the temperature probe from the input terminals of the multi-purpose socket, and remove the multi-purpose socket from the input terminals of the Meter.

I. Measuring Transistor (see figure 11)



(Figure 11)

To measure transistor, connect the Meter as follows:

1. Insert the multi-purpose socket into the **μAmA** and **Hz** input terminal.
2. Set the rotary switch to **hFE**.
3. Insert the NPN or PNP type transistor to be tested into the corresponding input terminals of the multipurpose socket.
4. The measured nearest transistor value shows on the display.

Note

- When transistor measurement has been completed, remove the tested transistor from the multi-purpose socket and remove the multi-purpose socket from the input terminal

Operation of Hold Mode

⚠ Warning

To avoid possibility of electric shock, do not use Hold mode to determine if circuits are without power. The Hold mode will not capture unstable or noisy readings.

The Hold mode is applicable to all measurement functions.

- Press **HOLD** to enter Hold mode.
- Press **HOLD** again to exit Hold mode and the Meter displays the present measurement value.
- In Hold mode, **H** is displayed.

The POWER Button

This is a self-lock switch used to turn on or off the power Meter. It is located at the rear of the Meter. "I" indicates power on, while "O" indicates power off.

The SELECT Button

Some positions of the rotary selector have more than one function. This button is used for selecting the second function.

Turning on the Display Backlight

Warning

In order to avoid the hazard arising from mistaken readings in low light situations, please use Display Backlight function.

- Press **LIGHT** button to turn the Display Backlight on.
- Press **LIGHT** button again to turn the Display Backlight off.
- When using the AC power, the Display Backlight always stays on.

The Range Button

- Press **RANGE** to enter the manual ranging mode.
- Press and hold **RANGE** for over 1 second to return to autoranging.

The MAX MIN Button

MAX MIN recording mode captures and stores the maximum and minimum input value detected.

To use the MAX MIN mode as follows:

- Press MAX MIN to display the highest reading (**MAX** is shown on display).
- Press MAX MIN again to display the lowest reading (**MIN** is shown on display). Press and hold MAX MIN for over 1 second to exit the MAX MIN mode.

AC/AC+DC Button

It is used to select measuring AC or AC+DC when measuring AC. Press it only at the AC voltage or current measuring mode which is at the rotary switch position **V \sim** , **mV \sim** , **μ A \sim** , **mA \sim** or **A \sim** . “+DC “ will be displayed when it is pressed under DC measurement mode.

Power Input Switch

It is used to select AC 120V/60Hz or DC 6pcs of 1.5V battery (R14) to power on the Meter. It is located at the rear of the Meter.

Sleep Mode

The meter will automatically enter the sleep mode after approximately 10 minutes of inactivity, to preserve battery life. The last value will be stored.


The Meter can be activated by pressing the **POWER** button off and then on or pressing the **HOLD** button, it will display the last measurement value before it entered sleep mode and under the HOLD mode.

Turning the rotary switch can also activate the Meter. However, it will start from the switch selected function and it will not display the last measurement value before it entered sleep mode.



To disable the Sleep Mode function, press **MAX MIN**, **RANGE**, or **RS232** button while turning on the Meter, the symbol  disappears.

RS232 Button

Press RS232 button to enter or exit data output mode.

In RS232C serial port data output mode, the Hold and Max Min mode cannot output to the computer, the computer will only display the present measuring value. In RS232C serial port data output mode, Sleep Mode function will be disabled,  symbol disappears. +DC, hFE and β cannot output to the computer.

General Specifications

- Maximum Voltage between any Terminals and Grounding:
Refer to different range input protection voltage.
- ⚠ Fused Protection for **H_zΩWmV** Input Terminal: 200mA, 250V, fast type, φ5 × 20mm (only apply on hFE functions)
- ⚠ Fused Protection for **μAmA** Input Terminal: 500mA, 125V, fast type, φ5 × 20mm.
- ⚠ Fused Protection for 10A Input Terminal: 10A, 250V, fast type, φ5 × 20mm.
- ⚠ Fused Protection for AC125V Terminal: 500mA, 125V, fast type, φ5 × 20mm.
At AC125V power: without fuse protection.
- Maximum Display : Digital: 5999
- Measurement Speed : Updates 2-3 times/second.
- Range : Manual or auto ranging.
- Polarity Display : Auto
- Overloading Display : OL
- Temperature:
 - Operating: 0°C to +40°C (32°F to +104°F).
 - Storage : -1°C to +50°C (14°F to +122°F).
- Relative Humidity:
 - ≤75% @ 0°C - 30°C below; ≤50% @ 30 - 40°C.
- Altitude:
 - Operating : 2000 m.
 - Storage : 10000 m.
- Below 1V/m electrostatic discharge:
Accuracy = specified accuracy + 5% of the range. Over 1V/m electrostatic discharge: Without specified accuracy.
- Power:
AC110V/60Hz or 6 pieces of 1.5V battery (R14).
- Low Battery:
Display 
- Dimensions (H × W × L):
4.13" × 9.45" × 12.21"
- Weight:
Approximate 4.4 lbs(accessories excluded).
- Safety/Compliances:
IEC61010 CAT. I 1000V, CAT. II 600V over voltage and double insulation standard.
- Certifications:
 UL pending.

Accuracy Specifications

Accuracy: $\pm(a\% \text{ reading} + b \text{ digits})$, guarantee for 1 year.

Operating temperature: $23^{\circ}\text{C} \pm 5^{\circ}\text{C}$.

Relative humidity: not more than 75% RH.

Temperature coefficient: $0.1 \times (\text{specified accuracy})/1^{\circ}\text{C}$.

A. DC Voltage

Range	Resolution	Accuracy	Overload Protection
600mV	0.1mV	$\pm(0.6\%+2)$	1000V
6V	0.001V	$\pm(0.3\%+2)$	
60V	0.01V		
600V	0.1V		
1000V	1V	$\pm(0.5\%+3)$	

Remarks:

- **Input Impedance:**

At 600mV range : Around > 3000M Ω .

At all other ranges : Around 10M Ω .

B. AC Voltage

Range	Resolution	Accuracy	Overload Protection
600mV	0.1mV	40Hz-50kHz: $\pm(0.6\%+5)$	1000V
		>50kHz-100kHz: $\pm(1\%+5)$	
6V	0.001V	40Hz-1kHz: $\pm(0.6\%+5)$	
		>1kHz-10kHz: $\pm(1.0\%+5)$	
		>10kHz-100kHz: $\pm(3\%+5)$	
60V	0.01V	40Hz-1kHz: $\pm(0.6\%+5)$	
		>1kHz-10kHz: $\pm(1.5\%+5)$	
		>10kHz-20kHz: $\pm(3\%+5)$	
		>20kHz-100kHz: $\pm(8\%+5)$	
600V	0.1V	40Hz-1kHz: $\pm(0.6\%+5)$	
		>1kHz-10kHz: $\pm(3.5\%+5)$	
1000V	1V	40Hz-1kHz: $\pm(1.2\%+3)$	
		>1kHz-3kHz: $\pm(3\%+3)$	

Remarks:

Input Impedance:

At 600mV range : Around > 3000M Ω

At all other ranges : Around 10M Ω

Displays:

True RMS (applicable to the range of 10% to 95%)

At 1000V range: AC peak factor 1.5.

All other ranges: AC peak factor 3.

Input short circuit has around less than 30 remaining digits, it will not affect accuracy.

AC+DC measurement accuracy = range's accuracy + 1%

C. DC Current

Range	Resolution	Accuracy	Overload Protection
600μA	0.1μA	±(0.5%+3)	Fuse 500mA, 125V, fast type, φ5 × 20mm.
6000μA	1μA		
60mA	0.01mA		
600mA	0.1mA	±(0.8%+3)	Fuse 10A, 250V, fast type, φ5 × 20mm.
10A	10mA	±(1.2%+3)	

Remarks:

- **At 5A range:** Continuous measurement is allowed.
- **At >5A range:** For continuous measurement ≤10 seconds and interval not less than 15 minutes.

D. AC Current

Range	Resolution	Accuracy	Overload Protection
600μA	0.1μA	40Hz to 10kHz: ±(1%+5) >10kHz to 15kHz: ±(2%+5)	Fuse 500mA, 125V, fast type, φ5 × 20mm.
6000μA	1μA		
60mA	0.01mA		
600mA	0.1mA	40Hz to 10kHz: ±(1%+5) >10kHz to 15kHz: ±(3%+5)	Fuse 10A, 250V, fast type, φ5 × 20mm
10A	10mA	40Hz to 5kHz: ±(2%+6)	

Remarks:

- **At ≤ 5A range :** Continuous measurement is allowed.
- **At >5A range :** For continuous measurement ≤10 seconds and interval not less than 15 minutes.
- **Displays:**
 - True RMS (applicable to the range of 10% to 95%)
 - AC peak factor 3.
 - Input short circuit has around less than 30 remaining digits, it will not affect accuracy.
 - AC+DC measurement accuracy = range's accuracy + 1%

E. Resistance

Range	Resolution	Accuracy	Overload Protection
600Ω	0.1Ω	±(0.8%+3) + test lead short circuit resistance value	250V rms
6kΩ	0.001kΩ	±(0.5%+2)	
60kΩ	0.01kΩ		
600kΩ	0.1kΩ		
6MΩ	0.001MΩ	±(0.8%+2)	
60MΩ	0.01MΩ	± (1.2%+3)	

F. Continuity Test

Range	Resolution	Overload Protection	Remarks
•)	1Ω	250V rms	<ul style="list-style-type: none"> Open circuit voltage approximate -1.2V. When circuit disconnected with resistance value > 30Ω, buzzer does not beep. When circuit is in good connection with resistance value ≤70Ω buzzer beeps continuously.

G. Diode Testst

Range	Resolution	Overload Protection	Remarks
→←	10mV	250V rms	<ul style="list-style-type: none"> Open circuit voltage approximate 2.7V. Working current approximate 1mA.

H. Capacitance

Range	Resolution	Accuracy	Overload Protection
6nF	0.001nF	± (2.5%+5)	250V rms
60nF	0.01nF		
600nF	0.1nF	± (2%+5)	
6μF	0.001μF		
60μF	0.01μF		
600μF	0.1μF	± (3%+4)	
6mF	0.001mF	± (5%+4)	

Remarks:

- At 6nF, 60nF and 600nF Range: reading must subtract the test lead open circuit capacitance value.

I. Frequency

Range	Resolution	Accuracy	Overload Protection
6kHz	0.001kHz	± (0.1%+3)	250V rms
60kHz	0.01kHz		
600kHz	0.1kHz		
6MHz	0.001MHz		
60MHz	0.01MHz		

Remarks:

- Input scope (a): (DC electric level is zero)
 - When 10Hz to 1MHz : 150mV ≤ a ≤ 30V rms
 - When > 1MHz to 10MHz : 300mV ≤ a ≤ 30V rms
 - When > 10MHz to 50MHz : 600mV ≤ a ≤ 30V rms
 - When > 50MHz : Unspecified

J. Temperature

Range	Resolution	Accuracy		Overload Protection
°C	1°C	-40°C to 0°C	± (8%+5)	250V rms
		>00C to 400°C	± (1%+7)	
		>400°C to 1000°C	± (2%+10)	
°F	1°F	-40°C to 32°C	± (8%+5)	
		>32°F to 752°F	± (1.5%+5)	
		>752°F to 1832°F	± (2.5%+5)	

Remarks:

- The included point contact temperature probe can only be used to measure under 230°C temperature. For any measurement higher than that, the rod type temperature probe must be used instead.

K. Transistor

Range	Resolution	Overload Protection	Remarks
hFE	1 _β	Fuse 200mA, 250V, fast type, φ5x20mm. Fuse 500mA, 125V, fast type, φ5x20mm	V _{ce} = 2.2V bo = 10μA 1000 _β MAX

Maintenance

This section provides basic maintenance information including battery and fuse replacement instruction.


Warning

Do not attempt to repair or service your Meter unless you are qualified to do so and have the relevant calibration, performance test, and service information. To avoid electrical shock or damage to the Meter, do you get water inside the case.

A. General Service

- Periodically wipe the case with a damp cloth and mild detergent. Do not use abrasives or solvents.
- To clean the terminals with cotton bar with detergent, as dirt or moisture in the terminals can affect readings.
- Turn off the power of the Meter when it is not in use.
- Take out the battery when it is using for a long time.
- Do not use or store the Meter in a place of humidity, high temperature, explosive, inflammable and strong magnetic field.

B. Replacing the Fuses (see figure 12)



(Figure 12)

⚠ Warning


To avoid electrical shock or arc blast, or personal injury or damage to the Meter, use specified fuses **ONLY** in accordance with the following procedure.

To replace the Meter's fuse:

1. Press the **POWER** to turn the Meter off, disconnect the power cord and remove all connections from the terminals.
2. Fuse 1: Remove the screws from the power socket at the rear of the Meter. Remove the fuse by gently prying one end loose, then take out the fuse from its bracket. Then install the replacement fuse. Fuse 2 and 3: Use a coin to open the accessories compartment at the top of the front cover, then you will see a fuse compartment. Open the fuse compartment to replace fuse 2 and 3. Remove the fuse by gently prying one end loose, then take out the fuse from its bracket. Then install the replacement fuse. Fuse 4: It is located at the PCB. Remove the fuse by gently prying one end loose, then take out the fuse from its bracket. Then install the replacement fuse
3. Install **ONLY** replacement fuses with the identical type and specification as follows and make sure the fuse is fixed firmly in the bracket.
 - Fuse 1: 500mA, 125V, fast type, $\phi 5 \times 20$ mm (AC125V)
 - Fuse 2: 10A, 250V, fast type, $\phi 5 \times 20$ mm (μ A, mA)
 - Fuse 3: 500mA, 125V, fast type, $\phi 5 \times 20$ mm (A)
 - Fuse 4: 200mA, 250V, fast type, $\phi 5 \times 20$ mm (hFE)

Replacement of the fuses is seldom required. Burning of a fuse always results from improper operation.

C. Replacing the Battery (see figure 13)



(Figure 13)

⚠ Warning

To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator “” appears when using battery to power on the Meter.

To replace the battery:

1. Press the **POWER** to turn the Meter off and remove all connections from the terminals.
2. Use a coin to open the accessories compartment at the top of the front case.
3. Use a coin to open the battery compartment inside the accessories compartment located at the top of the front case.
4. Remove all the batteries from the battery compartment.
5. Replace the battery with new 6pcs of 1.5V battery (R14).
6. Rejoin the battery compartment and also the accessories compartment located at the top of the front case.


RS232C Serial Port

System Requirements for Installing the 72-1015 Interface Program

To use 72-1015 Interface Program, you need the following hardware and software:

- An IBM PC or equivalent computer with 80486 or higher processor and 600 × 800 pixel or better monitor.
- Microsoft Windows 95 or above.
- At least 8MB of RAM.
- At least 8MB free space in hard drive.
- Can access to a local or a network CD-ROM.
- A free serial port.
- A mouse or other pointing device supported by Windows.

A. Connecting between the Meter and computer (see figure 14)



(Figure 14)

B. RS232C Port Cable

The Meter		Computer	
D-sub 9 Pin Male		D-sub 9 Pin Female	D-sub 25 Pin Female
1 (DCD)	—	1 (DCD)	8 (DCD)
2 (RXD)	—	3 (TXD)	2 (TXD)
3 (TXD)	—	2 (RXD)	3 (RXD)
4 (DTR)	—	4 (DTR)	20 (DTR)
5 (SG)	—	5 (SG)	7 (SG)
6 (DSR)	—	6 (DSR)	6 (DSR)
7 (RTS)	—	7 (RTS)	4 (RTS)
8 (CTS)	—	8 (CTS)	5 (CTS)
9 (RI)	—	9 (RI)	22 (RI)

C. Setting of RS232C Serial Ports

Default of RS232C serial port for communication is set as:

Baud Rate 19200
Start bit 1
Stop bit 1
Data bits 7
Parity Odd

Important Notice : This data sheet and its contents (the "Information") belong to the members of the AVNET group of companies (the "Group") or are licensed to it. No licence is granted for the use of it other than for information purposes in connection with the products to which it relates. No licence of any intellectual property rights is granted. The Information is subject to change without notice and replaces all data sheets previously supplied. The Information supplied is believed to be accurate but the Group assumes no responsibility for its accuracy or completeness, any error in or omission from it or for any use made of it. Users of this data sheet should check for themselves the Information and the suitability of the products for their purpose and not make any assumptions based on information included or omitted. Liability for loss or damage resulting from any reliance on the Information or use of it (including liability resulting from negligence or where the Group was aware of the possibility of such loss or damage arising) is excluded. This will not operate to limit or restrict the Group's liability for death or personal injury resulting from its negligence. TENMA is the registered trademark of Premier Farnell Limited 2019.

Newark.com/exclusive-brands
Farnell.com/exclusive-brands
Element14.com/exclusive-brands