

## YASKAWA AC Drive Option PROFIBUS-DP Installation Manual


Type: SI-P3

To properly use the product, read this manual thoroughly and retain for easy reference, inspection, and maintenance. Ensure the end user receives this manual.

## 安川インバータ オプション PROFIBUS-DP通信 取扱説明書

形 式 SI-P3

製品を安全にお使いいただくために、この取扱説明書を必ずお読みください。  
また、本書をお手元に保管していただくとともに、最終的に本製品をご使用になるユーザー様のお手元に確実に届けられるよう、お取り計らい願います。



---

## **Copyright © 2016 YASKAWA ELECTRIC CORPORATION**

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of Yaskawa. No patent liability is assumed with respect to the use of the information contained herein. Moreover, because Yaskawa is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Yaskawa assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

# Table of Contents

---

<b>1</b>	<b>PREFACE AND SAFETY</b> .....	<b>4</b>
<b>2</b>	<b>OVERVIEW</b> .....	<b>9</b>
<b>3</b>	<b>RECEIVING</b> .....	<b>10</b>
<b>4</b>	<b>OPTION COMPONENTS</b> .....	<b>11</b>
<b>5</b>	<b>INSTALLATION PROCEDURE</b> .....	<b>15</b>
<b>6</b>	<b>RELATED PARAMETERS</b> .....	<b>36</b>
<b>7</b>	<b>PROFIBUS-DP OPTION DATA AND I/O MAPS</b> .....	<b>40</b>
<b>8</b>	<b>TROUBLESHOOTING</b> .....	<b>44</b>
<b>9</b>	<b>EUROPEAN STANDARDS</b> .....	<b>49</b>
<b>10</b>	<b>SPECIFICATIONS</b> .....	<b>51</b>

## 1 Preface and Safety

YASKAWA Electric supplies component parts for use in a wide variety of industrial applications. The selection and application of YASKAWA products remain the responsibility of the equipment designer or end user.

YASKAWA accepts no responsibility for the way its products are incorporated into the final system design. Under no circumstances should any YASKAWA product be incorporated into any product or design as the exclusive or sole safety control. Without exception, all controls should be designed to detect faults dynamically and fail safely under all circumstances. All products designed to incorporate a component part manufactured by YASKAWA must be supplied to the end user with appropriate warnings and instructions as to the safe use and operation of that part. Any warnings provided by YASKAWA must be promptly provided to the end user. YASKAWA offers an express warranty only as to the quality of its products in conforming to standards and specifications published in the manual. **NO OTHER WARRANTY, EXPRESS OR IMPLIED, IS OFFERED.** YASKAWA assumes no liability for any personal injury, property damage, losses, or claims arising from misapplication of its products.

### ◆ Applicable Documentation

The following manuals are available for the option:

#### Option

<b>YASKAWA AC Drive Option PROFIBUS-DP Installation Manual Manual No: TOBP C730600 82 (This book)</b>	This guide is packaged together with the product and contains information necessary to install the option and set related drive parameters.
<b>YASKAWA AC Drive Option PROFIBUS-DP Technical Manual Manual No: SIEP C730600 82</b>	The technical manual contains detailed information about the option. Access the following sites to obtain the technical manual: U.S.: <a href="http://www.yaskawa.com">http://www.yaskawa.com</a> Europe: <a href="http://www.yaskawa.eu.com">http://www.yaskawa.eu.com</a> Japan: <a href="http://www.e-mechatronics.com">http://www.e-mechatronics.com</a> Other areas: Check the back cover of these manuals. For questions, contact Yaskawa or a Yaskawa representative.

## Yaskawa Drive

<b>YASKAWA AC Drive Manuals</b>	Drive manuals contain basic installation and wiring information in addition to detailed parameter setting, fault diagnostic, and maintenance information. The most recent versions of these manuals are available for download on our documentation websites: U.S.: <a href="http://www.yaskawa.com">http://www.yaskawa.com</a> Europe: <a href="http://www.yaskawa.eu.com">http://www.yaskawa.eu.com</a> Japan: <a href="http://www.e-mechatronics.com">http://www.e-mechatronics.com</a> Other areas: Check the back cover of these manuals. For questions, contact your local Yaskawa sales office or the nearest Yaskawa representative.
---------------------------------	--

## ◆ Terms and Abbreviations

<b>Note:</b>	Indicates a supplement or precaution that does not cause drive damage.
<b>Option:</b>	YASKAWA AC Drive Option PROFIBUS-DP
<b>Drive:</b>	<ul style="list-style-type: none"><li>• YASKAWA AC Drive 1000-Series (A1000, U1000, Z1000U)</li><li>• YASKAWA AC Drive GA700</li><li>• YASKAWA AC Drive GA800</li></ul>
<b>Keypad:</b>	<ul style="list-style-type: none"><li>• LCD Operator for YASKAWA AC Drive 1000-Series</li><li>• LED Operator for YASKAWA AC Drive 1000-Series</li><li>• LCD Keypad for YASKAWA AC Drive GA700 and GA800</li><li>• LED Keypad for YASKAWA AC Drive GA700 and GA800</li></ul>
<b>V/f:</b>	V/f Control
<b>OLV:</b>	Open Loop Vector Control
<b>CLV:</b>	Closed Loop Vector Control
<b>AOLV:</b>	Advanced Open Loop Vector Control
<b>OLV/PM:</b>	Open Loop Vector Control for PM
<b>AOLV/PM:</b>	Advanced Open Loop Vector Control for PM
<b>CLV/PM:</b>	Closed Loop Vector Control for PM
<b>EZOLV:</b>	EZ Open Loop Vector Control

## ◆ Registered Trademarks

- PROFIBUS-DP is a registered trademark of PROFIBUS and PROFINET International.
- Trademarks are the property of their respective owners.

# 1 Preface and Safety

---

## ◆ Supplemental Safety Information

Read and understand this manual before installing, operating, or servicing this option. Install the option according to this manual and local codes.

The following conventions indicate safety messages in this manual. Failure to heed these messages could cause fatal injury or damage products and related equipment and systems.

### **DANGER**

**Indicates a hazardous situation, which, if not avoided, will cause death or serious injury.**

### **WARNING**

**Indicates a hazardous situation, which, if not avoided, could cause death or serious injury.**

### **CAUTION**

**Indicates a hazardous situation, which, if not avoided, could cause minor or moderate injury.**

### **NOTICE**

**Indicates an equipment damage message.**

## ■ General Safety

### General Precautions

- The diagrams in this book may include options and drives without covers or safety shields to illustrate details. Be sure to reinstall covers or shields before operating any devices. Use the option according to the instructions described in this manual.
- The diagrams in this manual are provided as examples only and may not pertain to all products covered by this manual.
- The products and specifications described in this manual or the content and presentation of the manual may be changed without notice to improve the product and/or the manual.
- Contact Yaskawa or a Yaskawa representative and provide the manual number shown on the front cover to order new copies of the manual.

### DANGER

#### **Heed the safety messages in this manual.**

Failure to comply will cause death or serious injury.

The operating company is responsible for any injuries or equipment damage resulting from failure to heed the warnings in this manual.

### WARNING

#### **Electrical Shock Hazard**

**Do not attempt to modify or alter the drive or drive circuitry in any way not explained in this manual.**

Failure to comply could cause death or serious injury and will void warranty. Yaskawa is not responsible for any modification of the product made by the user. Do not modify this product.

### NOTICE

**Do not modify the drive or option circuitry.**

Failure to comply could result in damage to the drive or option and will void warranty. Yaskawa is not responsible for any modification of the product made by the user.

**Do not expose the drive or the option to halogen group disinfectants. Do not pack the drive or the option in fumigated or sterilized wooden materials. Do not sterilize the entire package after packing the product.**

Failure to comply could damage electrical components in the option.



## 2 Overview

The SI-P3 PROFIBUS-DP Option is an open digital communication system supporting a wide range of fast, time-critical applications.

PROFIBUS Decentralized Periphery (PROFIBUS-DP) is one of the three PROFIBUS variants. DP is dedicated to fast data communication between systems and peripherals at a field level. This option connects a Yaskawa drive to a field network using the PROFIBUS-DP protocol.

PROFIBUS-DP is included into the European Fieldbus Standard EN 50170.

The network is primarily used in process and factory automation.

Install the option/PROFIBUS option on a drive to perform the following functions from a PROFIBUS-DP master device:

- Operate the drive
- Monitor the drive operation status
- Change drive parameter settings

### ◆ Compatible Products

The option can be used with the products in [Table 1](#).

**Table 1 Compatible Products**

Product Series	Model(s)
A1000	All models
U1000	All models
Z1000U	All models
GA700	All models
GA800	All models

**Note:** For Yaskawa customers in the North or South America region: If your product is not listed in [Table 1](#), refer to the web page below to confirm this manual is correct for your product. The web page provides a list of option manuals by product, and a direct link to download a PDF.

Scan QR code



Or refer to: <http://www.yaskawa.com/optionlookup>

## 3 Receiving

After receiving the option package:







1. Make sure that the option is not damaged and no parts are missing. Contact your sales outlet if the option or other parts appear damaged.

**NOTICE:** Do not use damaged parts to connect the drive and the option. Failure to comply could damage the drive and option.

2. Confirm that the model number on the option nameplate and the model listed in the purchase order are the same. Refer to [Figure 1](#) on page 11 for details. Contact the distributor where the option was purchased or contact Yaskawa or a Yaskawa representative about any problems with the option.

### ◆ Contents and Packaging

Table 2 Contents of Package

Description:	Option	Ground Wire <1>	Screws (M3)	LED Labels		Installation Manual
				1000-Series	GA700 and GA800	
-						
<b>Quantity:</b>	1	1	3 <2>	1	1	1

<1> GA700 and GA800 drives do not use the ground wire.


<2> GA700 and GA800 drives use two screws only.

### ◆ Installation Tools

- A Phillips screwdriver. Phillips screw sizes vary by drive capacity.
- A flat-blade screwdriver (blade depth: 0.4 mm (0.02 in), width: 2.5 mm (0.1 in)).
- A pair of diagonal cutting pliers.
- A small file or medium-grit sandpaper.

## 4 Option Components

### ◆ PROFIBUS-DP Option



<1> Refer to *Option LED Display on page 12* for details on the LEDs

<2> Connect the provided ground wire during installation. Installation on GA700 and GA800 drives does not require the ground wire.


Figure 1 PROFIBUS-DP Option Components

## 4 Option Components

### ◆ Communication Connector

The option has a 9-pin D-sub connector to connect to a PROFIBUS network.

**Table 3 Communication Connector (9-pin D-sub)**

Connector	Pin	Signal	Description
	1	Shield	Connected to the metal-shell (no direct FG-connection)
	2	–	–
	3	RxD/TxD-P	Receive/Transmit data; line B (red)
	4	CNTR-P	Control signal for repeaters (direction control)
	5	DGND	Data ground (reference voltage to VP)
	6	VP	Power supply output for bus termination (for termination resistor)
	7	–	–
	8	RxD/TxD-N	Receive/Transmit data; line A (green)
	9	–	–

### ◆ Option LED Display



1000-Series Label



GA700 and GA800 Label

**Figure 2 Option LED Labels**

The option has four bicolor, red/green LEDs to relay information about power, communication status, and errors.

The operational states of the LEDs after completion of the power-up diagnostic process are described in [Table 5](#). Wait at least 2 seconds for the power-up diagnostic process to complete before verifying the states of the LEDs.

**Table 4 Option LED States**

LED	Display		Operating Status	Description
	Color	Status		
<b>RUN (Power)</b>	Green	ON	Power supply ON	Power is supplied to the option, and the option hardware self-diagnostics check is complete.
		OFF	Power supply OFF	<ul style="list-style-type: none"> <li>• The drive has no power supply.</li> <li>• Option and drive are not connected properly and/or no power is supplied to the option.</li> <li>• An internal, self-diagnostic error occurred in the option.</li> </ul>
<b>ERR (Option Error)</b>	Red	ON	Option error	Self-diagnostics error occurred in the option.
		Flashing	Drive connection error	Connection error between option and drive. This includes node address setting errors to parameter F6-30 on the drive side.
		OFF	Normal operation	Drive and option are properly connected.
<b>COMM (Communication Status)</b>	Green	ON	Communication connected	Normal send/receive between the option and the PROFIBUS-DP master.
		OFF	No data exchange	There is a problem establishing communication between the option and the PROFIBUS-DP master.
<b>BF (PROFIBUS-DP Error)</b>	Red	ON	Waiting for communication procedure setting	Communication-related parameters are in the process of being set or initialized by the PROFIBUS-DP master.
		Flashing	Communication setting error	Communication parameter error from PROFIBUS-DP master.
		OFF	Normal operation	LED shuts off when the PROFIBUS-DP master is finished setting communication-related parameters.

## 4 Option Components

Table 5 LED Operation After Power-up Diagnostic

LED				Communication Status	Possible Cause	Solution
RUN	ERR	COMM	BF			
●	●	●	●	No power	Drive has no power. Option is not properly connected to the drive or is not receiving enough power.	Check all wiring to the drive, then turn on the power. Shut off the drive and make sure the option is connected properly. Turn the power back on.
○	●	●	●	<ul style="list-style-type: none"> <li>Checking connection with the drive</li> <li>Waiting for data from the master</li> </ul>	<ul style="list-style-type: none"> <li>Option is reading the node address or parameter configuration.</li> <li>Waiting for initial input data from master device.</li> </ul>	—
●	○	●	●	Option self-diagnostics error	The option is damaged.	Cycle power to the drive. If the LED status does not change, replace the option.
●	◐	●	●	Problem connecting to the drive	<ul style="list-style-type: none"> <li>Problem initializing the drive and the option.</li> <li>Incorrect node address.</li> </ul>	<ul style="list-style-type: none"> <li>Cycle power to the drive. If the LED status does not change, replace the option.</li> <li>Check the node address setting in the drive (F6-30).</li> </ul>
○	●	●	○	Waiting for data from the master device	Waiting for data from the master device. (Set_Parm_Message or Chk_Cfg_Message)	<ul style="list-style-type: none"> <li>Check master network settings.</li> <li>Make sure the master device is operating normally.</li> <li>Check the terminal resistance settings on the data line.</li> <li>Check for problems with the data line and connector.</li> <li>Check if the data line is connected properly to communication connector CN5.</li> </ul>
○	●	●	◐	Incorrect data or option time out waiting for data	The communication settings in the master are set incorrectly.	Check the communication settings in the master.
○	●	○	●	Sending or receiving data	—	—

○: On / ◐ : Flashing / ●: Off

## 5 Installation Procedure

### ◆ Section Safety

#### DANGER

##### **Electric Shock Hazard**

**Do not inspect, connect, or disconnect any wiring while the drive is energized.**

Failure to comply will cause death or serious injury.

Before servicing, disconnect all power to the equipment and wait for at least the time specified on the warning label. The internal capacitor remains charged even after the drive is de-energized. The charge indicator LED will extinguish when the DC bus voltage is below 50 Vdc. When all indicators are OFF, measure for unsafe voltages to confirm the drive is safe.

#### WARNING

##### **Electrical Shock Hazard**

**Do not operate equipment with covers removed.**

Failure to comply could cause death or serious injury.

The diagrams in this section may include options and drives without covers or safety shields to illustrate details. Reinstall covers and shields before operating the drive and run the drive according to the instructions described in this manual.

**Do not allow unqualified personnel to perform work on the drive or option.**

Failure to comply could cause death or serious injury.

Only authorized personnel familiar with installation, adjustment, and maintenance of AC drives and options may perform work.

**Do not remove covers or touch circuit boards while the drive is energized.**

Failure to comply could cause death or serious injury.

## 5 Installation Procedure

### WARNING

**Do not use damaged wires, stress the wiring, or damage the wire insulation.**

Failure to comply could cause death or serious injury.

#### **Fire Hazard**

**Tighten all terminal screws to the specified tightening torque.**

Loose or overtightened connections could cause erroneous operation and damage to the terminal block or start a fire and cause death or serious injury.

### NOTICE

#### **Damage to Equipment**

**Observe proper electrostatic discharge (ESD) procedures when handling the option, drive, and circuit boards.**

Failure to comply could cause ESD damage to circuitry.

**Never connect or disconnect the motor from the drive while the drive is outputting voltage.**

Improper equipment sequencing could damage the drive.

**Do not connect or operate any equipment with visible damage or missing parts.**

Failure to comply could further damage the equipment.

**Do not use unshielded wire for control wiring.**

Failure to comply may cause electrical interference resulting in poor system performance. Use shielded, twisted-pair wires and ground the shield to the ground terminal of the drive.

**Properly connect all pins and connectors on the option and drive.**

Failure to comply could prevent proper operation and damage equipment.

**Confirm that all connections are correct after installing the option and connecting peripheral devices.**

Failure to comply could damage the option.



### ◆ Procedures for Installing and Wiring Options on a Drive

Procedures for installing and wiring options differ depending on the drive model.

Refer to [Table 6](#) to check the procedures for installing and wiring options on a drive.

**Table 6 Procedures for Installing and Wiring Options on a Drive**

Product Series	Procedures for Installing and Wiring Options on a Drive	Page
A1000	Procedure A	<a href="#">18</a>
U1000	Procedure A	<a href="#">18</a>
Z1000U	Procedure A	<a href="#">18</a>
GA700	Procedure B	<a href="#">24</a>
GA800	Procedure B	<a href="#">24</a>

## 5 Installation Procedure

### ■ Procedure A

This section shows the procedure to install and wire the option on a 1000-series drive.

#### Prepare the Drive for the Option

1. Correctly wire the drive as specified by the manual packaged with the drive.
2. Make sure that the drive functions correctly.

Refer to [Figure 3](#) for an exploded view of the drive with the option and related components for reference in the installation procedure.




Figure 3 Drive Components with Option

### Install the Option


Refer to the instructions below to install the option.

**Note:** Refer to the instruction manual of a specific drive for information on removing and installing the keypads and the covers.

**DANGER!** *Electrical Shock Hazard. Do not inspect, connect, or disconnect any wiring while the drive is energized. Failure to comply will cause death or serious injury. Before servicing, disconnect all power to the equipment and wait for at least the time specified on the warning label. The internal capacitor remains charged even after the drive is de-energized. The charge indicator LED will extinguish when the DC bus voltage is below 50 Vdc. When all indicators are OFF, measure for unsafe voltages to confirm the drive is safe.*

1. Shut off power to the drive, wait the appropriate amount of time for voltage to dissipate, then remove the keypad (D) and front covers (C, F). Refer to the manual packaged with the drive for details on keypad and cover removal.

**NOTICE:** *Damage to Equipment. Observe proper electrostatic discharge (ESD) procedures when handling the option, drive, and circuit boards. Failure to comply could cause ESD damage to circuitry.*



**Figure 4 Remove the Keypad, Front Cover, and Terminal Cover**

## 5 Installation Procedure

2. Affix the LED label (E) in the appropriate position on the drive front cover (C).




Figure 5 Affix the LED Label

3. Insert the option card (B) into the CN5-A (K) connector on the drive and fasten it into place using one of the included screws (H). Tighten the screw to 0.5 to 0.6 N·m (4.4 to 5.3 in·lb).





Figure 6 Insert the Option Card

4. Connect one end of the ground wire (I) to the ground terminal (J) using one of the remaining provided screws (H). Connect the other end of the ground wire (I) to the remaining ground terminal using the last remaining provided screw (H).




**Figure 7 Connect the Ground Wire**

**Note:** The drive has only two ground terminal screw holes (J). Two ground wires should share the same ground terminal when connecting three options.

## 5 Installation Procedure

5. Select the proper PROFIBUS-DP dedicated communication cable according to [Table 7](#) and [Table 8](#). Route the option wiring inside the enclosure as shown in [Figure 8-B](#). Take proper precautions so that the front covers will easily fit back onto the drive. Users may also choose to route the option wiring through openings on the front cover of some models. Remove the perforated tabs on the left side of the front cover as shown in [Figure 8-A](#) to create the necessary openings on these models. Refer to the Peripheral Devices & Options section of the drive instruction manual for more information.




<1> The drive will not meet Enclosed wall-mounted type (IP20/UL Type 1) requirements if wiring is exposed outside the enclosure.

**Figure 8 Wire Routing Examples**

6. Firmly connect the PROFIBUS-DP communication cable to option communication connector CN4.  
Install PROFIBUS-DP communications cables apart from main-circuit wiring and other electrical and power lines. Ensure the cable end is firmly connected (see [Figure 18](#)). Refer to [Communication Cable Specifications on page 32](#) for details.
7. Reattach the drive front covers (C, F) and the keypad (D).

**NOTICE:** Do not pinch cables between the front covers and the drive. Failure to comply could cause erroneous operation.



**Figure 9** Replace the Front Covers and Keypad

8. Set drive parameters in [Table 9](#) for correct option performance. Be sure to set parameter F6-30 to a node address unique to the network.

## 5 Installation Procedure

### ■ Procedure B

This section shows the procedure to install and wire the option on a GA700 or GA800 drive.

#### Prepare the Drive for the Option

1. Correctly wire the drive as specified by the manual packaged with the drive.
2. Make sure that the drive functions correctly.  
Refer to [Figure 10](#) for an exploded view of the drive with the option and related components for reference in the installation procedure.




Figure 10 Drive Components with Option



### Install the Option

Remove the front cover of the drive before you install the option.

Refer to the drive manual for information about how to remove the front cover. Different drive sizes have different cover removal procedures.

You can only install this option into the **CN5-A** connector on the drive control board.

**DANGER! Electrical Shock Hazard.** Do not inspect, connect, or disconnect any wiring while the drive is energized. Failure to comply will cause death or serious injury. Before servicing, disconnect all power to the equipment and wait for at least the time specified on the warning label. The internal capacitor remains charged even after the drive is de-energized. The charge indicator LED will extinguish when the DC bus voltage is below 50 Vdc. When all indicators are OFF, measure for unsafe voltages to confirm the drive is safe.

1. Affix the LED label (E) in the appropriate position on the drive front cover (D).





Figure 11 Affix the LED Label

## 5 Installation Procedure

2. Shut off power to the drive, wait the appropriate amount of time for voltage to dissipate, then remove the front cover (D). Refer to the manual packaged with the drive for details on cover removal.


**NOTICE: Damage to Equipment.** Observe proper electrostatic discharge (ESD) procedures when handling the option, drive, and circuit boards. Failure to comply could cause ESD damage to circuitry.



**Figure 12 Remove the Front Cover and Keypad**

3. Carefully remove the LED Status Ring board (G) and place it on the right side of the drive using the temporary placement holes. Refer to the manual packaged with the drive for details on removing the LED Status Ring board.

**NOTICE:** Do not remove the LED Status Ring board cable connector. Failure to comply could cause erroneous operation and damage the drive.




**Figure 13 Remove the LED Status Ring Board**

## 5 Installation Procedure

4. Insert the option card (B) into the CN5-A connector (H) on the drive and fasten it into place using the included screws (C). Tighten both screws to 0.5 to 0.6 N·m (4.4 to 5.3 in·lb).

**Note:** Installing the option card on GA700 and GA800 drives requires only two screws and does not require a ground wire. The option package ships with three screws and a ground wire for installation on other product series. Do not use the ground wire or the extra screw.



**Figure 14** Insert the Option Card

### 5. Confirm proper option wiring.

Depending on the drive model, some drives may require routing the wiring to the outside as shown in [Figure 15](#).

Route the wiring inside the enclosure through the lower wiring cover to the outside as shown in [Figure 16](#) for the drives that do not require routing the wiring to the outside.




Figure 15 Wire Routing Examples




Figure 16 Wire Routing Examples

### 6. Select the proper PROFIBUS-DP dedicated communication cable according to [Table 7](#) and [Table 8](#). Firmly connect the PROFIBUS-DP communication cable to option communication connector CN4.

Install PROFIBUS-DP communications cables apart from main-circuit wiring and other electrical and power lines. Ensure the cable end is firmly connected (see [Figure 18](#)). Refer to [Communication Cable Specifications on page 32](#) for details.

**Note:** Maximum transmission distance is 100 m (328 ft). Minimum wiring distance between stations is 0.2 m (7.9 in).


### 7. After you connect the prepared cable for the 9-pin D-sub communication connector CN5, make sure that the option wire routing from Step 6. is correct.

## 5 Installation Procedure

8. Reattach the LED Status Ring board (G).  
Use the open space provided inside the LED Status Ring board to route option wiring.

**NOTICE:** Do not pinch cables between the front cover or the LED Status Ring board and the drive. Failure to comply could cause erroneous operation.


9. Reattach the drive front cover (D) and the keypad (F).




**Figure 17 Replace the Front Cover and Keypad**

## 5 Installation Procedure

**Note:** Depending on the drive model, some drives may require replacing the front cover of the drive after routing the wiring to the outside. In these cases, use diagonal cutters to cut out the perforated openings in the right side of the drive front cover and leave no sharp edges to damage wiring. The drive will not meet IP20 conformity if wiring is exposed outside the enclosure.



Right side of the drive front cover



Route the wiring and connector to the outside.

10. Set drive parameters in [Table 9](#) for correct option performance. Be sure to set parameter F6-30 to a node address unique to the network.

## 5 Installation Procedure

---

### ◆ Communication Cable Specifications

To ensure proper performance, Yaskawa recommends using PROFIBUS-DP-dedicated cables. Refer to the PROFIBUS-DP website at [www.profibus.com](http://www.profibus.com) for more information on cables.

Yaskawa recommends using PROFIBUS-DP cables suitable for the conditions listed in [Table 7](#) and [Table 8](#).

**Table 7 Communication Cable Requirements**


Condition	Specifications
Impedance	135 to 165 $\Omega$ at a frequency of (3 to 20 MHz)
Capacity	30 pF/m maximum
Loop Resistance	110 $\Omega$ /km maximum
Core Cross-Section	0.34 mm <sup>2</sup> minimum
Core Diameter	0.64 mm minimum

**Table 8 Communication Cable Length**

Communication Speed (kbps)	Distance per Segment
9.6	1200 m (3937 ft)
19.2	1200 m (3937 ft)
45.45	1200 m (3937 ft)
93.75	1200 m (3937 ft)
187.5	1000 m (3280 ft)
500	400 m (1312 ft)
1500	200 m (656 ft)
3000	100 m (328 ft)
6000	100 m (328 ft)
12000	100 m (328 ft)



## ◆ Option Connection Diagram



**Figure 18 Option Connection Diagram**


- <1> Connect the provided ground wire for installations on 1000-series drives.  
The ground wire is not necessary for installation on GA700 or GA800 drives.

## 5 Installation Procedure

### ■ PROFIBUS-DP Termination

The option does not have a built-in termination resistor. The termination resistance must be set on the final drive in the network using a switch on the 9-pin D-sub connector. Make sure that only the connector for the final drive in the network has a termination resistor; communication problems may arise if any other network drive has a termination resistor.

Use only the input side cable entry as shown in *Figure 19* when connecting both ends of the network. Most 9-pin D-sub connectors have a function for disconnecting the output side of the cable. Communication will not be possible between devices if the connector is reversed. Most connectors have arrows indicating the input and output sides.




**Figure 19 PROFIBUS Cable Connection with Termination Resistors**

**Bus termination ON** = incoming and outgoing cables not connected.

**Bus termination OFF** = incoming and outgoing cables connected.

Termination resistors without inductors as shown in *Figure 20* can only be used for baud rates below 1.5 Mbps. Baud rates 1.5 Mbps and higher require termination with resistors and inductors as shown in *Figure 18*.



**Figure 20 Cable Termination of the Option Cable to EN50170  
(Pin Numbers for a 9-pin D-sub Connector)**

### ◆ GSD Files

To facilitate network implementation, obtain a GSD file from one of the following websites depending on your region:

U.S.: <http://www.yaskawa.com>

Europe: <http://www.yaskawa.eu.com>

Japan: <http://www.e-mechatronics.com>

Other areas: Check the back cover of these manuals.

For questions, contact Yaskawa or a Yaskawa representative.

# 6 Related Parameters

The parameters in *Table 9* set the drive for operation with the option. Confirm proper setting of all parameters in *Table 9* before starting network communications. Refer to the manual packaged with the drive for details on setting parameters.

**Note:** Hex.: MEMOBUS addresses that you can use to change parameters over network communication are represented in hexadecimal numbers.

**Table 9 Related Parameters**

No. (Hex.)	Name	Description	Values
b1-01 (0180) </>	Reference 1 Source	Selects the input method for frequency reference. 0: Keypad 1: Analog Input 2: Memobus/Modbus Communications 3: Option PCB 4: Pulse Train Input	Default: 1 Range: 0 to 4 (Set to 3)
b1-02 (0181) </>	Run Command 1 Source	Selects the input method for the Run command. 0: Keypad 1: Digital Input 2: Memobus/Modbus Communications 3: Option PCB	Default: 1 Range: 0 to 3 (Set to 3)
d5-01 (029A)	Torque Control Selection	0: Speed Control 1: Torque Control	Default: 0 Range: 0, 1
F6-01 (03A2) </>	Communication Error Selection	Selects drive response when a bUS error is detected during communications with the option. 0: Ramp to Stop 1: Coast to Stop 2: Fast Stop (Use C1-09) 3: Alarm Only </> 4: Alarm - Run at d1-04 </> </> 5: Alarm - Ramp to Stop </>	Default: 1 Range: 0 to 5 </>
F6-02 (03A3)	Comm External Fault (EF0) Detect	Selects the condition for external fault detection (EF0). 0: Always detected 1: Detection during run only	Default: 0 Range: 0, 1
F6-03 (03A4)	Comm External Fault (EF0) Select	Selects drive response for external fault input (EF0) detection during option communications. 0: Ramp to Stop 1: Coast to Stop 2: Fast Stop (Use C1-09) 3: Alarm Only </>	Default: 1 Range: 0 to 3

## 6 Related Parameters

No. (Hex.)	Name	Description	Values
F6-06 (03A7) <5>	Torque Reference/Limit by Comm	Enabling this parameter allows d5-01 to determine whether the value is read as the Torque Limit value (d5-01 = 0) or the Torque Reference value (d5-01 = 1). 0: Disabled 1: Enabled <6>	Default: 0 Range: 0, 1
F6-07 (03A8)	MultiStep Ref Priority Select	0: MultiStep References Disabled 1: MultiStep References Enabled	Default: 0 Range: 0, 1
F6-08 (036A)	Comm Parameter Reset @Initialize	Selects whether communication-related parameters F6-□□ and F7-□□ are set back to original default values when the drive is initialized using parameter A1-03. 0: No Reset - Parameters retained 1: Reset - Back to factory default Note: The setting value is not changed even when F6-08 is set to 1 and the drive is initialized using A1-03.	Default: 0 Range: 0, 1
F6-14 (03BB) <7> <8>	Communication Error Auto Reset	Enables or disables the Communication Error Auto Reset. 0: Disabled 1: Enabled	Default: 0 Range: 0, 1
F6-30 (03CB) <9> <10>	PROFIBUS-DP Node Address	Sets the node address.	Default: 0 Min: 0 Max: 125
F6-31 (03CC)	PROFIBUS-DP Clear Mode Selection	Selects the action to take after a "Clear Mode" command is received. 0: Resets to 0 1: Maintains the previous value	Default: 0 Range: 0, 1
F6-32 (03CD) <8> <10> <11>	PROFIBUS-DP Data Format Selection	0: PPO Type 1: Conventional 2: PPO (bit0) <7> <11> 3: PPO Type (Enter) <7> <12> 4: Conv (Enter) <7> <12> 5: PPO (bit0, Enter) <7> <11> <12>	Default: 0 Range: 0 to 5
F7-16 (03F4) <7> <8>	Timeout Value	Sets the time-out value for communication loss detection in tenths of a second. A value of 0 disables the connection time-out. Example: An entered value of 100 represents 10.0 seconds.	Default: 0.0 Min: 0.0 Max: 30.0
F7-60 (0780) <7> <8>	PZD1 Write	Sets MEMOBUS/Modbus address for PZD1 Write (PPO Write). The value of 0 to 2 enables the PZD1 Write as STW.	Default: 0H Min: 0H Max: FFFFH
F7-61 (0781) <7> <8>	PZD2 Write	Sets MEMOBUS/Modbus address for PZD2 Write (PPO Write). The value of 0 to 2 enables the PZD2 Write as HSW.	Default: 0H Min: 0H Max: FFFFH

## 6 Related Parameters

No. (Hex.)	Name	Description	Values
F7-62 (0780) <> <>	PZD3 Write	Sets MEMOBUS/Modbus address for PZD3 Write (PPO Write). The value of 0 to 2 disables the PZD3 Write.	Default: 0H Min: 0H Max: FFFFH
F7-63 (0783) <> <>	PZD4 Write	Sets MEMOBUS/Modbus address for PZD4 Write (PPO Write). The value of 0 to 2 disables the PZD4 Write.	Default: 0H Min: 0H Max: FFFFH
F7-64 (0784) <> <>	PZD5 Write	Sets MEMOBUS/Modbus address for PZD5 Write (PPO Write). The value of 0 to 2 disables the PZD5 Write.	Default: 0H Min: 0H Max: FFFFH
F7-65 (0785) <> <>	PZD6 Write	Sets MEMOBUS/Modbus address for PZD6 Write (PPO Write). The value of 0 to 2 disables the PZD6 Write.	Default: 0H Min: 0H Max: FFFFH
F7-66 (0786) <> <>	PZD7 Write	Sets MEMOBUS/Modbus address for PZD7 Write (PPO Write). The value of 0 to 2 disables the PZD7 Write.	Default: 0H Min: 0H Max: FFFFH
F7-67 (0787) <> <>	PZD8 Write	Sets MEMOBUS/Modbus address for PZD8 Write (PPO Write). The value of 0 to 2 disables the PZD8 Write.	Default: 0H Min: 0H Max: FFFFH
F7-68 (0788) <> <>	PZD9 Write	Sets MEMOBUS/Modbus address for PZD9 Write (PPO Write). The value of 0 to 2 disables the PZD9 Write.	Default: 0H Min: 0H Max: FFFFH
F7-69 (0789) <> <>	PZD10 Write	Sets MEMOBUS/Modbus address for PZD10 Write (PPO Write). The value of 0 to 2 disables the PZD10 Write.	Default: 0H Min: 0H Max: FFFFH
F7-70 (078A) <> <>	PZD1 Read	Sets MEMOBUS/Modbus address for PZD1 Read (PPO Read). The value of 0 to 2 enables the PZD1 Read as ZSW.	Default: 0H Min: 0H Max: FFFFH
F7-71 (078B) <> <>	PZD2 Read	Sets MEMOBUS/Modbus address for PZD2 Read (PPO Read). The value of 0 to 2 enables the PZD2 Read as HIW.	Default: 0H Min: 0H Max: FFFFH
F7-72 (078C) <> <>	PZD3 Read	Sets MEMOBUS/Modbus address for PZD3 Read (PPO Read). The value of 0 to 2 disables the PZD3 Read.	Default: 0H Min: 0H Max: FFFFH
F7-73 (078D) <> <>	PZD4 Read	Sets MEMOBUS/Modbus address for PZD4 Read (PPO Read). The value of 0 to 2 disables the PZD4 Read.	Default: 0H Min: 0H Max: FFFFH
F7-74 (078E) <> <>	PZD5 Read	Sets MEMOBUS/Modbus address for PZD5 Read (PPO Read). The value of 0 to 2 disables the PZD5 Read.	Default: 0H Min: 0H Max: FFFFH
F7-75 (078F) <> <>	PZD6 Read	Sets MEMOBUS/Modbus address for PZD6 Read (PPO Read). The value of 0 to 2 disables the PZD6 Read.	Default: 0H Min: 0H Max: FFFFH

## 6 Related Parameters

No. (Hex.)	Name	Description	Values
F7-76 (0790) <7> <8>	PZD7 Read	Sets MEMOBUS/Modbus address for PZD7 Read (PPO Read). The value of 0 to 2 disables the PZD7 Read.	Default: 0H Min: 0H Max: FFFFH
F7-77 (0791) <7> <8>	PZD8 Read	Sets MEMOBUS/Modbus address for PZD8 Read (PPO Read). The value of 0 to 2 disables the PZD8 Read.	Default: 0H Min: 0H Max: FFFFH
F7-78 (0792) <7> <8>	PZD9 Read	Sets MEMOBUS/Modbus address for PZD9 Read (PPO Read). The value of 0 to 2 disables the PZD9 Read.	Default: 0H Min: 0H Max: FFFFH
F7-79 (0793) <7> <8>	PZD10 Read	Sets MEMOBUS/Modbus address for PZD10 Read (PPO Read). The value of 0 to 2 disables the PZD10 Read.	Default: 0H Min: 0H Max: FFFFH

- <1> Set b1-02 = 3 to start and stop the drive with the PROFIBUS-DP master device using serial communications. Set b1-01 = 3 to control the frequency reference of the drive via the master device.
- <2> Setting this parameter to 3 or 4 will cause the drive to continue operation after detecting a fault. Take proper measures such as installing an emergency stop switch when using settings 3 or 4.
- <3> Refer to the drive manual to know if settings 4 and 5 are available. Settings 4 and 5 are available in A1000 software versions PRG: 1021 and later.
- <4> The setting range for 1000-Series drives is different for different software versions. Refer to the instruction manual of a specific drive for more information.
- <5> Control method availability of this parameter depends on product series.
  - 1000-Series Drives: Parameter is available in CLV, AOLV/PM, and CLV/PM.
  - In AOLV/PM, this value is read as the Torque Limit.
  - GA700, GA800 Drives: Parameter is available in OLV, CLV, AOLV, AOLV/PM, CLV/PM, and EZOLV.
  - In OLV and EZOLV, this value is read as the Torque Limit.
- <6> The setting specifies that network communications provide the torque reference or torque limit. The motor may not rotate if the PLC does not supply a torque reference or torque limit.
- <7> Available in the A1000 software versions PRG: 1021 and later.
- <8> Available in the option software versions PRG: 2103 and later. Refer to the option package labeling in the field designated "PRG" (four digit number)" or the option labeling in the field designated "C/N" (S + four digit number)" to identify the option software version.
- <9> All node addresses must be unique. Node addresses 0, 1, and 2 are typically reserved for control, maintenance, and diagnostic equipment. The "Err" LED will illuminate when a value of 0 or a value greater than 125 is entered.
- <10> Cycle power for setting changes to take effect.
- <11> Requires also setting bit 0 to 1 to issue Run command. Refer to the option Technical Manual for more information.
- <12> When writing this parameter to the drive through the PROFIBUS-DP network, the parameter is validated by automatically executing the Enter command.

# 7 PROFIBUS-DP Option Data and I/O Maps

---

### ◆ Conventional Formats

The PROFIBUS-DP master configuration tool sets the I/O data length of the option from Extended Data 1 (32 bytes), Extended Data 2 (12 bytes), and Basic Data (6 bytes).

Conventional formats have two message types: High-speed I/O Data and MEMOBUS/Modbus message. Set parameter F6-32 to 1 to use conventional formats.

#### ■ High-Speed I/O Data

High-speed I/O data is directly transferred between the drive and controller or PLC. When the drive is set for PROFIBUS-DP communications, the drive Run/Stop and Frequency Reference commands are transferred within 2 ms after being received by the option.

#### ■ MEMOBUS/Modbus Message

MEMOBUS/Modbus message data is transferred between the drive and controller or PLC using MEMOBUS/Modbus messages. All drive parameters and data can be accessed through MEMOBUS/Modbus. The data in this message type is transferred to the drive after being received and edited by the option and more time is required to return the data to the master. The master must synchronize the timing of sending and receiving the data by a process called handshaking.

### ◆ Memory Maps

The following register maps show the I/O data bytes.

#### ■ Basic and Extended Register Maps

Table 10 Number of Bytes in Basic and Extended Data Messages

	Basic Data (6 bytes)	Extended Data 1 (32 bytes)	Extended Data 2 (12 bytes)
High-speed I/O Data	Bytes 0 to 5	Bytes 0 to 15	Bytes 0 to 3
MEMOBUS/Modbus Data	–	Bytes 16 to 31	Bytes 4 to 11



**Table 11 Basic Data Register Map Detail**

Output (Master Device to Drive)		Input (Drive to Master Device)	
Byte	Description	Byte	Description
0	Operation Command High Byte	0	Drive Status High Byte
1	Operation Command Low Byte	1	Drive Status Low Byte
2	Frequency Reference High Byte	2	Motor Speed High Byte <2>
3	Frequency Reference Low Byte	3	Motor Speed Low Byte <2>
4	Torque Reference/Torque Limit High Byte <1>	4	Output Current High Byte (0.1 A units)
5	Torque Reference/Torque Limit Low Byte <1>	5	Output Current High Byte (0.1 A units)

<1> Control method availability of this parameter depends on product series.

- 1000-Series Drives: Parameter is available in CLV, AOLV/PM, and CLV/PM.

In AOLV/PM, this value is read as the Torque Limit.

- GA700, GA800 Drives: Parameter is available in OLV, CLV, AOLV, AOLV/PM, CLV/PM, and EZOLV.

In OLV and EZOLV, this value is read as the Torque Limit.

<2> Unit depends on the setting of o1-03 (Digital Operator Display Scaling). When the drive is operating in V/f Control or OLV/PM, the drive output frequency becomes the input data.

**Table 12 Extended Data 1 Register Map**

Output (Master Device to Drive)		Input (Drive to Master Device)	
Byte	Description	Byte	Description
0	Operation Command High Byte	0	Drive Status High Byte
1	Operation Command Low Byte	1	Drive Status Low Byte
2	Frequency Reference High Byte	2	Motor Speed High Byte <5>
3	Frequency Reference Low Byte	3	Motor Speed Low Byte <5>
4	Torque Reference High Byte <1>	4	Torque Reference Monitor High Byte <6>
5	Torque Reference Low Byte <1>	5	Torque Reference Monitor Low Byte <6>
6	Torque Compensation High Byte <2>	6	Speed Detection PG Pulse Count 1 High Byte
7	Torque Compensation Low Byte <2>	7	Speed Detection PG Pulse Count 1 Low Byte
8	Reserved	8	Frequency Reference High Byte
9		9	Frequency Reference Low Byte
10	Analog Output Channel 1 High Byte <3>	10	Output Frequency High Byte
11	Analog Output Channel 1 Low Byte <3>	11	Output Frequency Low Byte
12	Analog Output Channel 2 High Byte <3>	12	Output Current High Byte (0.1 A units)
13	Analog Output Channel 2 Low Byte <3>	13	Output Current Low Byte (0.1 A units)
14	Digital Output High Byte <4>	14	Analog Input Channel 1 High Byte
15	Digital Output Low Byte <4>	15	Analog Input Channel 1 Low Byte
16	MEMOBUS/Modbus Function Code	16	MEMOBUS/Modbus Function Code

## 7 PROFIBUS-DP Option Data and I/O Maps

Output (Master Device to Drive)		Input (Drive to Master Device)	
Byte	Description	Byte	Description
17	MEMOBUS/Modbus Starting Register Address High Byte	17	MEMOBUS/Modbus Starting Register Address High Byte
18	MEMOBUS/Modbus Starting Register Address Low Byte	18	MEMOBUS/Modbus Starting Register Address Low Byte
19	MEMOBUS/Modbus Number of Data	19	MEMOBUS/Modbus Number of Data
20	MEMOBUS/Modbus Data 1 High Byte	20	MEMOBUS/Modbus Data 1 High Byte
21	MEMOBUS/Modbus Data 1 Low Byte	21	MEMOBUS/Modbus Data 1 Low Byte
22	MEMOBUS/Modbus Data 2 High Byte	22	MEMOBUS/Modbus Data 2 High Byte
23	MEMOBUS/Modbus Data 2 Low Byte	23	MEMOBUS/Modbus Data 2 Low Byte
24	MEMOBUS/Modbus Data 3 High Byte	24	MEMOBUS/Modbus Data 3 High Byte
25	MEMOBUS/Modbus Data 3 Low Byte	25	MEMOBUS/Modbus Data 3 Low Byte
26	MEMOBUS/Modbus Data 4 High Byte	26	MEMOBUS/Modbus Data 4 High Byte
27	MEMOBUS/Modbus Data 4 Low Byte	27	MEMOBUS/Modbus Data 4 Low Byte
28 to 30	Reserved	28 to 30	Reserved
31	Handshaking Register	31	Handshaking Register

- <1> Control method availability of this parameter depends on product series.
  - 1000-Series Drives: Parameter is available in CLV, AOLV/PM, and CLV/PM. In AOLV/PM, this value is read as the Torque Limit.
  - GA700, GA800 Drives: Parameter is available in OLV, CLV, AOLV, AOLV/PM, CLV/PM, and EZOLV. In OLV and EZOLV, this value is read as the Torque Limit.
- <2> Enabled in CLV, AOLV, AOLV/PM, and CLV/PM control modes (A1-02 = 3, 4, 6, or 7).
- <3> To select drive analog output channel for communications, set parameters as follows:
  - Analog Output Channel 1: H4-01 (Multi-Function Analog Output Terminal FM) = 000 (through-mode)
  - Analog Output Channel 2: H4-04 (Multi-Function Analog Output Terminal AM) = 000 (through-mode)
- <4> Drive digital output ON/OFF during communications, Set H2-01 to H2-04 (Multi-Function Digital Output Function Selection) to F (through-mode). Refer to the instruction manual of a specific drive for more information.
- <5> Unit depends on the setting of o1-03 (Digital Operator Display Scaling). Input data is 0 when the drive is set for V/f Control or OLV/PM.
- <6> Not possible when using V/f control, V/f with PG, or OLV/PM (A1-02 = 0, 1, or 5).

**Table 13 Extended Data 2 Register Map**

Output (Master Device to Drive)		Input (Drive to Master Device)	
Byte	Description	Byte	Description
0	Operation Command High Byte	0	Drive Status High Byte
1	Operation Command Low Byte	1	Drive Status Low Byte
2	Frequency Reference High Byte	2	Motor Speed High Byte <I>
3	Frequency Reference Low Byte	3	Motor Speed Low Byte <I>
4	MEMOBUS/Modbus Function Code	4	MEMOBUS/Modbus Function Code
5	MEMOBUS/Modbus Starting Register Address High Byte	5	MEMOBUS/Modbus Starting Register Address High Byte

## 7 PROFIBUS-DP Option Data and I/O Maps

Output (Master Device to Drive)		Input (Drive to Master Device)	
Byte	Description	Byte	Description
6	MEMOBUS/Modbus Starting Register Address Low Byte	6	MEMOBUS/Modbus Starting Register Address Low Byte
7	MEMOBUS/Modbus Data Length	7	MEMOBUS/Modbus Data Length
8	MEMOBUS/Modbus Data 1 High Byte	8	MEMOBUS/Modbus Data 1 High Byte
9	MEMOBUS/Modbus Data 1 Low Byte	9	MEMOBUS/Modbus Data 1 Low Byte
10	Reserved	10	Reserved
11	Handshaking Register	11	Handshaking Register

<1> Unit depends on the setting of o1-03 (Digital Operator Display Scaling). When the drive is operating in V/f Control or OLV/PM, the drive output frequency becomes the input data.

### ◆ Supported Parameter Process Data Object (PPO) Type Formats

Set drive parameter F6-32 to 0 to use PPO type formats. The PPO is defined for cyclic data transfer, allowing the master and the slave to exchange process data (PZD) and parameters. Refer to the PROFIBUS specification for more information on PPO types 1~5.

The option supports five possible PPO type formats:

- PPO type 1 (8 octets PKW + 4 octets PZD)
- PPO type 2 (8 octets PKW + 12 octets PZD)
- PPO type 3 (4 octets PZD)
- PPO type 4 (12 octets PZD)
- PPO type 5 (8 octets PKW + 20 octets PZD)

All PPO Types have the registers STW, ZSW, HSW, and HIW. These registers are not mapped directly to drive registers.

# 8 Troubleshooting

### ◆ Drive-Side Error Codes

Drive-side error codes appear on the drive keypad. *Table 14* lists causes of the errors and possible corrective actions. Refer to the drive Technical Manual for additional error codes that may appear on the drive keypad.

#### ■ Faults

Both bUS (Option Communication Error) and EF0 (Option Card External Fault from the option) can appear as either an alarm or as a fault. When a fault occurs, the keypad ALM LED remains lit. When an alarm occurs, the keypad ALM LED flashes.

Check the following items first when an error code occurs on the drive:

- Communication cable connections
- Make sure the option is properly installed to the drive
- Operation status of the controller program and controller CPU
- Did a momentary power loss interrupt communications?

**Table 14 Fault Displays, Causes, and Possible Solutions**

Keypad Display		Fault Name
bUS	bUS	Option Communication Error
		<ul style="list-style-type: none"> <li>• After establishing initial communication, the connection was lost.</li> <li>• Only detected when the run command frequency reference is assigned to the option (bl-01 = 3 or bl-02 = 3).</li> </ul>
<b>Cause</b>		<b>Possible Solution</b>
No signal was received from the PLC.		<ul style="list-style-type: none"> <li>• Check for faulty wiring.</li> <li>• Correct any wiring problems.</li> </ul>
Faulty communications wiring		
An existing short circuit or communications disconnection		Check disconnected cables and short circuits and repair as needed.
A data error occurred due to electric interference		<ul style="list-style-type: none"> <li>• Counteract noise in the control circuit, main circuit, and ground wiring.</li> <li>• If a magnetic contactor is identified as a source of noise, install a surge absorber to the contactor coil.</li> <li>• Use only recommended cables or other shielded line. Ground the shield on the controller side or the drive input power side.</li> <li>• Separate all communication wiring from drive power lines. Install an EMC noise filter to the drive power supply input.</li> <li>• Counteract noise in the master controller (PLC).</li> </ul>
The option is not properly connected to the drive.		Reinstall the option.
Option is damaged.		If there are no problems with the wiring and the error continues to occur, replace the option.

Keypad Display		Fault Name
EF0	EF0	Option Card External Fault
		The alarm function for an external device has been triggered.
<b>Cause</b>		<b>Possible Solution</b>
An external fault was received from the PLC.		<ol style="list-style-type: none"> <li>1. Remove the cause of the external fault.</li> <li>2. Reset the external fault input from the PLC.</li> </ol>
Problem with the PLC program.		Check the PLC program.
Keypad Display		Fault Name
oFA00	oFA00	Option Card Connection Error (CN5-A)
		Option is not properly connected.
<b>Cause</b>		<b>Possible Solution</b>
The option card installed into port CN5-A is incompatible with the drive.		Connect the option to the correct option port. Note: Connect the SI-P3 to CN5-A. For other option connections, refer to the Installation Manual for those options.
Keypad Display		Fault Name
oFA01	oFA01	Option Card Fault (CN5-A)
		Option is not properly connected.
<b>Cause</b>		<b>Possible Solution</b>
The option connected to option port CN5-A was changed during run.		De-energize the drive and plug the option into the drive according to <i>Installation Procedure on page 15</i> .
Keypad Display		Fault Name
oFA03, oFA04	oFA03, oFA04	Option Card Error (CN5-A)
		Option Card Error (CN5-A)
<b>Cause</b>		<b>Possible Solutions</b>
A fault occurred in the option card.		<ol style="list-style-type: none"> <li>1. De-energize the drive.</li> <li>2. Make sure that the option card is correctly connected to the connector.</li> <li>3. If the problem continues, replace the option card.</li> </ol>
Keypad Display		Fault Name
oFA30 to oFA43	oFA30 to oFA43	Option Card Connection Error (CN5-A)
		Communication ID error.
<b>Cause</b>		<b>Possible Solution</b>
The option card connection to port CN5-A is faulty.		<ol style="list-style-type: none"> <li>1. Turn off the power.</li> <li>2. Check if the option is properly plugged into the option port.</li> <li>3. Replace the option if the fault continues to occur.</li> </ol>

## 8 Troubleshooting

Keypad Display		Fault Name
oFb00	oFb00	Option Fault (CN5-B)
		Non-compatible option is connected.
<b>Cause</b>		<b>Possible Solution</b>
The option card installed into port CN5-A is incompatible with the drive.		Connect the option to the correct option port. Note: Use connector CN5-B when connecting DO-A3, AO-A3, or two PG options. Use connector CN5-C when connecting only one PG option.
Keypad Display		Fault Name
oFb02	oFb02	Option Fault (CN5-B)
		Two identical options are connected at the same time.
<b>Cause</b>		<b>Possible Solution</b>
An option of the same type is already installed in option port CN5-A, CN5-B, or CN5-C.		Connect the option to the correct option port.
Keypad Display		Fault Name
oFC00	oFC00	Option Fault (CN5-C)
		Non-compatible option is connected.
<b>Cause</b>		<b>Possible Solution</b>
The option card installed into port CN5-C is incompatible with the drive.		Connect the option to the correct option port. Note: AI-A3, DI-A3, and communication options are not supported by option port CN5-C.
Keypad Display		Fault Name
oFC02	oFC02	Option Fault
		Option Flash write mode.
<b>Cause</b>		<b>Possible Solution</b>
An option of the same type is already installed in option port CN5-A, CN5-B, or CN5-C.		Connect the option to the correct option port.

### ■ Minor Faults and Alarms

Keypad Display		Minor Fault Name	
<i>bb</i>	bb	Baseblock	
		Data format and setting contents do not match.	
Cause		Possible Solution	Minor Fault (H2-□□ = 10)
The drive output is disabled. “bb” is displayed on the keypad when the drive is set for control by PROFIBUS-DP, and a conventional data format is used, and the operation command bit F is set to 1, or a PPO type data format is used, and the control word (STW) bit 3 is set to 0.		Set either of the bits depending on the data format used.	No output
External baseblock signal was entered via one of the multi-function input terminals (S1 to S8).		Check external sequence and baseblock signal input timing.	
Keypad Display		Minor Fault Name	
<i>CALL</i>	CALL	Serial communication transmission error	
		Communication is not established.	
Cause		Possible Solution	Minor Fault (H2-□□ = 10)
Communication wiring is faulty.		<ul style="list-style-type: none"> <li>• Check for wiring errors.</li> <li>• Correct the wiring.</li> </ul>	YES
An existing short circuit or communications disconnection		Check disconnected cables and short circuits and repair as needed.	
Programming error on the master side.		Check communications at start-up and correct programming errors.	
Communication circuitry is damaged.		<ul style="list-style-type: none"> <li>• Perform a self-diagnostics check</li> <li>• If the problem continues, replace either the control board or the entire drive. For instructions on replacing the control board, contact Yaskawa or a Yaskawa representative.</li> </ul>	
Termination resistor of the MEMOBUS/Modbus communications is not enabled.		Set DIP switch S2 to the ON position to enable the termination resistor on a drive located at the end of a network line.	

## 8 Troubleshooting

Keypad Display		Alarm Name	
	CyPo	Cycle Power to Active Parameters	
		Comm. Option Parameter Not Upgraded	
Cause		Possible Solution	Minor Fault (H2-□□ = 10)
Although F6-15 = 1 [Comm. Option Parameters Reload = Reload Now], the drive does not update the communication option parameters.		Re-energize the drive to update the communication option parameters. Note: If the option software version is not compatible or if you install an incorrect option to the drive, it will trigger an alarm.	YES



## 9 European Standards



Figure 21 CE Mark

The CE mark indicates compliance with European safety and environmental regulations. It is required for engaging in business and commerce in Europe.

European standards include the Machinery Directive for machine manufacturers, the Low Voltage Directive for electronics manufacturers, and the EMC guidelines for controlling noise.

This option displays the CE mark based on the EMC guidelines.

**EMC Guidelines:** 2014/30/EU

Drives used in combination with this option and devices used in combination with the drive must also be CE certified and display the CE mark. When using drives displaying the CE mark in combination with other devices, it is ultimately the responsibility of the user to ensure compliance with CE standards. Verify that conditions meet European standards after setting up the device.

---

### ◆ EMC Guidelines Compliance

This option is tested according to European standards EN61800-3:2004/A1:2012 and complies with EMC guidelines. The CE marking is declared based on the harmonized standards.

### ■ EMC Guidelines Installation Conditions

Verify the following installation conditions to ensure that other devices and machinery used in combination with this option and drives also comply with EMC guidelines:

1. Use dedicated shield cable for the option and external device (encoder, I/O device, master), or run the wiring through a metal conduit.
2. Keep wiring as short as possible and ground the largest possible surface area of the shield to the metal panel according to [Figure 23](#).




Figure 22 Ground Area

■ Option Installation for CE Compliance: Models PG-□□, DI-□□, DO-□□, AI-□□, AO-□□, SI-□□




Figure 23 Option Installation for CE Compliance (PG-□□, DI-□□, DO-□□, AI-□□, AO-□□, SI-□□)

# 10 Specifications

**Table 15 Option Specifications**

Items	Specifications
<b>Model</b>	SI-P3
<b>PROFIBUS-DP Data</b>	<ul style="list-style-type: none"> <li>• PROFIBUS-DP V0, V1</li> <li>• PPO-TYPE: 1 to 5 (No. 3.072, Profile for Variable Speed Drives)</li> <li>• Extended data 1               <ul style="list-style-type: none"> <li>High-speed I/O data (inputs: 16 bytes, outputs: 16 bytes)</li> <li>MEMOBUS/Modbus message (inputs: 16 bytes, outputs: 16 bytes)</li> </ul> </li> <li>• Extended data 2               <ul style="list-style-type: none"> <li>High-speed I/O data (inputs: 4 bytes, outputs: 4 bytes)</li> <li>MEMOBUS/Modbus message (inputs: 8 bytes, outputs: 8 bytes)</li> </ul> </li> <li>• Basic data               <ul style="list-style-type: none"> <li>High-speed I/O data (inputs: 6 bytes, outputs: 6 bytes)</li> </ul> </li> </ul>
<b>Connector</b>	9-pin D-sub connector (#4/40 UNC thread)
<b>Communications Speed</b>	9.6 kbps to 12 Mbps
<b>Ambient Temperature</b>	-10°C to +50°C (14°F to 122°F)
<b>Humidity</b>	95% RH or lower with no condensation
<b>Storage Temperature</b>	-20°C to +60°C (-4°F to 140°F) allowed for short-term transport of the product
<b>Area of Use</b>	Indoors and free from: <ul style="list-style-type: none"> <li>• Oil mist, corrosive gas, flammable gas, and dust</li> <li>• Radioactive materials or flammable materials, including wood</li> <li>• Harmful gas or fluids</li> <li>• Salt</li> <li>• Direct sunlight</li> <li>• Falling foreign objects</li> </ul>
<b>Altitude</b>	1000 m (3280 ft) or lower

## 10 Specifications

---

### ◆ Revision History

Revision dates and manual numbers appear on the bottom of the back cover.

MANUAL NO.

TOBP C730600 82B <1>

Revision number

Published in Japan October 2016

Date of publication

Date of Publication	Revision Number	Section	Revised Content
November 2018	<5>	All	Addition: Applicable product series Revision: Reviewed and corrected entire documentation.
		Back cover	Revision: Address
July 2018	<4>	–	Address in Japanese version.
July 2017	<3>	Chapter 2	Addition: Note in Table 1
		Back cover	Revision: Address
June 2017	<2>	Back cover	Revision: Address
October 2016	<1>	All	Revision: · Applicable product series · Reviewed and corrected entire documentation.
		Back cover	Revision: Address
April 2016	–	–	First Edition

# YASKAWA AC Drive Option PROFIBUS-DP Installation Manual

---

## **DRIVE CENTER (INVERTER PLANT)**

2-13-1, Nishimiyaichi, Yukuhashi, Fukuoka, 824-8511, Japan  
Phone: +81-930-25-2549 Fax: +81-930-25-3431  
<http://www.yaskawa.co.jp>

## **YASKAWA ELECTRIC CORPORATION**

New Pier Takeshiba South Tower, 1-16-1, Kaigan, Minato-ku, Tokyo, 105-6891, Japan  
Phone: +81-3-5402-4502 Fax: +81-3-5402-4580  
<http://www.yaskawa.co.jp>

## **YASKAWA AMERICA, INC.**

2121, Norman Drive South, Waukegan, IL 60085, U.S.A.  
Phone: +1-800-YASKAWA (927-5292) or +1-847-887-7000 Fax: +1-847-887-7310  
<http://www.yaskawa.com>

## **YASKAWA ELÉTRICO DO BRASIL LTDA.**

777, Avenida Piraporinha, Diadema, São Paulo, 09950-000, Brasil  
Phone: +55-11-3585-1100 Fax: +55-11-3585-1187  
<http://www.yaskawa.com.br>

## **YASKAWA EUROPE GmbH**

Hauptstraße 185, 65760 Eschborn, Germany  
Phone: +49-6196-569-300 Fax: +49-6196-569-398  
<http://www.yaskawa.eu.com> E-mail: [info@yaskawa.eu.com](mailto:info@yaskawa.eu.com)

## **YASKAWA ELECTRIC KOREA CORPORATION**

35F, Three IFC, 10 Gukjegeumjung-ro, Yeongdeungpo-gu, Seoul, 07326, Korea  
Phone: +82-2-784-7944 Fax: +82-2-784-9465  
<http://www.yaskawa.co.kr>

## **YASKAWA ASIA PACIFIC PTE. LTD.**

30A, Kallang Place, #06-01, 339213, Singapore  
Phone: +65-6282-3003 Fax: +65-6289-3003  
<http://www.yaskawa.com.sg>

## **YASKAWA ELECTRIC (THAILAND) CO., LTD.**

59, 1st-5th Floor, Flourish Building, Soi Ratchadapisek 18, Ratchadapisek Road, Huaykwang, Bangkok, 10310, Thailand  
Phone: +66-2-017-0099 Fax: +66-2-017-0799  
<http://www.yaskawa.co.th>

## **YASKAWA ELECTRIC (CHINA) CO., LTD.**

22F Link Square 1, No.222, Hubin Road, Shanghai, 200021, China  
Phone: +86-21-5385-2200 Fax: +86-21-5385-3299  
<http://www.yaskawa.com.cn>

## **YASKAWA ELECTRIC (CHINA) CO., LTD. BEIJING OFFICE**

Room 1011, Tower W3 Oriental Plaza, No. 1, East Chang An Ave.,  
Dong Cheng District, Beijing, 100738, China  
Phone: +86-10-8518-4086 Fax: +86-10-8518-4082

## **YASKAWA ELECTRIC TAIWAN CORPORATION**

12F, No.207, Sec. 3, Beishin Rd., Shindian Dist., New Taipei City 23143, Taiwan  
Phone: +886-2-8913-1333 Fax: +886-2-8913-1513 or +886-2-8913-1519  
<http://www.yaskawa.com.tw>

## **YASKAWA INDIA PRIVATE LIMITED**

#17/A, Electronics City, Hosur Road, Bangalore, 560 100 (Karnataka), India  
Phone: +91-80-4244-1900 Fax: +91-80-4244-1901  
<http://www.yaskawaindia.in>

---

# YASKAWA

**YASKAWA ELECTRIC CORPORATION**

In the event that the end user of this product is to be the military and said product is to be employed in any weapons systems or the manufacture thereof, the export will fall under the relevant regulations as stipulated in the Foreign Exchange and Foreign Trade Regulations. Therefore, be sure to follow all procedures and submit all relevant documentation according to any and all rules, regulations and laws that may apply.

Specifications are subject to change without notice for ongoing product modifications and improvements.

© 2016 YASKAWA ELECTRIC CORPORATION

MANUAL NO.

TOBP C730600 82D <5>-0

Published in Japan November 2018  
18-11-20