



Please dispose of packaging for the product in a responsible manner. It is suitable for recycling. Help to protect the environment, take the packaging to the local amenity tip and place into the appropriate recycling bin.



Never dispose of electrical equipment or batteries in with your domestic waste. If your supplier offers a disposal facility please use it or alternatively use a recognised re-cycling agent. This will allow the recycling of raw materials and help protect the environment.



**machinery specialists since 1968**

## **T800 / T1400 / T1600** **Arc Inverter Welder**



**FOR HELP OR ADVICE ON THIS PRODUCT PLEASE CONTACT YOUR DISTRIBUTOR,  
OR SIP DIRECTLY ON:**

**TEL: 01509500400**

**EMAIL: [sales@sip-group.com](mailto:sales@sip-group.com) or [technical@sip-group.com](mailto:technical@sip-group.com)**

**[www.sip-group.com](http://www.sip-group.com)**

**05703, 05705 & 05707**

**Please read and fully understand the instructions in this manual  
before operation. Keep this manual safe for future reference.**

**Declaration of Conformity**

We

SIP (Industrial Products) Ltd  
Gelders Hall Road  
Shepshed  
Loughborough  
Leicestershire  
LE12 9NH  
England

As the manufacturer's authorised representative within the EC  
declare that the


SIP T800 ARC Inverter Welder - SIP Part. No. 05703  
T1400 ARC Inverter Welder - SIP Part. No. 05705  
T1600ARC Inverter Welder - SIP Part. No. 05707

**Conforms to the requirements of the following directive(s), as indicated.**

2014/35/EU	Low Voltage Directive
2014/30/EU	EMC Directive
2011/65/EU	RoHS Directive

**And the relevant harmonised standard(s), including**

EN 60974-1:2012  
EN 60974-10:2014+A1:2015


Signed:  .....

Mr P. Ippaso - Director - SIP (Industrial Products) Ltd  
Date: 23/07/2017.



# EXPLODED DRAWING / PARTS LIST

T1600 (05707)



Ref. No.	Description	Sip Part No.	Ref. No.	Description	Sip Part No.
1.	Handle	WE07-00051	13.	Chassis	WE07-00063
2.	Cover	WE07-00079	14.	Positive Output Busbar	WE07-00076
3.	EMC Board	WE07-00080	15.	Electrolytic Capacitor	WE07-00081
4.	NTC Resistance	WE07-00054	16.	Fan	WE07-00077
5.	Main Control PCB	WE07-00081	17.	Fan Fixing Plate	WE07-00067
6.	Power Transformer	WE07-00056	18.	Plastic Rear Cover	WE07-00068
7.	Main Transformer	WE07-00075	19.	Main On/Off Switch	WE07-00069
8.	Front Plastic Panel	WE07-00058	20.	Mains Lead	WE07-00082
9.	Potentiometer knob	WE07-00059	21.	Earth Lead c/w Clamp	WE07-00037
10.	Potentiometer	WE07-00060	22.	Welding cable c/w Electrode Holder	WE07-00036
11.	Dinse Socket	WE07-00061	N/A	Front Cover Label	WE07-00083
12.	LED Holder	WE07-00062			

# CONTENTS

Page No.	Description
4.	Safety Symbols Used Throughout This Manual
4.	Safety Instructions
11.	Electrical Connection
13.	Guarantee
13.	Contents and Accessories
14.	Technical Specification
15.	Getting to Know Your Inverter Welder
16.	Operating Instructions
20.	Maintenance
21.	Troubleshooting
22.	Wiring Diagram - T800 (05703)
23.	Wiring Diagram - T1400 (05705) / T1600 (05707)
24.	Exploded Drawing / Parts List T800 (05703)
25.	Exploded Drawing / Parts List T1400 (05705)
26.	Exploded Drawing / Parts List T1600 (05707)
27.	Declaration of Conformity

## SAFETY SYMBOLS USED THROUGHOUT THIS MANUAL



**Danger / Caution:** Indicates risk of personal injury and/or the possibility of damage.



**Warning:** Risk of electrical injury or damage!



**Note:** Supplementary information.

## SAFETY INSTRUCTIONS



**Important:** Please read the following instructions carefully, *failure to do so could lead to serious personal injury and / or damage to the inverter welder.*

When using your inverter welder, basic safety precautions should always be followed to reduce the risk of personal injury and / or damage to the inverter welder.

Read all of these instructions before operating the inverter welder and save this user manual for future reference.

The inverter welder should **not** be modified or used for any application other than that for which it was designed.

This inverter welder was designed to supply electric current for ARC and TIG welding.

If you are unsure of its relative applications do not hesitate to contact us and we will be more than happy to advise you.

Before each use of the inverter welder always check no parts are broken and that no parts are missing.

Always operate the inverter welder safely and correctly.

**KNOW YOUR INVERTER WELDER:** Read and understand the owner's manual and labels affixed to the inverter welder. Learn its applications and limitations, as well as the potential hazards specific to it.


**KEEP WORK AREA CLEAN AND WELL LIT:** Cluttered work benches and dark areas invite accidents. Floors must not be slippery due to oil, water or sawdust etc.

**DO NOT USE THE INVERTER WELDER IN DANGEROUS ENVIRONMENTS:** Do not use the inverter welder in damp or wet locations, or expose it to rain. Provide adequate space surrounding the work area. Do not use in environments with a potentially explosive atmosphere.

**KEEP CHILDREN AND UNTRAINED PERSONNEL AWAY FROM THE WORK AREA:** All visitors

## EXPLODED DRAWING / PARTS LIST


T1400 (05705)



Ref. No.	Description	Sip Part No.	Ref. No.	Description	Sip Part No.
1.	Handle	WE07-00051	13.	Chassis	WE07-00063
2.	Cover	WE07-00072	14.	Positive Output Busbar	WE07-00076
3.	EMC Board	WE07-00073	15.	Electrolytic Capacitor	WE07-00065
4.	NTC Resistance	WE07-00054	16.	Fan	WE07-00077
5.	Main Control PCB	WE07-00074	17.	Fan Fixing Plate	WE07-00067
6.	Power Transformer	WE07-00056	18.	Plastic Rear Cover	WE07-00068
7.	Main Transformer	WE07-00075	19.	Main On/Off Switch	WE07-00069
8.	Front Plastic Panel	WE07-00058	20.	Mains Lead	WE07-00070
9.	Potentiometer knob	WE07-00059	21.	Earth Lead c/w Clamp	WE07-00037
10.	Potentiometer	WE07-00060	22.	Welding cable c/w Electrode Holder	WE07-00036
11.	Dinse Socket	WE07-00061	N/A	Front Cover Sticker	WE07-00078
12.	LED Holder	WE07-00062			

## EXPLODED DRAWING / PARTS LIST

T800 (05703)



Ref. No.	Description	Sip Part No.	Ref. No.	Description	Sip Part No.
1.	Handle	WE07-00051	13.	Chassis	WE07-00063
2.	Cover	WE07-00052	14.	Positive Output Busbar	WE07-00064
3.	EMC Board	WE07-00053	15.	Electrolytic Capacitor	WE07-00065
4.	NTC Resistance	WE07-00054	16.	Fan	WE07-00066
5.	Main Control PCB	WE07-00055	17.	Fan Fixing Plate	WE07-00067
6.	Power Transformer	WE07-00056	18.	Plastic Rear Cover	WE07-00068
7.	Main Transformer	WE07-00057	19.	Main On/Off Switch	WE07-00069
8.	Front Plastic Panel	WE07-00058	20.	Mains Lead	WE07-00070
9.	Potentiometer knob	WE07-00059	21.	Earth Lead c/w Clamp	WE07-00037
10.	Potentiometer	WE07-00060	22.	Welding cable c/w Electrode Holder	WE07-00036
11.	Dinse Socket	WE07-00061	N/A	Front Cover Sticker	WE07-00071
12.	LED Holder	WE07-00062			

## SAFETY INSTRUCTIONS...cont

should be kept at a safe distance from the work area.

**STORE THE INVERTER WELDER SAFELY WHEN NOT IN USE:** The inverter welder should be stored in a dry location and disconnected from the mains supply, and out of the reach of children.

**USE SAFETY CLOTHING / EQUIPMENT:** Use a CE approved welding mask at all times with the correct shade of filter lens. A fume extractor should be used particularly where there is little or no ventilation.

**PROTECT YOURSELF FROM ELECTRIC SHOCK:** When working with the inverter welder, avoid contact with any earthed items (e.g. pipes, radiators, hobs and refrigerators, etc.). It is advisable wherever possible to use an RCD (residual current device) at the mains socket.

**STAY ALERT:** Always watch what you are doing and use common sense. Do not operate the inverter welder when you are tired or under the influence of alcohol or drugs.

**DISCONNECT THE INVERTER WELDER FROM THE MAINS SUPPLY:** When not in use and before servicing.

**AVOID UNINTENTIONAL STRIKING:** Make sure the main switch is in the **Off** position before connecting the inverter welder to the mains supply.

**NEVER LEAVE THE INVERTER WELDER CONNECTED WHILST UNATTENDED:** Turn the inverter welder off and disconnect it from the mains supply between jobs. Do not leave the inverter welder connected to the mains supply if no more welding is to be done.

**DO NOT ABUSE THE MAINS LEAD:** Never attempt to move the inverter welder by the mains lead or pull it to remove the plug from the mains socket. Keep the mains lead away from heat, oil and sharp edges. If the mains lead is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid unwanted hazards. *All* extension cables must be checked at regular intervals and replaced if damaged.

**CHECK FOR DAMAGED PARTS:** Before every use of the inverter welder, any damage found should be carefully checked to determine that it will operate correctly, safely and perform its intended function. Any damaged, split or missing parts that may affect its operation should be correctly repaired or replaced by an authorised service centre unless otherwise indicated in this instruction manual.

**KEEP ALL COVERS / PANELS IN PLACE:** Never operate the inverter welder with any covers / panels removed, this is extremely dangerous.

**MAINTAIN THE INVERTER WELDER WITH CARE:** Keep the earth clamp and electrode holder clean for the best and safest performance.

**USE ONLY RECOMMENDED ACCESSORIES:** Consult this user manual, your distributor or SIP directly for recommended accessories. Follow the instructions that accompany the accessories. The use of improper accessories may cause hazards and will invalidate any warranty you may have.

**SECURE THE WORKPIECE:** Always use welding clamps to secure the workpiece. This frees up both hands to operate the inverter welder correctly.

**DO NOT OVERREACH:** Keep proper footing and balance at all times.

**USE THE RIGHT TOOL:** Do not use the inverter welder to do a job for which it was not

## SAFETY INSTRUCTIONS....cont

designed.

**DO NOT OPERATE THE INVERTER WELDER IN EXPLOSIVE ATMOSPHERES:** Do not use the inverter welder in the presence of flammable liquids, gases, dust or other combustible sources. Inverter welding will create sparks which can ignite the dust or fumes.


**DO NOT EXPOSE THE INVERTER WELDER TO RAIN OR USE IT IN WET CONDITIONS:** Water entering the inverter welder will greatly increase the risk of electric shock.

**HAVE YOUR INVERTER WELDER REPAIRED BY A QUALIFIED PERSON:** The inverter welder is in accordance with the relevant safety requirements. Repairs should only be carried out by qualified persons using original spare parts, otherwise this may result in considerable danger to the user.

- Stop operation immediately if you notice anything abnormal.
- Always disconnect the plug from the mains supply before cleaning or servicing etc.
- Be alert at all times, especially during repetitive, monotonous operations; Don't be lulled into a false sense of security.
- Use of improper accessories may cause damage to the inverter welder and surrounding area as well as increasing the risk of injury.
- **Do not** modify the inverter welder to do tasks other than those intended.
- To avoid injury, the workpiece should never be held with bare hands; The workpiece will become hot during normal welding operations, and stay hot for a period after the weld is complete.
- Appropriate personal protective equipment **must** be worn and **must** be designed to protect against all hazards created. Severe permanent injury can result from using inappropriate or insufficient protective equipment - Eyes in particular are at risk.
- The work should be clamped firmly whilst welding, If its loose it could result in personal injury or damage to the machine or item that is being welded.
- **Do not** attempt any repairs unless you are a competent electrician or engineer.
- Ensure that the machine is connected to the correct supply voltage and protected by a fuse or circuit breaker of the recommend rating.
- **Never** allow the earth clamp and electrode holder to come into contact with each other.

## WIRING DIAGRAM


T1400 (05705) & T1600 (05707)





## WIRING DIAGRAM

T800 (05703)



## SAFETY INSTRUCTIONS...cont

### ELECTRIC SHOCK

- Keep your body and clothing dry. Never work in a damp area without adequate insulation against electrical shock, stay on a dry duck board, or rubber mat when dampness or sweat can not be avoided. Sweat, sea water or moisture between the body and an electrically 'hot' part or grounded metal reduces the body surface electrical resistance enabling dangerous and possibly lethal currents to flow through the body.
- **Never** allow live metal parts to touch bare skin or any wet clothing, be sure welding gloves are dry.
- Before welding, check for continuity; Be sure the earth clamp is connected to the workpiece as close to the welding areas as possible. Grounds connected to building frame work or other remote locations from the welding area reduce efficiency and increase the potential electric shock hazard. Avoid the possibility of the welding current passing through lifting chains, crane cables or various electric paths.
- Frequently inspect leads for wear, splits, cracks and any other damage. **Immediately** replace those with worn or damaged insulation to avoid a possibly lethal shock from bare leads.

### FIRE

- All inflammable materials must be removed from the area.
- Have a suitable fire extinguisher available close by.
- Causes of fire and explosion include; combustibles reached by the arc, flame, flying sparks, hot slag or heated material, misuse of compressed gases and cylinders and short circuits.
- Flying sparks or falling slag can pass through cracks along pipes, through windows or doors and through walls or floor openings and out of sight of the operator. Sparks and slag can fly up-to 10 metres.
- Keep equipment clean and operable; Free of oil, grease and of metallic particles (in electrical parts) that can cause short circuits.
- If combustibles are in the area. **Do not** weld, move the work if practical to an area free of combustibles, avoid paint spray rooms, dip tanks, storage areas and ventilators. If the work can not be moved, then move the combustibles at least 10 metres away and out of the reach of sparks and heat or protect against ignition with suitable and snug fitting, fire resistant covers or shields.
- Walls touching combustibles on opposite sides should not be welded on, walls, ceilings and the floor near the work area should be protected by heat resistant covers or shields.
- Openings (concealed or visible) in floors or walls within 10 metres may expose combustibles to sparks.
- Combustibles adjacent to walls, ceilings, roofs or metal partitions can be igni-

## SAFETY INSTRUCTIONS....cont

- ed by radiant or conducted heat.
- After the work is done, check that the area is free of sparks, glowing embers and flames.
- An empty container that has held combustibles, or that can produce flammable or toxic vapours when heated, must never be welded, unless the container has first been cleaned. Consult HSE INDG214, HSG250 and CS15. HSE document CS15 includes information on cleaning by thorough steam or solvent/caustic cleaning followed by purging and inserting with nitrogen, carbon dioxide or water filling just below working level.
- A container with unknown contents should be treated as if it contained combustibles (see previous paragraph), **Do not** depend on sense of smell or sight to determine if it is safe to weld.
- Hollow items must be vented before welding as they can explode.
- Explosive atmosphere; Never weld when the air may contain flammable dust, gas or liquid vapours (such as petrol).

### GLARE AND BURNS

- The electric welding arc must not be observed with the naked eye. Always use a welding mask; Ensure the welding mask is fitted with the correct shade of filter lens for the welding current level.
- Welding gauntlet gloves should be worn to protect the hands from burns, non-synthetic overalls with buttons at the neck and wrist, or similar clothing should be worn. Greasy overalls should not be worn. Wear suitable protective footwear.
- Always wear correctly rated protective clothing.
- Avoid oily or greasy clothing, a spark may ignite them.
- Hot metal such as electrode stubs and workpieces should never be handled without gloves.
- First aid facilities and a qualified first aid person should be available for each shift unless medical facilities are close by for immediate treatment of flash burns to the eyes and skin.
- Flammable hair products should not be used by persons intending to weld.
- Warn bystanders not to watch the arc and not to expose themselves to the welding-arc rays or to hot metal.
- Keep children away whilst welding, they may not be aware that looking at an arc can cause serious eye damage.
- Protect other nearby personnel from arc rays and hot sparks with a suitable non-flammable partition.

## TROUBLESHOOTING

ARC		
Symptom	Possible Cause	Solution
Alarm light on.	<ul style="list-style-type: none"> <li>Overheated.</li> </ul>	<ul style="list-style-type: none"> <li>Allow the to cool .</li> </ul>
Difficult to strike an arc.	<ul style="list-style-type: none"> <li>Damp electrode.</li> <li>Incorrect electrode.</li> </ul>	<ul style="list-style-type: none"> <li>Warm the electrode or replace.</li> <li>Select the correct size electrode to match the amperage set on the machine.</li> </ul>
Burns through thin metal.	<ul style="list-style-type: none"> <li>Material too thin for arc welding.</li> </ul>	<ul style="list-style-type: none"> <li>Use the TIG function.</li> </ul>

TIG		
Symptom	Possible Cause	Solution
Quality of weld is poor.	<ul style="list-style-type: none"> <li>No gas flow.</li> <li>Incorrect ceramic nozzle.</li> <li>Check condition of tungsten.</li> </ul>	<ul style="list-style-type: none"> <li>Check gas flow and adjust as required.</li> <li>Select correct ceramic nozzle to match tungsten.</li> <li>Re-grind to shape or replace.</li> </ul>
Overheating.	<ul style="list-style-type: none"> <li>Fan problem.</li> <li>Rear casing blocked, obstructing air flow.</li> <li>Poor connection on earth clamp/ electrode holder.</li> <li>Tungsten does not match collet/collet body.</li> </ul>	<ul style="list-style-type: none"> <li>Check fan connections, replace fan.</li> <li>Check and clean.</li> <li>Check and clean all connections.</li> <li>Change collet/collet body to match tungsten.</li> </ul>
Difficult to strike an arc.	<ul style="list-style-type: none"> <li>Tungsten in poor condition</li> </ul>	<ul style="list-style-type: none"> <li>Re-grind to shape or replace.</li> </ul>
Alarm light on.	<ul style="list-style-type: none"> <li>Overheated.</li> </ul>	<ul style="list-style-type: none"> <li>Allow the to cool.</li> </ul>



**Note:** If none of the above solutions work then contact your local distributor for repair, or contact SIP technical for more advise.



## MAINTENANCE

- Clear dust from the machine at regular intervals, if used in a dirty environment the machine should be cleaned once a month.
- Check all connections are clean and tight, if there is any oxidization clean the connection with a mild abrasive or wire brush.
- Check all cables for damage or degradation to the insulation, replace if any is found.
- Check electrode holder and earth clamps condition; Ensure they clamp tightly, replace if damaged or loose.
- If the machine is not to be used for a long time, store it in the original packing and in a dry place.

## SAFETY INSTRUCTIONS...cont

### VENTILATION

- Ventilation must be adequate to remove the smoke and fumes during welding (see the relevant safety standard for acceptable levels).
- Toxic gases may be given off when welding, especially if zinc or cadmium coated materials are involved, welding should be carried out in a well ventilated area and the operator should always be alert to fume build-up.
- Areas with little or no ventilation should always use a fume extractor.
- Vapours of chlorinated solvents can form the toxic gas phosgene when exposed to U.V radiation from an electric arc. All solvents, degreasers and potential sources of these vapours must be removed from the arc area.
- Severe discomfort, illness or death can result from fumes, vapours, heat, oxygen enrichment or depletion that welding (or cutting) may produce. This will be prevented by adequate ventilation or using a fume extractor. **Never** ventilate with oxygen.
- Lead, cadmium, zinc, mercury, beryllium bearing and similar materials when welded may produce harmful concentrations of toxic fumes. Adequate ventilation must be provided for every person in the area. The operator should also wear an air supplied respirator, for beryllium both must be used.
- Metals coated with or containing materials that emit toxic fumes should not be heated unless coating is removed from the work surface. The area should be well ventilated or the operator should wear an air supplied respirator.
- Work in a confined space only while it is being ventilated and if necessary whilst wearing an air supplied respirator.
- Gas leaks in a confined space should be avoided, leaking gas in large quantities can change oxygen concentration dangerously. **Do not** bring gas cylinders into a confined space.
- Leaving a confined space you must shut off the gas supply at the source to prevent possible accumulation of gases in the space if down stream valves are left open. Check to be sure that the space is safe before re entering it.
- Vapours from chlorinated solvents can be decomposed by the heat of the arc (or flame) to form phosgene a highly toxic gas and other lung and eye-irritating products. The ultra violet (radiant) energy of the arc can also decompose trichloroethylene and perchlorethylene vapours to form phosgene. **Do not weld** or cut where solvent vapours can be drawn into the welding atmosphere, or where the radiant energy can penetrate to atmospheres containing even minute amounts of trichloroethylene or perchlorethylene.

## SAFETY INSTRUCTIONS...cont



When using the Inverter welder always ensure the operator as well as those in the area use a welding mask with the correct shade filter lens.



Some metals and metal composites have the potential to be highly toxic; always wear a face mask .



**Caution:** The warnings and cautions mentioned in this user manual can not cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be applied.

## OPERATING INSTRUCTIONS...cont

### PREPARATION FOR WELDING

- Clean the area to be welded, and the earthing point of all rust, paint and contaminants etc.
- Connect the earth clamp dinse plug into the positive dinse socket on the welder.
- Place the earth clamp onto a cleaned area of the workpiece.
- Fit the grounded tungsten into the TIG torch head.
- Connect the TIG torch (not supplied) power connector to the negative dinse socket on the welder.
- Connect the regulator (not supplied) onto the gas bottle.
- Connect the TIG torch gas pipe onto the regulator.
- Check the TIG torch gas valve is closed.
- Turn the regulator on.
- Connect the welder to the electrical supply and switch on.

### WELDING



**Caution:** Ensure all protective equipment is worn and bystanders are not in the vicinity.

- Set the amperage control to match the tungsten size.
- Open the TIG torch gas valve.
- Place a face mask over your face (not supplied).
- Scratch the tungsten on the workpiece, when the arc is created proceed steadily in one direction, maintaining a constant distance between the tip of the tungsten and the workpiece.
- Once all work has been done, switch the machine off and turn the gas off.



**Note:** This is a DC welder and therefore can not be used for aluminium welding.

## OPERATING INSTRUCTIONS...cont

The required tungsten diameter is determined by the thickness of the material to be welded, for each tungsten size there are strict current limits which should be adhered to. Too great a current causes excessive tungsten consumption and weld pool contamination, whilst a too small a current causes arc instability.

The table below gives a guide as to which tungsten is most suitable according to the material thickness. This table is only a guide, and values given are a indication only.

These welding current values are for thorium 2% (red) tungsten electrodes.


Welding Thickness mm	Tungsten Diameter mm	Welding Current Steel	Welding Current Stainless Steel
0.5	1.0	30-60	15-30
1.0	1.6	50-70	50-70
1.5	1.6	90-110	60-90
2.0	1.6	100-130	80-100
3.0	2.4	120-140	100-130
4.0	2.4	150-190	130-170



**Note:** The above is a guide only; always try a short weld test at the setting selected. It is normal to make minor adjustments to achieve the required weld.

### PREPARING THE TUNGSTEN

It is important to choose a tungsten with the correct diameter for the current to be used. The tungsten will normally protrude from the ceramic nozzle by 2 or 3mm, in order to gain access to areas such as internal corners the tungsten can be made to protrude by up to 8mm. The tungsten should be sharpened facing the grinding wheel (see right picture). The tip should be perfectly concentric in order to avoid arc deviations. It is best to regularly inspect the tungsten to maintain peak condition.



## ELECTRICAL CONNECTION

**Warning!** It is the responsibility of the owner and the operator to read, understand and comply with the following:

You must check all electrical products, before use, to ensure that they are safe. You must inspect power cables, plugs, sockets and any other connectors for wear or damage.


You must ensure that the risk of electric shock is minimised by the installation of appropriate safety devices; A residual current circuit Breaker (RCCB) should be incorporated in the main distribution board. We also recommend that a residual current device (RCD) is used. It is particularly important to use an RCD with portable products that are plugged into a supply which is not protected by an RCCB. If in any doubt consult a qualified electrician.

### Connecting to the power supply 05703 & 05705:

These SIP Inverter welders (05703 & 05705) are fitted with a standard 230v ~ 13 amp type plug. Before using the Inverter welder, inspect the mains lead and plug to ensure that neither are damaged. If any damage is visible have the welder inspected / repaired by a suitably qualified person. If it is necessary to replace the plug a heavy duty impact resistant plug would be preferable.

The wires for the plug are coloured in the following way:

Yellow / green	Earth
Blue	Neutral
Brown	Live



As the colours of the wires may not correspond with the markings in your plug, proceed as follows: The wire which is coloured blue, must be connected to the terminal marked with N or coloured black. The wire which is coloured brown, must be connected to the terminal, which is marked L or coloured red. The wire which is coloured yellow / green should be connected to the terminal which is coloured the same or marked



Always secure the wires in the plug terminal carefully and tightly. Secure the cable in the cord grip carefully.

## ELECTRICAL CONNECTION...cont

### Connecting to the power supply 05707:

The 05707 is supplied without a plug fitted, it must not be connected to a standard 13A supply, consult the technical specification table (page 14) for the required rating, if in doubt contact a qualified electrician.



**Warning:** Never connect live or neutral wires to the earth terminal of the plug. Only fit an approved plug with the correct rated fuse. If in doubt consult a qualified electrician.



**Note:** Always make sure the mains supply is of the correct voltage and the correct fuse protection is used. In the event of replacing the fuse always replace the fuse with the same value as the original.



**Note:** Due to the input current required to run the inverter welder, it is advisable not to use an extension lead. No more than 1 welder should be ran from the same ring main for the same reason.



**Note:** If an extension lead is necessary in order to reach the mains supply; The cross section should be checked so that it is of sufficient size so as to reduce the chances of voltage drops. Always fully unwind the lead during use.

## OPERATING INSTRUCTIONS...cont

The amperage control is operated by rotating the knob on the front of the welder; Rotate the knob clockwise to increase the amperage and anticlockwise to reduce the amperage. Once the amperage control is set do a short weld and check for cor-

### PREPARATION FOR WELDING

- Clean the area to be welded, and the earthing point of all rust, paint and contaminants etc.
- Place the earth clamp on to a cleaned area of the workpiece.
- Connect the welder to the electrical supply but do not switch on.

### WELDING



**Caution:** Ensure all protective equipment is worn and bystanders are not in the vicinity.

- Fit the required electrode securely into the electrode holder.
- Switch the welder on.
- Set the amperage control to match your electrode size.
- Place a face mask over your face (not supplied).
- Bring the electrode into contact with the workpiece using a light tapping action and withdrawing to create a gap of 1.5 mm – 3.0 mm.



**Note:** Be aware that the electrode is now live, simply touching any part of the workpiece will create a spark.

- When the arc is created, proceed steadily in one direction keeping the gap between the electrode and the workpiece constant.
- When the weld is complete simply remove the electrode from the workpiece.
- Remove any excess weld / slag with a wire brush / hammer (not supplied).

### TIG WELDING

You will need to purchase the following items in order to TIG weld (not supplied):

• TIG torch (with gas valve) - SIP Part No. 05029	• Regulator	• Tungsten electrode
• Bottle of argon gas	• Filler rod	

## OPERATING INSTRUCTIONS

**Important information:** These units can be set to deliver different output currents at a duty cycle that is written as a percentage on page 14. This percentage represents the welding time in a 10 minute cycle, e.g. 60% means that the welding time is 6 minutes and the rest time is 4 minutes. If a unit is used beyond its duty cycle the temperatures of some components might become too high due to over use; The internal thermal protector will then prevent the unit from operating. Its Intervention is Indicated by the alarm light on the front panel, If this happens leave the machine switched on with the fan running and allow it to cool down. The thermal protector will re-set automatically after a short period of time when the components have cooled you will be able to restart welding.

### ARC WELDING

There are no hard and fast rules by which a particular gauge of electrode is selected, usually this is determined by the type of welding required and the thickness of the workpiece e.g. a butt weld in 1.5mm (1/16") sheet metal can be done by a 1.6mm or 2.0mm electrode, the difference being that the 2.0mm electrode will do the job more quickly.

The table below gives a guide as to which electrode is most suitable according to the material thickness. This table is only a guide, and values given are a indication only.

These welding current values are for the E6013 electrodes, for other types of electrode consult their data sheet.

Electrode Size mm	Material Thickness mm	Welding Current (A)
1.6	1 - 1.6	25 - 40
2.0	1.6 - 2.6	40 - 70
2.5	2.6 - 4.0	60 - 100
3.25	3.0 - 5.0	80 - 130
4.0	5.0 - 7.0	130 - 170



**Note:** The above is a guide only; always try a short weld test at the setting selected. It is normal to make minor adjustments to achieve the required weld.

### AMPERAGE CONTROL

The welder should be set to a specific amperage to match the electrode size (see above table).

## GUARANTEE

These SIP Inverter welders are covered by a 12 month parts and labour warranty covering failure due to manufacturers defects. This does not cover failure due to misuse or operating the inverter welder outside the scope of this manual - any claims deemed to be outside the scope of the warranty may be subject to charges including, but not limited to parts, labour and carriage costs, failure to regularly clean your inverter welder will shorten its working life and reduce performance.

The warranty does not cover consumable items such as electrode holders & clamps, etc.



**Note:** Proof of purchase will be required before any warranty can be honoured.

## CONTENTS AND ACCESSORIES

- Inverter Welder.
- Instruction Manual.
- 1.2m Welding Cable with Electrode Holder.
- 800mm Earth Cable with Earth Clamp.



**Note:** If any of the above are missing or damaged, contact your distributor immediately.

## TECHNICAL SPECIFICATION

Model	05703 T800	05705 T1400	05707 T1600
Input Voltage	230V ~ 50/60Hz	230V ~ 50/60Hz	230V ~ 50/60Hz
Input Current	13 amps	13 amps	16 amps
OCV	68V	68V	68V
Welding Current Range (Amps)	10 - 80	20 - 140	20 - 160
Welding Voltage	20.4v - 23.2V	20.8v - 25.6V	20.8v - 26.4V
Weld Thickness (mild steel)	1.5mm - 4mm	1.5mm - 7mm	1.5mm - 8mm
Duty Cycle	80 amps @ 60%	140 amps @ 20%	160 amps @ 20%
		81 amps @ 60%	92 amps @ 60%
	62 amps @ 100%	63 amps @ 100%	71 amps @ 100%
Power Factor	0.65	0.65	0.65
Efficiency	85%	85%	85%
Insulation Class	H	H	H
Protection	IP21S	IP21S	IP21S
Net Weight	2.8Kg	3.8Kg	3.8Kg



**Note:** Only the T800 and T1400 should be operated from a 13A supply.



**Note:** Operation of the T1600 from a 13A supply could invalidate the warranty and affect performance.

## GETTING TO KNOW YOUR INVERTER WELDER



Ref. No.	Description	Ref. No.	Description
1.	Negative Dinse Socket	6.	Carry Handle
2.	Positive Dinse Socket	7.	On/Off Switch
3.	Amperage control	8.	Mains Lead
4.	Power Indicator	9.	Welding Cable (c/w electrode holder)
5.	Thermal Overload Indicator	10.	Earth Cable (c/w earth clamp)