## SKU:SEN0339 (https://www.dfrobot.com/product-2065.html)




(https://www.dfrobot.com/product-2065.html)

## Introduction

CCS811 Air Quality Sensor can measure the eCO2 (equivalent CO2) and TVOC (Total Volatile Organic Compounds) density. It can be widely used in many applications, such as air quality detection, air purifiers, ventilation system and so on. This CCS811 air quality sensor uses AMS's unique micro-hot plate technology. Compared to conventional gas sensors, this sensor is lower power consumption, heating faster, and smaller. Internally integrated ADCs and MCUs allow data to be collected, calculated, and returned via IIC. The CCS811 supports a concentration alarm, which is triggered when the concentration exceeds the user-set threshold.

The CCS811 air quality sensor supports multiple modes, such as detect in every second, in every 10s, in every one minute, in every 250ms and sleep mode. These modes are optimized for low power consumption during the sensor measurement, so the CCS811 is also suitable for portable applications.



The following table shows the effects of carbon dioxide and TVOC on the human body.


| Carbon Dioxide (PPM) | Effect on Human |  | TVOC Concentration (PPB) | Effect on Human |
|----------------------|-----------------|--|--------------------------|-----------------|
|----------------------|-----------------|--|--------------------------|-----------------|

| <500      | Normal                 | <50      | Normal                            |
|-----------|------------------------|----------|-----------------------------------|
| 500-1000  | A little uncomfortable | 50-750   | Anxious, un comfortable           |
| 1000-2500 | Tired                  | 750-6000 | depressive, headache              |
| 2500-5000 | Unhealthy              | >6000    | headache and other nerve problems |

## Features

- Short warm-up time
- Low power consumption
- High integrated MCUs and ADCs
- IAQ threshold alert


# Specification



- Operating Voltage: 3.3V~5.5V
- Warm-up Time: <15s
- IIC Address: 0x5A (in default) / 0x5B
- Operating Temperature: -40°C~85°C
- Operating Humidity: 0ppb~1100ppb

#### • Dimension: 16\*20mm / 0.63\*0.79 "

## **Board Overview**



| Num | Label | Description |
|-----|-------|-------------|
| 1   | VCC   | +           |

| 2 | GND  | -  |  |
|---|------|--|--|
| 3 | SCL  | IIC clock line                                       |  |
| 4 | SDA  | IIC data line  |  |
| 5 | INT  | Interrupt pin: interrupt in low level                |  |
| 6 | WAKE | Switch pin: awake in low level / sleep in high level |  |
| 7 | RST  | Reset pin: reset in low level                        |  |

## Tutorial

The product warm-up time is short, accurate readings can be made quickly once powered up. The read time can be shorten by setting the environmental baseline (the baseline acquisition and setup method is explained below; for more details about baseline, go to the end of the wikipage to find the related document).

NOTE: Please run the sensor for 48hours when using it for the first time.

## Requirements

- Hardware
  - DFRduino UNO R3 (https://www.dfrobot.com/product-838.html) (or similar) x 1
  - CCS811 Air Quality Sensor x 1

- Jumper wires
- Software
  - Arduino IDE (https://www.arduino.cc/en/Main/Software)
  - Download and install the **CCS811 Library and examples** (https://github.com/DFRobot/DFRobot\_CCS811) (About how to install the library? (https://www.arduino.cc/en/Guide/Libraries#.UxU8mdzF9H0))
- About API Function List

```
/**
* @brief Judge if the data can be read
* @return true when the reading is successful, false means it fails to read.
 */
bool checkDataReady();
  /**
* @brief Set environment parameter
 * @param temperature Input temperature value, unit: centigrade, range (-40 \sim 85^{\circ})
 * @param humidity
                      Input humidity value, unit: RH, range (0~100)
 */
void setInTemHum(float temperature, float humidity);
/**
* @brief Measurement parameter configuration
  @param mode:in typedef enum{
 *
                              //Idle (Measurements are disabled in this mode)
                eClosed,
                             //Constant power mode, IAO measurement every second
                eCvcle 1s,
                eCycle 10s, //Pulse heating mode IAQ measurement every 10 seconds
                eCycle 60s, //Low power pulse heating mode IAQ measurement every 60 seconds
                eCycle 250ms //Constant power mode, sensor measurement every 250ms 1xx: Reserved modes (For future use)
            }eCycle t;
 * @param thresh:0 for Interrupt mode operates normally; 1 for interrupt mode only asserts the nINT signal (driven low) if the new
 * @param interrupt:0 for Interrupt generation is disabled; 1 for the nINT signal is asserted (driven low) when a new sample is re-
 */
setMeasurementMode(eCycle t mode, uint8 t thresh = 0, uint8 t interrupt = 0),
/**
* @brief Get the current carbon dioxide concentration
* @return current carbon dioxide concentration, unit:ppm
```

```
*/
```


\*

\*

\*

```
uintio_t getCU2PPM();
/**
 * @brief Get current TVOC concentration
* @return Return current TVOC concentration, unit: ppb
*/
uint16_t getTVOCPPB();
/**
 *@brief get the current baseline number
 *@return a Hexadecimal number of the current baseline number
*/
uint16_t readBaseLine();
/**
*@brief write a baseline number into register
 *@param a Hexadecimal number get from getBaseLine.ino
 */
void writeBaseLine(uint16_t baseLine);
```

## **Connection Diagram**





## Sample Code

#### 1.Get Baseline

Why should we get the baseline? Because once get it, we can show the air quality quickly after the sensor warm-up by inputting the baseline. Otherwise, it will cost a long time to read correctly when startup in polluted air.

During the first week of running the sensor, it is recommended to save a new baseline every 24 hours. After 1 week of operation, it can be saved every 1-28 days



- Please place it in a fresh air environment (20 minutes or more) to obtain the baseline.
- Different sensors, different measurement cycles have different baselines.

#### /\*!

```
* @file getBaseLine.ino
```

\* @brief Put the module in clear air and work a few minutes, wait for baseline doing not change

```
* @n Experiment phenomenon: get
```

\*

```
* @copyright Copyright (c) 2010 DFRobot Co.Ltd (http://www.dfrobot.com)
```

```
* @licence The MIT License (MIT)
```

```
* @author [LuoYufeng](yufeng.luo@dfrobot.com)
```

```
* @version V0.1
```

```
* @date 2019-07-19
```

```
* @get from https://www.dfrobot.com
```

```
* @url https://github.com/DFRobot/DFRobot_CCS811
```

```
*/
```

```
#include "DFRobot_CCS811.h"
```

```
/*
 * IIC address default 0x5A, the address becomes 0x5B if the ADDR_SEL is soldered.
 */
//DFRobot_CCS811 CCS811(&Wire, /*IIC_ADDRESS=*/0x5A);
DFRobot CCS811 CCS811;
```

```
void setup(void)
```

#### {

```
Serial.begin(115200);
/*Wait for the chip to be initialized completely, and then exit*/
while(CCS811.begin() != 0){
    Serial.println("failed to init chip, please check if the chip connection is fine");
    delay(1000);
}
```

```
void ioop() {
    if(CCS811.checkDataReady() == true){
        /*!
        * @brief Set baseline
        * @return baseline in clear air
        */
        Serial.println(CCS811.readBaseLine(), HEX);
    }
    else {
        Serial.println("Data is not ready!");
    }
    //delay cannot be less than measurement cycle
    delay(1000);
}
```

#### **Expected Results**

After a while, the baseline reaches to a stable value.

#### 2.Get Data

Input the baseline value to the function sensor.writeBaseLine(); If you don't want to set the baseline, please disable this function in the sample program. The sensor will automatically calibrate the baseline, but it would be a pretty long process. after the function uploaded to UNO, open the serial port monitor to check the carbide dioxide concentration and TVOC concentration.

#### /\*!

```
* @file readData.ino
```

```
\ast @brief Read the concentration of carbon dioxide and TVOC
```

```
* @n Experiment phenomenon: read data every 0.5s, and print it out on serial port.
```

```
*
```

```
* @copyright Copyright (c) 2010 DFRobot Co.Ltd (http://www.dfrobot.com)
```

```
* @licence The MIT License (MIT)
```

```
* @author [LuoYufeng](yufeng.luo@dfrobot.com)
```

```
* @version V0.1
```

```
* @date 2019-07-19
```

```
* @get from https://www.dfrobot.com
```

```
* @url https://github.com/DFRobot/DFRobot_CCS811
```

```
*/
```

```
#include "DFRobot_CCS811.h"
```

#### /\*

```
* IIC address default 0x5A, the address becomes 0x5B if the ADDR_SEL is soldered.
*/
//DFRobot_CCS811 CCS811(&Wire, /*IIC_ADDRESS=*/0x5A);
DFRobot CCS811 CCS811;
```

```
void setup(void)
```

```
{
```

```
Serial.begin(115200);
/*Wait for the chip to be initialized completely, and then exit*/
while(CCS811.begin() != 0){
    Serial.println("failed to init chip, please check if the chip connection is fine");
    delay(1000);
  }
}
void loop() {
```

```
C/CCC011 shashDataDaadu/// taua//
```

```
T(USMIL.CNECKDATAKEAGY() == True)
    Serial.print("CO2: ");
    Serial.print(CCS811.getCO2PPM());
    Serial.print("ppm, TVOC: ");
    Serial.print(CCS811.getTV0CPPB());
    Serial.println("ppb");
} else {
    Serial.println("Data is not ready!");
}
/*!
 * @brief Set baseline
* @param get from getBaseline.ino
 */
CCS811.writeBaseLine(0x447B);
//delay cannot be less than measurement cycle
delay(1000);
```

#### **Expected Results**

}

#### **3.Concentration Alarm**

Input the baseline value to the function sensor.writeBaseLine(); Upload it to UNO, when the CO2 concentration moves from the current range (low, medium, high) to another range (more than 50 ppm), an interruption is generated and the current CO2 value will be printed.

# NOTE: This example requires the INT pin of the sensor to be connected to the corresponding interrupt pin on the main board (in the sample, D2 of UNO is selected).

AVR Series Interrupt Pin and Interrupt Number

| 328 Mainboards: Uno, Nano, Mini | Mega2560 | 32u4 Mainboards: Leonardo |  |
|---------------------------------|----------|---------------------------|--|
|                                 |          |                           |  |

| Interrupt Pin    | B28 Mainboards: Uno, Nano, Mini | Mega25601, D20, D19, D18 | BZuDMD0b0arD5: Leonardo |
|------------------|---------------------------------|--------------------------|-------------------------|
| Interrupt Number | 0, 1                            | 0, 1, 2, 3, 4, 5         | 0, 1, 2, 3 ,4           |

/\*! \* @file setInterrupt.ino \* @brief Set interrupt parameter, when CO2 concentration range changes, get an interrupt \* On Experiment phenomenon: read data every 1s, and print it out on serial port. \* Copyright (c) 2010 DFRobot Co.Ltd (http://www.dfrobot.com) \* @copyright \* @licence The MIT License (MIT) \* @author [LuoYufeng](yufeng.luo@dfrobot.com) \* @version V1.0 \* @date 2019-07-13 \* @get from https://www.dfrobot.com \* @url https://github.com/DFRobot/DFRobot Sensor \*/ #include "DFRobot CCS811.h" volatile int8 t GPI01TRIG = 0; /\* \* IIC address default 0x5A, the address becomes 0x5B if the ADDR SEL is soldered. \*/ //DFRobot\_CCS811 CCS811(&Wire, /\*IIC\_ADDRESS=\*/0x5A); DFRobot CCS811 CCS811; void setup(void) { Serial.begin(115200); /\*wait for the chip to be initialized completely, and then exit\*/ while(CCS811.begin() != 0){ Serial.println("failed to init chip, please check if the chip connection is fine"); delay(1000); } -++--bT-+----+/A S-+-----+ BTCTNC)

```
attacninterrupt(0, interrupt, KisiNG);
    /**
     * @brief Measurement parameter configuration
     * @param mode:in typedef enum{
     *
                    eClosed,
                                  //Idle (Measurements are disabled in this mode)
     *
                                  //Constant power mode, IAO measurement every second
                    eCycle 1s,
     *
                    eCycle 10s, //Pulse heating mode IAQ measurement every 10 seconds
     *
                    eCycle 60s, //Low power pulse heating mode IAO measurement every 60 seconds
                    eCycle 250ms //Constant power mode, sensor measurement every 250ms 1xx: Reserved modes (For future use)
     *
                }eCvcle t;
     * @param thresh:0 for Interrupt mode operates normally; 1 for interrupt mode only asserts the nINT signal (driven low) if the new
     * @param interrupt:0 for Interrupt generation is disabled; 1 for the nINT signal is asserted (driven low) when a new sample is re
     */
    CCS811.setMeasurementMode(CCS811.eCvcle 250ms, 1, 1);
    /**
     * @brief Set interrupt thresholds
    * @param lowToMed: interrupt triggered value in range low to middle
     * @param medToHigh: interrupt triggered value in range middle to high
     */
    CCS811.setThresholds(1500,2500);
}
void loop() {
    if(GPI01TRIG == 1){
        Serial.println("CO2 range has changed");
        Serial.print("CO2: ");
        Serial.print(CCS811.getCO2PPM());
        Serial.print("ppm, TVOC: ");
        Serial.print(CCS811.getTV0CPPB());
        Serial.println("ppb");
        delay(1000);
    }
    GPIO1TRIG = 0;
    Serial.print("CO2: ");
    Serial.print(CCS811.getCO2PPM());
    Serial.print("ppm, TVOC: ");
    Serial.print(CCS811.getTV0CPPB());
    Serial.println("ppb");
                   . . . . . . . . . .
```

```
CCS811.writeBaseLine(0x447B);
delay(1000);
}
void interrupt(){
GPI01TRIG = 1;
}
```

#### **Expected Results**

## **More Documents**

- Schematics (https://dfimg.dfrobot.com/nobody/wiki/15e41c6b99c913114e831ce131f2d52f.pdf)
- Dimension (https://dfimg.dfrobot.com/nobody/wiki/5076dd596c399ea39363b0656633b5db.pdf)
- Datasheet (https://dfimg.dfrobot.com/nobody/wiki/7334c560756596ba0cf3f1d2102d19dd.pdf)
- CCS811 Baseline (https://dfimg.dfrobot.com/nobody/wiki/ab83d61ed52c66c2dd4067eed25b0c35.pdf)

Get CCS811 Air Quality Sensor (https://www.dfrobot.com/product-2065.html) from DFRobot Store or DFRobot Distributor. (https://www.dfrobot.com/index.php?route=information/distributorslogo)

Turn to the Top