

multicomp PRO



Digital Oscilloscope & Multimeter Clamp Meter User Manual

MP101

Table of Contents

1. Safety Information	1
General Safety Requirements.....	Error! Bookmark not defined.
Measurement Category	3
Safety Terms and Symbols	4
2. Quick Start	5
General Inspection	5
Battery Replacement	5
Power on/off	6
Selecting the Range	6
3. Instrument Panel.....	7
Front Panel and Keys	7
4. How to Use the Multimeter.....	9
About This Chapter.....	9
Instrument Interface.....	9
Input terminals.....	11
Making Measurements	11
Measuring DC or AC Current.....	11
Measuring AC or DC Voltage.....	13
Measuring Resistance	15
Measuring Continuity.....	16
Measuring Diodes	17
Measuring Capacitance.....	18
Measuring Frequency.....	19
Measuring NCV	20
Multimeter Features.....	21
Setting Scale	21
Setting Range.....	21
Making Max/Min Measurements	22
Making Relative Measurements.....	22
Value Hold Mode	23
5. How to Use the Oscilloscope.....	25
Introduction to the User Interface of the Oscilloscope	25
Measuring System.....	26
Automatic Measurement.....	26
System Settings.....	27
How to use Bluetooth.....	28
6. Technical Specifications.....	30
Multimeter Specification	30
Oscilloscope Specification	32

7. Appendix.....	34
Appendix A: List of Accessories	34
Appendix B: Maintenance and Cleaning	34
General maintenance	34
Charging the Battery.....	Error! Bookmark not defined.

1.Safety Information

(Be sure to read the safety information before using this product.)

General Safety Requirements

Before first use, please read the following safety precautions to avoid

any possible personal injury and prevent this product or any other products connected to it from damage.

- **Limit operation to the specified measurement category, voltage, or amperage ratings.**
- **Do not use the digital clamp meter if it is damaged.** Before you use the digital clamp meter, inspect the case. Look for cracks or missing plastic. Pay particular attention to the insulation surrounding the connectors.
- **Do not use the test leads provided for other products.** Use only the certified test leads specified for this product.
- **Inspect the test leads for damaged insulation or exposed metal.**
- **Before use, verify the digital clamp meter's operation by measuring a known voltage.**
- **No user serviceable parts inside.** Do not disassemble, all servicing must be done by an approved technician.
- **Always use the specified battery type.** The power for the digital clamp meter is supplied with a battery. Observe the correct polarity markings before you insert the batteries to ensure proper insertion of the batteries in the digital clamp meter.
- **Check all Terminal Ratings.** To avoid fire or shock hazard, check all ratings and markings on this product. Refer to the user's manual for more information about ratings before connecting to the digital clamp meter.
- **Do not operate without covers.** Do not operate the instrument with covers or panels removed.
- **Do not operate if in any doubt.** If you suspect damage occurs to the digital clamp meter, have it inspected by qualified service personnel before further operations.
- **Do not operate this product in wet or damp conditions.**
- **Do not operate in an explosive atmosphere.**

-
- **Keep product surfaces clean and dry.**
 - Do not apply more than the rated voltage (as marked on the digital clamp meter) between terminals, or between terminal and earth ground.
 - When measuring current, turn off the circuit power before connecting the digital clamp meter in the circuit. Remember to place the digital clamp meter in series with the circuit.
 - When servicing the digital clamp meter, use only the specified replacement parts.
 - Use caution when working above 60 V DC, 30 V AC RMS, or 42.4 V peak. Such voltages pose a shock hazard.
 - When using the test leads, keep your fingers behind the finger guards on the test leads.
 - Remove the test leads from the digital clamp meter before you open the battery cover.
 - To avoid false readings, which may lead to possible electric shock or personal injury, recharge the battery as soon as the low battery warning indicator appears.
 - Disconnect circuit power and discharge all high-voltage capacitors before testing resistance, continuity, diodes, or capacitance.
 - **Use the proper terminals, function, and range for your measurements.**
When the range of the value to be measured is unknown, set the rotary switch position as the highest range, or choose the auto ranging mode. To avoid damages to the digital clamp meter, do not exceed the maximum limits of the input values shown in the technical specification tables.
 - Connect the common test lead before you connect the live test lead. When you disconnect the leads, disconnect the live test lead first.
 - Before changing functions, disconnect the test leads from the circuit under test.

Measurement Category

The digital clamp meter has a safety rating of 1000 V,CAT III and 600V,CAT IV.

Measurement category definition

Measurement CAT I applies to measurements performed on circuits not directly connected to the AC mains. Examples are measurements on circuits not derived from the AC mains and specially protected (internal) mains-derived circuits.

Measurement CAT II applies to protect against transients from energy-consuming equipment supplied from the fixed installation, such as TVs, PCs, portable tools, and other household circuits.

Measurement CAT III applies to protect against transients in equipment in fixed equipment installations, such as distribution panels, feeders and short branch circuits, and lighting systems in large buildings.

Measurement CAT IV applies to measurements performed at the source of the low-voltage installation. Examples are electricity meters and measurements on primary over current protection devices and ripple control units.

Safety Terms and Symbols

Safety Terms

Terms in this Manual. The following terms may appear in this manual:



Warning: Warning indicates the conditions or practices that could result in personal injury or death.



Caution: Caution indicates the conditions or practices that could result in damage to this product or other property.

Terms on the Product. The following terms may appear on this product:

Danger: It indicates an injury or hazard may immediately happen.

Warning: It indicates an injury or hazard may potentially happen.

Caution: It indicates a potential damage to the instrument or other property might occur.

Safety Symbols

Symbols on the Product. The following symbol may appear on the product:

	Direct current (DC)		Fuse
	Alternating current (AC)		Caution, risk of danger (refer to this manual for specific Warning or Caution information)
	Both direct and alternating current	CAT I	Category I overvoltage protection
	Ground terminal	CAT II	Category II overvoltage protection
	Conforms to European Union directives	CAT III	Category III overvoltage protection
	Equipment protected throughout by double insulation or reinforced insulation	CAT IV	Category IV overvoltage protection

2. Quick Start

General Inspection

After you get a new digital clamp meter, make a check on the instrument according to the following steps:

1. Check whether there is any damage caused by transportation.

If it is found that the outer carton or internal packaging has suffered serious damage, do not dispose of it until the complete device and its accessories have been thoroughly tested.

2. Check the Accessories

Check that all the accessories are intact. If there is any accessory missing or damaged, please get in touch with the Multicomp-pro distributor.

3. Check the Complete Instrument

If it is found that there is damage to the appearance of the instrument, or the instrument does not work normally, or fails in the performance test, please get in touch with the Multicomp-pro distributor.

If there is damage to the instrument caused by the transportation, please keep all the packaging. Please get in touch with the Multicomp-pro distributor to arrange repair or replacement as required.

Battery Replacement

The digital clamp meter is powered by a pre-fitted 3.7V 2600mA (18650) type lithium battery.



Warning: To avoid false readings, which could lead to possible electric shock or personal injury, recharge the battery as soon as the low battery indicator appears using the supplied USB C cable. If the battery is to be replaced, turn off the meter, disconnect test leads and any connectors from any circuit under test, remove test leads from the input terminals. Use only the specified battery type.

Use the following procedure to replace the battery:

- (1) Power off, remove test leads and any connectors from the input terminals.
- (2) Loosen the screw with a suitable Phillips screwdriver and remove the battery cover.


-
- (3) Observe the battery polarity indicated inside the battery compartment, Insert the battery.
 - (4) Place the battery cover back in its original position and tighten the screw.
-




Caution: To avoid instruments being damage from battery leakage, remove the batteries and store them separately if the digital clamp meter is not going to be used for a long period.

Power on/off






It can be turned on in the following ways:

- Press the  button at the bottom left of the host;

It can be turned off in the following ways:

- Manual shutdown, tap and hold  button;
- Automatic shutdown, emit a short beep one minute before shutdown, emit a long beep during shutdown;
- Low power automatic shutdown.

Selecting the Range

- Auto ranging is set as default when the meter is powered on, **Auto** is displayed.
- Under automatic range, press  or  to enter the manual range mode.
- Under manual range, each additional press of  sets the next higher range; each additional press of  sets the next lower range.
- Under manual range, press  to enter the auto range mode.

Note: Manual range is not available when measuring capacitance, only in multimeter measurement mode.

3.Instrument Panel

Front Panel and Keys









The front panel and keys of the digital clamp meter are shown in Figure 3-1:



Figure 3-1: Front panel

Description:

Num	Illustration in multimeter mode	Illustration in oscilloscope mode
1	NCV measurement.	

2	Safety level.	
3	Maximum current allowed to be measured.	
4	Operation indicator light.	
5	Reading hold button, press and hold to perform DCA to zero.	Run/Stop button.
6	Display area.	
7	The F1 - F4 keys are multi-function keys. In each menu mode, press the corresponding key to select the corresponding menu item.	
8	<p>Function of direction keys  : used for changing range.</p> <p>Function of  key: Restore auto gear.</p>	<p>Function of direction keys  : used for the voltage or current scales.</p> <p>Function of direction keys  : used for zooming waveforms and the time base changing.</p> <p>Function of  key: Perform automatic setup.</p>
9	Measurement input port: the input of the measurement signal.	
10	Charging port.	
11	Switch key for working state of oscilloscope and multimeter. Press the power button briefly to turn on the device. After powering on, press briefly to switch to the oscilloscope or multimeter mode. Press and hold to turn off the device.	
12	Tab function switch button.	
13	Clamp head trigger: Press the trigger to open the clamp heads; release the trigger, and the clamp heads will automatically close.	
14	Clamp head: The current measurement sensor converts alternating or direct current into voltage.	


4.How to Use the Multimeter

About This Chapter

This chapter introduces the multimeter function and provides some basic examples of basic operations and how to use the menu.

Instrument Interface

The digital clamp meter uses four 2 safety banana plug input ends:**COM** and



Multimeter interface:




Figure 4-1:Multimeter interface

Description:

1. Measurement type indication:

Measurement type	Description
A, DC	DC current measurement
A, AC	AC current measurement
V, DC, mV ,DC	DC voltage measurement
V, AC, mV, AC	AC voltage measurement

Res	Resistance measurement
Cont	On/Off measurement
Diode	Diode measurement
Cap	Capacitance measurement
Freq	Frequency measurement
NCV	Non-contact AC voltage sensing

2. Range indication: **Manu** means manual range; **Auto** means automatic range.
3. Current measurement range.
4. Automatic shutdown sign: Display the flag when enabled. Closing will hide the identity.
5. Bluetooth sign: Display the flag when enabled. Closing will hide the identity.
6. Battery power and external power supply indication.
7. Inrush mode (Only in ACA mode).
8. Reading hold mode.
9. Current measurement menu.
10. Current measurement unit
11. DC/AC/On-Off/Diode/Capacitance mode.
12. Range simulation strip.
13. Operation menu.

Measurement units

Sign	Description	
M	Mega	1E+06 (1000000)
k	kilo	1E+03 (1000)
m	milli	1E-03 (0.001)
μ	micro	1E-06 (0.000001)
n	nano	1E-09 (0.000000001)

Sign	Description	Measurement type
V	Voltage	Voltage

A	Ampere	Current
Ω	Ohm	Resistance
Hz	Hertz	Frequency
%	Percent	Duty cycle
F	Farad	Capacitance

Input terminals

The terminal connections for the different measurement functions of the digital clamp meter are described in the table below.



Warning: Before starting any measurement, observe the rotary switch position of the digital clamp meter, and then connect the test leads to the correct terminals.



Caution: To avoid damaging the digital clamp meter, do not exceed the rated input limit.

Measurement function	Input terminals	Overload protection
		1000 VAC/1000 VDC
	 COM	250 VAC/300 VDC

Making Measurements

Measuring DC or AC Current



Warning: Do not attempt to measure current if the open-circuit voltage between the live and ground exceeds 250V, as this may damage the digital clamp meter and pose a risk of electric shock or personal injury.




Caution: -

- To avoid damaging the digital clamp meter or the measured device, check the digital clamp meter before measuring current. Ensure the







correct input terminals, function settings, and range are used for the measurement.

- The current measurement function must be operated between 0°C and 40°C. Avoid suddenly releasing the trigger; the Hall effect sensor is sensitive not only to magnetic fields but also to heat and mechanical stress. Impact can temporarily alter readings.
- For accurate measurement, ensure the conductor is positioned at the center of the clamp heads. Positioning outside the center can introduce an additional error of $\pm 1.0\%$ of the reading.


1. Press **F1** to switch DC Current measurement mode, A, **DC** will be displayed in the upper left corner. Then press **F1** to switch into AC Current measurement mode, A, **AC** will be displayed in the upper left corner.
2. Hold the trigger to open the clamp heads. Place the conductor to be measured in the clamp and then slowly release the trigger until the clamp heads are fully closed. Ensure the conductor is centered in the clamp as shown in the diagram. If not centered, additional errors may occur. The clamp meter can measure only one current conductor at a time; measuring two or more conductors simultaneously will result in incorrect readings.



3. Read the display. Press **▲** or **▼** to enable and cycle through the manual ranges. If "OL" is displayed, it indicates the input exceeds.

-
4. In AC current mode, press the  key to switch to the second page of the menu, then press the  key to enable the surge current measurement mode. At this point, start the electrical device to measure its inrush current. Press the  key again to exit this mode.
 5. In AC current mode, press the  key to switch to the second page of the menu. Press the  key again to enable the AC current frequency measurement mode. You can then directly read the frequency of the AC current from the display. Press the  key once more to exit this mode.

Note:






- After testing DC current, especially with large currents, the open-circuit baseline might be high. Perform an AC current test to eliminate residual magnetic signals from the clamp heads.
- If there is residual magnetism, press the  key to select "Zero." This will temporarily subtract the current residual magnetism from the readings. Note that the residual magnetism value will return after restarting the instrument.

Measuring AC or DC Voltage







Warning: Do not measure any voltage of over 1000 Vdc or 1000 Vac rms to avoid instrument damage or electric shock.
Do not apply more than 1000 Vdc or 1000 Vac rms between the common terminal and the earth ground to avoid instrument damage or electric shock.




This digital clamp meter displays DC voltage values as well as their polarity. Negative DC voltages will display a negative sign on the left of the screen.


1. Press  to switch DC voltage measurement mode, *,**DC** will be displayed in the upper left corner (* denotes mV or V). Then press  to switch into AC Voltage measurement mode, *,**AC** will be displayed in the upper left corner (* denotes mV or V). And then press  to switch into mV、V measurement function, press  or  to up and down


measurement scales.

2. Connect the black test lead to the **COM** terminal and the red test lead to the  terminal.
3. Probe the test points and read the display, this is shown in the figure below.
Press  or  to enable and cycle through the manual ranges.



4. In AC voltage mode, press the  key to switch to the second page of the menu. Press the  key again to enable the AC voltage frequency measurement mode. You can then directly read the frequency of the AC voltage from the display. Press the  key once more to exit this mode.

Note: When the measured voltage exceeds 42V DC, the instrument's LCD will display a high voltage warning symbol  and the screen will show a red alert as shown in the image.




Measuring Resistance



Caution: To avoid possible damage to your digital clamp meter or to the equipment under test, disconnect the circuit power and discharge all high-voltage capacitors before measuring resistance.

1. Press **F3** to enter resistance testing mode, **Res** will be displayed in the upper left corner.
2. Connect the black test lead to the **COM** terminal and the red test lead to the **V-Ω** terminal.
3. Probe the test points to measure the resistance in the circuit, as shown in the image.




Measuring Continuity



Caution: To avoid possible damage to your digital clamp meter or to the equipment under test, disconnect the circuit power and discharge all high-voltage capacitors before testing for continuity.

1. Press **F3** to enter continuity testing mode, **Cont** will be displayed in the upper left corner.
2. Connect the black test lead to the **COM** terminal and the red test lead to the **V-Ω** terminal.
3. Probe the test points to measure the resistance in the circuit, as shown in the image. If the reading is below 50 Ω , the digital clamp meter will beep continuously.




Measuring Diodes



Caution: To avoid possible damage to your digital clamp meter or to the equipment under test, disconnect the circuit power and discharge all high-voltage capacitors before testing diodes.

1. Press **F3** to enter diode testing mode, **Diode** will be displayed in the upper left corner.
2. Connect the black test lead to the **COM** terminal and the red test lead to the **Diode** terminal.
3. Connect the red test lead to the positive terminal of the diode and the black test lead to the negative terminal, as shown in the image.




4. Read the diode forward bias. If the test lead connection is reversed, the digital clamp meter will display "OL".

Measuring Capacitance




Caution: To avoid possible damage to the digital clamp meter or to the equipment under test, disconnect circuit power and discharge all high-voltage capacitors before measuring capacitance. Use the DC voltage function to confirm that the capacitor is fully discharged.

1. Press **F4** to enter capacitance testing mode, **Cap** will be displayed in the upper left corner.
2. Connect the black test lead to the **COM** terminal and the red test lead to the **V-Ω** terminal.
3. Probe the test points to measure the capacitance in the circuit, as shown in the image.



Measuring Frequency

1. Press **F4** to enter frequency measurement mode, **Freq** will be displayed in the upper left corner.
2. Connect the black test lead to the **COM** terminal and the red test lead to the **V-Ω** terminal.
3. Probe the test points to measure the frequency in the circuit, as shown in the image.



4. Press **Tab ⇌** to the second page menu and press **F4** to switch between the frequency and duty cycle measurements.


Measuring NCV

1. Press **F4** to enter capacitance testing mode, **NCV** will be displayed in the upper left corner. Bring the front end of the clamp head close to the measured conductor for AC voltage detection.
2. To detect whether there is AC voltage or an electromagnetic field in the area, the LCD will display a dash ("-"). The display will indicate four levels based on the voltage detected: "-", "- -", "- - -", and "- - - -". Additionally, the buzzer will emit a continuous intermittent sound, and the NCV LED will light up. If no voltage is detected, the LCD will display "EF".

3. Press **F2** to switch into DC voltage measurement, press **F2** to switch into mV、V, and then press **▲** or **▼** to up and down measurement scales.
4. Press **F2** to switch into AC voltage measurement, press **F2** to switch into mV、V, and press **Tab ⇌** to the second page menu, then press **F4** to select Hz/V function, and then press **▲** or **▼** to up and down measurement scales.

Making Max/Min Measurements

Press **Tab ⇌** switch into the second page menu and press **F1** to enter Max/Min measurement. When the button is pressed, it will automatically enter the manual gear mode. Press the button again to exit the Maxmin mode and resume the automatic gear mode.




Making Relative Measurements

When making relative measurements, reading is the difference between a stored reference value and the input signal.

1. Press **Tab ⇌** switch into the second page menu and press **F2** to

-
- enter the relative mode, Δ will be shown on the display. The measurement value when pressing **F2** is stored as the reference value. In this mode, $\Delta(\text{current reading}) = \text{input value} - \text{reference value}$.
2. Press it again to exit the mode.




In relative measurement, the manual range mode will be activated automatically (The relative measurement should be carried out under a certain range, that is, this function is only available under the manual range mode.).

Value Hole Mode

The value hold mode keeps the current reading on the display.

1. Press **HOLD** on the right, the current reading will be maintained, **HOLD** will be displayed.
2. Press it again to exit the mode.



5. How to Use the Oscilloscope

Introduction to the User Interface of the Oscilloscope




Figure 5-1: Oscilloscope Interface

Description:

1. Time base display (In the horizontal direction, each grid represents a specific time interval.).
2. Scale (In the vertical direction, each grid represents a specific voltage or current value.)
3. The trigger status indicates the following information:
 - Trig: A trigger has been detected and post trigger information is being collected.
 - Ready: All pre trigger data have been obtained and the oscilloscope is ready.
 - Scan: Continuously collect and display waveform data.
 - Stop: Stop collecting waveform data.
4. Automatic shutdown sign: Displays the flag when enabled. Closing will hide the identity.

-
5. Bluetooth sign: Displays the flag when enabled. Closing will hide the identity.
 6. Battery power and external power supply indication.
 7. Rms value.
 8. Trigger horizontal displacement.
 9. Trigger level position.
 10. Measurement value.
 11. Operation menu.
 12. Waveform display area.
 13. Channel waveforms.
 14. Frequency value.

Measuring System

Automatic Measurement

In oscilloscope mode, it will display automatic measurement value, the screen displays six measurement types in the bottom: Freq, Rms, Max, Min, Vpp and Avg.

The automatic measurement of voltage parameters

The oscilloscopes provide automatic voltage measurements including Avg, Vpp, Rms, Max, Min and Vamp. Figure 5-2 below shows a pulse with some of the voltage measurement points.




Figure 5-2

Avg: The arithmetic mean over the entire waveform.





















Vpp: Peak-to-Peak Voltage.

Rms: The true Root Mean Square voltage over the entire waveform.




Max: The most positive peak voltage measured over the entire waveform.


Min: The most negative peak voltage measured over the entire waveform.

Measurement:

1. Press  to switch into oscilloscope mode.
2. Press  switch into voltage measurement and then press  or  to up and down measurement gear, press  or  can adjust time base gear.
3. Press  switch into current measurement and then press  or  to up and down measurement gear, press  or  can adjust time base gear.
4. Press  switch into current measurement, if there is residual magnetism, press the  key to select "Zero." This will temporarily subtract the current residual magnetism from the readings.
5. Press  or **HOLD** in the right. While in pause mode, press  or  can zoom in or out the waveform.
6. Press  to enter the second page menu, press  to set the trigger is rise or fall and press  or  to up and down the trigger level position.


System Settings

Press  to enter the third page menu. Press  ~  can select the desired function menu.



1. **Brightness setting:** Press  the brightness varies between Low, Mid, and High.
2. **Automatic shutdown setting:** Press  to open or close the function.


When the function is turned on, it will automatically shut down after a specified period of time. However, When the function is turned off, manual shutdown is required.

3. **Theme setting:** Press  to change the display theme.




How to use Bluetooth


- (1) On your mobile device, download the mobile app from the product page (Technical documents) section of the Farnell website.
- (2) Open the installed application on your mobile device.
- (3) Turn on the multimeter, press and hold  until  appear on the display.
- (4) Click on **"Device List"** in the bottom navigation bar.




- (5) Click the "+" icon in the upper left corner to begin searching for devices and list out the multimeters found.




- (6) If the Bluetooth of the mobile device is not enabled, a prompt box will pop up at the bottom, indicating **"Bluetooth is not turned on"**. You need to manually open the Bluetooth of the mobile device before connection can be made.



- (7) Active **"Filter device"** to hide incompatible multimeters.



- (8) After **"BDM"** appears in the list of available devices, click and select to connect it to the mobile device.



Note: When Bluetooth is enabled, the auto power-off function is disabled. After Bluetooth is turned off, the auto power-off function will be restored.

6. Technical Specifications

Standard conditions: The environment temperature is 18°C to 28°C, the relative humidity is less than 80%.

Note:

- When measuring AC voltage, AC current, accuracy guarantee range is 10% to 100% of the range.
- When measuring DC voltage, DC current or capacitance, accuracy guarantee range is 5% to 100% of the range.

Multimeter Specification

Function		Measurement Range	Resolution	Function	
DC Voltage (V)	mV	20.000mV	0.001mV	±（0.1%+20dig）	
		200.00mV	0.01mV	±（0.1%+6dig）	
	V	2.0000V	0.0001V	±（0.1%+5dig）	
		20.000V	0.001V		
		200.00V	0.01V		
		1000.0V	0.1V	±（0.15%+5dig）	
AC Voltage (V)	mV	200.00mV	0.01 mV	VRMS Freq range: 40Hz-1000Hz	±（0.6%+10dig）
	V	2.0000V	0.0001V		
		20.000V	0.001V		
		200.00V	0.01V		
		1000.0V	0.1V		±（0.8%+10dig）
DC Current (A)	A	20.00A	0.01A	±（2.0%+10dig）	
		200.0A	0.1A	±（2.0%+5dig）	
		1000A	1A		
AC Current (A)	A	20.00A	0.01A	VRMS	±（3.0%+10dig）
		200.0A	0.1A	Freq range: 40Hz-1000Hz	±（2.5%+5dig）
		1000A	1A		
Inrush Current(A)	A	20.00A	0.01A	VRMS	± （ 10.0%+10dig ）
		200.0A	0.1A	Freq range: 40Hz-1000Hz	
		1000A	1A		
NCV		Support			
Resistance(Ω)		200.00Ω	0.01Ω	±（0.8%+10dig）	
		2.0000kΩ	0.0001kΩ	±（0.3%+10dig）	
		20.000kΩ	0.001kΩ		
		200.00kΩ	0.01kΩ		

	2.0000MΩ	0.0001MΩ	
	20.000MΩ	0.001MΩ	± (0.5%+5dig)
	100.00MΩ	0.01MΩ	± (5.0%+10dig)
Capacitance(F)	2.000nF	0.001nF	± (5.0%+10dig)
	20.00nF	0.01nF	± (3.0%+10dig)
	200.0nF	0.1nF	
	2.000μF	0.001μF	
	20.00μF	0.01μF	
	200.0μF	0.1μF	
	2000μF	1μF	
	20.00mF ^[1]	0.01mF	
Frequency ^[2](Hz)	200.00Hz	0.01Hz	± (0.1%+5dig)
	2.0000kHz	0.0001kHz	
	20.000kHz	0.001kHz	
	200.00kHz	0.01kHz	
	2.0000MHz	0.0001MHz	
	20.000MHz	0.001MHz	
Duty Cycle ^[3](%)	0.1%-99.9% (Typical: Vrms=1 V, f=100Hz)	0.10%	± (1.2%+3dig)
	0.1%-99.9% (≥1 kHz)		± (2.5%+10dig)
Diode	3.0000V	0.0001V	Open circuit voltage 3.2V
On-Off	0~200.0Ω	0.1Ω	Buzzer limit 50Ω; The measurement value is displayed from 00 to 200.0Ω, and "OL" is displayed if the value exceeds.

[1] When measuring capacitance, for the 20.00mF range, the measuring duration should be over 30 seconds.

[2] When measuring frequency, the typical waveform is Square or Sine. The signal meets the following conditions:

Frequency	Amplitude (rms)
1 Hz – 20 MHz	≥ 1 V

[3] When measuring duty cycle, the typical waveform is Square.

Note: when measuring resistance and capacitance, the influence of the resistance reactance of the pen itself on the measured value should be considered.

Oscilloscope Specification

Characteristics	Instruction
Analog bandwidth	Voltage: 1MHz Current: 1KHz
Sample mode	Real-time sample
Real-time sampling rate	5.0 MSa/s
Channel	1
Input impedance	$\geq 10\text{ M}\Omega$
Maximum input voltage	Maximum peak voltage 1000V
Maximum sample current	Maximum peak current 1000A
Scan speed	2.5 us/div - 10 s/div
Time base accuracy	$\pm(0.01\% + 0.1\text{ div})$
Sensitivity	30 mV/div - 500 V/div
Displacement range	± 3 grid
Sensitivity accuracy	$\pm(5\% + 0.2\text{ div})$
Measurement value	Rms, Freq, Max, Min, PK-PK, Avg
Trigger mode	Auto
Trigger type	Rise、Fall
Bluetooth communication	A smart phone can be used to view the measurement data of the multimeter on the mobile phone side, perform remote control, display data charts, and store the measurement data in CSV format.
Automatic shutdown	When all functions are not used, the meter will automatically shut down in about 10 minutes (the default is 10 minutes of automatic shutdown when starting, which can be canceled)
True effective value	$\sqrt{\quad}$

Display mode	DMM or OSC
Return zero measurement	√
Input protection	√
Digital hold	√
Power	Single section 18650 3.7V 2600mA
Low battery display	When the power is low, there will be a low power window, and wait for a period of time to shut down automatically.
Backlight function	√
LCD Size	2.8 inch
Weight	Approx. 0.35kg
Dimension	248mm (L) x 94.5mm (W) x 37.8mm (D)

Interval Period of Adjustment:

One year is recommended for the calibration interval period.

Note: The signal is within 5dB attenuation with an analog bandwidth of up to 1MHz.

7. Appendix

Appendix A: List of Accessories


- 1 set of probe leads
- 1 quick guide
- 1 USB-TYPE C cable



USB Cable



Quick Guide



Multimeter
Leads

Appendix B: Maintenance and Cleaning

General maintenance

Do not store or place the instrument in a place where the LCD screen will be exposed to direct sunlight for long periods.

Caution: Do not let spray, liquid or solvent touch the instrument or probe to prevent damage to the instrument or probe.

Cleaning:

Check the instrument and probe frequently according to the operation. Clean the external surface of the instrument as follows:

1. Wipe any dust outside the instrument and probe with a soft cloth. When cleaning the LCD, be careful not to scratch the transparent LCD display screen.

2. Wipe the instrument with a moist soft cloth. Please disconnect the power supply. Stubborn marks can be removed using a mild detergent. Do not use any abrasive chemical cleaning agent to avoid damaging the instrument or probe.



Warning: Please make sure the instrument is dry before re-energizing to avoid electrical short circuit or personal injury caused by moisture.

Charging the Battery

During the long-term storage of the device, the battery may be discharged due to the self-discharge of the lithium battery and the device cannot be turned on. This is a normal phenomenon.

Please use the included USB cable to pre-charge the device for 0.5 to 1 hour (depending on the storage time) before turning it on. In addition, if the device is not used for a long time, it is recommended to charge it at regular intervals to avoid over-discharge of the lithium battery.

Battery Charging

The lithium battery may not be fully charged when delivered. To fully charge may take up to 8 hours resulting in a peak discharge battery life of about 18.5 hours. The power supply and battery indicator symbols in the upper right corner of the screen are explained as follows:



symbol indicates the power-on charging status;



symbol indicates battery power charge rating;



symbol indicates that there is only about five minutes of use time left.

Please charge as soon as possible when this low battery warning displays to avoid damage to the battery.

Charging Method

Connect the digital clamp meter to a suitable USB power source through a USB charge cable for charging (pay attention to the load capacity of the power supply equipment to avoid possible damage).

Note

To avoid overheating of the battery during charging, the ambient temperature must not exceed the allowable value given in the technical specifications.



INFORMATION ON WASTE DISPOSAL FOR CONSUMERS OF ELECTRICAL & ELECTRONIC EQUIPMENT.

When this product has reached the end of its life it must be treated as Waste Electrical & Electronic Equipment (WEEE). Any WEEE marked products must not be mixed with general household waste, but kept separate for the treatment, recovery and recycling of the materials used. Contact your local authority for details of recycling schemes in your area.



Made in China
150 Armley Road, Leeds, LS12 2QQ (UK)
Riverside One, Sir John Rogerson Quay, Dublin 2, D02 X576 (EU)