

# USB BitJetLite Download Cable

---

## User Guide



**System Level Solutions, Inc. (USA)**  
14100 Murphy Avenue  
San Martin, CA 95046  
(408) 852 - 0067

<http://www.slscorp.com>

Product Version: 1.0  
Document Version: 1.0  
Document Date: August 2010

---

Copyright©2010, System Level Solutions. All rights reserved. SLS, An Embedded systems company, the stylized SLS logo, specific device designations, and all other words and logos that are identified as trademarks and/or service marks are, unless noted otherwise, the trademarks and service marks of SLS in India and other countries. All other products or service names are the property of their respective holders. SLS products are protected under numerous U.S. and foreign patents and pending applications, mask working rights, and copyrights. SLS warrants performance of its semiconductor products to current specifications in accordance with SLS is standard warranty, but reserves the right to make changes to any products and services at any time without notice. SLS assumes no responsibility or liability arising out of the application or use of any information, products, or service described herein except as expressly agreed to in writing by SLS. SLS customers are advised to obtain the latest version of specifications before relying on any published information and before orders for products or services.

ug\_dc\_ubjl\_1.0



# About this Guide

## Introduction

This document familiarizes you with the contents of the USB BitJetLite Download Cable that allows to configure the Altera FPGA.

Table below shows the revision history of this document.

Version	Date	Description
1.0	August 2010	First Publication





## How to Contact SLS

For the most up-to-date information about SLS products, go to the SLS worldwide website at <http://www.slscorp.com>. For additional information about SLS products, consult the source shown below.

Information Type	E-mail
Product literature services, SLS literature services, Non-technical customer services, Technical support.	<a href="mailto:support@slscorp.com">support@slscorp.com</a>

# Typographic Conventions

The document uses the typographic conventions shown as below.

Visual Cue	Meaning
Bold Type with Initial Capital Letters	All Headings and Sub Headings Titles in a document are displayed in bold type with initial capital letters; Example: <b>Introduction, Hardware Setup, Software Setup</b>
Bold Type with Italic Letters	All Definitions, Figure and Table Headings are displayed in Italics. Examples: <b>Figure 1. USB BitJetLite Download Cable</b>
1. 2.	Numbered steps are used in a list of items, when the sequence of items is important. such as steps listed in procedure.
• ■	Bullets are used in a list of items when the sequence of items is not important.
	The hand points to information that requires special attention.
	The caution indicates required information that needs special consideration and understanding and should be read prior to starting or continuing with the procedure or process.
	The warning indicates information that should be read prior to starting or continuing the procedure or processes.
	The feet direct you to more information on a particular topic.



# Contents

---

<i>About this Guide</i> .....	<i>iii</i>
Introduction .....	iii
How to Contact SLS .....	iii
Typographic Conventions .....	iv
<b>1. Introduction</b> .....	<b>1</b>
Device Support .....	1
Power Requirements .....	1
Software Requirements .....	1
<b>2. USB BitJetLite Hardware and Software Setup</b> .....	<b>3</b>
Hardware Setup .....	3
Software Setup .....	4
Installing USB BitJetLite Driver on Windows XP systems .....	5
Installing USB BitJetLite Driver on Windows Vista System .....	9
Installing USB BitJetLite Driver on Windows 7 Systems .....	14
Setting up the USB BitJetLite hardware in the Quartus II software .....	20
<b>3. USB BitJetLite Download Cable Specifications</b> .....	<b>23</b>
USB BitJetLite Connections .....	23
Voltage Requirements .....	23
USB BitJetLite Plug Connection .....	24
Circuit Board Header Connection .....	25
Operating Conditions .....	26
LED Indication .....	27

The USB BitJetLite interfaces a USB port on a host computer to an Altera® FPGA mounted on a printed circuit board. The cable sends configuration data from the PC to a standard 10-pin header connected to the FPGA. You can use the USB BitJetLite to iteratively download configuration data to a system during prototyping or to program data into the system during production.

## Device Support

The USB BitJetLite download cable allows you to program and configure Altera devices. Specifically, you can do the followings:

- Download configuration data to FPGA devices:
  - Stratix® series FPGAs
  - Cyclone® series FPGAs
  - MAX® series CPLDs
  - Arria® series FPGAs
- In-system programming of the following devices:
  - Serial configuration devices including EPCS1, EPCS4, EPCS16, EPCS64 and EPCS128 devices.
- Perform SignalTap® II logic analysis

USB BitJetLite supports target systems using 3.3 V LVTTTL/LVCMOS and single-ended I/O standards from 1.5 V to 3.3 V.

## Power Requirements

The USB BitJetLite download cable requires the following power sources:

- 5.0 V from the USB cable
- Between 1.5 V and 3.3 V from the target circuit board

## Software Requirements

The USB BitJetLite is available for Windows XP (32-bit and 64-bit) with service pack 2, Windows Vista (32-bit and 64-bit) and Windows 7 (32-bit and 64-bit) systems.



Use the Quartus® II software version 7.2 or later to configure your device.

The USB BitJetLite download cable also supports the following:

- Quartus II Programmer (for programming and configuration)
- Quartus II SignalTap<sup>®</sup> II Logic Analyzer (for logic analysis)
- Quartus II Programmer (standalone version)
- Quartus II SignalTap II logic analyzer (standalone version)



Quartus II v8.1 service pack 1.0 is required to be installed in Quartus II v8.1.



® indicates registered mark of Altera products only.

## 2. USB BitJetLite Hardware and Software Setup

### Hardware Setup

This section describes how to install and set up the USB BitJetLite download cable for device configuration or programming.




For plug and header dimensions, pin names, and operating conditions, see [Chapter 3, “USB BitJetLite Download Cable Specifications”](#).

Connect your USB BitJetLite download cable to the circuit board as instructed below.

1. Disconnect the power cable from the circuit board.
2. Connect the USB cable to the USB port on your PC and to the USB BitJetLite port.
3. Connect the USB BitJetLite download cable to the 10-pin header on the device board. [Figure 2-1.](#) shows the USB BitJetLite download cable and the circuit board connector.



Figure 2-1. USB BitJetLite Download Cable



To avoid damaging the USB BitJetLite cable, first unplug the cable from the 10-pin header on the target board before unplugging the cable from the USB port on your PC. It is safest to remove power first from the target board before unplugging the USB BitJetLite cable.

4. Reconnect the power cable to apply power to the circuit board.

## Software Setup

This section describes the following:

- Installing USB BitJetLite Driver on Windows XP systems
- Installing USB BitJetLite Driver on Windows Vista systems
- Installing USB BitJetLite Driver on Windows 7 systems
- Settings up USB BitJetLite hardware in Quartus II software

Before you begin the installation, verify that the USB BitJetLite drivers are located in `<USB BitJetLite Installation Path>\Drivers` directory.

## Installing USB BitJetLite Driver on Windows XP systems

This section describes how to install the USB BitJetLite drivers on Windows XP 32/64-Bit systems.

To install the driver, follow the directions below:


1. Plug in the USB BitJetLite download cable to the PC.
2. On the **Found New Hardware Wizard** window, click **Yes, this time only** and then click **Next** to continue. See [Figure 2-2](#).

*Figure 2-2. Found New Hardware Wizard (1)*




3. Select **Install from a list or specific location (Advanced)** and click **Next** to continue. See [Figure 2-3](#).

Figure 2-3. Found New Window Wizard (2)




4. Select **Don't search. I will choose the driver to install.** Click **Next**. See [Figure 2-4](#).

Figure 2-4. Choosing Installation Option Window




5. Select **Universal Serial Bus controllers** and click **Next** to continue. See [Figure 2-5](#).

*Figure 2-5. Hardware type Window*



6. Click on **Have Disk** button and browse to the location your `<USB BitJetLite Installation Path>\Drivers\{x32|x64}` of the driver. Click **OK**. See [Figure 2-6](#).

*Figure 2-6. Install From Disk Window*



7. Select **SLS USB BitJetLite** and click **Next** to continue. See [Figure 2-7](#).

Figure 2-7. Device Driver Selection Window



8. It will install the driver for the download cable. On successful driver installation you will see the windows as shown in Figure 2-8.

Figure 2-8. Finish Installation



9. Click **Finish** to exit the New Hardware Installation Wizard.


## Installing USB BitJetLite Driver on Windows Vista System

This section describes how to install the USB BitJetLite driver on Windows Vista systems.

To install the driver, follow the directions below:


1. Plug in the USB BitJetLite download cable to the PC.
2. On the **Found New Hardware Wizard** window, click **Locate and install driver software** to continue. See [Figure 2-9](#).

*Figure 2-9. Choosing Installation Option (1)*




3. Click on **I don't have the disk. Show me other options** to continue. See [Figure 2-10](#).

*Figure 2-10. Choosing Installation Option (2)*



- 
4. Click on **Browse my computer for driver software** to continue. See [Figure 2-11](#).


Figure 2-11. Choosing Installation Option (3)




5. Select on **Browse** and browse to the location *<USB BitJetLite Installation Path>\Drivers\{x32|x64}* of the driver. Click **OK**. See [Figure 2-12](#).




*Figure 2-12. Browsing Driver Installation Directory*



6. Click **Next** to install the driver. See [Figure 2-13](#).


*Figure 2-13. Driver Installation Directory Selection*

7. Windows security dialog box pop up. Check on "**Always trust software from "System Level Solutions, Inc."**" and click **Install**. See [Figure 2-14](#).

*Figure 2-14. Windows Security Dialog Box*

8. Click on **Close** to exit Hardware Installation Wizard. See [Figure 2-15](#).

*Figure 2-15. Finish Installation*




---

## Installing USB BitJetLite Driver on Windows 7 Systems


This section describes how to install the USB BitJetLite driver on Windows 7 systems.

To install the driver, follow the directions below:

1. Plug in the USB BitJetLite download cable to the PC.
2. Right click on **My Computer**. Select **Manage** option. See [Figure 2-16](#).


*Figure 2-16. Device Manager Selection*

3. Select **Device Manage**. It will list all drivers of all devices. See [Figure 2-17](#).


*Figure 2-17. Device Manager Window*

4. Expand **Other devices** option. Right click on **USB BitJetLite** and Select on **Update Driver Software...** option. See [Figure 2-18](#).

*Figure 2-18. Update Driver Software Selection*




5. On the Update Driver Software wizard, select **Browse my computer for driver software**. See [Figure 2-19](#).


*Figure 2-19. Update Driver Software Wizard*

6. Click on **Browse** and browse to the location *<USB BitJetLite Installation Path>\Drivers\{x32|x64}* of the driver. Click **OK**. See [Figure 2-20](#).


*Figure 2-20. Browsing Driver Installation Directory*



7. Click **Next** to install the driver. See [Figure 2-21](#).

*Figure 2-21. Driver Installation Directory Selection*


8. Windows security dialog box pop up. Check on "**Always trust software from "System Level Solutions, Inc."** and click **Install**. See [Figure 2-22](#).

*Figure 2-22. Windows Security Dialog Box*

9. Click on **Close** to exit Update Driver Software Wizard. See [Figure 2-23](#).



*Figure 2-23. Finish Installation*




---

## Setting up the USB BitJetLite hardware in the Quartus II software

Use the following steps to set up the USB BitJetLite hardware in the Quartus II software:

1. Start the Quartus II software.
2. Choose **Tools>Programmer**.
3. Click on **Hardware Setup**. The Hardware Setup dialog box is displayed. See [Figure 2-24](#).

Figure 2-24. Hardware Setup



4. From the drop-down menu, select **USB-BitJetLite [USB-0]**. See [Figure 2-24](#).
5. Click **Close** to close Hardware Setup dialog box.
6. In the Mode list, select the desired mode to program in Programmer Window. [Table 2-1](#) describes each mode.



The USB BitJetLite supports the Joint Test Action Group (JTAG), Passive Serial Programming and Active Serial modes.

Table 2-1. Programming Modes

Mode	Mode Description
Joint Test Action Group (JTAG)	Programs or configures all Altera devices supported by Quartus II software, excluding FLEX 6000.
In-Socket Programming	Not supported by USB-BitJetLite
Passive Serial Programming	Configures all Altera devices supported by Quartus II software excluding MAX 3000 and MAX 7000 devices.
Active Serial Programming	Programs a single EPCS1, EPCS4, EPCS16 and EPCS64 serial configuration device.



For more information about programming devices and creating secondary programming files, refer to *Programming & Configuration* chapter of the [Introduction to Quartus II Manual](#).



### 3. USB BitJetLite Download Cable Specifications

#### USB BitJetLite Connections

The USB BitJetLite cable has a USB universal plug that connects to the PC USB port and a 10-pin female plug that connects to the circuit board. Data is downloaded from the USB port on the PC through the USB BitJetLite cable to the circuit board via the connections discussed in this section.

#### Voltage Requirements

The USB BitJetLite VCC (TRGT) pin must be connected to a specific voltage for the device being programmed. It supports maximum VCC (TRGT) of 3.3 V. Connect pull-up resistors to the same power supply as the USB BitJetLite V<sub>CC(TRGT)</sub>. See [Table 3-1](#).


*Table 3-1. Typical USB BitJetLite V<sub>CC(TRGT)</sub> Pin Voltage Requirements*

Device Family	USB BitJetLite V <sub>CC</sub> Voltage Required
MAX <sup>®</sup> II devices	As specified by V <sub>CCIO</sub> of Bank 1
MAX 7000AE and MAX 3000A devices	3.3 V
MAX 7000B devices	2.5 V
Cyclone and Cyclone II devices	As specified by V <sub>CCIO</sub>
Cyclone III devices	As specified by V <sub>CCA</sub> or V <sub>CCIO</sub>
Cyclone <sup>®</sup> IV devices	V <sub>CCA</sub>
Stratix devices	As specified by V <sub>CCSEL</sub>
Stratix II, Stratix III, Stratix <sup>®</sup> IV, Arria <sup>™</sup> II GX and Arria GX devices	V <sub>CCPD</sub>
EPC2 devices	3.3 V
EPC4, EPC8 and EPC16 devices	3.3 V
EPCS1, EPCS4, EPCS16, EPCS64 and EPCS128 devices	3.3 V

## USB BitJetLite Plug Connection

The 10-pin female plug connects to a 10-pin male header on the circuit board containing the target device. [Figure 3-1](#). shows the dimension of the female plug.

*Figure 3-1. USB BitJetLite 10 Pin Female Plug Dimension*



Dimensions are shown in inches. Spacing between pin centers is 0.1 inches.

[Table 3-2](#). identifies the 10-pin female plug pin names and the corresponding programming mode.

Pin	AS Mode		PS Mode		JTAG Mode	
1	DCLK	Clock signal	DCLK	Clock signal	TCK	Clock signal
2	GND	Signal ground	GND	Signal ground	GND	Signal ground
3	CONF_DONE	Configuration done	CONF_DONE	Configuration done	TDO	Data from device
4	VCC (TRGT)	Target power supply	VCC (TRGT)	Target power supply	VCC (TRGT)	Target power supply
5	nCONFIG	Configuration control	nCONFIG	Configuration control	TMS	JTAG state machine

*Table 3-2. USB BitJetLite Female Plug Signal Names & Programming Modes*

Pin	AS Mode		PS Mode		JTAG Mode	
6	nCE	Cyclone chip enable	—	No connect	—	No connect
7	DATAOUT	Active serial data out	nSTATUS	Configuration status	—	No connect
8	nCS	Serial configuration device chip select	—	No connect	—	No connect
9	ASDI	Active serial data in	DATA0	Data to device	TDI	Data to device
10	GND	Signal ground	GND	Signal ground	GND	Signal ground



The circuit board must supply  $V_{CC(TRGT)}$  and ground to the USB BitJetLite cable for the I/O drivers.


## Circuit Board Header Connection

The circuit board's 10-pin male header, which connects to the USB BitJetLite cable's 10-pin female plug, has two rows of five pins. These pins are connected to the device's programming or configuration pins. [Figure 3-2](#) shows the dimensions of a typical 10-pin male header.



Although a 10-pin surface mount header can be used for the JTAG, AS or PS download cable, Altera recommends using a through-hole connector because of the repeated insertion and removal force needed.

**Figure 3-2. 10 Pin Male Header Dimensions**



## Operating Conditions

Table 3-3. and Table 3-4. summarize the maximum ratings, recommended operating conditions and DC operating conditions for the USB BitJetLite cable.

Symbol	Parameter	Conditions	Min	Max	Unit
$V_{CC(TRGT)}$	Target supply voltage	With respect to ground	-0.3	4.6	V
$V_{CC(USB)}$	USB supply voltage	With respect to ground	-0.3	6.0	V
$I_I$	Input current	TDO or dataout	-10.0	10.0	mA
$I_O$	Output current	TCK, TMS, TDI, nCS, nCE	-50.0	50.0	mA


Symbol	Parameter	Conditions	Min	Max	Unit
$V_{CC(TRGT)}$	Target supply voltage, 3.3 V operation	—	3.0	3.6	V
	Target supply voltage, 2.5 V operation	—	2.375	2.625	V
	Target supply voltage, 1.8 V operation	—	1.72	1.89	V
	Target supply voltage, 1.5 V operation	—	1.43	1.57	V

## LED Indication

The USB BitJetLite is having LED for the power and process status indication. The LED on the USB connector side is used for power indication and LED on 10x2 connector side is used for process status indication.

[Figure 3-3.](#) shows the Power LED and Status LED on the USB BitJetLite.

*Figure 3-3. USB BitJetLite LED Indication*



While programming the device the Status LED will continuously blink and as the process gets completed, it becomes OFF. The power LED will remain ON until the USB cable is connected to the hardware.