

SMART TWEEZERS™ Colibri™




DISCHARGE CAPACITOR BEFORE MEASUREMENTS


Measuring with Colibri

- Press button twice to turn LCR meter on.
- The device powers off automatically if it not operational for 60 seconds.
- To change **test frequency** press button.
- To change **measurement function** press key and hold it for 2 seconds
- To charge the device use a standard Micro USB charger or a computer

Menu Structure



SMART TWEEZERS™ Colibri™



Measurement functions:

AM - autoidentification of L, C or R

L - inductance + resistance

C - capacitance + resistance

ESR - equivalent series resistance

Test frequency:

AF - auto selection of the optimal test frequency

Or 100Hz, 1kHz, 10kHz

Specifications

Test frequency: 100Hz, 1kHz, 10kHz

Test signal: 0.45Vrms, CW

Basic accuracy*: Resistors 0.5% (1% Rx<10Ω ; 0.5% 10Ω<Rx<5MΩ ; 1% Rx>5MΩ)

Capacitors** 1% (5% Cx<10pF ; 1% 10pF<Cx<5000uF ; 5% Cx>5000uF)

Inductance 1% (5% Lx<10uH ; 1% 10uH<Lx<500mH ; 5% LX>500mH)

Battery life: up to 20hours of continuous operation

Charge time: up to 3hours, DC 5V, 50mA

Physical specification: Dimensions 148x20x15 mm, Weight 29g, Operating temperature 0 - 50C

* optimal test frequency, offset subtracted from the result. Typical offset for resistance - 0.035 Ohm, for capacitance - 0.3pF

** capacitors with Cx<5pF can be measured only with manual settings.