



PNOZ m EF 16DI

PILZ
THE SPIRIT OF SAFETY

- ▶ Configurable control systems PNOZmulti 2

This document is a translation of the original document.

All rights to this documentation are reserved by Pilz GmbH & Co. KG. Copies may be made for internal purposes. Suggestions and comments for improving this documentation will be gratefully received.

Pilz®, PIT®, PMI®, PNOZ®, Primo®, PSEN®, PSS®, PVIS®, SafetyBUS p®, SafetyEYE®, SafetyNET p®, the spirit of safety® are registered and protected trademarks of Pilz GmbH & Co. KG in some countries.



SD means Secure Digital

| | | |
|------------------|---|-----------|
| Section 1 | Introduction | 4 |
| | 1.1 Validity of documentation | 4 |
| | 1.2 Using the documentation | 4 |
| | 1.3 Definition of symbols | 4 |
| Section 2 | Overview | 6 |
| | 2.1 Scope of supply | 6 |
| | 2.2 Unit features | 6 |
| | 2.3 Front view | 7 |
| Section 3 | Safety | 8 |
| | 3.1 Intended use | 8 |
| | 3.2 System requirements | 8 |
| | 3.3 Safety regulations | 8 |
| | 3.3.1 Safety assessment | 8 |
| | 3.3.2 Use of qualified personnel | 9 |
| | 3.3.3 Warranty and liability | 9 |
| | 3.3.4 Disposal | 9 |
| | 3.3.5 For your safety | 9 |
| Section 4 | Function description | 10 |
| | 4.1 Integrated protection mechanisms | 10 |
| | 4.2 Functions | 10 |
| | 4.3 System reaction time | 10 |
| | 4.4 Block diagram | 10 |
| Section 5 | Installation | 11 |
| | 5.1 General installation guidelines | 11 |
| | 5.2 Dimensions in mm | 11 |
| | 5.3 Connecting the base unit and expansion modules | 11 |
| Section 6 | Commissioning | 13 |
| | 6.1 General wiring guidelines | 13 |
| | 6.2 Connection | 13 |
| | 6.3 Download modified project to the PNOZmulti system | 13 |
| Section 7 | Operation | 14 |
| | 7.1 Messages | 14 |
| Section 8 | Technical details | 15 |
| | 8.1 Safety characteristic data | 17 |
| Section 9 | Order reference | 18 |
| | 9.1 Product | 18 |
| | 9.2 Accessories | 18 |

1 Introduction

1.1 Validity of documentation

This documentation is valid for the product PNOZ m EF 16DI. It is valid until new documentation is published.

This operating manual explains the function and operation, describes the installation and provides guidelines on how to connect the product.

1.2 Using the documentation

This document is intended for instruction. Only install and commission the product if you have read and understood this document. The document should be retained for future reference.

1.3 Definition of symbols

Information that is particularly important is identified as follows:



DANGER!

This warning must be heeded! It warns of a hazardous situation that poses an immediate threat of serious injury and death and indicates preventive measures that can be taken.



WARNING!

This warning must be heeded! It warns of a hazardous situation that could lead to serious injury and death and indicates preventive measures that can be taken.



CAUTION!

This refers to a hazard that can lead to a less serious or minor injury plus material damage, and also provides information on preventive measures that can be taken.



NOTICE

This describes a situation in which the product or devices could be damaged and also provides information on preventive measures that can be taken. It also highlights areas within the text that are of particular importance.

**INFORMATION**

This gives advice on applications and provides information on special features.

2 Overview

2.1 Scope of supply

- ▶ Expansion module PNOZ m EF 16DI
- ▶ Jumper

2.2 Unit features


Using the product PNOZ m EF 16DI:

Expansion module for connection to a base unit from the configurable control system .

The product has the following features:

- ▶ Can be configured in the PNOZmulti Configurator
- ▶ 16 inputs for connecting, for example:
 - E-STOP pushbutton
 - Two-hand button
 - Safety gate limit switch
 - Start button
 - Light beam devices
 - Scanner
 - Enabling switch
 - PSEN
 - Operating mode selector switch
- ▶ LED for:
 - Error messages
 - Diagnostics
- ▶ Test pulse outputs used to monitor shorts across the inputs
- ▶ Plug-in connection terminals:
Either spring-loaded terminal or screw terminal available as an accessory (see order reference)
- ▶ Please refer to the document "PNOZmulti System Expansion" for the PNOZmulti base units that can be connected.

2.3 Front view



Legend:

- ▶ Inputs I0 – I15
- ▶ LEDs:
 - POWER
 - Run
 - Diag
 - Fault
 - I Fault

3 Safety


3.1 Intended use

The expansion module may only be connected to a base unit from the configurable system (please refer to the document "PNOZmulti System Expansion" for details of the base units that can be connected).

The configurable system is used for the safety-related interruption of safety circuits and is designed for use in:

- ▶ Emergency stop equipment
- ▶ Safety circuits in accordance with VDE 0113 Part 1 and EN 60204-1

The following is deemed improper use in particular:

- ▶ Any component, technical or electrical modification to the product
- ▶ Use of the product outside the areas described in this manual
- ▶ Use of the product outside the technical details (see [Technical details](#) [ 15]).



NOTICE

EMC-compliant electrical installation

The product is designed for use in an industrial environment. The product may cause interference if installed in other environments. If installed in other environments, measures should be taken to comply with the applicable standards and directives for the respective installation site with regard to interference.

3.2 System requirements

Please refer to the "Product Modifications PNOZmulti" document in the "Version overview" section for details of which versions of the base unit and PNOZmulti Configurator can be used for this product.

3.3 Safety regulations

3.3.1 Safety assessment

Before using a unit it is necessary to perform a safety assessment in accordance with the Machinery Directive.

Functional safety is guaranteed for the product as a single component. However, this does not guarantee the functional safety of the overall plant/machine. In order to achieve the required safety level for the overall plant/machine, define the safety requirements for the plant/machine and then define how these must be implemented from a technical and organisational standpoint.

3.3.2 Use of qualified personnel

The products may only be assembled, installed, programmed, commissioned, operated, maintained and decommissioned by competent persons.

A competent person is someone who, because of their training, experience and current professional activity, has the specialist knowledge required to test, assess and operate the work equipment, devices, systems, plant and machinery in accordance with the general standards and guidelines for safety technology.

It is the company's responsibility only to employ personnel who:

- ▶ Are familiar with the basic regulations concerning health and safety / accident prevention
- ▶ Have read and understood the information provided in this description under "Safety"
- ▶ And have a good knowledge of the generic and specialist standards applicable to the specific application.

3.3.3 Warranty and liability

All claims to warranty and liability will be rendered invalid if

- ▶ The product was used contrary to the purpose for which it is intended
- ▶ Damage can be attributed to not having followed the guidelines in the manual
- ▶ Operating personnel are not suitably qualified
- ▶ Any type of modification has been made (e.g. exchanging components on the PCB boards, soldering work etc.).

3.3.4 Disposal

- ▶ In safety-related applications, please comply with the mission time T_M in the safety-related characteristic data.
- ▶ When decommissioning, please comply with local regulations regarding the disposal of electronic devices (e.g. Electrical and Electronic Equipment Act).

3.3.5 For your safety

The unit meets all the necessary conditions for safe operation. However, you should always ensure that the following safety requirements are met:

- ▶ This operating manual only describes the basic functions of the unit. The expanded functions are described in the PNOZmulti Configurator's online help. Only use these functions once you have read and understood the documentations.
- ▶ Do not open the housing or make any unauthorised modifications.
- ▶ Please make sure you shut down the supply voltage when performing maintenance work (e.g. exchanging contactors).

4 Function description

4.1 Integrated protection mechanisms

The relay conforms to the following safety criteria:

- ▶ The circuit is redundant with built-in self-monitoring.
- ▶ The safety function remains effective in the case of a component failure.

4.2 Functions

The expansion module provides additional inputs.


The function of the inputs on the safety system depends on the safety circuit created using the PNOZmulti Configurator. A chip card is used to download the safety circuit to the base unit. The base unit has 2 microcontrollers that monitor each other. They evaluate the input circuits on the base unit and expansion modules and switch the outputs on the base unit and expansion modules accordingly.

The online help on the PNOZmulti Configurator contains descriptions of the operating modes and all the functions of the PNOZmulti safety system, plus connection examples.

4.3 System reaction time

Calculation of the maximum reaction time between an input switching off and a linked output in the system switching off is described in the document "PNOZmulti System Expansion".

4.4 Block diagram



5 Installation

5.1 General installation guidelines

- ▶ The unit should be installed in a control cabinet with a protection type of at least IP54.
- ▶ Fit the safety system to a horizontal mounting rail. The venting slots must face upward and downward. Other mounting positions could damage the safety system.
- ▶ Use the locking elements on the rear of the unit to attach it to a mounting rail.
- ▶ In environments exposed to heavy vibration, the unit should be secured using a fixing element (e.g. retaining bracket or end angle).
- ▶ Open the locking slide before lifting the unit from the mounting rail.
- ▶ To comply with EMC requirements, the mounting rail must have a low impedance connection to the control cabinet housing.
- ▶ The ambient temperature of the PNOZmulti units in the control cabinet must not exceed the figure stated in the technical details, otherwise air conditioning will be required.




NOTICE

Damage due to electrostatic discharge!

Electrostatic discharge can damage components. Ensure against discharge before touching the product, e.g. by touching an earthed, conductive surface or by wearing an earthed armband.

5.2 Dimensions in mm



5.3 Connecting the base unit and expansion modules

Connect the base unit and the expansion modules as described in the operating manuals for the base modules.

- ▶ The terminator must be fitted to the last expansion module
- ▶ Install the expansion module in the position configured in the PNOZmulti Configurator.

The position of the expansion modules is defined in the PNOZmulti Configurator. The expansion modules are connected to the left or right of the base unit, depending on the type. Please refer to the document "PNOZmulti System Expansion" for details of the number of modules that can be connected to the base unit and the module types.

6 Commissioning

6.1 General wiring guidelines

The wiring is defined in the circuit diagram of the PNOZmulti Configurator.

Please note:

- ▶ Information given in the [Technical details](#) [15] must be followed.
- ▶ Use copper wire that can withstand 75° C.

6.2 Connection

| Input circuit | Single-channel | Dual-channel |
|--|----------------|--------------|
| Example: E-Stop without detection of shorts across contacts | | |
| Example: E-Stop with detection of shorts across contacts | | |

6.3 Download modified project to the PNOZmulti system

As soon as an additional expansion module has been connected to the system, the project must be amended using the PNOZmulti Configurator. Proceed as described in the operating instructions for the base unit.



NOTICE

For the commissioning and after every program change, you must check whether the safety devices are functioning correctly.

7 Operation




When the supply voltage is switched on, the PNOZmulti safety system copies the configuration from the chip card.












The LEDs "POWER", "DIAG", "FAULT", "IFFAULT" and "OFAULT" will light up on the base unit.

The PNOZmulti control system is ready for operation when the "POWER" and "RUN" LEDs on the base unit are lit continuously.

7.1 Messages

Legend

-  LED on
-  LED flashes
-  LED off

| Error | | | | | |
|---|---|------|---|---|---|
| POWER | Run | Diag | Fault | IFault | |
| | | | | | No supply voltage |
|  |  | | | | Expansion module PNOZ m EF 16DI is running without error |
|  | | | | | Expansion module PNOZ m EF 16DI is in a STOP condition |
|  | | |  | | Internal error on the expansion module PNOZ m EF 16DI or on the overall system. Expansion module is in a safe condition. |
|  | | |  | | External error on the expansion module PNOZ m EF 16DI or on the overall system. Expansion module is in a safe condition. |
|  | | | |  | Internal error on the inputs of the expansion module PNOZ m EF 16DI. Expansion module is in a safe condition, e.g. pulse error. |
|  | | | |  | External error on the inputs of the expansion module PNOZ m EF 16DI. Expansion module is in a safe condition. |

8 Technical details

| General | |
|--|---|
| Approvals | BG, CCC, CE, GOST, TÜV, cULus Listed |
| Application range | Failsafe |
| Module's device code | 00E2h |
| Electrical data | |
| Supply voltage | |
| for | Module supply |
| internal | Via base unit |
| Voltage | 24,0 V |
| Kind | DC |
| Current consumption | 46 mA |
| Power consumption | 1,1 W |
| Max. power dissipation of module | 3,00 W |
| Status indicator | LED |
| Inputs | |
| Number | 16 |
| Input voltage in accordance with EN 61131-2 Type 1 | 24 V DC |
| Input current at rated voltage | 5 mA |
| Input current range | 2,5 - 5,3 mA |
| Pulse suppression | 0,5 ms |
| Maximum input delay | 8 ms |
| Potential isolation | No |
| Environmental data | |
| Ambient temperature | |
| In accordance with the standard | EN 60068-2-14 |
| Temperature range | 0 - 60 °C |
| Forced convection in control cabinet off | 55 °C |
| Storage temperature | |
| In accordance with the standard | EN 60068-2-1/-2 |
| Temperature range | -25 - 70 °C |
| Climatic suitability | |
| In accordance with the standard | EN 60068-2-30, EN 60068-2-78 |
| Condensation during operation | Not permitted |
| EMC | EN 61131-2 |
| Vibration | |
| In accordance with the standard | EN 60068-2-6 |
| Frequency | 5,0 - 150,0 Hz |
| Acceleration | 1g |
| Shock stress | |
| In accordance with the standard | EN 60068-2-27 |
| Acceleration | 15g |
| Duration | 11 ms |
| Max. operating height above sea level | 2000 m |

| Environmental data | |
|---|--|
| Airgap creepage | |
| In accordance with the standard | EN 61131-2 |
| Overvoltage category | II |
| Pollution degree | 2 |
| Rated insulation voltage | |
| | 30 V |
| Protection type | |
| In accordance with the standard | EN 60529 |
| Mounting area (e.g. control cabinet) | IP54 |
| Housing | IP20 |
| Terminals | IP20 |
| Mechanical data | |
| Mounting position | |
| | Horizontal on top hat rail |
| DIN rail | |
| Top hat rail | 35 x 7,5 EN 50022 |
| Recess width | 27 mm |
| Max. cable length | |
| Max. cable length per input | 1,0 km |
| Material | |
| Bottom | PC |
| Front | PC |
| Top | PC |
| Connection type | |
| | Spring-loaded terminal, screw terminal |
| Mounting type | |
| | plug-in |
| Conductor cross section with screw terminals | |
| 1 core flexible | 0,25 - 2,50 mm², 24 - 12 AWG |
| 2 core with the same cross section, flexible without crimp connectors or with TWIN crimp connectors | 0,20 - 1,50 mm², 24 - 16 AWG |
| Torque setting with screw terminals | |
| | 0,50 Nm |
| Conductor cross section with spring-loaded terminals: | |
| Flexible with/without crimp connector | 0,20 - 2,50 mm², 24 - 12 AWG |
| Spring-loaded terminals: Terminal points per connection | |
| | 2 |
| Stripping length with spring-loaded terminals | |
| | 9 mm |
| Dimensions | |
| Height | 101,4 mm |
| Width | 22,5 mm |
| Depth | 120,0 mm |
| Weight | |
| | 95 g |

Where standards are undated, the 2012-08 latest editions shall apply.

8.1 Safety characteristic data



NOTICE

You must comply with the safety-related characteristic data in order to achieve the required safety level for your plant/machine.

| Unit | Operating mode | EN ISO 13849-1: 2008 PL | EN ISO 13849-1: 2008 Category | EN 62061 SIL CL | EN 62061 PFH _D [1/h] | EN ISO 13849-1: 2008 T _M [year] |
|--------------|-----------------------------|-------------------------|-------------------------------|-----------------|---------------------------------|--|
| Logic | | | | | | |
| CPU | – | PL e | Cat. 4 | SIL CL 3 | 2,84E-10 | 20 |
| Input | | | | | | |
| SC inputs | 1-channel | PL d | Cat. 2 | SIL CL 2 | 2,10E-09 | 20 |
| SC inputs | 2-channel | PL e | Cat. 4 | SIL CL 3 | 4,27E-11 | 20 |
| SC inputs | 1-ch., pulsed light barrier | PL e | Cat. 4 | SIL CL 3 | 2,10E-10 | 20 |

All the units used within a safety function must be considered when calculating the safety characteristic data.



INFORMATION

A safety function's SIL/PL values are **not** identical to the SIL/PL values of the units that are used and may be different. We recommend that you use the PAScal software tool to calculate the safety function's SIL/PL values.

9 Order reference

9.1 Product

| Product type | Features | Order No. |
|----------------|------------------|-----------|
| PNOZ m EF 16DI | Expansion module | 772 140 |

9.2 Accessories

Connection terminals

| Product type | Features | Order No. |
|----------------------|----------------------------------|-----------|
| Set spring terminals | 1 set of spring-loaded terminals | 751 004 |
| Set screw terminals | 1 set of screw terminals | 750 004 |

Terminator, jumper

| Product type | Features | Order No. |
|----------------------------|--|-----------|
| PNOZ mm0.xp connector left | Jumper yellow/black to connect the modules, 10 piece | 779 260 |

► Support

Technical support is available from Pilz round the clock.

Americas

Brazil
+55 11 97569-2804

Canada
+1 888-315-PILZ (315-7459)

Mexico
+52 55 5572 1300

USA (toll-free)
+1 877-PILZUSA (745-9872)

Asia

China
+86 21 60880878-216

Japan
+81 45 471-2281

South Korea
+82 31 450 0680

Australia

+61 3 95446300

Europe

Austria
+43 1 7986263-0

Belgium, Luxembourg
+32 9 3217575

France
+33 3 88104000

Germany
+49 711 3409-444

Ireland
+353 21 4804983

Italy
+39 0362 1826711

Scandinavia

+45 74436332

Spain

+34 938497433

Switzerland

+41 62 88979-30

The Netherlands

+31 347 320477

Turkey

+90 216 5775552

United Kingdom

+44 1536 462203

You can reach our international hotline on:

+49 711 3409-444
support@pilz.com

Pilz develops environmentally-friendly products using ecological materials and energy-saving technologies. Offices and production facilities are ecologically designed, environmentally-aware and energy-saving. So Pilz offers sustainability, plus the security of using energy-efficient products and environmentally-friendly solutions.

Energy saving by Pilz



Pilz GmbH & Co. KG
Felix-Wankel-Straße 2
73760 Ostfildern, Germany
Tel.: +49 711 3409-0
Fax: +49 711 3409-133
info@pilz.com
www.pilz.com

PILZ
THE SPIRIT OF SAFETY