# OMRON

# **Digital Temperature Controllers**

User's Manual E5□D 1 Introduction

**2** Preparations

3
Part Names and Basic Procedures

4
Basic
Operation

5 Advanced

6 Parameters

**Operations** 

7
User Calibration

A Appendices

Index



# **Preface**

Thank you for purchasing an E5□D Digital Controller.

This manual describes how to use the E5 $\square$ D. Read this manual thoroughly and be sure you understand it before attempting to use the Digital Controller and use the Digital Controller correctly according to the information provided. Keep this manual in a safe place for easy reference. Refer to the *E5\squareD Digital Controllers Communications Manual* (Cat. No. H225) for information on communications.

#### © OMRON, 2017

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

# **Terms and Conditions Agreement**

## Warranty, Limitations of Liability

## **Warranties**

## Exclusive Warranty

Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

#### Limitations

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

### Buyer Remedy

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

# Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

## **Application Considerations**

## **Suitability of Use**

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

# **Programmable Products**

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

### **Disclaimers**

## **Performance Data**

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

# **Change in Specifications**

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

## **Errors and Omissions**

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

# **Safety Precautions**

## **Definition of Precautionary Information**

The following notation is used in this manual to provide precautions required to ensure safe usage of the  $E5\square D$  Digital Controllers.

The safety precautions that are provided are extremely important to safety. Always read and heed the information provided in all safety precautions.

The following notation is used.



Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or in property damage.

# **Symbols**

Sym	nbol	Meaning				
Caution	$\triangle$	General Caution     Indicates non-specific general cautions, warnings, and dangers.				
Caution		Electrical Shock Caution     Indicates possibility of electric shock under specific conditions.				
Prohibition	0	General Prohibition     Indicates non-specific general prohibitions.				
Prombition		Disassembly Prohibition     Indicates prohibitions when there is a possibility of injury, such as from electric shock, as the result of disassembly.				
Mandatory Caution	0	General Caution     Indicates non-specific general cautions, warnings, and dangers.				

## Safety Precautions

# **⚠** CAUTION

Minor injury due to electric shock may occasionally occur. Do not touch the terminals while power is being supplied.



Electric shock, fire, or malfunction may occasionally occur.

Do not allow metal objects, conductors, debris (such as cuttings) from installation work, moisture, or other foreign matter to enter the Digital Controller, the Setup Tool ports, or between the pins on the connectors on the Setup Tool cable.



Attach the cover to the front-panel Setup Tool port whenever you are not using it to prevent foreign objects from entering the port.

Minor injury from explosion may occasionally occur.

Do not use the product where subject to flammable or explosive gas.



Minor electric shock or fire may occasionally occur. Do not use a Digital Controller or cable that is damaged.



Minor electric shock, fire, or malfunction may occasionally occur. Never disassemble, modify, or repair the product or touch any of the internal parts.



If the output relays are used past their life expectancy, contact fusing or burning may occasionally occur.

Always consider the application conditions and use the output relays within their rated load and electrical life expectancy. The life expectancy of output relays varies considerably with the output load and switching conditions.



# **⚠** CAUTION

Loose screws may occasionally result in fire.

Tighten the terminal screws to the specified torque of 0.43 to 0.58  $N \cdot m$ .



Set the parameters of the product so that they are suitable for the system being controlled. If they are not suitable, unexpected operation may occasionally result in property damage or accidents.



A malfunction in the Digital Controller may occasionally make control operations impossible or prevent alarm outputs, resulting in property damage. To maintain safety in the event of malfunction of the Digital Controller, take appropriate safety measures, such as installing a monitoring device on a separate line.



# 

CAUTION - Risk of Fire and Electric Shock

- (a) This product is UL listed as Open Type Process Control Equipment. It must be mounted in an enclosure that does not allow fire to escape externally.
- (b) More than one disconnect switch may be required to de-energize the equipment before servicing.



- (c) Signal inputs are SELV, limited energy. \*1
- (d) Caution: To reduce the risk of fire or electric shock, do not interconnect the outputs of different Class 2 circuits.\*2
- \*1 An SELV (separated extra-low voltage) system is one with a power supply that has double or reinforced insulation between the primary and the secondary circuits and has an output voltage of 30 V r.m.s. max. and 42.4 V peak max. or 60 VDC max.
- \*2 A class 2 circuit is one tested and certified by UL as having the current and voltage of the secondary output restricted to specific levels.

# **Precautions for Safe Use**

Be sure to observe the following precautions to prevent operation failure, malfunction, or adverse affects on the performance and functions of the product. Not doing so may occasionally result in unexpected events. Do not handle the Digital Controller in ways that exceed the ratings.

(1) The product is designed for indoor use only. Do not use or store the product outdoors or in any of the following places.

Places directly subject to heat radiated from heating equipment.

Places subject to splashing liquid or oil atmosphere.

Places subject to direct sunlight.

Places subject to dust or corrosive gas (in particular, sulfide gas and ammonia gas).

Places subject to intense temperature change.

Places subject to icing and condensation.

Places subject to vibration and large shocks.

- (2) Use and store the Digital Controller within the rated ambient temperature and humidity.
  - Gang-mounting two or more Digital Controllers, or mounting Digital Controllers above each other may cause heat to build up inside the Digital Controllers, which will shorten their service life. In such a case, use forced cooling by fans or other means of air ventilation to cool down the Digital Controllers.
- (3) To allow heat to escape, do not block the area around the Digital Controller. Do not block the ventilation holes on the Digital Controller.
- (4) Always check the terminal names and polarity and be sure to wire properly.
- (5) To connect bare wires, use copper stranded or solid wires.

Use the wire sizes and stripping lengths given in the following table to prevent smoking and firing of the wiring material.

#### **Recommended Wires**

Model	Recommended wires	Stripping length
E5CD or E5ED	AWG24 to AWG18	6 to 8 mm
	(0.205 to 0.823 mm <sup>2</sup> )	
E5□D-B (Push-In Plus terminal blocks)	0.25 to 1.5 mm <sup>2</sup> (equivalent to AWG24 to AWG16)	Without ferrules: 8 mm

Use the specified size of crimped terminals to wire the E5CD or E5ED.

## **Crimp Terminal Sizes**

Model	Crimp terminal size
E5CD or E5ED	M3, Width: 5.8 mm max.

For the E5D-B (models with Push-In Plus terminal blocks), connect only one wire to each terminal. For the E5CD or E5ED (models with screw terminals), you can connect up to two wires of the same size and type, or two crimped terminals, to a single terminal.

(6) Do not wire the terminals that are not used.

- (7) To avoid inductive noise, keep the wiring for the Digital Controller's terminal block away from power cables that carry high voltages or large currents. Also, do not wire power lines together with or parallel to Digital Controller wiring. Using shielded cables and using separate conduits or ducts is recommended.
  - Attach a surge suppressor or noise filter to peripheral devices that generate noise (in particular, motors, transformers, solenoids, magnetic coils or other equipment that have an inductance component).
  - When a noise filter is used at the power supply, first check the voltage or current, and attach the noise filter as close as possible to the Digital Controller.
  - Allow as much space as possible between the Digital Controller and devices that generate powerful high frequencies (high-frequency welders, high-frequency sewing machines, etc.) or surge.
- (8) Use the Digital Controller within the rated load and power supply.
- (9) Make sure that the rated voltage is attained within 2 seconds of turning ON the power using a switch or relay contact. If the voltage is applied gradually, the power may not be reset or output malfunctions may occur.
- (10) Make sure that the Digital Controller has 30 minutes or more to warm up after turning ON the power before starting actual control operations to ensure the correct temperature display.
- (11) When using adaptive control, turn ON power for the load (e.g., heater) at the same time as or before supplying power to the Digital Controller. If power is turned ON for the Digital Controller before turning ON power for the load, tuning will not be performed properly and optimum control will not be achieved.
- (12) During tuning,\* ensure that the power for the load (e.g., heater) is ON. If the power supply to the load (e.g., heater) is not turned ON during tuning, tuning results will not be calculated correctly and it will not be possible to achieve optimum control.
  - \* "Tuning" refers to the following functions: AT, adaptive control, automatic filter adjustment, and water-cooling output adjustment.
- (13) A switch or circuit breaker must be provided close to Digital Controller. The switch or circuit breaker must be within easy reach of the operator, and must be marked as a disconnecting means for Digital Controller.
- (14) Wipe off any dirt from the Digital Controller with a soft dry cloth. Never use thinners, benzine, alcohol, or any cleaners that contain these or other organic solvents. Deformation or discoloration may occur.
- (15) Design the system (e.g., control panel) considering the 2 seconds of delay in setting the Digital Controller's output after the power supply is turned ON.
- (16) The output will turn OFF when you move to the Initial Setting Level. Take this into consideration when performing control.
- (17) The number of non-volatile memory write operations is limited. Therefore, use RAM write mode when frequently overwriting data, e.g., through communications.
- (18) Always touch a grounded piece of metal before touching the Digital Controller to discharge static electricity from your body.
- (19) Use suitable tools when taking the Digital Controller apart for disposal. Sharp parts inside the Digital Controller may cause injury.
- (20) Install the DIN Track vertically to the ground.

- (21) Observe the following precautions when drawing out the body of the Digital Controller.
  - Follow the procedure given in 2-1-4 Drawing Out the Interior Body of the Digital Controller to Replace It on page 2-7 of this manual.
  - Turn OFF the power supply before you start and never touch nor apply shock to the terminals or electric components.
    - When connecting or disconnecting the Main Unit, do not allow the electronic components to touch the rear case.
  - When you insert the interior body into the rear case, confirm that the hooks on the top and bottom are securely engaged with the case.
  - If the terminals are corroded, replace the rear case as well
- (22) For the power supply voltage input, use a commercial power supply with an AC input. Do not use the output from an inverter as the power supply. Depending on the output characteristics of the inverter, temperature increases in the product may cause smoke or fire damage even if the product has a specified output frequency of 50/60 Hz.
- (23) Do not continue to use the Digital Controller if the front surface peels.
- (24) Do not exceed the communications distance that is given in the specifications and use the specified communications cable.
- (25) Do not turn the power supply to the Digital Controller ON or OFF while the USB-Serial Conversion Cable is connected. The Digital Controller may malfunction.
- (26) Do not place heavy objects on top of the USB-Serial Conversion Cable, bend the Cable beyond its natural bending limit, or pull on the Cable. Doing so may result in failure.
- (27) Make sure that the indicators on the USB-Serial Conversion Cable are operating properly. Depending on the application conditions, deterioration in the connectors and cable may be accelerated, and normal communications may become impossible. Perform periodic inspection and replacement.
- (28) Do not disconnect the USB-Serial Conversion Cable while communications are in progress. The Digital Controller may be damaged or may malfunction.
- (29) Connectors may be damaged if they are inserted with excessive force. When connecting a connector, always make sure that it is oriented correctly. Do not force the connector if it does not connect smoothly.
- (30) Do not touch the external power supply terminals or other metal parts of the cables on the Digital Controller.
- (31) Noise may enter on the USB-Serial Conversion Cable, possibly causing equipment malfunctions. Do not leave the USB-Serial Conversion Cable connected constantly to the equipment.
- (32) With the E5ED/E5ED-B, do not connect cables to both the front-panel Setup Tool port and the top-panel Setup Tool port at the same time. The Digital Controller may be damaged or may malfunction.
- (33) Observe the following precautions when wiring the E5 $\square$ D-B.
  - Follow the procedures given in E5□D-B (Models with Push-In Plus Terminal Blocks) on page 2-25
    of this manual.
  - Do not wire anything to the release holes.
  - Do not tilt or twist a flat-blade screwdriver while it is inserted into a release hole on the terminal block. The terminal block may be damaged.
  - Insert a flat-blade screwdriver into the release holes at an angle. The terminal block may be damaged if you insert the screwdriver straight in.
  - Do not allow the flat-blade screwdriver to fall out while it is inserted into a release hole.
  - Do not bend a wire past its natural bending radius or pull on it with excessive force. Doing so may cause the wire to break.
  - Do not use crossover wiring except for the input power supply and communications.

# **Precautions for Correct Use**

#### Service Life

- (1) Use the Digital Controller within the following temperature and humidity ranges: Temperature: -10 to 55°C (with no icing or condensation), Humidity: 25% to 85% If the Digital Controller is installed inside a control board, the ambient temperature must be kept to under 55°C, including the temperature around the Digital Controller.
- (2) The service life of electronic devices like Digital Controllers is determined not only by the number of times the relay is switched but also by the service life of internal electronic components. Component service life is affected by the ambient temperature: the higher the temperature, the shorter the service life and, the lower the temperature, the longer the service life. Therefore, the service life can be extended by lowering the temperature of the Digital Controller.
- (3) When two or more Digital Controllers are mounted horizontally close to each other or vertically next to one another, the internal temperature will increase due to heat radiated by the Digital Controllers and the service life will decrease. In such a case, use forced cooling by fans or other means of air ventilation to cool down the Digital Controllers. When providing forced cooling, however, be careful not to cool down the terminals sections alone to avoid measurement errors.

### Ensuring Measurement Accuracy

- (1) When extending or connecting the thermocouple lead wire, be sure to use compensating wires that match the thermocouple types.
- (2) When extending or connecting the lead wire of the platinum resistance thermometer, be sure to use wires that have low resistance and keep the resistance of the three lead wires the same.
- (3) Mount the Digital Controller so that it is horizontally level.
- (4) If the measurement accuracy is low, check to see if input shift has been set correctly.

#### Resistance to Water

The degree of protection is as shown below. Sections without any specification on their degree of protection or those with  $IP \square 0$  are not waterproof.

Front panel: IP66

Rear case: IP20, Terminal section: IP00

When waterproofing is required, insert the Waterproof Packing on the backside of the front panel. Keep the Port Cover on the front-panel Setup Tool port of the E5ED or E5ED-B securely closed. The degree of protection when the Waterproof Packing is used is IP66. To maintain an IP66 degree of protection, the Waterproof Packing and the Port Cover for the front-panel Setup Tool port must be periodically replaced because they may deteriorate, shrink, or harden depending on the operating environment. The replacement period will vary with the operating environment. Check the required period in the actual application. Use 3 years or sooner as a guideline. If the Waterproof Packing and Port Cover are not periodically replaced, waterproof performance may not be maintained.

If a waterproof structure is not required, then the Waterproof Packing does not need to be installed.

## Precautions during Operation

- (1) It takes approximately two seconds for the outputs to turn ON from after the power supply is turned ON. Design the system (e.g., control panel) to allow for this delay.
- (2) Make sure that the Digital Controller has 30 minutes or more to warm up after turning ON the power before starting actual control operations to ensure the correct temperature display.
- (3) Avoid using the Digital Controller in places near a radio, television set, or wireless installing. The Digital Controller may cause radio disturbance for these devices.

#### Others

- (1) Do not rapidly and repeatedly insert and disconnect the USB connector on the USB-Serial Conversion Cable. The computer may operate incorrectly.
- (2) The personal computer requires time to recognize the cable connection after the USB connector is connected to the personal computer. This delay does not indicate failure. Check the COM port number before starting communications.
- (3) Do not connect to a personal computer through a USB hub. The USB-Serial Conversion Cable may malfunction.
- (4) Do not extend the USB cable with an extension cable to connect to the personal computer. The USB-Serial Conversion Cable may malfunction.


# **Preparations for Use**

Be sure to thoroughly read and understand the manual provided with the product, and check the following points.

Timing	Check point	Details
Purchasing the product	Product appearance	After purchase, check that the product and packaging are not dented or otherwise damaged. Damaged internal parts may prevent optimum control.
	Product model and specifications	Make sure that the purchased product meets the required specifications.
Setting the Unit	Product installation location	Provide sufficient space around the product for heat dissipation. Do not block the vents on the product.
Wiring	Terminal wiring	Do not subject the terminal screws to excessive stress (force) when tightening them.  Make sure that there are no loose screws after tightening terminal screws to the specified torque of 0.43 to 0.58 N·m.
		Be sure to confirm the polarity for each terminal before wiring the terminal block and connectors.
		For the E5\(\subseteq\text{D-B}\) (models with Push-In Plus terminal blocks), do not attempt to wire anything to the release holes.
		For the E5 D-B (models with Push-In Plus terminal blocks), use crossover wiring only for the input power supply and communications. Do not exceed the maximum number of Digital Controllers given below if you use crossover wiring for the input power supply.  100 to 240 VAC Controllers: 16 max.  24 VAC/VDC Controllers: 8 max.
	Power supply inputs	Wire the power supply inputs correctly. Incorrect wiring will result in damage to the internal circuits.
Operating environment	Ambient temperature	The ambient operating temperature for the Digital Controller is $-10$ to $55^{\circ}$ C (with no condensation or icing).  To extend the service life of the product, install it in a location with an ambient temperature as low as possible. In locations exposed to high temperatures, if necessary, cool the products using a fan or other cooling method.
	Vibration and shock	Check whether the standards related to shock and vibration are satisfied at the installation environment. (Install the product in locations where the contactors will not be subject to vibration or shock.)
	Foreign particles	Install the product in a location that is not subject to liquid or foreign particles entering the product.


# **Versions**

Check the version on the nameplate on the E5□D Digital Controller or on the label on the packing box.



# **Revision History**

A manual revision code appears as a suffix to the catalog number on the front cover of the manual.



Revision code	Date	Revised content	
01	March 2017	Original production	
02	October 2017	Added E5CD-B and E5ED-B.	
		Added models with linear current outputs.	

# **Conventions Used in This Manual**

#### **Model Notation**

"E5□D" is used to indicate information that is the same for the E5CD and E5ED Digital Controllers.

"E5□D-B" is used to indicate information that is the same for the E5CD-B and E5ED-B Digital Controllers.

# **Meanings of Abbreviations**

The following abbreviations are used in parameter names, figures, and other descriptions. These abbreviations mean the following:

Symbol	Term
PV	Process value
SP	Set point
SV	Set value
AT	Auto-tuning
EU	Engineering unit*
LBA	Loop burnout alarm
НВ	Heater burnout
HS	Heater short

<sup>\* &</sup>quot;EU" stands for Engineering Unit. EU is used as the minimum unit for engineering units such as °C, m, and g. The size of the EU depends on the input type. For example, when the input temperature setting range is –200 to 1,300°C, 1 EU is 1°C, and when the input temperature setting range is –20.0 to 500.0°C, 1 EU is 0.1°C. For analog inputs, the size of the EU depends on the decimal point position of the scaling setting, and 1 EU is the minimum scaling unit.

000	: Functions	with this	s mark car	he lised	only with	the E5□[	)-[]-0[]

MASK: Parameters with this mark can be used with either the E5\(\text{D}\)-\(\text{-0}\) or E5\(\text{D}\)-\(\text{-8}\), but they are masked with the default settings.

MASK8: Parameters with this mark can be used with the E5\(\sigma\)D-\(\sigma\)-8\(\sigma\), but they are masked with the default settings.

Refer to *5-12 Hiding and Displaying Parameters* on page 5-46 for information on displaying parameters that are masked.

## **Terminology**

The following term definitions are used in this manual.

system: The control loop, including the Digital Controller.

system fluctuations: Fluctuations in the temperature inside and outside the control loop.

Examples: Deterioration in heaters or other equipment

Seasonal changes in the ambient temperature

# **How to Read Display Symbols**

The following tables show the correspondence between the symbols displayed on the displays and alphabet characters.

Я	Ь	Ε	d	Ε	F	Б	Н	Ĺ	Л	К	L	М
Α	В	С	D	E	F	G	Н	I	J	К	L	М
N	ō	Р	ū	R	5	Ł	Ц	l'	Н	X	У	7
N	0	Р	Q	R	S	Т	U	V	W	Х	Υ	Z


# **How This Manual is Organized**

Goal	Related sections	Contents
Learning about the	Section 1 Introduction	
appearance, features,		
functions, and model numbers		
Setting up the E5□D	Section 2 Preparations	This section describes the steps that are
		required before turning ON the power supply
		(including installation, terminal usage, wiring,
		and isolation/insulation block diagram). It also
		describes how to use the Setup Tool ports.
Learning the basic procedures	Section 3 Part Names and	This section serves as a basic tutorial for
from turning ON the power	Basic Procedures	first-time users of the E5□D.
supply to starting actual		
operation		
Learning the basic operating	Section 4 Basic Operation	These sections describe basic operating
methods	Section 6 Parameters	methods.
Learning advanced operating	Section 5 Advanced	These sections describe advanced operating
methods	Operations	methods.
	Section 6 Parameters	
Calibrating the E5□D	Section 7 User Calibration	This section describes the procedures that you
		can use to calibrate the sensor or transfer
		output of the E5□D.
Learning the specifications	Appendices	
and parameters of the E5□D		

# **Related Manuals**

Also refer to the *E5*\_D Digital Controllers Communications Manual (Cat. No. H225) for information on communications.

# **Sections in this Manual**



# **CONTENTS**

FIE	face	
Ter	ms and Conditions Agreement	2
	Warranty, Limitations of Liability	
	Application Considerations	3
	Disclaimers	3
Safe	ety Precautions	4
	Definition of Precautionary Information	
	Symbols	
Pre	cautions for Safe Use	7
Pre	cautions for Correct Use	10
Pre	parations for Use	12
Ver	sions	13
Rev	vision History	14
Cor	nventions Used in This Manual	15
	Model Notation	15
	Meanings of Abbreviations	
	Terminology	
	How to Read Display Symbols	
	How This Manual is Organized	
Sec	How This Manual is Organized	16
Section 1	How This Manual is Organized Related Manuals  tions in this Manual  Introduction	16
	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5□D	1617
Section 1	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5□D	1617
Section 1	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5□D  1-1-1 Appearance	16171-21-2
Section 1	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5□D  1-1-1 Appearance 1-1-2 Features 1-1-3 Main Functions	16171-21-21-5
Section 1	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5□D  1-1-1 Appearance 1-1-2 Features 1-1-3 Main Functions  I/O Configuration and Model Number Legend	16171-21-21-51-7
Section 1	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5D  1-1-1 Appearance 1-1-2 Features 1-1-3 Main Functions  I/O Configuration and Model Number Legend	16171-21-21-51-7
Section 1	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5□D  1-1-1 Appearance	16171-21-21-51-7
1-1 1-2	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5D  1-1-1 Appearance	
Section 1  1-1  1-2  Section 2	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5□D  1-1-1 Appearance 1-1-2 Features 1-1-3 Main Functions  I/O Configuration and Model Number Legend 1-2-1 I/O Configuration 1-2-2 Model Number Legends  Preparations  Installation  2-1-1 Dimensions (Unit: mm)	
Section 1  1-1  1-2  Section 2	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5□D	
Section 1  1-1  1-2  Section 2	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5□D  1-1-1 Appearance 1-1-2 Features 1-1-3 Main Functions  I/O Configuration and Model Number Legend 1-2-1 I/O Configuration 1-2-2 Model Number Legends  Preparations  Installation  2-1-1 Dimensions (Unit: mm) 2-1-2 Panel Cutout (Unit: mm) 2-1-3 Mounting	
Section 1 1-1 1-2 Section 2 2-1	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5 D	16171-21-51-71-81-82-22-22-52-7
Section 1  1-1  1-2  Section 2	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5□D  1-1-1 Appearance 1-1-2 Features 1-1-3 Main Functions  I/O Configuration and Model Number Legend 1-2-1 I/O Configuration 1-2-2 Model Number Legends  Preparations  Installation  2-1-1 Dimensions (Unit: mm) 2-1-2 Panel Cutout (Unit: mm) 2-1-3 Mounting 2-1-4 Drawing Out the Interior Body of the Digital Controller to Replace It  Using the Terminals	
Section 1 1-1 1-2 Section 2 2-1	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5□D.  1-1-1 Appearance. 1-1-2 Features. 1-1-3 Main Functions.  I/O Configuration and Model Number Legend. 1-2-1 I/O Configuration. 1-2-2 Model Number Legends.  Preparations  Installation.  2-1-1 Dimensions (Unit: mm). 2-1-2 Panel Cutout (Unit: mm). 2-1-3 Mounting. 2-1-4 Drawing Out the Interior Body of the Digital Controller to Replace It.  Using the Terminals. 2-2-1 E5CD Terminal Block Wiring Example.	
Section 1 1-1 1-2 Section 2 2-1	How This Manual is Organized Related Manuals	
Section 1 1-1 1-2 Section 2 2-1	How This Manual is Organized Related Manuals  Introduction  Appearance, Features, and Functions of the E5□D	
Section 1 1-1 1-2 Section 2 2-1	How This Manual is Organized Related Manuals	

2-3	Installing Temperature Sensors for Packing Machines	2-36
2-4	Insulation Block Diagrams	2-38
2-5	Using the Setup Tool Port 000	2-39
	2-5-1 Procedure	2-39
	2-5-2 Connection Method	
	2-5-5 Installing the Driver	2-42
Section 3	Part Names and Basic Procedures	
3-1	Basic Flow of Operation	3-2
3-2	Power ON	3-3
3-3	Part Names, Part Functions, and Setting Levels	3-4
	3-3-1 Part Names and Functions	
	3-3-2 Entering Numeric Values	
	3-3-3 Setting Levels	
3-4	Procedures after Turning ON the Power Supply	
	3-4-1 Basic Flow of Operations	
	3-4-2 Dasic i Tocedure	5-11
Section 4	Basic Operation	
4-1	Moving between Setting Levels	
	4-1-1 Moving to the Initial Setting Level	
	4-1-2 Moving to the Adjustment Level	
	4-1-4 Moving to the Advanced Function Setting Level	
	4-1-5 Moving to the Communications Setting Level	
4-2	Initial Setting Examples	4-8
4-3	Setting the Input Type	
	4-3-1 Input Type	
4-4	Selecting the Temperature Unit	
	4-4-1 Temperature Unit	
4-5	Selecting PID Control or ON/OFF Control	4-14
4-6	Setting Output Specifications	
	4-6-1 Control Period	
	4-6-3 Assigned Output Functions	
	4-6-4 Auxiliary Output Opening or Closing in Alarm	
4-7	Setting the Set Point (SP)	4-20
	4-7-1 Changing the SP	
4-8	Using ON/OFF Control	4-21
_	4-8-1 ON/OFF Control	
	4-8-2 Settings	4-22
4-9	Determining PID Constants (AT, Manual Setup)	
	4-9-1 AT (Auto-tuning)	
	4-9-2 RT (Robust Tuning) (Use with AT)	
4-10	Alarm Outputs4-10-1 Alarm Types	
	4-10-1 Alarm Types	
<i>1</i> -11	Alarm Hysteresis	
<del></del> -11	4-11-1 Standby Sequence	
	4-11-2 Alarm Latch	

	4-12	Using Heater Burnout (HB) and Heater Short (HS) Alarms	
		4-12-2 HS Alarm	
		4-12-3 Installing Current Transformers (CT)	
		4-12-4 Calculating Detection Current Values	
		4-12-5 Application Examples	4-44
	4-13	Customizing the PV/SP Display	. 4-46
		4-13-1 PV/SP Display Selections	4-46
Section	n 5	Advanced Operations	
	<b>5</b> -1	Suppressing Temperature Variations When Using a Temperature Sensor for Packing	
		Machines (for Packing Machines)	
	5-2	Automatically Adjusting a Water-cooling Output (for Water-cooled Extruders)	5-7
	5-3	Performing Adaptive Control	
		5-3-1 Overview	
		5-3-2 Application Methods for Adaptive Control	5-19
	5-4	Indication Data	. 5-21
	5-5	Shifting Input Values	. 5-25
	5-6	Setting Scaling Upper and Lower Limits for Analog Inputs	. 5-27
	5-7	Executing Heating/Cooling Control	. 5-29
		5-7-1 Heating/Cooling Control	
	5-8	Using Event Inputs	. 5-33
		5-8-1 Event Input Settings	
		5-8-2 How to Use the Multi-SP Function	
		5-8-3 Operation Commands Other than Multi-SP	5-35
	5-9	Setting the SP Upper and Lower Limit Values	
		5-9-1 Set Point Limiter	
		5-9-2 Setting	
	5-10	Using the SP Ramp Function to Limit the SP Change Rate	
		5-10-1 SP Ramp	
	5-11	Using the Key Protect Level	
		5-11-1 Protection	
		-	
	5-12	Hiding and Displaying Parameters	
	- 40	-	
	5-13	OR Output of Alarms  5-13-1 Integrated Alarm	
	- 44	•	
	5-14	Alarm Delays	
	E 1E		
	5-15	Loop Burnout Alarm	
	5-16	Performing Manual Control	. 5-56
	0 .0	5-16-1 Manual MV	
	5-17	Using the Simple Program Function	. 5-59
		5-17-1 Simple Program Function	5-59
		5-17-2 Operation at the Program End	
		5-17-3 Application Example Using a Simple Program	
	5-18	Output Adjustment Functions	
		5-18-1 Output Limits	
		5-18-3 MV at PV Error	

5-		Using the Extraction of Square Root Parameter	
		5-19-1 Extraction of Square Roots	
5-		Setting the Width of MV Variation	
5.		Setting the PF Key	
J.		5-21-1 PF Setting (Function Key)	
5-	-22	Displaying PV/SV Status	5-73
		5-22-1 PV and SV Status Display Functions	
5-		Logic Operations 000	
		5-23-1 The Logic Operation Function (CX-Thermo)	
5-	-24	Initializing Settings	5-84
5-	-25	Setting the Operating Status to Use When Power Is Turned ON	5-85
5-	-26	Using the Transfer Output for the Process Value, Set Point, or other Data 000	5-86
		5-26-1 Transfer Output Function	
<b>.</b>	_	_	
Section	16	Parameters	
6-	-1	Conventions Used in this Section	6-2
6-	-2	Protect Level	6-3
6-	-3	Operation Level	6-7
6-	-4	Adjustment Level	6-16
6-	-5	Monitor/Setting Item Level	6-37
6-	-6	Manual Control Level	6-38
6-	-7	Initial Setting Level	6-40
6-	-8	Advanced Function Setting Level	6-62
6-	-9	Communications Setting Level	6-97
Section	<b>7</b>	User Calibration	
	1	User Calibration	7.0
-		Parameter Structure	
		Thermocouple Calibration	
-		Resistance Thermometer Calibration	
		Calibrating Analog Input	
		Calibrating the Transfer Output	
7-	-7	Checking Indication Accuracy	7-15

# Section A Appendices

	<b>A-1</b>		
		A-1-1 Ratings	
		A-1-2 Characteristics	
		A-1-3 Hating and Characteristics of Options	
		A-1-5 Setup Tool Port Cover for Front Panel 000	A-6
		A-1-6 Draw-out Jig	
	A-2	Current Transformer (CT)	A-8
		A-2-1 Specifications	
		A-2-2 Dimensions (Unit: mm)	A-8
	<b>A-3</b>	USB-Serial Conversion Cable and Conversion Cable 000	
		A-3-1 E58-CIFQ2 USB-Serial Conversion Cable	
		A-3-2 E58-CIFQ2-E Conversion Cable	A-12
	<b>A-4</b>	Temperature Sensor for Packing Machines	A-13
		A-4-1 Model Number Legend	
		A-4-2 Dimensions	
		A-4-3 Mounting Brackets	A-15
	A-5	Error Displays	A-16
	<b>A-6</b>	Troubleshooting	A-20
	<b>A-7</b>	Parameter Operation Lists	A-23
		A-7-1 Operation Level	A-23
		A-7-2 Adjustment Level	
		A-7-3 Initial Setting Level	
		A-7-4 Manual Control Level	
		A-7-5 Monitor/Setting Item Level	
		A-7-6 Advanced Function Setting Level	
		A-7-8 Communications Setting Level	
		A-7-9 Initialization According to Parameter Changes	
	<b>A-8</b>	Sensor Input Setting Range, Indication Range, Control Range	A-39
	A-9	Setting Levels Diagram	A-40
	A-10	Parameter Flow 000	A-41
	A-11	Parameter Flow (For E5□D-□-80□)	A-43
		·	
Index			Index-1



# Introduction

1-1	Appea	arance, Features, and Functions of the E5□D	1-2
	1-1-1	Appearance	1-2
	1-1-2	Features	1-2
	1-1-3	Main Functions	1-5
1-2	I/O Co	onfiguration and Model Number Legend	1-7
	1-2-1	I/O Configuration	1-7
	1-2-2	Model Number Legends	1-8

# 1-1 Appearance, Features, and Functions of the E5□D

#### 1-1-1 **Appearance**





- Functions specialized for packaging machines.
- · Functions specialized for water-cooled extruders.
- Automatic optimization of control for system fluctuations.\*
- Displays of the heater current or manipulated value on a bar display.
- · Various indication data.
- A stylish design that gives a new look to control panels.
- · Large display characters and white backlight for better visibility.
- A compact size to help downsize control panels.
- system fluctuations: Fluctuations in the temperature inside and outside the control loop.

Examples: Deterioration in heaters or other equipment

Seasonal changes in the ambient temperature

#### 1-1-2 **Features**

The E5 $\square$ D provides the following features.

# Temperature Sensors for Packing Machines and Automatic Filter Adjustment

Temperature Sensors for Packing Machines are available and automatic filter adjustment is supported. Mainly, temperature variations in packing machines are suppressed to maintain stable performance.

#### Temperature Sensors for Packaging Machines

The temperature of a packing machine is normally controlled by measuring the temperature of a heater that is separate from the sealing section. When that is done, a deviation occurs between the temperature of the seal and the temperature of the heater, which can lead to sealing faults.

To solve this problem, OMRON provides Temperature Sensors for Packing Machines (E52-CA□□A□ D=1 S□, sold separately) that can be used to measure the actual temperature of the seal. You can use these Temperature Sensors to reduce the number of sealing faults caused by this temperature deviation.

#### **Automatic Filter Adjustment**

When controlling the temperature of a packing machine, temperature variations can occur due to periodic disturbances and other factors.

To handle this, you can use the automatic filter adjustment function in the Digital Controller to suppress temperature variations caused by periodic disturbances and other factors.

Particularly if you use the above Temperature Sensors for Packing Machines, the affect of packing material heat increases and the periodic temperature variation becomes apparent. Automatic filter adjustment enables stable control.

We recommend that you use automatic filter adjustment in the following cases.

- If temperature variation occurs when Temperature Sensors for Packing Machines are used even if AT is performed
- If temperature variation occurs after a heater is replaced
- If temperature variation occurs after packing materials are changed or the packing speed is changed
- If temperature variation occurs due to changes in the operating environment

Note: This function cannot be used during ON/OFF control or heating/cooling control.

# **Water-cooling Output Adjustment**

Mainly, temperature variations in water-cooled extruders are suppressed to maintain stable performance.

When hunting occurs in heating/cooling control of water-cooled extruders, it was previously necessary to have a worker skilled in PID adjustment or water-cooled valve adjustment adjust the system.

With water-cooling output adjustment, you can automatically adjust the cooling proportional band to suppress temperature hunting. Because adjustment is performed during operation, optimum control is enabled even during material condition changes.

We recommend that you use water-cooling output adjustment in the following cases.

- If temperature variation occurs due to changes in the water-cooling system
- If temperature variation occurs due to changes in the cooling valve settings
- To reduce the amount of work required to adjust cooling valves

Note: This function cannot be used during any of the following: standard control, an analog input type, any other heating/cooling method (i.e., except for water cooling), direct operation, and SP ramp operation.

# **Adaptive Control**

Adaptive control is a control method that helps to maintain optimum temperature control by following any changes that may occur due to system fluctuations, such as changes in the environment or equipment deterioration.

With adaptive control, AT (auto-tuning) is required only the first time operation is performed. After that, the equipment startup temperature is monitored to detect system fluctuations and update the PID constants for adaptive control.

There is no need to execute AT again or to manually adjust the PID constants, and higher control performance is achieved than is possible with AT alone.

We recommend that you use adaptive control in the following cases.

- To reduce decline in control performance caused by environmental changes or equipment deterioration
- To increase control performance over AT

Note: This function cannot be used during any of the following: heating/cooling control, an analog input type, direct operation, and SP ramp operation.

# **Various Indication Data**

Various indication data is provided to help predict the product service life and replacement period. You can use it in the host system to collect and analyze data and make predictions.

The following data can be read through host communications or checked with key operations on the front panel.

• Power ON time data: You can display the total power ON time of the Digital Controller or read it with

communications.

The service life of the Digital Controller and equipment depends on the operating

environment.

You can collect power ON time data to clarify the relation between the operating environment and service life and use it to predict future machine maintenance periods

and to improve the operating environment.

• Ambient temperature

monitor:

You can display the temperature around the terminals or read it with communications. You can monitor trends in the ambient temperature to monitor for abnormal heat

generation in the panel.

 Output relay ON/OFF count monitors:

The contacts in the relays have a service life. You can display the number of relay ON/OFF operations or read it with communications.

You can monitor this data to determine replacement periods before the service life

count to make maintenance more efficient.

## 1-1-3 Main Functions

For details on particular functions and how to use them, refer to *Section 3 Part Names and Basic Procedures* and following sections.

## Input Sensor Types

You can connect the following sensors and signals to the universal input.

Thermocouple (temperature input): K, J, T, E, L, U, N, R, S, B, C/W, or PL II

Resistance thermometer (temperature input): Pt100, JPt100

Infrared Temperature Sensor (temperature input): ES1B

10 to 70°C, 60 to 120°C, 115 to 165°C, 140 to 260°C

Current input (analog input): 4 to 20 mA DC, 0 to 20 mA DC

Voltage input (analog input): 1 to 5 VDC, 0 to 5 V DC, 0 to 10 V DC

### Control Outputs

• A control output can be a relay output, voltage output (for driving SSR), or linear current output, depending on the model.

### Adjusting PID Constants

- You can easily set the optimum PID constants by performing AT (auto-tuning) with the limit cycle method.
- You can also add RT (robust tuning) to give priority to controlling stability.

#### Alarms

#### **Standard Alarms**

- You can output an alarm when the deviation, process value, set point, or manipulated value reaches a specified value.
- You can also output alarms for the PV rate of change and for loop burnouts.
- If necessary, a more comprehensive alarm function can be achieved by setting a standby sequence, alarm hysteresis, auxiliary output close in alarm/open in alarm, alarm latch, alarm ON delay, and alarm OFF delay.

#### **HB and HS Alarms**

• With models with the optional HB and HS alarms, you can detect heater burnout and heater short alarms based on CT inputs.

#### Integrated Alarm

• You can output an integrated alarm if a standard alarm, HB alarm, or HS alarm turns ON.

## Event Inputs

• With any model that supports event inputs, you can use external contact or transistor inputs to achieve any of the following functions: Switching set points (Multi-SP No. Switch, 8 points max.), switching RUN/STOP, switching between automatic and manual operation, starting/resetting the program, inverting direct/reverse operation, 100% AT execute/cancel, 40% AT execute/cancel, setting change enable/disable, communications write enable/disable, canceling the alarm latch, PID updating (adaptive control), automatic filter adjustment, and water-cooling output adjustment.

#### Communications Functions

With any model that supports communications, you can use communications via CompoWay/F, Modbus-RTU,\* or programless communications.


\* Modbus is a registered trademark of Schneider Electric.

#### Transfer Output

With any model that provides a transfer output, you can output the set point, process value, manipulated variable, or other values as a 4 to 20 mA or 1 to 5 V transfer output.

# 1-2 I/O Configuration and Model Number Legend

## 1-2-1 I/O Configuration



Note: Not all models support these functions. For details, refer to 1-2-2 Model Number Legends.

#### 1-2-2 **Model Number Legends**

• E5CD (Models with Screw Terminal Blocks)

000

(1)	(2	2)	(3)	(4)	(5)	(6)	(7)	(7) Meaning			
Size	Control Outputs 1 and 2		No. of auxiliary outputs	Power supply voltage	Terminal type	Input type	Options				
С								48 × 48 mm			
								Control			output 2
	R	Х						Relay	•		one
	Q	Χ						Voltage output (		No	one
	С	Χ						Linear curr	rent output	No	one
			2					2			
				Α				100 to 240 VAC			
				D				24 VAC/DC			
					6			Screw terminals (with Cover: E53-COV23)			
								Draw-out model			
						М		Universal input			
								Event inputs	Communi cations	HB alarm and HS alarm	Transfer output
							000		-		
	*1				*1	001	2		1		
	*1						002		RS-485	1	
	*2						004	2	RS-485	-	
						*2	006	2	-		Provided

You can select option 001 or 002 if RX and QX control outputs are selected.

You can select option 004 or 006 if CX control outputs are selected.

(2	2)	(3)	(4)	(5)	(6)	(7)	Meaning				
Control Outputs 1 and 2		No. of auxiliary outputs	Power supply voltage	Terminal type	Input type	Options					
							48 × 48 mm		Control output 2		
								Control output 1			
R	Х						Relay	output	None		
Q	Х						Voltage output (	for driving SSR)	None		
С	Х						Linear curi	rent output	None		
		2					2				
			Α				100 to 240 VAC				
			D				24 VAC/DC				
				D			Screw terminals (no cove	er)			
							Draw-out model				
				-	М		Universal input				
							Event inputs	Communications	HB alarm and HS alarm		
						800					
*1				*1	802		RS-485	1			
					*2	804		RS-485	1		
	B G Spire Latination Contract	Q X	Control Outputs 1 and 2  X X X  No. of auxiliary outputs	Control Outputs 1 and 2  X X X X No. of auxiliary outputs Power supply voltage	Control Outputs 1 and 2  X X X  No. of auxiliary outputs  Power supply voltage  Terminal type	Control Outputs 1 and 2  X X X  Control Outputs 1 and 2  X X X  D A D No. of auxiliary outputs  D Power supply voltage  Terminal type	Control Outputs 1 and 2  Control Outputs 1 and 2  X X X C  C X X C  D X X X  D D M  *1  B00  800  802	No of the part o	Note		

<sup>\*1</sup> You can select option 802 if RX and QX control outputs are selected.

<sup>\*2</sup> You can select option 804 if CX control outputs are selected.

**E 5**CD - (2) (3) (4) (5) (6)

000

(1)	(2	2)	(3)	(4)	(5)	(6)	(7)	Meaning			
Size	Control Quitnuts 1 and 2		No. of auxiliary outputs	Power supply voltage	Terminal type	Input type	Options				
С										48 × 48 mm	
								Control	<u> </u>	Control	
	R	Χ							output	No	
	Q	X						Voltage outp		No	ne
	С	Χ						Linear curi	rent output	No	ne
	,		2						2	(one common)	
				Α					1	100 to 240 VAC	
				D						24 VAC/DC	
					В				Push-li	n Plus terminal blocks	
						М				Universal input	
								Event inputs	Communi cations	HB alarm and HS alarm	Transfer output
							000				-
*1						*1	001	2		1	
*1						-	002		RS-485	1	
*2 00							004	2	RS-485		
						*2	006	2			Provided

<sup>\*1</sup> You can select option 001 or 002 if RX and QX control outputs are selected.

You can select option 004 or 006 if CX control outputs are selected.

(1)	(2	2)	(3)	(4)	(5)	(6)	(7)	Meaning				
Size	C bas t stuatuo lostao 2		No. of auxiliary outputs	Power supply voltage	Terminal type	Input type	Options					
С								$48 \times 48 \text{ mm}$				
,								Control	output 1	Control output 2		
	R	Χ						Relay	output	None		
	a	Χ						Voltage output	(for driving SSR)	None		
*1	O	Χ						Linear cur	rent output	None		
'			2						2 (one co	ommon)		
				Α					100 to 2	40 VAC		
				D					24 VA	C/DC		
					В				Push-In Plus to	erminal blocks		
						М			Univers Communications	al input		
								Event inputs	HB alarm and HS alarm			
						800	-					
	*1					*1	802		RS-485	1		
						*2	804	RS-485 1				

<sup>\*1</sup> You can select option 802 if RX and QX control outputs are selected.

<sup>\*2</sup> You can select option 804 if CX control outputs are selected.

## • E5ED (Models with Screw Terminal Blocks)

E5ED - 6 - 0 (2) (3) (4) (5) (6) (1) (7) 000

7) Meaning					
48 × 96 mm					
Control output 2					
None					
g SSR) None					
ut None					
g SSR) Relay output					
Relay output					
4					
100 to 240 VAC					
24 VAC/DC					
minals (with Cover: E53-COV24)					
Draw-out model					
Universal input					
unication HB alarm and S HS alarm Transfer output					
S-485					
G-485 1					
1					
S-485 Provided					

<sup>\*1</sup> You can select option 004 or 022 if CX control outputs are selected.

You can select option 008 if RX, QX, QR or RR control outputs are selected.

You can select option 010 if RX or QX control outputs are selected.

(1)	(2	2)	(3)	(4)	(5)	(6)	(7)		Meaning	
Size	Control Outputs 1 and 2		No. of auxiliary outputs	Power supply voltage	Terminal type	Input type	Options			
Е									48 × 96 mm	
								Conti	Control output 2	
	R	Χ						Re	None	
	Q	Χ						Voltage output (for driving SSR)		None
	С	Χ						Linear current output		None
			2					2		
		-		Α					100 to 240 VAC	
				D					24 VAC/DC	
					D				Screw terminals (no cover)	
								Draw-out model		
						М		Universal input		
								Event inputs	HB alarm and HS alarm	
							800			
						*1	804	2 RS-485 1		
						*2	808	2		

<sup>\*1</sup> You can select option 804 if RX and QX control outputs are selected.

<sup>\*2</sup> You can select option 808 if CX control outputs are selected.

# • E5ED-B (Models with Push-In Plus Terminal Blocks)

E5ED - B - 0 (2) (3) (4) (5) (6) (1) (7) 000

(1)	(2	2)	(3)	(4)	(5)	(6)	(7)	Meaning			
Size	Control Outpute 1 and 2		No. of auxiliary outputs	Power supply voltage	Terminal type	Input type	Options				
Е									48 × 9		
								Control	output 1	Control	output 2
	R	Χ						Relay	output	None	
	Q	Χ						Voltage output (	(for driving SSR)	None	
	С	Χ						Linear cur	rent output	None	
	Q	R						Voltage output (for driving SSR)		No	ne
	R	R						Relay output		Relay	output
			4					4			
		-		Α				100 to 240 VAC			
				D					24 VA	IC/DC	
					В				Push-In Plus to		
						М			Univers	· · · · · · · · · · · · · · · · · · ·	
					Event inputs	Communications	HB alarm and HS alarm	Transfer output			
	000			000	-						
*1 004				*1	004	2	RS-485				
						*2	800	2	RS-485	1	
						*3	010	4		1	
						*1	022	4	RS-485		Provided
	1 Vou can calcut aption 004 or 0					-					i iovided

<sup>\*1</sup> You can select option 004 or 022 if CX control outputs are selected.

<sup>\*2</sup> You can select option 008 if RX, QX, QR or RR control outputs are selected.

<sup>\*3</sup> You can select option 010 if RX or QX control outputs are selected.

Meaning	
48 × 96 mm	
Control output 2	
None	
ng SSR) None	
out None	
2	
00 to 240 VAC	
24 VAC/DC	
Plus terminal blocks	
Jniversal input	
ommunications HB alarm and HS alarm	
RS-485	
RS-485 1	

<sup>\*1</sup> You can select option 804 if RX or QX control outputs are selected.

<sup>\*2</sup> You can select option 808 if CX control outputs are selected.


# **Preparations**


2-1	Instal	lation	2-2
	2-1-1	Dimensions (Unit: mm)	
	2-1-2	Panel Cutout (Unit: mm)	
	2-1-3	Mounting	
	2-1-4	Drawing Out the Interior Body of the Digital Controller to Replace It	2-7
2-2	Using	the Terminals	2-9
	2-2-1	E5CD Terminal Block Wiring Example	
	2-2-2	E5CD-B Terminal Block Wiring Example	
	2-2-3	E5ED Terminal Block Wiring Example	
	2-2-4	E5ED-B Terminal Block Wiring Example	
	2-2-5	Precautions when Wiring	
	2-2-6	Wiring	
2-3	Instal	ling Temperature Sensors for Packing Machines	2-36
2-4	Insula	ation Block Diagrams	2-38
2-5	Using	the Setup Tool Port 000	2-39
	2-5-1	Procedure	
	2-5-2	Connection Method	
	2-5-3	Installing the Driver	

#### 2-1 Installation


#### **Dimensions (Unit: mm)** 2-1-1

### • E5CD







### • E5CD-B




#### • E5ED





<sup>\*</sup> The E5ED-□-8□□ does not have a tool port (i.e., a pin jack) on the front.


# • E5ED-B




#### Panel Cutout (Unit: mm) 2-1-2

#### • E5CD/E5CD-B


#### **Individual Mounting**






#### • E5ED/E5ED-B

**Individual Mounting** 






- Waterproofing is not possible when group mounting several Digital Controllers.
- The recommended panel thickness is 1 to 5 mm for the E5CD and E5CD-B and 1 to 8 mm for E5ED and E5ED-B.
- Digital Controllers must not be group mounting vertically. (Observe the recommended mounting space limits.)
- When two or more Digital Controllers are mounted, make sure that the ambient temperature of the Digital Controllers does not exceed the allowable operating temperature specified in the specifications.

# 2-1-3 Mounting

#### ● E5CD/E5CD-B




# Mounting to the Panel (E5CD or E5CD-B)

- (1) For waterproof mounting, waterproof packing must be installed on the Digital Controller. Waterproofing is not possible when group mounting several Digital Controllers.
- (2) Insert the E5CD or E5CD-B into the mounting hole in the panel.
- (3) Push the Adapter from the terminals up to the panel, and temporarily fasten the E5CD.
- (4) Tighten the two fastening screws on the Adapter. Alternately tighten the two screws little by little to maintain a balance. Tighten the screws to a torque of 0.29 to 0.39 N·m.


### Mounting the Terminal Cover (E5CD Only)

There are two models of Terminal Covers that you can use with the E5CD.

Slightly bend the E53-COV23 Terminal Cover to attach it to the terminal block as shown in the following diagram. The Terminal Cover cannot be attached in the opposite direction. Or, you can use the E53-COV17 Terminal Cover. Make sure that the "UP" mark is facing up, and then attach the E53-COV17 Terminal Cover to the holes on the top and bottom of the Digital Controller. (The E53-COV23 Terminal Cover is not provided with the E5CD- $\square$ -8 $\square$ .)








Enlarged Illustration of Terminal Section

#### • E5ED/E5ED-B




#### Mounting to the Panel (E5ED or E5ED-B)

- (1) For waterproof mounting, waterproof packing must be installed on the Digital Controller. Waterproofing is not possible when group mounting several Digital Controllers.
- (2) Insert the E5ED or E5ED-B into the mounting hole in the panel.
- (3) Push the Adapter from the terminals up to the panel, and temporarily fasten the E5ED.
- (4) Tighten the two fastening screws on the Adapter. Alternately tighten the two screws little by little to maintain a balance. Tighten the screws to a torque of 0.29 to 0.39 N·m.

#### Mounting the Terminal Cover (E5ED Only)

Slightly bend the E53-COV24 Terminal Cover to attach it to the terminal block as shown in the following diagram. The Terminal Cover cannot be attached in the opposite direction. (The E53-COV24 Terminal Cover is not provided with the E5ED-□-8□□.)




# 2-1-4 Drawing Out the Interior Body of the Digital Controller to Replace It

You can use the Draw-out Jig to remove the interior body of the Digital Controller from the case to perform maintenance without removing the terminal leads. Use the Y92F-58 Draw-out Jig for the E5CD and the Y92F-59 Draw-out Jig for the E5ED. Check the specifications of the case and Digital Controller before removing the interior body from the case. (The E5 $\square$ D-B cannot be removed the interior body from the case.)


# Draw out the interior body from the rear case.


(1) Align the arms on the Draw-out Jig with the top of the front panel on the Digital Controller and position it vertically.

(The Y92F-58 is shown in the figure.)



(2) Align the hooks on the Draw-out Jig with the Draw-out Jig insertion holes on the Digital Controller and slowly insert the Draw-out Jig into the Draw-out Jig insertion holes laterally until it clicks into place. (If you attempt to draw out the interior body of the Digital Controller when only one hook is engaged, the Digital Controller may be damaged.)






- (3) Pull out the Draw-out Jig together with the front panel. Do not pull with excessive force. Slowly pull out the Digital Controller laterally. (If you pull the interior body out at an angle, the Digital Controller may be damaged.)
- (4) After the interior body is free from the rear case, support the interior body with one hand and pull it out slowly in a horizontal direction.


# **2** Prepare the new interior body.

- (1) Place the Digital Controller flat on a table and slowly insert the Draw-out Jig into the Draw-out Jig insertion holes laterally until it clicks into place. (There is a hole at both the top and bottom.)
  - (The E5CD is shown in the figure.)
- (2) Place the Digital Controller on a table facing upward.
- (3) Hold the rear case with your hand and slowly draw out the interior body in a vertical direction. If you draw out the interior body horizontally while holding the Digital Controller in your hand, the interior body will fall and may be damaged.




# Insert the new interior body into the rear case.

(1) When inserting the interior body back into the rear case, mount the sealing rubber in the position shown on the right, make sure the PCBs are parallel to each other, and press the interior body toward the rear case and into position, making sure that the sealing rubber does not move.



(2) When you press the Digital Controller into position, press down on the rear case hooks so that the case hooks securely lock in place. (There are rear case hooks at both the top and bottom of the rear case.) If the Digital Controller is not correctly mounted into the rear case, the rear case may not be waterproof. When inserting the Digital Controller, do not allow the electronic components to touch the rear case. (The E5CD is shown in the figure.)






#### **Additional Information**

Removing the draw-out jig when only one hook is caught in the draw-out jig insertion hole

- (1) Pull the Draw-out Jig slowly in the direction shown in the figure. (This step is the same even if the other hook is caught.)
- (2) Confirm that the Draw-out Jig is free of the Draw-out Jig insertion hole.
- If the interior body separates from the rear case, slowly press the interior body into the rear case in a horizontal direction. (The E5CD is shown in the figure.) If you do not follow the procedures above, the Digital Controller may be damaged.




# 2-2 Using the Terminals

# 2-2-1 E5CD Terminal Block Wiring Example

#### Terminal Arrangement

The terminals block of the E5CD is divided into five types of terminals: control output 1, sensor input, auxiliary outputs, input power supply, and options.





#### **Precautions for Correct Use**

When you purchase the Digital Controller, it will be set for a K thermocouple (input type = 5) by default. If a different sensor is used, an input error (5.ERR) will occur. Check the setting of the Input Type parameter.

# **Control Output 1**

#### Model Numbers

The control output 1 specification of the E5CD is given in the following location in the model number.



Code	Output type	Specification
RX	1 relay output	250 VAC, 3 A (resistive load)
QX	1 voltage output (for driving SSR)	12 VDC, 21 mA
CX	1 linear current output 4 to 20 mA DC or	DC with load of 500 $\Omega$ max.
	0 to 20 mA	

#### Terminal Details

Do not connect anything to the terminals that are shaded gray.

RX	QX	СХ
Control output 1 Relay output	Control output 11 + Voltage output (for driving SSR)	Control output 1 2 Linear current output

# **Sensor Input**

#### Model Numbers

All E5CD models have universal sensor inputs, so the code in the model number is always "M."

E5CD-Sensor input

#### Terminal Details

Do not connect anything to the terminals that are shaded gray.

TC (thermocouple)	Pt (resistance thermometer)	I (current)	V (voltage)
(4) (5) (6)	A (4) B (5) B (6)	□ + 4 □ A 5 □ 6	4 - 5 - 5 - 6



### **Precautions for Correct Use**

- · When complying with EMC standards, the line connecting the sensor must be 30 m or less. If the cable length exceeds 30 m, compliance with EMC standards will not be possible.
- · The sensor input is not electrically isolated from the internal circuits. If you use a grounded thermocouple, do not connect one of the sensor input terminals to ground. (If the sensor input terminals are connected to ground, errors will occur in the measured temperature as a result of leakage current.)


# **Auxiliary Outputs**

#### Model Numbers

The number of auxiliary outputs on the E5CD is given in the following location in the model number.

Code	Auxiliary outputs	Specification
2	Model with 2 auxiliary outputs	SPST-NO, 250 VAC, 3 A

### Terminal Details



# **Input Power Supply**

### Model Numbers

The input power supply specification of the E5CD is given in the following location in the model number.



Code	Specification	Power consumption
Α	100 to 240 VAC, 50/60 Hz	Option number 000 or 800: 5.2 VA max.
		Other option numbers: 6.5 VA max.
D	24 VAC, 50/60 Hz	Option number 000 or 800: 3.1 VA max./1.6 W max.
	24 VDC (no polarity)	Other option numbers: 4.1 VA max./2.3 W max.

### Terminal Details

100 to 240 VAC	24 VAC/DC
(1) <del>(</del> 2) (12) <del>(</del> 4)	(No polarity)

# **Options**

### Model Numbers


The options specification of the E5CD is given in the following location in the model number.



Code	Specification
000 or 800	None
001	Event inputs 1 and 2, and CT1
002 or 802	Communications (RS-485) and CT1
004 or 804	Communications (RS-485), and event inputs 3 and 4
006	Event inputs 1 and 2, and transfer output
	Transfer output:
	Current: 4 to 20 mA DC
	Voltage: 1 to 5 VDC

#### Terminal Details

Do not connect anything to the terminals that are shaded gray.




Note: Use non-voltage inputs for the event inputs.

The polarity for a non-contact input is indicated by "(-)."

# 2-2-2 E5CD-B Terminal Block Wiring Example

### Terminal Arrangement

The terminals block of the E5CD-B is divided into five types of terminals: control output 1, sensor input, auxiliary outputs, input power supply, and options.





#### **Precautions for Correct Use**

When you purchase the Digital Controller, it will be set for a K thermocouple (input type = 5). If a different sensor is used, an input error (5.ERR) will occur. Check the setting of the Input Type parameter.

# **Control Output 1**

#### Model Numbers

The control output 1 specification of the E5CD-B is given in the following location in the model number.

Code	Output type	Specification
RX	1 relay output	250 VAC, 3 A (resistive load)
QX	1 voltage output (for driving SSR)	12 VDC, 21 mA
CX	1 linear current output	4 to 20 mA DC or 0 to 20 mA DC with load of 500 $\Omega$
		max.

#### Terminal Details

RX	QX	CX
Control output 1 Relay output	Control output 1 + Voltage output (for driving SSR)	Control output 1 2 Linear current output

# **Sensor Input**

#### Model Numbers

All E5CD-B models have universal sensor inputs, so the code in the model number is always "M."



TC (thermocouple)	Pt (resistance thermometer)	I (current)	V (voltage)
(6) (7) (8)	A 6 7 B 8	mA 7 - 8	6 - 7 - 8 8



#### **Precautions for Correct Use**

- When complying with EMC standards, the line connecting the sensor must be 30 m or less. If the cable length exceeds 30 m, compliance with EMC standards will not be possible.
- The sensor input is not electrically isolated from the internal circuits. If you use a grounded thermocouple, do not connect one of the sensor input terminals to ground. (If the sensor input terminals are connected to ground, errors will occur in the measured temperature as a result of leakage current.)

# **Auxiliary Outputs**


#### Model Numbers

The number of auxiliary outputs on the E5CD-B is given in the following location in the model number.



Code	Output type	Specification
2	Model with 2 auxiliary outputs	SPST-NO, 250 VAC, 2 A

#### **Terminal Details**



Common terminals are indicated with asterisks (\*).

# Input Power Supply

#### Model Numbers

The input power supply specification of the E5CD-B is given in the following location in the model number.

E5CD- B M- D Input power supply

The codes that are given in the following table show the specification.

Code	Specification	Specification
Α	100 to 240 VAC, 50/60 Hz	Option number 000: 5.2 VA max.
		Other option numbers: 6.5 VA max.
D	24 VAC, 50/60 Hz	Option number 000: 3.1 VA max./1.6 W max.
	24 VDC (no polarity)	Other option numbers: 4.1 VA max./2.3 W max.

#### Terminal Details

Details on the input power supply terminals are shown below.

100 to 240 VAC	24 VAC/DC
(3) (14) (15) (16)	(No polarity)

Common terminals are indicated with asterisks (\*). You can use them for crossover wiring.

For crossover wiring, do not exceed the maximum number of Temperature Controllers given below.

100 to 240 VAC Controllers: 16 max.

24 VAC/VDC Controllers: 8 max.

# **Options**

#### Model Numbers


The options specification of the E5CD-B is given in the following location in the model number.



Code	Specification
000 or 800	None
001	Event inputs 1 and 2, and CT1
002 or 802	Communications (RS-485) and CT1
004 or 804	Communications (RS-485), and event inputs 3 and 4
006	Event inputs 1 and 2, and transfer output
	Transfer output:
	Current: 4 to 20 mA DC
	Voltage: 1 to 5 VDC

# Terminal Details

Do not connect anything to the terminals that are shaded gray.



Common terminals are indicated with asterisks (\*).

You can use communications common terminals for crossover wiring.


Note: Use non-voltage inputs for the event inputs.

The polarity for a non-contact input is indicated by "(-)."

# 2-2-3 E5ED Terminal Block Wiring Example

# Terminal Arrangement

The terminals block of the E5ED is divided into five types of terminals: control outputs 1 and 2, sensor input, auxiliary outputs, input power supply, and options.





### **Precautions for Correct Use**

When you purchase the Digital Controller, it will be set for a K thermocouple (input type = 5). If a different sensor is used, an input error (5.ERR) will occur. Check the setting of the Input Type parameter.

# **Control Outputs 1 and 2**

#### Model Numbers


The control outputs 1 and 2 specifications of the E5ED are given in the following location in the model number.



Code	Output type	Specification
RX	1 relay output	250 VAC, 5 A (resistive load)
QX	1 voltage output (for driving SSR)	12 VDC, 40 mA
CX	1 linear current output	4 to 20 mA DC or 0 to 20 mA DC with load of 500 $\Omega$ max.
QR	1 voltage output (for driving SSR) and	12 VDC, 21 mA for voltage output
	1 relay output	250 VAC, 5 A (resistive load) for relay output
RR	2 relay outputs	250 VAC, 5 A (resistive load)

#### Terminal Details

Do not connect anything to the terminals that are shaded gray.



# **Sensor Input**

#### Model Numbers

All E5ED models have universal sensor inputs, so the code in the model number is always "M."



#### Terminal Details

Do not connect anything to the terminals that are shaded gray.

TC (thermocouple)	Pt (resistance thermometer)	I (current)	V (voltage)
23) + (24)	A (22) B (23) B (24)	□ + (22) □ A   (23) □ - (24)	220 - (23) V (24)




### **Precautions for Correct Use**

- · When complying with EMC standards, the line connecting the sensor must be 30 m or less. If the cable length exceeds 30 m, compliance with EMC standards will not be possible.
- The sensor input is not electrically isolated from the internal circuits. If you use a grounded thermocouple, do not connect one of the sensor input terminals to ground. (If the sensor input terminals are connected to ground, errors will occur in the measured temperature as a result of leakage current.)

# **Auxiliary Outputs**

#### Model Numbers

The number of auxiliary outputs on the E5ED is given in the following location in the model number.



Code	Auxiliary outputs	Specification
2	Model with 2 auxiliary outputs	SPST-NO, 250 VAC, 3 A
4	Model with 4 auxiliary outputs	SPST-NO, 250 VAC, 2 A

#### Terminal Details

Do not connect anything to the terminals that are shaded gray.

Model with 2 auxiliary outputs	Model with 4 auxiliary outputs
Auxiliary output 2  Auxiliary output 1  Auxiliary output 1  12	Auxiliary output 4  Auxiliary output 3  Auxiliary output 2  Auxiliary output 1  Auxiliary output 1

# **Input Power Supply**

### Model Numbers

The input power supply specification of the E5ED is given in the following location in the model number.

Code	Specification	Power consumption	
Code	Specification	Options No.: 000 or 800	Other option numbers
A	100 to 240 VAC (50/60 Hz)	6.6 VA max.	8.3 VA max.
D	24 VAC, 50/60 Hz	4.1 VA max.	5.5 VA max.
	24 VDC (no polarity)	2.3 W max.	3.2 W max.

#### Terminal Details

100 to 240 VAC	24 VAC/DC
	(no polarity)

# **Options**

#### Model Numbers


The options specification of the E5ED is given in the following location in the model number.



Code	Specification	
000 or 800	None	
004 or 804	Communications (RS-485), and event inputs 1 and 2	
008 or 808	Communications (RS-485), event inputs 1 and 2, and CT1	
010	Event inputs 1 to 4, and CT1	
022	Communications (RS-485), and event inputs 1, 2, 5 and 6, and transfer output	

#### Terminal Details

Do not connect anything to the terminals that are shaded gray.




Note: Use non-voltage inputs for the event inputs.

The polarity for a non-contact input is indicated by "(-)."

# 2-2-4 E5ED-B Terminal Block Wiring Example

### Terminal Arrangement

The terminals block of the E5ED-B is divided into five types of terminals: control outputs 1 and 2, sensor input, auxiliary outputs, input power supply, and options.



Note: The terminals that are shaded gray are not used.



### **Precautions for Correct Use**

When you purchase the Digital Controller, it will be set for a K thermocouple (input type = 5). If a different sensor is used, an input error (5.ERR) will occur. Check the setting of the Input Type parameter.

# **Control Outputs 1 and 2**

#### Model Numbers

The control outputs 1 and 2 specifications of the E5ED-B are given in the following location in the model number.



Code	Output type	Specification
RX	1 relay output	250 VAC, 5 A (resistive load)
QX	1 voltage output (for driving SSR)	12 VDC, 40 mA
CX	1 linear current output	4 to 20 mA DC or 0 to 20 mA DC with load of 500 $\Omega$ max.
QR	1 voltage output (for driving SSR) and	12 VDC, 21 mA for voltage output
	1 relay output	250 VAC, 5 A (resistive load) for relay output
RR	2 relay outputs	250 VAC, 5 A (resistive load)

#### Terminal Details

RX	QX	СХ	
Control output 1 6 Relay output	Control output 1 Voltage output (for driving SSR)	Control output 1 + Linear current output	
QR	RR		
Control output 1	Control output 1 6 Relay output  Control output 2 Relay output		

# **Sensor Input**

#### Model Numbers

All E5ED-B models have universal sensor inputs, so the code in the model number is always "M."



#### Terminal Details

Do not connect anything to the terminals that are shaded gray.

TC (thermocouple)	Pt (resistance thermometer)	I (current)	V (voltage)
30 - 31 - 32 + 32	A 30 B 31 B 32	**************************************	(30) - (31) - (32) + (32)



### **Precautions for Correct Use**

- When complying with EMC standards, the line connecting the sensor must be 30 m or less. If the cable length exceeds 30 m, compliance with EMC standards will not be possible.
- The sensor input is not electrically isolated from the internal circuits. If you use a grounded thermocouple, do not connect one of the sensor input terminals to ground. (If the sensor input terminals are connected to ground, errors will occur in the measured temperature as a result of leakage current.)

# **Auxiliary Outputs**

#### Model Numbers

The number of auxiliary outputs on the E5ED-B is given in the following location in the model number.

E5ED- B M- No. of auxiliary outputs

Code	Auxiliary outputs	Specification
2	Model with 2 auxiliary outputs	SPST-NO, 250 VAC, 3 A
4	Model with 4 auxiliary outputs	SPST-NO, 250 VAC, 2 A

#### Terminal Details

Do not connect anything to the terminals that are shaded gray.

Model with 2 auxiliary outputs	Model with 4 auxiliary outputs
9 10	Auxiliary output 4
Auxiliary output 2	Auxiliary output 3
(3) (4)	Auxiliary output 2
Auxiliary output 1	Auxiliary output 1 16

Common terminals are indicated with asterisks (\*).

# **Input Power Supply**


#### Model Numbers

The input power supply specification of the E5ED-B is given in the following location in the model number.

E5ED-

Code	Specification	Power consumption		
Code	Specification	Options No.: 000	Other option numbers	
А	100 to 240 VAC, 50/60 Hz	6.6 VA max.	8.3 VA max.	
D	24 VAC, 50/60 Hz	4.1 VA max.	5.5 VA max.	
	24 VDC (no polarity)	2.3 W max.	3.2 W max.	

#### Terminal Details



<sup>\*</sup> Common terminals are indicated with asterisks (\*). You can use them for crossover wiring. For crossover wiring, do not exceed the maximum number of Digital Controllers given below.

100 to 240 VAC Controllers: 16 max.

24 VAC/VDC Controllers: 8 max.

# **Options**

#### Model Numbers


The options specification of the E5ED-B is given in the following location in the model number.



Code	Specification		
000 or 800	None		
004 or 804	Communications (RS-485), event inputs 1 and 2		
008 or 808	Communications (RS-485), event inputs 1 and 2, and CT1		
010	Event inputs 1, 2, 3, and 4, and CT1		
022	Communications (RS-485), event inputs 1, 2, 3, 4, 5, and 6, transfer output		

#### Terminal Details

Do not connect anything to the terminals that are shaded gray.



Common terminals are indicated with asterisks (\*).

You can use communications common terminals for crossover wiring.

Note: Use non-voltage inputs for the event inputs.

The polarity for a non-contact input is indicated by "(-)."

# 2-2-5 Precautions when Wiring

- Separate input leads and power lines in order to prevent external noise.
- · Use crimp terminals when wiring the screw terminals.
- Use the suitable wiring material and crimp tools for crimp terminals.
- Tighten the terminal screws to a torque of 0.43 to 0.58 N·m.

#### • E5CD or E5ED (models with screw terminal blocks)

#### Wires


Use the wire specifications given in the following table.

Model	Recommended wires	Stripping length
E5CD or E5ED	AWG24 to AWG18 ( 0.205 to 0.823	6 to 8 mm (when crimp terminals are not
	mm <sup>2</sup> )	used)

- Strip the wires on which crimp terminals will be used to the length recommended by the crimp terminal manufacturer.
- Use shielded twisted-pair cables for signal lines to prevent the influence of noise.

#### **Crimp Terminals**

For the E5CD or E5ED, use the following types of crimp terminals for M3 screws.




Although you can connect two crimp terminals with insulation sleeves to one terminal, you cannot do so if the diameter of the insulation sleeves is too large.


# ● E5□D-B (Models with Push-In Plus Terminal Blocks)

### 1. Connecting to the Push-In Plus Terminal Block

· Part Names of the Terminal Block




• Connecting Wires with Ferrules or Solid Wires




If a wire is difficult to connect because it is too thin, use a flat-blade screwdriver in the same way as when connecting stranded wire.

- · Connecting Stranded Wires
  - Use the following procedure to connect the wires to the terminal block.
    - (1) Hold a flat-blade screwdriver at an angle and insert it into the release hole. The angle should be between 10° and 15°. If the flat-blade screwdriver is inserted correctly, you will feel the spring in the release hole.
    - (2) With the flat-blade screwdriver still inserted into the release hole, insert the wire into the terminal hole until it strikes the terminal block.
    - (3) Remove the flat-blade screwdriver from the release hole.



- · Checking Connections
  - · After the insertion, pull gently on the wire to make sure that it will not come off and the wire is securely fastened to the terminal block.
  - To prevent short circuits, insert the stripped part of a stranded or solid wire or the conductive part of a ferrule until it is hidden inside the terminal insertion hole. (See the following diagram.)




#### 2. Removing Wires from the Push-In Plus Terminal Blocks

Use the following procedure to remove wires from the terminal block.

The same method is used to remove stranded wires, solid wires, and ferrules.

- (1) Hold a flat-blade screwdriver at an angle and insert it into the release hole.
- (2) With the screwdriver still inserted into the release hole, remove the wire from the terminal insertion hole.
- (3) Remove the flat-blade screwdriver from the release hole.



# 3. Recommended Wires, Ferrules and Crimp Tools


• Recommended Wires (stranded or solid wires)

Recommended wires	Stripping length (ferrules not used)	
AWG24 to AWG16 (0.25 to 1.5 mm <sup>2</sup> )	8 mm	

#### • Recommended Ferrules

Applicable wire F		Ferrule	Stripping	Recommended ferrules		
(mm <sup>2</sup> )	(AWG)	conductor length (mm)	length (mm) (ferrules used)	Manufactured by Phoenix Contact	Manufactured by Weidmuller	Manufactured by Wago
0.25	24	8	10	AI0,25-8	H0.25/12	FE-0.25-8N-YE
		10	12	AI0,25-10		
0.34	22	8	10	AI0,34-8	H0.34/12	FE-0.34-8N-TQ
		10	12	AI0,34-10		
0.5	20	8	10	AI0,5-8	H0.5/14	FE-0.5-8N-WH
		10	12	AI0,5-10	H0.5/16	FE-0.5-10N-WH
0.75	18	8	10	AI0,75-8	H0.75/14	FE-0.75-8N-GY
		10	12	AI0,75-10	H0.75/16	FE-0.75-10N-GY
1 or	18 or	8	10	Al1-8	H1.0/14	FE-1.0-8N-RD
1.25	17	10	12	Al1-10	H1.0/16	FE-1.0-10N-RD
1.25 or	17 or	8	10	Al1,5-8	H1.5/14	FE-1.5-8N-BK
1.5	16	10	12	Al1,5-10	H1.5/16	FE-1.5-10N-BK
	Recommended crimp tool			CRIMPFOX6 CRIMPFOX6T-F CRIMPFOX10S	PZ6 roto	Variocrimp4


- Note 1: Make sure that the outer diameter of the wire coating is smaller than the inner diameter of the insulation sleeve of the recommended ferrule.
  - 2: Make sure that the ferrule processing dimensions conform to the following figures.



### • Recommended Flat-blade Screwdriver

Use a flat-blade screwdriver to connect and remove wires.

Use the following flat-blade screwdriver.



Model	Manufacturer
ESD 0,40 × 2,5	Wera
SZS 0,4 × 2,5	Phoenix Contact
SZF 0-0,4 × 2,5 *	
$0.4 \times 2.5 \times 75\ 302$	Wiha
AEF.2,5 × 75	Facom
210-719	Wago
SDI 0.4 × 2.5 × 75	Weidmuller

You can purchase the SZF 0-0,4 × 2,5 flat-blade screwdriver made by PHOENIX CONTACT with OMRON model XW4Z-00B.

#### Wiring 2-2-6

In the connection diagrams, the left side of the terminal numbers represents the inside of the Digital Controller and the right side represents the outside.

# Power Supply **Power Consumption**

	E5CD or E5CD-B		E5ED or E5ED-B	
Input Power Supply	Options No.:	Options No.:	Options No.:	Options No.:
	000 or 800	Not 000 or 800	000 or 800	Not 000 or 800
100 to 240 VAC, 50/60 Hz	5.2 VA max.	6.5 VA max.	6.6 VA max.	8.3 VA max.
24 VAC, 50/60 Hz	3.1 VA max.	4.1 VA max.	4.1 VA max.	5.5 VA max.
24 VDC (no polarity)	1.6 W max.	2.3 W max.	2.3 W max.	3.2 W max.

· These models have reinforced insulation between the input power supply, the relay outputs, and other terminals.

### Inputs

Refer to 2-2-1 E5CD Terminal Block Wiring Example, 2-2-2 E5CD-B Terminal Block Wiring Example, 2-2-3 E5ED Terminal Block Wiring Example or 2-2-4 E5ED-B Terminal Block Wiring Example for the terminal arrangement.

When extending the thermocouple lead wires, be sure to use compensating wires that match the thermocouple type. When extending the lead wires of a resistance thermometer, be sure to use wires that have low resistance and keep the resistance of the three lead wires the same.

# Control Outputs 1 and 2

The following diagrams show the applicable outputs and their internal equivalent circuits.

# E5CD

RX (relay output)	QX (voltage output (for driving SSR))	CX (linear current output)
	+V + 1 L 2 - 7777 -	1+1

Output ty	уре	Specification
RX	Relay output	SPST-NO, 250 VAC, 3 A (resistive load), Electrical life:
		100,000 operations
QX	Voltage output (for driving SSR)	PNP, 12 VDC ±20%, 21 mA (with short-circuit protection)
CX	Linear current output	4 to 20 mA DC or 0 to 20 mA DC with load of 500 $\Omega$ max.,
		Resolution: 10,000

# E5CD-B

RX (relay output)	QX (voltage output (for driving SSR))	CX (linear current output)
	+V + L - 2	+V + L

Output type		Specification
RX	Relay output	SPST-NO, 250 VAC, 3 A (resistive load), Electrical life:
		100,000 operations
QX	Voltage output (for driving SSR)	PNP, 12 VDC ±20%, 21 mA (with short-circuit protection)
CX	Linear current output	4 to 20 mA DC or 0 to 20 mA DC with load of 500 $\Omega$ max.,
		Resolution: 10,000

# E5ED

RX (relay output)	QX (voltage output (for driving SSR))	CX (linear current output)	RR (2 relay outputs)	QR (voltage output (for driving SSR) and relay output)
3	†V 3 + L 4	3+ L	3 4 5 6	†V 3 + L - S 6 6

Output t	уре	Specification
RX	Relay output	SPST-NO, 250 VAC, 5 A (resistive load), Electrical life:
		100,000 operations
QX	Voltage output (for driving SSR)	PNP, 12 VDC ±20%, 40 mA (with short-circuit protection)
CX	Linear current output	4 to 20 mA DC or 0 to 20 mA DC with load of 500 $\Omega$ max.,
		Resolution: 10,000
RR	2 relay outputs	SPST-NO, 250 VAC, 5 A (resistive load), Electrical life:
		100,000 operations
QR	Voltage output (for driving SSRs)	PNP, 12 VDC ±20%, 21 mA (with short-circuit protection)
	(control output 1)	
	Relay output (control output 2)	SPST-NO, 250 VAC, 5 A (resistive load), Electrical life:
		100,000 operations

# E5ED-B

RX (relay output)	QX (voltage output (for driving SSR))	CX (linear current output)	RR (2 relay outputs)	QR (voltage output (for driving SSR) and relay output)
(5) (6)	†V † 5 † L	5 + L	(5) (6) (7) (8) (8) (1) (1) (1) (1) (1) (1) (1) (1) (1) (1	+ + + + + + + + + + + + + + + + + + +

Output t	уре	Specification
RX	Relay output	SPST-NO, 250 VAC, 5 A (resistive load), Electrical life:
		100,000 operations
QX	Voltage output (for driving SSR)	PNP, 12 VDC ±20%, 40 mA (with short-circuit protection)
CX	Linear current output	4 to 20 mA DC or 0 to 20 mA DC with load of 500 $\Omega$ max.,
		Resolution: 10,000
RR	2 relay outputs	SPST-NO, 250 VAC, 5 A (resistive load), Electrical life:
		100,000 operations
QR	Voltage output (for driving SSRs)	PNP, 12 VDC ±20%, 21 mA (with short-circuit protection)
	(control output 1)	
	Relay output (control output 2)	SPST-NO, 250 VAC, 5 A (resistive load), Electrical life:
		100,000 operations

# Auxiliary Outputs 1 to 4

- When heating/cooling control is selected for the E5CD or E5CD-B, auxiliary output 2 is assigned as the control output for cooling.
- If heating/cooling control is selected for the E5ED or E5ED-B when there is only one control output, the auxiliary output 4 terminal is assigned as the control output for cooling. (However, if the Digital Controller has two auxiliary outputs, auxiliary output 2 is the cooling control output.)

### Event Inputs

Models with an option number of 001, 004, 006, 008, 010, 022, 804 or 808 have one or more event inputs.

#### E5CD

Contact inputs	Non-contact inputs
Option number: 001 or 006	
13 ← EV1 15 ← EV2	13 EV1 14 EV2
Option number: 004 or 804	
16 ← EV3 18 ← EV4	16 - EV3 17 + EV4


# E5CD-B

Contact inputs	Non-contact inputs
Option number: 001 or 006	
17 EV2	17 - EV1   EV2   EV2
Option number: 004 or 804	
21 EV3 EV4	21 — ———————————————————————————————————

# E5ED

Contact inputs	Non-contact inputs
Option number: 004, 008 or 808	
16 ← EV1 18 ← EV2	EV1 (B) EV2
Option number: 010	
13 ← EV3 15 ← EV4 16 ← EV1 18 ← EV2	EV3  EV4  EV1  EV2
Option number: 022	
28 ← EV5 17 ← EV1 30 ← EV6 18 ← EV2	28 - EV5 16 - EV1 29 + EV6 18 + EV2

#### E5ED-B



- Use non-voltage inputs for the event inputs.
- Use event inputs under the following conditions: The outflow current is approximately 7 mA.

Contact input ON: 1 k $\Omega$  max., OFF: 100 k $\Omega$  min.

No-contact input ON: Residual voltage of 1.5 V max.; OFF: Leakage current of 0.1 mA max.


#### CT Inputs

Models with an option number of 001, 002, 008, 010, 802 or 808 have one or more CT inputs.


#### Transfer Output

Models with an option number of 006 or 022 have a transfer output.


#### E5CD




#### E5CD-B



### E5ED



#### E5ED-B



Output type	Specification
Linear current output	4 to 20 mA DC, Load: 500 $\Omega$ max., Resolution: 10,000
Linear voltage output	1 to 5 VDC, Load: 1 kΩ min., Resolution: 10,000

#### Communications


#### **RS-485**

Models with an option number of 002, 008, 802 or 808 support RS-485.


To use communications with the E5CD or E5ED, connect the communications cable to terminals 13 and 14, with the E5CD-B or E5ED-B, to terminals 17 or 18 and 19 or 20.

#### **Communications Unit Connection Diagram**

#### E5□D




E5□D-B



• The RS-485 connection can be either one-to-one or one-to-N. A maximum of 32 Units (including the host computer) can be connected in one-to-N systems.

The maximum total cable length is 500 m. Use shielded twisted-pair cable.




# 2-3 **Installing Temperature Sensors for Packing Machines**

A Temperature Sensor for Packing Machines\*1 has a diameter of 1.0 mm and it is embedded in a heating plate. It has superior heat resistance and flexibility.

Refer to 5-1 Suppressing Temperature Variations When Using a Temperature Sensor for Packing Machines (for Packing Machines) for general information.


To measure the temperature close to the seal surface, mount the Sensor as close as possible to the surface.



- The specifications of E52-series Temperature Sensors for Packing Machines and mounting brackets are provided as an appendix.
- \*2 Models with ferrules are available.

# The following installation methods are assumed.


Example 1: Groove for Temperature Sensor created in heating plate and Temperature Sensor secured with mounting brackets.



#### **Insulation Block Diagrams** 2-4

The insulation block diagrams are provided in this section.

#### ● E5CD/E5CD-8□□/E5ED-8□□/E5ED-B-8□□



#### ● E5CD-B/E5CD-B-8□□

Power supply	Sensor input and CT input	
	Communications and event inputs	
	Voltage output (for driving SSRs), linear current output, and transfer output	
	Relay output	
	Auxiliary outputs 1 and 2	
	: Reinforced insulation	
	: Functional isolation	

#### ● E5ED/E5ED-B

Power supply	Sensor input and CT input		
	Communications and event inputs  Voltage output (for driving SSRs),  linear current output, and transfer output		
	Relay output 1		
	Relay output 2		
	Auxiliary outputs 1 and 2		
	Auxiliary outputs 3 and 4		
_	: Reinforced insulation		
	: Functional isolation		

# 2-5 Using the Setup Tool Port 000

Use one of the Setup Tool ports to connect the computer to the Digital Controller when using the CX-Thermo (EST2-2C-MV4 or later) or other Support Software.

The E58-CIFQ2 USB-Serial Conversion Cable<sup>\*1</sup> is required for the connection. For information on the models that can be used with CX-Thermo, contact your OMRON sales representative.

\*1 The E58-CIFQ2-E is required to connect to the Setup Tool port on the front panel of the E5ED or E5ED-B.

#### 2-5-1 Procedure

When the USB-Serial Conversion Cable is connected to the Digital Controller, the following operations are possible even if the power supply to the Digital Controller is not turned ON.

- Setting up the Digital Controller from a computer (Special software is required.)
- · Changing settings by using key operations on the Digital Controller
- · Displaying the current temperature on the Digital Controller

The control outputs, alarm outputs, transfer output, event inputs, and external communications for the Digital Controller will not operate unless the power supply to the Digital Controller is turned ON.


#### 2-5-2 Connection Method

Use the E58-CIFQ2 USB-Serial Conversion Cable to connect the E5□D to the computer. The USB-Serial Conversion Cable is used to communicate with a USB port on a computer as a virtual COM port.

#### E5CD/E5CD-B


#### Setup Tool Port and Connecting Cable

The location of the Setup Tool port on the E5CD or E5CD-B and the required cable are shown below.



#### **Connection Procedure**


Connect the serial connector on the USB-Serial **Conversion Cable to the** Setup Tool port on the top panel of the Digital Controller.



# E5ED/E5ED-B

#### Setup Tool Ports and Connecting Cables


The location of the Setup Tool port on the E5ED or E5ED-B and the required cable are shown below. There are Setup Tool ports on both the top panel and front panel of the Digital Controller.



This Cable is required only to connect to the front-panel Setup Tool port.


#### Connection Procedure

- · Top-panel Port
- Connect the serial connector to the Setup Tool port on the top panel of the Digital Controller.




Front-panel Port

1 Connect the E58-CIFQ2
USB-Serial Conversion Cable
to the E58-CIFQ2-E
Conversion Cable.



2 Remove the Port Cover from the front-panel Setup Tool port, and then plug in the Conversion Cable.





#### **Precautions for Correct Use**

- Hold the connector when inserting or disconnecting the Cable.
- When connecting a connector, always make sure that it is oriented correctly. Do not force the
  connector if it does not connect smoothly. Connectors may be damaged if they are connected
  with excessive force.
- Do not connect cables to both of the Setup Tool ports at the same time. The Digital Controller may be damaged or may malfunction.

#### 2-5-3 Installing the Driver

1. Connect a USB connector on the computer with a Setup Tool port on the Digital Controller using the Cable or Cables.

#### 2. Obtaining the Driver

When the CX-Thermo Support Software for the Digital Controller is installed, the driver for the USB-Serial Conversion Cable will be copied to the following folder.

C:\Program Files\OMRON\Drivers\USB\E58-CIF

#### 3. Installing the Driver

Install the driver to enable the Cable to be used with the personal computer.

Installation

When the Cable is connected with the personal computer, the OS will detect the product as a new device. At this time, install the driver using the Installation Wizard.

Note 1: We recommend that you install the driver for each USB port on the computer at the start. The Digital Controller assigns a COM port number to each USB port on the computer. If the same USB port is used, you will be able to use the same COM port number even if you use a different Cable.

2: Installation of the driver will not be completed if the installation is canceled before it is completed. Normal communications will not be possible unless the driver is installed completely. If the driver is not installed completely, uninstall it, and then install it correctly.

#### 4. Setting Setup Tool Communications Conditions

Set the communications port (COM port) number to be used for the CX-Thermo Setup Tool to the COM port number assigned to the USB-Serial Conversion Cable.

Refer to the E58-CIFQ2 USB-Serial Conversion Cable Instruction Manual and Setup Manual for details on how to check the COM port assigned to the USB-Serial Conversion Cable.

The communications conditions for Setup Tool COM ports are fixed as shown in the table below. Set the communications conditions for the CX-Thermo Setup Tool according to the following table

Parameter	Set value
Communications Unit No.	01
Communications baud rate	38.4 (kbps)
Communications data length	7 (bits)
Communications stop bits	2 (bits)
Communications parity	Even




# **Part Names and Basic Procedures**

3-1	Basic	Flow of Operation	3-2
3-2	Powe	r ON	3-3
3-3	Part N	lames, Part Functions, and Setting Levels	3-4
		Part Names and Functions	
	3-3-2	Entering Numeric Values	. 3-7
	3-3-3	Setting Levels	. 3-8
3-4	Proce	dures after Turning ON the Power Supply	3-11
	3-4-1	Basic Flow of Operations	3-11
	3-4-2	Basic Procedure	3-11

# **Basic Flow of Operation**

The following figure shows the basic flow for operating the Digital Controller.



# 3-2 Power ON

Operation will start as soon as you turn ON the power supply to the E5 D.\*

\* With the E5□D, you can set the Operation After Power ON parameter to change the operation that is performed when the power supply is turned ON. For details, refer to *5-25 Setting the Operating Status to Use When Power Is Turned ON*.


The following default settings will be used when operation starts.

- Input type 5: K thermocouple
- PID control operation
- Alarm: Upper-limit alarm\*
- Set point: 0°C

\* If the Controller is equipped with HB/HS alarm detection, the default setting for the Auxiliary Output 1 Assignment is for heater alarms. Therefore, the alarm 1 function is disabled and the Alarm 1 Type is not displayed. To enable alarm 1, set an output assignment to alarm 1.

After the power comes ON, all indicators and displays will light for approximately 1 second, and then the operation display will appear.


The top display will show the PV and the bottom display will show the SP.




# Part Names, Part Functions, and 3-3 **Setting Levels**

#### 3-3-1 **Part Names and Functions**

# E5CD/E5CD-B



# E5ED/E5ED-B



# Displays

Name	Description	
No. 1 display	Displays the process value or a monitor/setting item.	
No. 2 display	Displays the set point or the value of a monitor/setting item.	
No. 3 Display (E5ED and E5ED-B only)	Displays the manipulated variable, remaining soak time, multi-SP No., internal SP (ramp SP), or alarm value 1. (The value that is displayed is set in the PV/SP Display Selection parameter in the Advanced Function Setting Level.)	
Temperature unit	Displays the temperature unit ( ${}^{\circ}\!\mathcal{L}$ or ${}^{\circ}\!\mathcal{F}$ ).	

# Indicators

<b>Operation indicators</b>	Name	Description
SUB1 SUB2 SUB3 SUB4	Auxiliary outputs 1 to 4 (Only the E5ED and E5ED-B have auxiliary outputs 3 and 4.)	Each indicator lights when the function that is assigned to corresponding auxiliary output (1 to 4) is ON.
OUT1 OUT2	Control outputs 1 and 2 (Only the E5ED and E5ED-B have control output 2.)	Each indicator lights when the function that is assigned to corresponding control output (1 or 2) is ON. (For a linear current output, the indicator is not lit for values below 0%.)
CMW	Communications writing	This indicator lights when wiring with communications is enabled.
MANU	Manual	This indicator is lit in Manual Mode.
STOP	Stop	This indicator is lit while operation is stopped.
TUNE	AT execution in progress	This indicator is lit during autotuning.
Α	Adaptive control in progress	This indicator is flashing or lit during adaptive control.
	Bar display	This bar display indicates the manipulated value or heater current.
Оп	Setting change protection	This indicator is lit while setting change protection is ON.

# Keys

Key	Name	Overview	Description
	Level Key	Selects the setting level.  The next setting level depends on how long the key is pressed.	<ul> <li>In Operation Level</li> <li>Press once for less than 1 second to go to Adjustment Level.</li> <li>Press for at least 3 seconds to go to Initial Setting Level.</li> <li>In Adjustment Level</li> <li>Press once for less than 1 second to go to Operation Level.</li> <li>Press for at least 3 seconds to go to Initial Setting Level.</li> <li>In Initial Setting Level</li> <li>Press for at least 1 second to go to Operation Level.</li> </ul>
Q	Mode Key	Changes the parameter that is displayed within a setting level.	<ul><li>Press once to go to the next parameter.</li><li>Hold to go to the previous parameter.</li></ul>
<b>≫</b>	Down Key and Up Key	Set the value.	<ul> <li>Hold the key to increment or decrement the value quickly.</li> <li>Any changes in settings are applied at the following times: <ul> <li>After 3 seconds elapse</li> <li>When the  Key is pressed</li> <li>When the level is changed with the  Key</li> </ul> </li> </ul>
<b>《PF</b> )	Shift Key (PF Key)	Operates as a user-defined function key.	<ul> <li>Press the Press the Press than 1 second to select the digit to change. The key operates as a Shift Key to change the digit by one digit every time you press the key (default setting).</li> <li>You can change the Presetting parameter in the Advanced Setting Level to assign any of the following functions to the Press Key.  Run/stop, auto/manual, autotune, cancel alarm latch, display monitor/setting item, digit shift (default), PID update (adaptive control), automatic filter adjustment, or water-cooling output adjustment</li> <li>Example: If you set the Presetting parameter in the Advanced Setting Level to 5 £ a P, operation will be stopped when you press the Presetting items), each time you press the Presetting items), each time you press the Presetting items and the second, the display is changed in order for the items that are set for the Monitor/Setting Item 1 to 5 parameters.</li> </ul>

# Setup Tool Ports 000

Setup Tool port	Name	Description
	Setup Tool port (card edge type)	Use the E58-CIFQ2 USB-Serial Conversion Cable to connect the E5□D to the computer (i.e., the CX-Thermo Support Software). E5CD, E5ED, E5CD-B, or E5ED-B: On top panel
	Setup Tool port (pin jack)	Use the E58-CIFQ2 USB-Serial Conversion Cable and the E58-CIFQ2-E Conversion Cable to connect the E5ED or E5ED-B to the computer (i.e., the CX-Thermo Support Software).  E5ED or E5ED-B: On front panel

### 3-3-2 Entering Numeric Values

# **Applying Changes to Numeric Values**

After you change a numeric value with the 🔊 🗷 Keys, the changes are applied 1) when 3 seconds elapses, 2) when the 😨 Key is pressed, or 3) when the level is changed with the 🖾 Key.



#### **Precautions for Correct Use**

Always make sure that any changes to numeric values are applied for one of the three methods that are given above before you turn OFF the power supply to the E5\_D.

If you only change the values with the SK Keys and turn OFF the power supply before 3.


If you only change the values with the  $ext{ } ext{ } ext{$ 

# Moving between Digits (Digit Shift Key)

Press the Shift Key (PF Key) to select the digit to change.

This is useful when entering a numeric value with many digits.

Use this key to change levels: The digit to change will move as follows: 1s digit, 10s digit, 100s digit, 1000s digit, and then back to the 1s digit. Press the ♠ + ❤ Keys to change the value of a digit.




#### 3-3-3 **Setting Levels**

On the E5DD, the parameters are classified into levels according to their applications. These levels are called setting levels. The setting levels consist of some basic setting levels and other setting levels.

# Moving between Setting Levels

The following figure gives an overall image of the setting levels. The setting levels consist of the basic setting levels (shaded below) and the other setting levels (not shaded).

The Initial Setting Level, Communications Setting Level, Advanced Function Setting Level, and Calibration Level can be used only when control is stopped. If you change to any of these levels, control will stop.



- \*1 Set the Auto/Manual Select Addition parameter to ON and set the PF Setting parameter to A-M (Auto/Manual).
- \*2 The No. 1 display will flash when the keys are pressed for 1 s or longer.
- \*3 Set the PF Setting parameter to PF dP (monitor/setting items).

# **Basic Setting Levels**

#### Operation Level

This level is displayed automatically when the power supply is turned ON.

This level is used for the SP, alarm values, and other basic settings and monitoring.

Normally, select this level for operation.

#### Adjustment Level

This level is used to set the PID constants and to perform tuning, such as autotuning.

In Adjustment Level, the settings of the parameters can be changed during operation. This is not possible in the Initial Setting Level or Advanced Function Setting Level.

#### Initial Setting Level

This level is used for the most basic settings.

It is used to set the input type and other parameters.

Use it to set the input type, alarm type, and other basic settings.

#### Advanced Function Setting Level


This level is used for advanced settings.

Use it to assign functions to the control outputs and auxiliary outputs.

You will not be able to enter the Advanced Function Setting Level with the default settings.

To enter the Advanced Function Setting Level, first disable Initial Setting/Communications Protection and then enter the password (–169) at the PMaV (Move to Advanced Function Setting Level) parameter in the Initial Setting Level.

Use the following procedure to move to Advanced Function Setting Level.



Step 2: Change the parameter with the  $\ \ \ \$  Key and change the setting of the  $\ \ \ \$   $\ \$  parameter to 0.



Step 1: Move to Protect Level.

Step 2: Display LEPE (Initial Setting/Communications Protect) and set it to 0.

Step 3: Return to Operation Level.

Step 4: Return to Initial Setting Level.

Step 5: Display AMaV (Move to Advanced Function Setting Level) and then enter –169.

Steps 1 to 3 are necessary only the first time. Perform only steps 4 and 5 to move to Advanced Function Setting Level.

# Other Setting Levels

There are five other setting levels: Manual Control Level, Protect Level, Communications Setting Level, Calibration Level, and Monitor/Setting Item Level.

#### Manual Control Level

This level is used to set the MV manually. With the default settings, you cannot move to the Manual Control Level.

- To use the F Key to move to the Manual Control Level, change the setting of the PF Setting parameter to R-M.
- You can use the Level Key on the Auto/Manual Switch Display to move to the Manual Control
- To use an event input to move to the Manual Control Level, change the setting of the Event Input Assignment 1 to 6 parameter to MRNU.

#### Protect Level

This level is used to restrict the operations that can be performed and the parameters that can be displayed with the front-panel keys. For example, you can prohibit changing the SP and other parameters in the Operation Level and Adjustment Level. You can move to the Protect Level from the Operation Level or the Adjustment Level. To move to the Advanced Function Setting Level, you must first cancel the protection that is set in the Protect Level.

#### Communications Setting Level

This level is used to set the communications parameters. You can move to the Communications Setting Level from the Initial Setting Level.

#### Calibration Level

This level is used to calibrate the Digital Controller. You can move to the Calibration Level from the Advanced Function Setting Level.


#### Monitor/Setting Item Level

To use the F Key to display the Monitor/Setting Items, change the setting of the PF Setting parameter to PFdP. The items that will be displayed in the Monitor/Setting Item Level are set using the Monitor/Setting Item 1 to 5 parameters.

# 3-4 Procedures after Turning ON the Power Supply

#### 3-4-1 Basic Flow of Operations

The basic flow of operations after you turn ON the power supply is shown below.



#### 3-4-2 Basic Procedure

The basic procedure is given below.


**1** Turn ON the power supply.





-5.ERR (input error) flashes on the display if a sensor is not connected or if the connected sensor is different from input type. Connect a sensor if one is not already connected.

# **2** Set the input type.





# **List of Input Types**

	Input type	Specifications	Set value	Temperature range in °C	Temperature range in °F
	Resistance	Pt100	0	-200 to 850	-300 to 1500
	thermometer		1	-199.9 to 500.0	-199.9 to 900.0
			2	0.0 to 100.0	0.0 to 210.0
		JPt100	3	-199.9 to 500.0	-199.9 to 900.0
			4	0.0 to 100.0	0.0 to 210.0
	Thermocouple	K	5	-200 to 1300	-300 to 2300
			6	-20.0 to 500.0	0.0 to 900.0
		J	7	-100 to 850	-100 to 1500
			8	-20.0 to 400.0	0.0 to 750.0
_		Т	9	-200 to 400	-300 to 700
ndı			10	-199.9 to 400.0	-199.9 to 700.0
Temperature input		E	11	-200 to 600	-300 to 1100
atul		L	12	-100 to 850	-100 to 1500
per		U	13	-200 to 400	-300 to 700
em			14	-199.9 to 400.0	-199.9 to 700.0
Ė		N	15	-200 to 1300	-300 to 2300
		R	16	0 to 1700	0 to 3000
		S	17	0 to 1700	0 to 3000
		В	18	0 to 1800	0 to 3200
		C/W	19	0 to 2300	0 to 3200
		PLII	20	0 to 1300	0 to 2300
	Infrared	10 to 70°C	21	0 to 90	0 to 190
	temperature	60 to 120°C	22	0 to 120	0 to 240
	sensor ES1B	115 to 165°C	23	0 to 165	0 to 320
		140 to 260°C	24	0 to 260	0 to 500
=	Current input	4 to 20 mA	25	One of the following ranges	according to the scaling:
ndı		0 to 20 mA	26	-1999 to 9999	
Analog input	Voltage input	1 to 5 V	27	-199.9 to 999.9	
Jak		0 to 5 V	28	-19.99 to 99.99	
Ā		0 to 10 V	29	-1.999 to 9.999	

The default is 5.

# 3 Set the control method.






If  $P\bar{L}d$  (PID control) is displayed, press the 8 (Down) Key to change to  $\bar{a}N\bar{a}F$ 

(ONOF) (ON/OFF control).

# Set the alarm type.




If the Digital Controller is equipped with HB/HS alarm detection, the Alarm 1 Type is not displayed for the default settings. To use alarm 1, set an output assignment to alarm 1. For details, refer to 4-6-3 Assigned Output Functions.

If required, use the @ (Mode) Key and the @ (Up) and W (Down) Keys to repeat the procedure to set alarm types for RLE2 (ALT2) (Alarm 2 Type), RLE3 (ALT3) (Alarm 3 Type), and RLE4 (ALT4) (Alarm 4 Type). (The number of alarms that is supported depends on the model of Digital Controller. Some of the alarm parameters may not be displayed.)

When you are finished, press the (Level) Key for at least 1 second to return to the operation display.


# **Alarm Type Numbers**

Set value	Alarm type	Description	Operation
<u> </u>	Alarm function OFF	There will be no alarm outputs.	
I	Upper- and lower-limit alarm	The alarm output is ON while the PV is equal to or higher than the upper-limit alarm point or while the PV is equal to or lower than the lower-limit alarm point.	Example:  ON  OFF  Lower-limit alarm Set point Upper-limit alarm point (e.g., 80°C) (e.g., 100°C) point (e.g., 130°C)  Alarm value lower Alarm value upper limit (e.g., 20°C) limit (e.g., 30°C)
2	Upper-limit alarm	The alarm output is ON while the PV is equal to or higher than the upper-limit alarm point.	Example:  ON  OFF  Set point Upper-limit alarm (e.g., 100°C) point (e.g., 120°C)  Alarm value upper limit (e.g., 20°C)
3	Lower-limit alarm	The alarm output is ON while the PV is equal to or lower than the lower-limit alarm point.	Example:  ON  OFF  Lower-limit alarm point Set point (e.g., 80°C) (e.g., 100°C)  Alarm value lower limit (e.g., 20°C)
Ч	Upper- and lower-limit range alarm	The alarm output is ON while the PV is equal to or lower than the upper-limit alarm point or equal to or higher than the lower-limit alarm point.	Example:  ON  OFF  Lower-limit alarm Set point Upper-limit alarm point (e.g., 80°C) (e.g., 100°C) point (e.g., 130°C)  Alarm value lower Alarm value upper limit (e.g., 20°C) limit (e.g., 30°C)
5	Upper- and lower-limit alarm with standby sequence	This alarm provides a standby sequence. The alarm output is ON while the PV is equal to or higher than the upper-limit alarm point or while the PV is equal to or lower than the lower-limit alarm point.	Example:  ON  OFF  Lower-limit alarm Set point Upper-limit alarm point (e.g., 80°C) (e.g., 100°C) point (e.g., 130°C)  Alarm value lower Alarm value upper limit (e.g., 20°C) limit (e.g., 30°C)
Б	Upper-limit alarm with standby sequence	This alarm provides a standby sequence. The alarm output is ON while the PV is equal to or higher than the upper-limit alarm point.	Example:  ON  OFF  Set point Upper-limit alarm (e.g., 100°C) point (e.g., 120°C)  Alarm value upper limit (e.g., 20°C)
<u>u</u>	Lower-limit alarm with standby sequence	This alarm provides a standby sequence. The alarm output is ON while the PV is equal to or lower than the lower-limit alarm point.	Example:  ON  OFF  Lower-limit alarm point Set point (e.g., 80°C) (e.g., 100°C)  Alarm value lower limit (e.g., 20°C)



Set value	Alarm type	Description	Operation
13	PV change rate alarm	The alarm output turns ON if the change in the PV within the specified calculation period exceeds a specific width.	PV Change rate width  PV rate of change calculation period  PV Change Rate Alarm Output  ON  OFF  Time  The PV rate of change calculation period and the alarm value are set in parameters.
14	SP absolute-value upper-limit alarm	The alarm output is ON while the SP is equal to or higher than the alarm value.	Example:  ON  OFF  Upper-limit alarm point (e.g., 100°C)  Alarm value (e.g., 100°C)
15	SP absolute-value lower-limit alarm	The alarm output is ON while the SP is equal to or lower than the alarm value.	Example:  ON  OFF    Lower-limit alarm point (e.g., 100°C)  Alarm value (e.g., 100°C)
16	MV absolute-value upper-limit alarm	The alarm output is ON while the MV is equal to or higher than the alarm value.	Example for Standard Control:  ON  OFF  Upper-limit alarm point (e.g., 60%)  Alarm value (e.g., 60%)
IΠ	MV absolute-value lower-limit alarm	The alarm output is ON while the MV is equal to or lower than the alarm value.	Example for Standard Control:  ON  OFF  O  Lower-limit alarm point (e.g., 80%)  Alarm value (e.g., 80%)

# Set the set point.




\*Hold the 

(Up) or 

(Down) Key to increment or decrement the value quickly.

#### Set the alarm set value or values.

Change the parameter that is displayed with the (2) (Mode) Key.



This concludes the procedure to set the input type, alarm type, control method, set point, and alarm set values. For information on the settings of the ON/OFF hysteresis, PID constants, HS alarm, HS alarm, and other parameters, refer to Section 4 Basic Operation or Section 5 Advanced Operations.



# **Basic Operation**

4-1	Moving between Setting Levels  4-1-1 Moving to the Initial Setting Level  4-1-2 Moving to the Adjustment Level  4-1-3 Moving to the Protect Level  4-1-4 Moving to the Advanced Function Setting Level  4-1-5 Moving to the Communications Setting Level	4-3 4-4 4-4
4-2	Initial Setting Examples	4-8
4-3	Setting the Input Type	
4-4	Selecting the Temperature Unit	
4-5	Selecting PID Control or ON/OFF Control	4-14
4-6	Setting Output Specifications  4-6-1 Control Period  4-6-2 Direct and Reverse Operation  4-6-3 Assigned Output Functions  4-6-4 Auxiliary Output Opening or Closing in Alarm	4-15 4-15 4-16
4-7	Setting the Set Point (SP)	
4-8	Using ON/OFF Control 4-8-1 ON/OFF Control 4-8-2 Settings	4-2 <sup>-</sup>
4-9	Determining PID Constants (AT, Manual Setup)	
4-10	4-10-1       Alarm Types         4-10-2       Alarm Values	4-3 <sup>-</sup>

# 4-1 Moving between Setting Levels

The Operation Level is displayed first when the power supply to the Digital Controller is turned ON. To display the parameters, you must move to the following setting levels.

- Operation Level (Entered when the power supply is turned ON.)
- Initial Setting Level
- · Adjustment Level
- Protect Level
- · Advanced Function Setting Level
- · Communications Setting Level

The procedures to move between the setting levels starting from the Operation Level are provided below.

# 4-1-1 Moving to the Initial Setting Level

# Moving from the Operation Level to the Initial Setting Level

1 Press the Key for at least 3 seconds in the Operation Level.

The No. 1 display will flash when the key is pressed for 1 s or longer.

The display will change from the Operation Level to the Initial Setting Level.

Operation Level



Initial Setting Level

# Moving from the Initial Setting Level to the Operation Level

1 Press the Key for at least 1 second in the Initial Setting Level.

The display will change from the Initial Setting Level to the Operation Level.

Initial Setting Level

Operation Level

#### Moving to the Adjustment Level 4-1-2

# Moving from the Operation Level to the Adjustment Level

Press the Key for less than 1 second in the Operation Level.

Operation Level П

The display will change from the Operation Level to the Adjustment

Adjustment Level



Level.

L.Add will be displayed only once when you move to the Adjustment

# Moving from the Adjustment Level to the Operation Level

Press the Key for less than 1 second in the Adjustment Level.

Adjustment Level

0.0

Process Value Input Shift

The display will change from the Adjustment Level to the Operation Level.

Operation Level



#### 4-1-3 Moving to the Protect Level

# Moving from the Operation Level to the Protect Level

Press the and Keys simultaneously for at least 3

seconds\* in the Operation Level. The No. 1 display will flash when the keys are pressed for 1 s or

longer. The key pressing time can be changed in the Move to Protect Level Operation Level



Time parameter in the Advanced Function Setting Level.

The display will change to the Protect Level.

Protect Level



Operation/ Adjustment

# Moving from the Protect Level to the Operation Level

Press the and Keys simultaneously for at least 1 second in the Protect Level.

Protect Level



The display will change from the Protect Level to the Operation Level.

Operation Level



### 4-1-4 Moving to the Advanced Function Setting Level

# Moving to the Advanced Function Setting Level for the First Time (i.e., with the Default Settings)

To enter the Advanced Function Setting Level, you must first enter the Protect Level and change the setting of the  $\bar{L}EPE$  (Initial Setting/Communications Protect) parameter to  $\bar{U}$  (enable moving to Advanced Function Setting Level) to clear the protection.

#### Clearing Protection

1	Press the  and  Keys simultaneously for at least 3	Operation Level
	seconds* in the Operation Level.	25
	The No. 1 display will flash when the key is pressed for 1 s or	
	longer.	
	* The key pressing time can be changed in the Move to Protect Level Time parameter in the Advanced Function Setting Level.	
	The display will change to the Protect Level.	
2	Press the	Protect Level
	<b>parameter.</b> The display will change to the Initial Setting/Communications Protect parameter.	Operation/ Adjustment Protect
3	Press the  or  Key at the Initial Setting/Communications  Protect parameter to change the set value to 0 (enable moving	Initial Setting/ Communications Protect
	to Advanced Function Setting Level).	Protect
	Now the AMav (Move to Advanced Function Setting Level)	f: Moving to Advanced
	parameter can be displayed in the Initial Setting Level.	Function Setting
	The default is <i>l</i> (disable moving to Advanced Function Setting Level).	Level is disabled.
4	Press the  and  Keys simultaneously for at least 1 second	Protect Level
-	in the Protect Level.	Initial Setting/ Communications Protect
	The display will change from the Protect Level to the Operation	Operation Level
	Level.	PV/SP

# Moving to the Advanced Function Setting Level after Clearing **Protection**

After you have set the LLPL (Initial Setting/Communications Protect) parameter to  $\mathcal{U}$  (enable moving to Advanced Function Setting Level), select AMak (Move to Advanced Function Setting Level) in the Initial Setting Level.

#### Moving to the Advanced Function Setting Level


1	Press the  Key for at least 3 seconds in the Operation Level. The No. 1 display will flash when the key is pressed for 1 s or longer. The display will change from the Operation Level to the Initial Setting Level.	Operation Level
2	Press the  Key several times in the Initial Setting Level (or hold it down to move through the parameters in reverse) to display the Move to Advanced Function Setting Level parameter.  The display will change to  Mar (Move to Advanced Function Setting Level).	Initial Setting Level Input Type
3	Press the → and  Keys at the Move to Advanced Function  Setting Level parameter and then enter - 159.  * You can hold the (Up) or (Down) Key to increment or decrement the set value quickly.	Initial Setting Level  Move to Advanced Function Setting Level
4	Press  Key once or wait for 2 seconds or longer without doing anything.	Move to Advanced Function Setting Level -169: Password to move to Advanced Function Setting Level
	The display will change to the Advanced Function Setting Level.	Advanced Function Setting Level Parameter Initialization

#### Moving from the Advanced Function Setting Level to the Operation Level

1	Press the  Key for at least 1 second in the Advanced Function Setting Level.  The display will change from the Advanced Function Setting Level to the Initial Setting Level.	Advanced Function Setting Level  LINLL  GFF
2	Press the   Key for at least 1 second in the Initial Setting Level.	Initial Setting Level Input Type 5
	The display will change from the Initial Setting Level to the Operation Level.	Operation Level

# 4-1-5 Moving to the Communications Setting Level

#### Moving from the Operation Level to the Communications Setting Level




#### • Moving from the Communications Setting Level to the Operation Level

1	Press the  Key for at least 1 second in the Communications	Communications Setting Level
	Setting Level.  The display will change from the Communications Setting Level to the Initial Setting Level.	PSEL EWF
		Operation Level
		<b>25</b> PV/SP

# **Initial Setting Examples**

Initial hardware setup, including the sensor input type, alarm types, control periods, and other settings, is done using parameter displays. The one and keys are used to switch between parameters, and the amount of time that you press the keys determines which parameter you move to. This section describes three typical examples.

# **Explanation of Examples**




A image means that there are parameters. Continue pressing the Key several times to change parameters until you reach the intended parameter.

**Changing Numbers** 



# **Example 1**




\* If the Controller is equipped with HB/HS alarm detection, the default setting for the Auxiliary Output 1 Assignment is for heater alarms. Therefore, the alarm 1 function is disabled and the Alarm 1 Type is not displayed. To enable alarm 1, set an output assignment to alarm 1. For details, refer to 4-6-3 Assigned Output Functions.



#### **Additional Information**

If you go past the desired parameter, hold down the  $\ \ \$  Key to move through the parameters in reverse.

# **Example 2**



If the Controller is equipped with HB/HS alarm detection, the default setting for the Auxiliary Output 1 Assignment is for heater alarms. Therefore, the alarm 1 function is disabled and the Alarm 1 Type is not displayed. To enable alarm 1, set an output assignment to alarm 1. For details, refer to 4-6-3 Assigned Output Functions.

# 4-3 Setting the Input Type

The Digital Controller supports four input types: resistance thermometer, thermocouple, infrared temperature sensor, and analog inputs. Set the input type that matches the sensor that is used.

# 4-3-1 Input Type

The following example shows how to set a K thermocouple for -20.0 to  $500.0^{\circ}$ C (input type 6).

# **Operating Procedure**

Press the  $\bigcirc$  Key for at least 3 seconds to move from the Operation Level to the Initial Setting Level. The  $\bar{L}N-\bar{L}$  (Input Type) parameter will be displayed.

Initial Setting Level

Input Type

**2** Press the ♠ or ❤ Key to select 5 (K thermocouple at –20.0 to 500.0°C).

IN-E

The default is 5 (5: K thermocouple at -200 to 1,300°C).



#### **Additional Information**

Changes that are made with key operations are applied when the or real Key is pressed. They are also applied if you do nothing for 3 seconds or longer.

# **List of Input Types**

		Specifications	Set value	Temperature range in °C	Temperature range in °F
		Pt100	0	-200 to 850	-300 to 1500
	Resistance thermometer		1	-199.9 to 500.0	-199.9 to 900.0
			2	0.0 to 100.0	0.0 to 210.0
		JPt100	3	-199.9 to 500.0	-199.9 to 900.0
			4	0.0 to 100.0	0.0 to 210.0
		К	5	-200 to 1300	-300 to 2300
			6	-20.0 to 500.0	0.0 to 900.0
		J	7	-100 to 850	-100 to 1500
			8	-20.0 to 400.0	0.0 to 750.0
		Т	9	-200 to 400	-300 to 700
ont			10	-199.9 to 400.0	-199.9 to 700.0
Temperature input		E	11	-200 to 600	-300 to 1100
atur	Tl	L	12	-100 to 850	-100 to 1500
ηper	Thermocouple	U	13	-200 to 400	-300 to 700
Ten			14	-199.9 to 400.0	-199.9 to 700.0
		N	15	-200 to 1300	-300 to 2300
		R	16	0 to 1700	0 to 3000
		S	17	0 to 1700	0 to 3000
		В	18	0 to 1800	0 to 3200
		C/W	19	0 to 2300	0 to 3200
		PLII	20	0 to 1300	0 to 2300
İ		10 to 70°C	21	0 to 90	0 to 190
	Infrared	60 to 120°C	22	0 to 120	0 to 240
	temperature sensor ES1B	115 to 165°C	23	0 to 165	0 to 320
	0011001 2012	140 to 260°C	24	0 to 260	0 to 500
	0	4 to 20 mA	25	One of the following ranges	according to the scaling:
put	Current input	0 to 20 mA	26	-1999 to 9999	
og in		1 to 5 V	27	-199.9 to 999.9 -19.99 to 99.99	
Analog input	Voltage input	0 to 5 V	28	-1.999 to 9.999	
⋖	•	0 to 10 V	29		

The default is 5.



# **Precautions for Correct Use**

5.ERR: input error) flashes on the display if a sensor is not connected or if the connected sensor is different from input type. Connect a sensor if one is not already connected.



Е

# 4-4 Selecting the Temperature Unit

# 4-4-1 Temperature Unit

*[*: °C, *F*: °F

- Either °C or °F can be selected as the temperature unit.
- Set the temperature unit in the Temperature Unit (d-U) parameter of the Initial Setting Level. The default is  $\mathcal{L}$  (°C).
- If you change the temperature unit, the units of temperature set values (e.g., the alarm values) will be automatically converted.

The following procedure selects °C.

Ope	Operating Procedure				
1	Press the  Key several times in the Initial Setting Level to display <i>d-U</i> (Temperature Unit).	Initial Setting Level  Temperature Unit			
2	Press the $\bigcirc$ or $\bigcirc$ Key to select $^{\circ}$ C. The default is $\mathcal{L}$ ( $^{\circ}$ C).	d-U			

# **Selecting PID Control or ON/OFF** 4-5 **Control**

Two control methods are supported: 2-PID control and ON/OFF control. Switching between 2-PID control and ON/OFF control is executed by means of the PID ON/OFF parameter in the initial setting level. When this parameter is set to  $P\bar{L}d$ , 2-PID control is selected, and when set to  $\bar{a}N\bar{a}F$ , ON/OFF control, is selected. The default is Pīd.

#### 2-PID Control

Use autotuning to set the PID constants, or set them manually.

For PID control, set the PID constants in the Proportional Band ( $\bar{P}$ ), Integral Time ( $\bar{L}$ ), and Derivative Time (d) parameters.

For heating and cooling control, also set the Proportional Band (Cooling) (£-P), Integral Time (Cooling)  $(\underline{\Gamma} - \underline{\Gamma})$ , and Derivative Time (Cooling)  $(\underline{\Gamma} - \underline{d})$ .

For details, refer to 4-7 Setting the Set Point (SP).

#### ON/OFF Control

In ON/OFF control, the control output is turned ON when the process value is lower than the current set point, and the control output is turned OFF when the process value is higher than the current set point (reverse operation).

For details, refer to 4-8 Using ON/OFF Control.

# **Setting Output Specifications**

#### **Control Period** 4-6-1



Control Period




- · Set the output periods (control periods). Though a shorter period provides better control performance, it is recommended that the control period be set to 20 seconds or longer for a relay output to preserve the service life of the relay. After the settings have been made in the initial setup, readjust the control period, as required, by means such as trial operation.
- Set the control periods in the Control Period (Heating) and Control Period (Cooling) parameters in the Initial Setting Level. The default is 20 seconds for a relay output and 2 seconds for a voltage output (for driving SSR).
- The control periods are used only for PID control.
- The Control Period (Cooling) parameter is used only for heating/cooling
- When control output is used as a linear current output, the Control Period parameter cannot be used.

#### 4-6-2 **Direct and Reverse Operation**



• Direct operation increases the manipulated variable whenever the process value increases. Reverse operation decreases the manipulated variable whenever the process value increases.



For example, when the process value (PV) is lower than the set point (SP) in a heating control system, the manipulated variable increases according to the difference between the PV and SP. Accordingly, reverse operation is used in a heating control system. Direct operation is used in a cooling control system, in which the operation is the opposite of a heating control system. The Control Output 1 Assignment is set to  $\bar{a}$  (control output (heating)) for either direct or reverse operation.

• Direct/reverse operation is set in the Direct/Reverse Operation parameter in the Initial Setting Level. The default is  $\bar{a}R - \bar{R}$  (reverse operation).

In this example, direct/reverse operation, and control period (heating) parameters are checked.

Direct/reverse operation =  $\bar{a}R - \bar{R}$  (reverse operation)

Control period (heating) = 20 (seconds)

# **Operating Procedure**

Setting the Control Period (Heating) Parameter

1	Press the $oxtimes$ Key several times in the Initial Setting Level to display $\mathcal{LP}$ (Control Period (Heating)).	Initial Setting Level  Control Period (Heating)
2	Press the ♠ or ❤ Key to set the value to 20.  The default for a relay output is 20 seconds.	[
• Se	etting Direct/Reverse Operation	
1	Press the $\  \   $ Key several times in the Initial Setting Level to display $\  \   $ (Direct/Reverse Operation).	Initial Setting Level  TO RELY  Direct/Reverse Operation
2	Press the $\bigcirc$ or $\bigcirc$ Key to select $\bar{a}R - R$ (Reverse Operation). The default is $\bar{a}R - R$ (Reverse Operation).	āREV āR-R

#### **Assigned Output Functions** 4-6-3

- · Function assignments can be changed by changing the settings for control and auxiliary output assignments.
- The default function assignments for each output are shown below.
- During tuning,\* ensure that the power for the load (e.g., heater) is ON. If the power supply to the load (e.g., heater) is not turned ON during tuning, tuning results will not be calculated correctly and it will not be possible to achieve optimum control.
  - "Tuning" refers to the following functions: AT, adaptive control, automatic filter adjustment, and water-cooling output adjustment.

Parameter name	Display	Initial status
Control Output 1 Assignment	ōUE I	Control output
		(heating)
Control Output 2 Assignment (E5ED or E5ED-B only)	ōUE2	Not assigned.
Auxiliary Output 1 Assignment	5Ub 1	Alarm 1 <sup>*1</sup>
Auxiliary Output 2 Assignment	SU62	Alarm 2
Auxiliary Output 3 Assignment (E5ED or E5ED-B only)	SU63	Alarm 3
Auxiliary Output 4 Assignment (E5ED or E5ED-B only)	SUBY	Alarm 4

- \*1. If the Digital Controller is equipped with HB/HS alarm detection, it is set by default to detect heater alarms (HA). Therefore, the alarm 1 function is disabled and the Alarm 1 Type is not displayed. To enable alarm 1, set an output assignment to alarm 1. If the Program Pattern parameter is changed to a setting other than OFF, Auxiliary Output 1 Assignment parameter is set as the program end output.
- Refer to page 6-80 and page 6-81 for the functions that can be assigned to the outputs.
- Each output is automatically initialized as shown below by changing the control mode between standard and heating/cooling.

# **Assigned Output Functions**

Two Auxiliary Outputs (E5CD, E5ED, E5CD-B, or E5ED-B)

Parameter name	Display	Allocations	
raidilletei liaille		Standard	Heating/cooling
Control Output 1 Assignment	āUE I	Control output (heating)	Control output (heating)
Auxiliary Output 1 Assignment	5U6 T	Alarm 1 <sup>*1</sup>	Alarm 1 <sup>*1</sup>
Auxiliary Output 2 Assignment	5062	Alarm 2	Control output (cooling)

Four Auxiliary Outputs (E5ED or E5ED-B)

Parameter name	Display	Without control output 2		With control output 2	
Parameter mame	Display	Standard	Heating/cooling	Standard	Heating/cooling
Control Output 1	ōUE I	Control output	Control output	Control output	Control output
Assignment		(heating)	(heating)	(heating)	(heating)
Control Output 2 Assignment	ōUE2			Not assigned.	Control output (cooling)
Auxiliary Output 1 Assignment	5Ub 1	Alarm 1 <sup>*1</sup>	Alarm 1 <sup>*1</sup>	Alarm 1 <sup>*1</sup>	Alarm 1 <sup>*1</sup>
Auxiliary Output 2 Assignment	SU62	Alarm 2	Alarm 2	Alarm 2	Alarm 2
Auxiliary Output 3 Assignment	5063	Alarm 3	Alarm 3	Alarm 3	Alarm 3
Auxiliary Output 4 Assignment	5064	Alarm 4	Control output (cooling)	Alarm 4	Alarm 4

<sup>\*1.</sup> If the Digital Controller is equipped with HB/HS alarm detection, it is set by default to detect heater alarms (HA). Therefore, the alarm 1 function is disabled and the Alarm 1 Type is not displayed. To enable alarm 1, set an output assignment to alarm 1. If the Program Pattern parameter is changed to a setting other than OFF, Auxiliary Output 1 Assignment parameter is set as the program end output.

#### Alarms

It will be specified in this section when an alarm must be assigned, i.e., when an alarm must be set for the Control Output 1 or 2 Assignment parameters, or for the Auxiliary Output 1 to 4 Assignment parameters. For example, if alarm 1 is set for the Control Output 1 Assignment parameter, then alarm 1 has been assigned.

Assigning a work bit to either control output 1 or 2 or to auxiliary output 1 to 4 is also considered to be the same as assigning an alarm. For example, if work bit 1 is set for the Auxiliary Output 1 Assignment parameter, then alarms 1 to 4 have been assigned.

Assign the control outputs and auxiliary outputs.

Control output 1: Control output (heating)

Control output 2: Control output (cooling)

Auxiliary output 1: Alarm 1 Auxiliary output 2: Alarm 2

# **Operating Procedure**

• Se	etting Heating/Cooling Control	
1	Press the $f Q$ Key several times in the Initial Setting Level to display $5$ - $HL$ (Standard or Heating/Cooling).	Initial Setting Level  5 - HC Standard or Heating/Cooling
2	Press the ♠ or ❤ Key to set the parameter to H-£.  The default is 5ŁNd (standard).	<b>5-H</b> [ H-[
• Se	* Use the following procedures to check the output assignments. The output assignments are changed automatically when you change between standard and heating/cooling control. You do not have to set them. etting Control Output 1	
1	Press the  Key several times in the Advanced Function Setting Level to display  (Control Output 1 Assignment).	Advanced Function Setting Level  Control Output 1 Assignment
2	Set the parameter to $\bar{a}$ (Control Output (Heating)). The default is $\bar{a}$ (Control Output (Heating)).	āUL [
• Se	etting Control Output 2	
1	Press the  Key several times in the Advanced Function Setting Level to display  (Control Output 2 Assignment).	Advanced Function Setting Level  Control Output 2 Assignment
2	Set the parameter to $\mathcal{L}$ - $\bar{a}$ (Control Output (Cooling)). As soon as you select $\mathcal{H}$ - $\mathcal{L}$ (Heating/Cooling) for the Standard or Heating/Cooling parameter, the setting of this parameter is automatically changed to $\mathcal{L}$ - $\bar{a}$ (Control Output (Cooling)).	āUŁZ [-ā
• Se	etting Auxiliary Output 1	
1	Press the  Key several times in the Advanced Function Setting Level to display 546 (Auxiliary Output 1 Assignment).	Advanced Function Setting Level  Auxiliary Output 1 Assignment
2	Press the or Vec Key to set the parameter to RLM I.  The default is RLM I (Alarm 1).  If the Digital Controller is equipped with HB/HS alarm detection, this parameter is set by default to HR (heater alarm).	SUB I ALM I

• Setting Auxiliary Output 2

1	Press the ☑ Key several times in the Advanced Function Setting Level to display 5੫b² (Auxiliary Output 2 Assignment).	Advanced Function Setting Level  Substitute   Auxiliary Output 2 Assignment
2	Press the ♠ or ♥ Key to set the parameter to RLM2.  The default is RLM2 (Alarm 2).	5U62 RLM2

# 4-6-4 Auxiliary Output Opening or Closing in Alarm

- When "close in alarm" is set, the status of the auxiliary output is output unchanged. When "open in alarm" is set, the status of the auxiliary output function is reversed before being output.
- Each auxiliary output can be set independently.
- These settings are made in the Auxiliary Output 1 to 4 Open in Alarm parameters (Advanced Function Setting Level).
- The default is  $N-\bar{a}$ : Close in Alarm.

	Auxiliary output functions 1 to 4	Auxiliary output	Indicators (SUB1 to SUB4)
Close in Alarm	ON	ON	Lit
(N - <u>a</u> )	OFF	OFF	Not lit
Open in Alarm	ON	OFF	Lit
(N-E)	OFF	ON	Not lit

• The alarm will turn OFF (i.e., the relay contacts will open) when power is interrupted and for about two seconds after the power is turned ON regardless of the setting of the Auxiliary Output 1 to 4 Open in Alarm parameter.

# **Setting the Set Point (SP)**

Operation Level



The Operation Level is displayed when the power is turned ON. For the default setting, the No. 1 display shows the PV, the No. 2 display shows the SP, and the No. 3 display (E5ED or E5ED-B only) shows the MV.

The contents that is set in the PV/SP Display Screen Selection parameter in the Advanced Function Setting Level are displayed.

For details, refer to 4-13-1 PV/SP Display Selections.

#### 4-7-1 Changing the SP

50.0

- The set point cannot be changed when the Operation/Adjustment Protect parameter is set to 3. For details, refer to 5-11 Using the Key Protect Level.
- SP/SP (character display) display in the Operation Level, and set the desired set value. The new set point is selected three seconds after you have specified the new value.
- Multi-SP can be used to switch between eight set points. For details, refer to 5-8 Using Event Inputs for details.

In this example, the set point is changed from 0°C to 200°C.

#### **Operating Procedure**

Press the A or Key in the Operation Level to set the SP to 200°C. The default SP is 0°C. The default SP is 0°C.

Operation Level 30

200



# **Additional Information**

• If there are a lot of digits in a numeric value, you can use the (CF) (Shift Key) to select the digit to change before you change the value of the digit.

Example: Changing 1,000°C to 1,200°C

Press (PF) Key three times.

The third digit will flash.

Operation Level



Press the Key to set the value to 1200.



# 4-8 Using ON/OFF Control

In ON/OFF control, the control output turns OFF when the temperature being controlled reaches the preset set point. When the manipulated variable turns OFF, the temperature begins to fall and the control turns ON again. This operation is repeated over a certain temperature range. At this time, how much the temperature must fall before control turns ON again is determined by the Hysteresis (Heating) parameter. Also, what direction the manipulated variable must be adjusted in response to an increase or decrease in the process value is determined by the Direct/Reverse Operation parameter.


## 4-8-1 ON/OFF Control

• Switching between 2-PID control and ON/OFF control is performed using the PID ON/OFF parameter in the Initial Setting Level. When this parameter is set to P̄c̄d, 2-PID control is selected, and when it is set to āNāF, ON/OFF control is selected. The default is P̄c̄d.

#### Hysteresis

- With ON/OFF control, hysteresis is used to stabilize operation when switching between ON and OFF. The control output (heating) and control output (cooling) functions are set in the Hysteresis (Heating) and Hysteresis (Cooling) parameters, respectively.
- In standard control (heating or cooling control), the setting of the Hysteresis (Heating) parameter
  in the Adjustment Level is used as the hysteresis regardless of whether the control type is heating
  control or cooling control.

Reverse operation



#### **Parameters**

Display	Parameter	Application	Level
5-H[	Standard or	Specifying control	Initial Setting Level
	Heating/Cooling	method	
ENEL	PID ON/OFF	Specifying control	Initial Setting Level
		method	
āREV	Direct/Reverse	Specifying control	Initial Setting Level
	Operation	method	
E-db	Dead Band	Heating/cooling	Adjustment Level
		control	
H42	Hysteresis (Heating)	ON/OFF control	Adjustment Level
EH45	Hysteresis (Cooling)	ON/OFF control	Adjustment Level

#### 4-8-2 **Settings**

To execute ON/OFF control, set the Set Point, PID ON/OFF, and Hysteresis parameters.

# **Setting the PID ON/OFF Parameter**

Confirm that the PID ON/OFF parameter is set to  $\bar{a}N\bar{a}F$  in the Initial Setting Level.

# **Operating Procedure**

1	Press the $\textcircled{P}$ Key several times in the Initial Setting Level to display $\emph{ENEL}$ (PID ON/OFF). The default is $\emph{PLd}$ (PID control).	Initial Setting Level    Initial Setting Level
2	Press the ♠ or ❤ Key to set āNāF (ON/OFF control).	ENEL

# **Setting the SP**

In this example, the set point is set to 200°C. The set value (i.e., the SP) is shown at the bottom of the display.

# **Operating Procedure**

1	Select PV/SP in the Operation Level.	Operation Level
	·	PV/SP
2	Press the or Key to set the SP to 200.  The default is 0.  The new set value can be saved by pressing the Key, or it will go into effect after 3 seconds has elapsed.	25 200

# **Setting the Hysteresis**

Set the heating hysteresis to 2.0°C.

Opera	atina	Dro	റമപ	ıırΔ
Opera	สเบเน	FIU	ceu	ure

1	Press the $\textcircled{9}$ Key several times in the Adjustment Level to display $H95$ (Hysteresis (Heating)).	Adjustment Level  Hysteresis (Heating)
2	Press the  or  Key to set the hysteresis to 2.0.  The default is 1.0.  The new set value can be saved by pressing the  Key, or it will go into effect after 3 seconds has elapsed.	H45 2.0


# 4-9 **Determining PID Constants (AT, Manual Setup)**

#### 4-9-1 AT (Auto-tuning)



- . When AT is executed, the optimum PID constants for the set point at that time are set automatically. A method (called the limit cycle method) for forcibly changing the manipulated variable and finding the characteristics of the control object is employed.
- Either 40% AT or 100% AT can be selected depending on the width of MV variation in the limit cycle. In the AT Execute/Cancel parameter, specify RE-2 (100% AT) or RE = 1 (40% AT). To cancel AT, specify  $\overline{a}FF$  (AT cancel).
- Only 100% AT can be executed for heating and cooling control.
- If the Heating/Cooling Tuning Method parameter is set to any value other than 0 (same as heating control), the PID constants are set automatically for both heating control and cooling control.
- AT cannot be executed when control has stopped or during ON/OFF control.
- . The results of autotuning are saved in the following parameters in the Adjustment Level: Proportional Band (P), Integral Time (I), Derivative Time (D), Proportional Band (Cooling) (C-P), Integral Time (Cooling) (C-I), and Derivative Time (Cooling) (C-D). If the Adaptive Control parameter (AdPt) in the Initial Setting Level is set for automatic updating  $(AUE_{\bar{a}})$  or notification  $(\overline{L}NF\overline{a})$ , the change will be reflected in set point response PID, disturbance PID, and model parameters that give the system characteristics. (\*For information on adaptive control, refer to 5-3 Performing Adaptive Control.)

#### PID Constants Updated for 2-PID Control Adjustment Level



# Model Parameters and PID Constants Updated for Adaptive Control Adjustment Level

## AT Operations

AT is started when either RE - 2 (100% AT) or RE - 1 (40% AT) is specified for the AT Execute/Cancel parameter.

The TUNE indicator will light during execution.

Only the Communications Writing, RUN/STOP, AT Execution/Cancel, and Program Start parameters can be changed during AT execution. Other parameters cannot be changed.

# AT Calculated Gain MASK8

Sets the gain used when calculating the PID constants in autotuning. When emphasizing rapid response, decrease the set value. When emphasizing stability, increase the set value.

## AT Hysteresis MASK8

The AT Hysteresis parameter sets the hysteresis when switching ON and OFF for the limit cycle operation during auto-tuning.


# Limit Cycle MV Amplitude MASK8


The Limit Cycle MV Amplitude parameter sets the MV amplitude for limit cycle operation during auto-tuning.

\* This setting is disabled for 100% AT.

#### 40% AT


 The width of MV variation in the limit cycle can be changed in the Limit Cycle MV Amplitude parameter, but the AT execution time may be longer than for 100% AT. The limit cycle timing varies according to whether the deviation (DV) at the start of auto-tuning execution is less than 10% FS.





#### 100% AT

 Operation will be as shown in the following diagram, regardless of the deviation (DV) at the start of AT execution. To shorten the AT execution time, select 100% AT.



The Limit Cycle MV Amplitude parameter is disabled

The 100% autotuning is executed.

#### **Operating Procedure**

1	Press the    Key several times in the Adjustment Level to dis-	Adjustment Level
	play RŁ (AT Execute/Cancel).	AT Execute/ Cancel
2	Press the ♠ or ❤ Key to select RŁ - 2 (100% AT execute).  * The TUNE indicator will light during autotuning.	<b>AF</b> 8F-5
3	When AT ends, the AT Execute/Cancel parameter is set to ΔFF.	Adjustment Level  AT Execute/ Cancel



## **Precautions for Correct Use**

To execute autotuning, you must set the RUN/STOP parameter to RUN (default: RUN) and the PID ON/OFF parameter to PID (default: PID). If the RUN/STOP parameter is set to STOP or the PID ON/OFF parameter is set to ON/OFF, the settings for the AT Execute/Cancel parameter will not be displayed.

#### **Supplemental Information on AT Operation**

- Perform AT with the control set point set and the power supply to the output side (e.g., heater) turned ON.
- You can start AT from any current temperature.



#### **Additional Information**

PID Constants

When control characteristics are already known, PID constants can be set directly to adjust control. The PID constants are set in the following parameters in the Adjustment Level: Proportional Band (P), Integral Time (I), Derivative Time (D), Proportional Band (Cooling) (C-P), Integral Time (Cooling) (C-I), and Derivative Time (Cooling) (C-D).

 Integral/Derivative Time Unit If the results of executing AT give a derivative time (D) of less than 10 seconds, we recommend that you set the Integral/Derivative Time Unit parameter (Advanced Setting Level) to 0.1 seconds and perform AT again.


# 4-9-2 RT (Robust Tuning) (Use with AT) MASK8

RL


- When AT is executed with RT selected, PID constants are automatically set that make it hard for control performance to deteriorate even when the characteristics of the controlled object are changed.
- RT can be set in the Advanced Function Setting Level when PID control has been set.
- The RT mode cannot be selected while an analog input is set.
- Selecting the RT mode in the following cases will help to prevent hunting from occurring.
  - When the set temperature is not constant and is changed in a wide range
- When there are large variations in ambient temperatures due to factors such as seasonal changes or differences between day and night temperatures
- When there are large variations in ambient wind conditions and air flow
- When heater characteristics change depending on the temperature
- When an actuator with disproportional I/O, such as a phase-control-type power regulator, is used
- When a rapidly heating heater is used
- When the control object or sensor has much loss time
- When hunting occurs in normal mode for any reason
  - PID constants are initialized to the factory settings by switching to RT mode.
  - \* When the RT mode is selected, the Integral/Derivative Time Unit parameter changes to 0.1 s.

#### RT Features

• Even when hunting occurs for PID constants when AT is executed in normal mode, it is less likely to occur when AT is executed in RT Mode.



• When the temperature (PV) falls short of the set point for the PID constants when using AT in normal mode, executing AT in RT Mode tends to improve performance.



• When the manipulated variable (MV) is saturated, the amount of overshooting may be somewhat higher in comparison to PID control based on AT in normal mode.

This procedure selects RT mode.

Ope	rating Procedure	
1	Press the $\  \   \  $ Key several times in the Advanced Function Setting Level to display $RE$ (RT: robust tuning).	Advanced Function Setting Level  RT  GFF  MASK8
2	Press the $\bigcirc$ or $\bigcirc$ Key to select $\bar{a}N$ (RT ON). The default is $\bar{a}FF$ .	₽L āN MASK8

# 4-9-3 Manual Setup

Individual PID constants can be manually set in the Proportional Band, Integral Time, and Derivative Time parameters in the Adjustment Level.

In this example, the Proportional Band parameter is set to 10.0, the Integral Time parameter to 250, and the Derivative Time parameter to 45.

#### **Operating Procedure**

•	Setting	the	Proportional	Rand

1	Press the  Rey several times in the Adjustment Level to	Adjustment Level	
_	display the <i>P</i> (Proportional Band) parameter.	Proportional Band	
2	Press the ♠ or ❤ Key to set the value to 10.0.  The default settings are as follows:  • Temperature input (°C or °F): 8.0  • Analog input (%FS): 10.0	P 10.0	
• S	etting the Integral Time		
1	Press the  Key several times in the Adjustment Level to	Adjustment Level	

	display the L (Integral Time) parameter.	233	Integral Time
2	Press the  or  Key to set the value to 250.  The default settings are as follows:  Integral/Derivative Time Unit of 1 s: 233  Integral/Derivative Time Unit of 0.1 s: 233.0	250	

<sup>•</sup> Setting the Derivative Time

1	Press the $\  \   \  \  $ Key several times in the Adjustment Level to display the $d$ (Derivative Time) parameter.	Adjustment Level  d Derivative Time
2	Press the or Vec Key to set the value to 45.  The default settings are as follows:  Integral/Derivative Time Unit of 1 s: 40  Integral/Derivative Time Unit of 0.1 s: 40.0	<b>d</b> 45



#### **Additional Information**


Proportional Action

When PID constants I (integral time) and D (derivative time) are set to 0, control is executed according to proportional action. As the default, the center value of the proportional band becomes the set point.


- \* Related parameter: Manual Reset Value (Adjustment Level)
- Integral/Derivative Time Unit

If the results of executing AT give a derivative time (D) of less than 10 seconds, we recommend that you set the Integral/Derivative Time Unit parameter (Advanced Setting Level) to 0.1 seconds and perform AT again.


## When P (Proportional Band) Is Adjusted



#### When I (Integral Time) Is Adjusted



## When D (Derivative Time) Is Adjusted



# 4-10 Alarm Outputs

- Alarms are output from auxiliary outputs. For relay outputs or voltage outputs (for driving SSRs), alarms can also be used by setting the Control Output 1 Assignment or Control Output 2 Assignment parameter to any of the alarms from alarm 1 to 4. The alarm output condition is determined by a combination of the alarm type, alarm value, alarm hysteresis, and the standby sequence. For details, refer to 4-11 Alarm Hysteresis.
- This section describes the Alarm Type, Alarm Value, Upper-limit Alarm and Lower-limit Alarm parameters.

# 4-10-1 Alarm Types

RLL Alarm 1 Type

Alarm 2 Type

Alarm 3 Type

Alarm 4 Type


- Set the alarm type independently for each alarm in the Alarm 1 to 4 Type parameters in the Initial Setting Level.
- The alarms that can be set are listed in the following table.
- You can use an LBA (12) only for alarm 1.
- If the Controller is equipped with HB/HS alarm detection, the default setting for the Auxiliary Output 1 Assignment is for heater alarms. Therefore, the alarm 1 function is disabled and the Alarm 1 Type is not displayed. To use alarm 1, set an output assignment to alarm 1. (Refer to 4-6-3 Assigned Output Functions on page 4-16.)

0.1		Alarm outp	ut operation	
Set value	Alarm type	When alarm value X is positive	When alarm value X is negative	Description of function
0	Alarm function OFF	Outpu	it OFF	No alarm
1	Upper- and lower-limit*1	ON DOFF SP PV	*2	Set the upward deviation in the set point for the alarm upper limit (H) and the lower deviation in the set point for the alarm lower limit (L). The alarm is ON when the PV is outside this deviation range.
2 (default)	Upper-limit	ON OFF SP PV	ON SP PV	Set the upward deviation in the set point by setting the alarm value (X). The alarm is ON when the PV is higher than the SP by the deviation or more.
3	Lower-limit	ON X PV	ON X PV	Set the downward deviation in the set point by setting the alarm value (X). The alarm is ON when the PV is lower than the SP by the deviation or more.


0.1				
Set value	Alarm type	When alarm value	ut operation When alarm value	Description of function
value		X is positive	X is negative	
4	Upper- and lower-limit range*1	ON OFF SP PV	*3	Set the upward deviation in the set point for the alarm upper limit (H) and the lower deviation in the set point for the alarm lower limit (L). The alarm is ON when the PV is inside this deviation range.
5	Upper- and lower-limit with standby sequence*1	ON OFF SP PV	*4	A standby sequence is added to the upper- and lower-limit alarm (1).*6
6	Upper-limit with standby sequence	ON X PV	ON SP PV	A standby sequence is added to the upper-limit alarm (2).*6
7	Lower-limit with standby sequence	ON X PPV	ON OFF SP PV	A standby sequence is added to the lower-limit alarm (3).*6
8	Absolute-value upper-limit	ON ← X → PV	ON OFF 0 PV	The alarm will turn ON if the process value is larger than the alarm value (X) regardless of the set point.
9	Absolute-value lower-limit	ON	ON OFF O PV	The alarm will turn ON if the process value is smaller than the alarm value (X) regardless of the set point.
10	Absolute-value upper-limit with standby sequence	ON PV	ON PV	A standby sequence is added to the absolute-value upper-limit alarm (8).*6
11	Absolute-value lower-limit with standby sequence	ON PV	ON OFF O PV	A standby sequence is added to the absolute-value lower-limit alarm (9).*6
12	LBA (alarm 1 type only)			*7
13	PV change rate alarm			*8
14	SP absolute-value upper-limit alarm	ON	ON → X → SP	This alarm type turns ON the alarm when the set point (SP) is higher than the alarm value (X).
15	SP absolute-value lower-limit alarm	ON	ON → X → OFF SP	This alarm type turns ON the alarm when the set point (SP) is lower than the alarm value (X).
16	MV absolute-value upper-limit alarm*9	Standard Control  ON OFF O MV  Heating/Cooling Control (Heating MV)  ON OFF O MV	Standard Control  ON OFF  OFF  OFF  ON	This alarm type turns ON the alarm when the manipulated variable (MV) is higher than the alarm value (X).

Set		Alarm outpo	ut operation	
value	Alarm type	When alarm value	When alarm value	Description of function
		X is positive	X is negative	
17	MV absolute-value	Standard Control	Standard Control	This alarm type turns ON
	lower-limit alarm*9	ON OFF 0 MV	ON OFF 0 MV	the alarm when the manipulated variable (MV) is lower than the alarm
		Heating/Cooling	Heating/Cooling	value (X).
		Control (Cooling	Control (Cooling	,
		MV)	MV)	
		ON OFF O MV	Always ON	

- \*1 With set values 1, 4, and 5, the upper- and lower-limit values can be set independently for each alarm type, and are expressed as "L" and "H."
- \*2 Set value: 1 (Upper- and lower-limit alarm)



\*3 Set value: 4 (Upper- and lower-limit range)



- \*4 Set value: 5 (Upper- and lower-limit alarm with standby sequence)
  - For the upper- and lower-limit alarms in cases 1 and 2 above, the alarm is always OFF if upper- and lower-limit hysteresis overlaps.
  - In case 3, the alarm is always OFF.
- \*5 Set value: 5 (Upper- and lower-limit alarm with standby sequence)
  - The alarm is always OFF if upper- and lower-limit hysteresis overlaps.
- \*6 Refer to *Standby Sequence Reset* on page 6-65 for information on the operation of the standby sequence.
- \*7 Refer to 5-15-1 Loop Burnout Alarm (LBA).
- \*8 Refer to PV Change Rate Alarm on page 4-35.
- \*9 When heating/cooling control is performed, the MV absolute-value upper-limit alarm functions only for the heating operation and the MV absolute-value lower-limit alarm functions only for the cooling operation.

# 4-10-2 Alarm Values

IL Alarm Lower RLLimit Value

- RL2L
- AL 3L
- AL YL
- AL IH Alarm Upper Limit Value
- RL2H
- RL 3H
- AL YH
- AL 1 Alarm Value
- AL -2
- AL-3
- AL-4

• Alarm values are indicated by "X" in the table on the previous page. When the upper and lower limits are set independently, "H" is displayed for upper limit values, and "L" is displayed for lower limit values.

• To set the alarm value upper and lower limits for deviation, set the upper and lower limits in each of the Alarm 1 to 4 Upper Limit, and Alarm 1 to 4 Lower Limit parameters in the Operation Level.

This procedure sets alarm 1 as an upper-limit alarm. The alarm is output when the process value (PV) exceeds the set point (SP) by 10°C. (In this example, the temperature unit is °C.)

This procedure sets the Alarm 1 Type parameter to 2 (upper alarm) and the Alarm 1 parameter to 10.

#### **Operating Procedure**

Selecting the Alarm 1 Type

1	Press the  Key several times in the Initial Setting Level to display  FLE (Alarm 1 Type).*	Initial Setting Level  Alarm 1 Type
2	Press the or Vec Key to set the set value to 2.  The default is 2 (upper-limit alarm).	ALE I

#### · Setting the Alarm Value

1	Press the $\  \   \  \  $ Key several times in the Operation Level to display $\  \   RL - I$ (Alarm Value 1).	Operation Level  Alarm Value 1
2	Press the ♠ or ❤ Key to set the set value to 10. The default is 10.	AL - 1

\* If the Controller is equipped with HB/HS alarm detection, the default setting for the Auxiliary Output 1 Assignment is for heater alarms. Therefore, the alarm 1 function is disabled and the Alarm 1 Type is not displayed. To enable alarm 1, set an output assignment to alarm 1. For details, refer to 4-6-3 Assigned Output Functions on page 4-16.

#### PV Change Rate Alarm


The change width can be found for PV input values in any set period. Differences with previous values in each set period are calculated, and an alarm is output if the result exceeds the alarm value. The PV rate of change calculation period can be set in units of 50 ms.

If a positive value is set for the alarm value, the PV will operate as a change rate alarm in the rising direction. If a negative value is set, the PV will operate as a change rate alarm in the falling direction.



#### **Precautions for Correct Use**

If a shorter PV rate of change calculation period is set, outputs set for the PV change rate alarm function may repeatedly turn ON and OFF for a short period of time. It is therefore recommended that the PV change rate alarm be used with the alarm latch turned ON.




Parameter name	Setting range	Unit	Default
PV Rate of Change	1 to 999	Sampling cycle	20 (1 s)
Calculation Period			

#### SP Alarms

You can set an SP absolute-value upper-limit or SP absolute-value lower-limit alarm for the set point

The alarm point is set in the corresponding alarm value parameter. The Alarm SP Selection parameter is used to specify the alarm for either the ramp SP or the target SP.


The corresponding alarm hysteresis setting is also valid.



#### MV Alarms


You can set an MV absolute-value upper-limit or MV absolute-value lower-limit alarm for the manipulated value (MV).

The alarm point is set in the corresponding alarm value parameter. The corresponding alarm hysteresis setting is also valid.



# 4-11 Alarm Hysteresis

• The hysteresis of alarm outputs when alarms are switched ON/OFF can be set as follows:



- Alarm hysteresis is set independently for each alarm in the Alarm 1 to 4 Hysteresis parameters (Initial Setting Level).
- For all alarms except for MV alarms, the default is 0.2 (°C/°F) for temperature inputs and 0.02% FS for analog inputs. The default is 0.50(%) for MV alarms.

# 4-11-1 Standby Sequence

- The standby sequence can be used so that an alarm will not be output until the process value leaves the alarm range once and then enters it again.
- For example, with a lower-limit alarm, the process value will normally be below the set point, i.e., within the alarm range, when the power supply is turned ON, causing an alarm to be output.
   If the lower-limit alarm with a standby sequence is selected, an alarm will not be output until the process value increases above the alarm set value, i.e., until it leaves the alarm range, and then falls back below the alarm set value.

#### Restart

• The standby sequence is canceled when an alarm is output. It is, however, restarted later by the Standby Sequence Reset parameter (Advanced Function Setting Level). For details, refer to the Standby Sequence Reset parameter in *Section 6 Parameters*.

## 4-11-2 Alarm Latch

• The alarm latch can be used to keep the alarm output ON until the latch is canceled regardless of the temperature once the alarm output has turned ON.

Any of the following methods can be used to clear the alarm latch.


- Turn OFF the power supply. (The alarm latch is also cleared by switching to the Initial Setting Level, Communications Setting Level, Advanced Function Setting Level, or Calibration Level.)
- · Use the PF Key.
- Use an event input.

For details on setting the PF Key, refer to 5-21 Setting the PF Key. For details on setting events, refer to 5-8 Using Event Inputs.

## Summary of Alarm Operation

The following figure summarizes the operation of alarms when the Alarm Type parameter is set to "lower-limit alarm with standby sequence" and "close in alarm" is set.

Alarm type: Lower-limit alarm with standby sequence



#### **Parameters**

Display	Parameter	Description	Level
ALH*	Alarm 1 to 4 Hysteresis	Alarm	Initial Setting Level
RESE	Standby Sequence	Alarm	Advanced Function Setting Level

<sup>\*= /</sup> to 4


# 4-12 Using Heater Burnout (HB) and Heater Short (HS) Alarms

These functions are supported for models that detect heater burnout (HB) and heater short (HS) alarms.

#### 4-12-1 HB Alarm

#### What Is an HB Alarm?


An HB alarm is detected by measuring the heater current with a current transformer (CT) when the control output is ON. If the measured heater current is lower than the setting of the Heater Burnout Detection Current parameter, an alarm is output.



- This alarm cannot be used for the cooling control output.
- The default setting for the Auxiliary Output 1 Assignment is for heater alarms. Therefore, the alarm 1 function is disabled and the Alarm 1 Type is not displayed. You can use the output assignment parameters to change the alarm output location. For details, refer to 4-6-3 Assigned Output Functions on page 4-16.
- You can use an integrated alarm to output an OR of alarms 1 to 4 and the other alarms. For details on the integrated alarm, refer to 5-13 OR Output of Alarms on page 5-49.


#### Parameters

Parameter	No. 1 display	Value	No. 2 display	Level
HB ON/OFF	НЬИ	OFF or ON (default: ON)	āFF, āN	Advanced Function
Heater Burnout	HbL	OFF or ON (default: OFF)	ōFF, ōN	Setting Level
Latch				
Heater Burnout	НЬН	0.1 to 50.0 A (default: 0.1 A)	0.1 to 50.0	
Hysteresis				
Heater Burnout	НЬ І	0.0 to 50.0 A (default: 0.0 A)	0.0 to 50.0	Adjustment Level
Detection 1 or 2				
(alarm current)				
Heater Current 1 or	[F]	0.0 to 55.0 A	0.0 to 55.0	
2 Value Monitor	[F5			
Auxiliary Output 1	5Ub / to 5UbY	HB: HB alarm or HA: Heater	HЬ or HЯ	Advanced Function
to 4 Assignment		alarm		Setting Level



In the above diagram, power is considered to be ON (normal) if the heater current is greater than Hb I (Heater Burnout Detection Current) during the Ton interval. The HB alarm will be OFF in this case. If the heater current is less than Hb I (Heater Burnout Detection Current) during the Ton interval, the HB alarm will turn ON. Heater burnout is not detected if the ON time (Ton) for the control output for heating is 100 ms or less (30 ms or less if the control period is 0.1 or 0.2 s). Heater burnouts are not detected in the following cases.

- Turn ON the heater power supply simultaneously or before turning ON the E5□D power supply. If the heater power supply is turned ON after turning ON the E5□D power supply, the HB alarm will be output.
- · Control will be continued even when there is an HB alarm.
- The rated current may sometimes differ slightly from the actual current flowing to the heater. Check the current value in an actual operating state in the Heater Current Value 1 Monitor parameter.
- · If there is little difference between the current in normal and abnormal states, detection may be unstable. To stabilize detection, set a current difference of at least 1.0 A for heaters lower than 10.0 A, and at least 2.5 A for heaters of 10.0 A or higher. If the heater current is too low, loop the load line several times through a CT, as shown in the following diagram. Looping it through once will double the detected current.





#### **Precautions for Correct Use**

Due to UL Listing requirements, use the E54-CT1L or E54-CT3L Current Transformer with the factory wiring (internal wiring). Use a UL category XOBA or XOBA7 current transformer that is UL Listed for field wiring (external wiring) and not the factory wiring (internal wiring).


#### Operating Procedure

Set the HB ON/OFF parameter in the Advanced Function Setting Level, and set the Heater Burnout Detection 1 parameter in the Adjustment Level.

Heater Burnout Detection 1 = 2.5

#### **Operating Procedure**

• Checking the HB ON/OFF Parameter Setting




2	Check to see if the set value is $\bar{a}N$ (enabled, default).	HLU
• Cł	necking the Heater Current	
1	Press the	Adjustment Level  Heater Current 1 Value Monitor
2	Check the heater current from the CT input that is used to detect heater burnout.  The monitoring range is 0.0 to 55.0 A.	EE 1
• Se	tting Heater Burnout Detection	
1	Press the	Adjustment Level  Heater Burnout Detection 1
2	Press the  or  Key to set the set value to 2.5  Refer to 4-12-4 Calculating Detection Current Values when you set the value.	Hb 1 2.5

# 4-12-2 HS Alarm

#### • What Is an HS Alarm?

An HS alarm is detected by measuring the heater current with a current transformer (CT) when the control output is OFF. If the measured heater current is higher than the setting of the HS Alarm parameter, an alarm is output.




Control output (heating)	Power to heater	HS alarm output
OFF	Yes (HS alarm)	ON
<u> </u>	No (normal)	OFF

This alarm cannot be used for the cooling control output. With the default settings, the HS alarm is output on auxiliary output 1. You can use the output assignment parameters to change the output. You can use an integrated alarm to output an OR of alarms 1 to 4 and the other alarms. For details on the integrated alarm, refer to *5-13 OR Output of Alarms*.

#### Parameters

Parameter	No. 1 display	Value	No. 2 display	Level
HS Alarm Use	H5U	OFF or ON	āFF, āN	Advanced Function
		(default: ON)		Setting Level
HS Alarm Latch	HSL	OFF or ON	āFF, āN	
		(default: OFF)		
HS Alarm Hysteresis	HSH	0.1 to 50.0 A	0.1 to 50.0	
		(default: 0.1 A)		
HS Alarm 1 (alarm	H5 I	0.0 to 50.0 A	0.0 to 50.0	Adjustment Level
current)		(default: 50.0 A)		
Leakage Current 1	LERI	0.0 to 55.0 A	0.0 to 55.0	
Monitor				
Auxiliary Output 1 to 4	5Ub I to 5UbY	HS: HS alarm or	HS or HR	Advanced Function
Assignment		HA: Heater alarm		Setting Level



In the above diagram, power is considered to be OFF (normal) if the leakage current is less than #5 / (Heater Short Detection Current) during the Toff interval. The HS alarm will be OFF in this case. If the leakage current is greater than 45 ! (Heater Short Detection Current) during the Toff interval, the HS alarm will turn ON. Heater short are not detected if the OFF time (Toff) for the control output for heating is 100 ms or less (38 ms or less if the control period is 0.1 or 0.2 s). Heater shorts are not detected in the following cases.

- Control will be continued even when there is an HS alarm.
- The rated current may sometimes differ slightly from the actual current flowing to the heater. Check the current value in an actual operating state in the Leakage Current Value 1 Monitor parameter.

Set the HS Alarm Use parameter to ON in the Advanced Function Setting Level and set the HS Alarm 1 parameter in the Adjustment Level. This procedure sets the HS Alarm 1 parameter to 2.5.

#### **Operating Procedure**

Setting the HS Alarm Use Parameter

1	Press the @ Key several times in the Advanced Function Setting Level to display H5년 (HS Alarm Use).	Advanced Function Setting Level  HS Alarm Use
2	Check to see if the set value is $\tilde{a}N$ (enabled, default).	HSU an

- Setting the Leakage Current Value Monitor
- Press the Key several times in the Adjustment Level to display L[R I (Leakage Current 1 Value Monitor).

  Check the leakage current from the CT input that is used to detect heater short.

  The monitoring range is 0.0 to 55.0 A.

  Adjustment Level

  Leakage Current 1 Value Monitor

  LURI

  LUR
- · Setting Heater Short Alarm Detection
- Press the 
  Key several times in the Adjustment Level to display H5 I (HS Alarm 1).

  Press the 
  or 
  Key to set the set value to 2.5

  Refer to 4-12-4 Calculating Detection Current Values when you set the value.

  Adjustment Level

  HS Alarm 1

  5□.□

  HS Alarm 1
  - If there is little difference between the current in normal and abnormal states, detection may be unstable. To stabilize detection, set a current difference of at least 1.0 A for heaters lower than 10.0 A, and at least 2.5 A for heaters of 10.0 A or higher. If the heater current is too low, loop the load line several times through a CT, as shown in the following diagram. Looping it through once will double the detected current.






#### **Precautions for Correct Use**

Due to UL Listing requirements, use the E54-CT1L or E54-CT3L Current Transformer with the factory wiring (internal wiring). Use a UL category XOBA or XOBA7 current transformer that is UL Listed for field wiring (external wiring) and not the factory wiring (internal wiring).

# 4-12-3 Installing Current Transformers (CT)

• CTs can be used for the heater burnout (HB) and heater short (HS) alarms.
For the E5CD, connect the CT in advance to terminals 16 and 17 (CT1). For the E5CD-B, connect the CT in advance to terminals 21 and 22 (CT1). For the E5ED, connect the CT in advance to terminals 19 and 20 (CT1). For the E5ED-B, connect the CT in advance to terminals 25 and 26 (CT1). Then pass the heater power line through the hole in the CT. For specifications, models, and dimensions of the CTs that can be used with the Digital Controller, refer to A-2 Current Transformer (CT). Install the CT in the position shown in the following diagram.



# 4-12-4 Calculating Detection Current Values

Calculate the set value using the following equation:

• To set the current for heater burnout when two or more heaters are connected through the CT, use the value from when the heater with the smallest current burns out. If all of the heaters have the same current, use the value from when any one of them burns out.

• Make sure that the following conditions are satisfied:

Heater with a current of less than 10.0 A:

(Normal current value) – (Burnout current value) ≥ 1 A

When the difference is less than 1 A, detection is unstable.

Heater with a current of 10.0 A or more:

(Normal current value) - (Burnout current value) ≥ 2.5 A


When the difference is less than 2.5 A, detection is unstable.

- The setting range is 0.1 to 49.9 A. Heater burnouts and heater shorts are not detected when the set value is 0.0 or 50.0. When the set value is 0.0, the HB alarm is always OFF and the HS alarm is always ON. When the set value is 50.0, the HB alarm is always ON and the HS alarm is always OFF.
- Set the total current value for normal heater operation to 50 A or less. When a current value of 55.0 A
  is exceeded, FFFF is displayed in the Heater Current 1 Value Monitor and Leakage Current 1 Monitor
  parameters.


# 4-12-5 Application Examples

Example: Using a 200-VAC, 1-kW Heater

Normal




Burnout



The heater power supply provides 5 A when the current is normal, and 0 A when there is a burnout, so the heater burnout detection current is calculated as follows:

Heater burnout detection current = 
$$\frac{\text{(Normal current)} + \text{(Heater burnout current)}}{2}$$
$$= \frac{5+0}{2} = 2.5 \text{ [A]}$$

Example: Using Three 200-VAC, 1-kW Heaters



The heater power supply provides 15 A when the current is normal, and 10 A when there is a burnout, so the heater burnout detection current is calculated as follows:

Heater burnout detection current = 
$$\frac{\text{(Normal current)} + \text{(Heater burnout current)}}{2}$$
$$= \frac{15 + 10}{2} = 12.5 \text{ [A]}$$

# 4-13 Customizing the PV/SP Display

The following table shows the contents of the No. 1, 2, and 3 displays, according to the setting of the PV/SP Display Screen Selection parameter.

# **PV/SP Display Selections**

The following table shows the contents of the No. 1, 2, and 3 displays, according to the setting of the PV/SP Display Screen Selection parameter in the Advanced Function Setting Level.

Set value	No. 1 display	No. 2 display	No. 3 display (E5ED or E5ED-B only)
0	Nothing is displayed.	Nothing is displayed.	Nothing is displayed.
1	PV	SP	Nothing is displayed.
2	PV	Nothing is displayed.	Nothing is displayed.
3	SP	SP (character display)	Nothing is displayed.
4	PV	SP	MV (Heating)
5	PV	SP	Multi-SP No.*
6	PV	SP	Soak Time Remain *
7	PV	SP	Internal Set Point (ramp SP)
8	PV	SP	Alarm Value 1*
9	PV	SP	MV (Cooling)*

Nothing is displayed on the No. 1, 2, and 3 displays if the display conditions are not met.

	Monitoring range	Unit
D\/	Temperature input: The specified range for the specified sensor.	EU
PV	Analog input: Scaling lower limit -5%FS to Scaling upper limit +5%FS	

	Setting (monitoring) range	Unit
SP	SP lower limit to SP upper limit	EU

During temperature input, the decimal point position depends on the currently selected sensor, and during analog input it depends on the Decimal Point parameter setting.

# PV/SP Display Selections

Code	Parameter	Default	Level
SPd I	PV/SP No. 1 Display Selection	4	Advanced Function Setting
5Pd2	PV/SP No. 2 Display Selection	0	Level

# **Advanced Operations**

5-1		essing Temperature Variations When Using a Temperature Sensong Machines (for Packing Machines)	
5-2		natically Adjusting a Water-cooling Output ater-cooled Extruders)	. 5-7
5-3	<b>Perfor</b> 5-3-1 5-3-2	ming Adaptive Control	5-1
5-4	Indicat	tion Data	<b>5-2</b> 1
5-5	Shiftin	g Input Values	5-25
5-6	Setting	g Scaling Upper and Lower Limits for Analog Inputs	5-27
5-7	<b>Execu</b> <sup>1</sup> 5-7-1	ting Heating/Cooling Control	
5-8	<b>Using</b> 5-8-1 5-8-2 5-8-3	Event Inputs  Event Input Settings  How to Use the Multi-SP Function  Operation Commands Other than Multi-SP	5-33 5-33
5-9	<b>Setting</b> 5-9-1 5-9-2	g the SP Upper and Lower Limit Values Set Point Limiter Setting	5-39
5-10		the SP Ramp Function to Limit the SP Change Rate	
5-11	5-11-1	the Key Protect Level	5-43
5-12		and Displaying Parameters	
5-13	<b>OR O</b> u 5-13-1	Itput of Alarms	
5-14		<b>Delays</b> Alarm Delays	
5-15	•	Burnout Alarm Loop Burnout Alarm (LBA)	

5-16		ming Manual Control	
5-17	5-17-1 5-17-2	the Simple Program Function Simple Program Function Operation at the Program End Application Example Using a Simple Program	5-59 5-62
5-18	5-18-1 5-18-2	t Adjustment Functions	5-65 5-65
5-19		the Extraction of Square Root Parameter	
5-20		g the Width of MV Variation	
5-21		p the PF Key PF Setting (Function Key)	
5-22	•	ying PV/SV Status	
5-23	5-23-1	Operations 000	5-75
5-24	Initializ	zing Settings	5-84
5-25	Setting	g the Operating Status to Use When Power Is Turned ON5	5-85
5-26	Using	the Transfer Output for the Process Value, Set Point,	
		er Data 000	


# 5-1 Suppressing Temperature Variations When Using a Temperature Sensor for Packing Machines (for Packing Machines)

# Overview

The seal quality in packing machines is influenced by the temperature of the seal surface at the hot plates.

Traditionally, the temperature of hot plates in packing machines is measured a distance from the seal surface in the hot plates, which makes the measurement easily influenced by the heat from the heaters and creates a deviation between the measured temperature and the actual temperature of the seal surface.

\* The actual seal surface temperature is essentially the same as the surface temperature of the heating plate.



To solve this problem, OMRON provides Temperature Sensors for Packing Machines\* and automatic filter adjustment to measure the surface temperature of the hot plate. If you use our Temperature Sensors for Packing Machines, you can measure the actual temperature of the seal surface. However, heat is taken from the packing materials, so periodic temperature variations can occur. If you also use the automatic filter adjustment function of the E5□D, you can automatically suppress these temperature fluctuations.


This lets you use the Temperature Sensors for Packing Machines together with automatic filter adjustment to control quality with the actual seal surface temperature while also suppressing temperature variations automatically without workers performing adjustments. You can also use automatic filter adjustment to suppress temperature variations for periodic disturbances even when using traditional temperature sensors.

\* Refer to 2-3 Installing Temperature Sensors for Packing Machines.


We recommend that you use automatic filter adjustment in the following cases.

 If temperature variation occurs when Temperature Sensors for Packing Machines are used even if AT is performed

- If temperature variation occurs after a heater is replaced
- If temperature variation occurs after packing materials are changed or the packing speed is changed
- If temperature variation occurs due to changes in the operating environment
- Example of Temperature Control with a Traditional Measurement Point




Control Example Using a Temperature Sensor for Packing Machines



Particularly when packing materials are thick or the contents are cold, heat is taken from the hot plates and temperature variations occur. If normal temperature control is used in this case, there will be large temperature variations for each seal and over long periods of several tens of seconds. If this occurs, the automatic filter adjustment function of the E5 D can be used to improve control.

• Control Example Where Automatic Filter Adjustment Suppresses Temperature Variations Caused by a Temperature Sensor for Packing Machines



Note: When using automatic filter adjustment, turn ON power for the load (e.g., heater) at the same time as or before supplying power to the Digital Controller. Also, do not turn OFF the load power supply during the adjustment. Doing so will prevent correct calculation of the input digital filter.

# Parameters Related to Automatic Filter Adjustment

Parameter	Display	Set (monitor) values	Unit	Default	Level	
Automatic Filter Adjustment*	FA	āFF: OFF āN: ON		OFF	Adjustment Level	
Input Digital Filter	INF	0.0 to 999.9	Seconds	0.0	Adjustment Level	
Automatic Filter Adjustment Seal Period*	FRSP	0.1 to 10.0	Seconds	2.0	Advanced Function Setting Level	

Parameter	Display	Set (monitor) values	Unit	Default	Level
Automatic Filter Adjustment Hunting Monitor Period*	FAHP	10 to 1999	Seconds	200	Advanced Function Setting Level

\* These parameters are displayed when 2-PID control or standard control (not heating/cooling control) is selected.

### Parameters

• Automatic Filter Adjustment (FR)

This parameter is used to execute automatic filter adjustment.

• Input Digital Filter ( INF)

The set value of this parameter is used by a digital filter through which the sensor input passes to create a stable input value even when the sensor input value fluctuates due to noise. This parameter is automatically set when automatic filter adjustment is used.

• Automatic Filter Adjustment Seal Period (FR5P)

This is the period of small temperature variations (up to several seconds) that occur in one seal. Normally, use the default for this parameter.\*

• Automatic Filter Adjustment Hunting Monitor Period (FRHP)

This is the period of large temperature variations (several tens of seconds or longer) when packing.

Normally, use the default for this parameter.

If tuning for the automatic filter adjustment continues indefinitely or tuning requires a long time, measure the temperature waveform to set this parameter.\*

\* If tuning for the automatic filter adjustment continues indefinitely or tuning requires a long time, measure the temperature waveform to set this parameter according to the frequency of oscillation.

# Operating Conditions

Operation is possible when all of the following conditions are met.

Startup Conditions

Automatic filter adjustment will start when all of the following conditions are met.

- The PID ON/OFF parameter must be set to "PID."
- The Standard or Heating/Cooling parameter must be set to "Standard."
- The Auto/Manual parameter must be set to "Automatic."
- The RUN/STOP parameter must be set to "RUN."
- The AT Execute/Cancel parameter must be set to "AT Cancel."
- There must be no input errors.

# Restrictions during Execution

During automatic filter adjustment, the settings of other parameters cannot be changed in the same way that they cannot be changed during auto-tuning.

However, the following parameters can be changed.

- Auto/Manual
- · Communications Writing
- RUN/STOP

- Automatic Filter Adjustment
- AT Execute/Cancel
- Program Start (simple program)

Automatic filter adjustment will be cancelled in the following cases. The value of the Input Digital Filter parameter that was set during adjustment will not be saved.

- When the Automatic Filter Setting parameter is set to "OFF"
- When the RUN/STOP parameter is set to "STOP"
- When auto-tuning (AT) has been executed
- When the display is moved to the Initial Setting Level or Manual Control Level
- · When a sensor error occurs
- When the temperature variations cannot be eliminated
- When the power supply is turned OFF

Calculations for the input digital filter will not be performed if the following things occur at startup.


- When the process value is not close to the set point
- When the SP ramp operates

# Using Automatic Filter Adjustment

Automatic filter adjustment will be performed with the following operation.

Execute auto-tuning in advance. Refer to 4-9-1 AT (Auto-tuning). Or, if you are also using adaptive control, make preparations for adaptive control in advance. (Refer to 5-3 Performing Adaptive Control)

# **Operating Procedure**



<sup>\*</sup>For example, setting startup conditions.

· Automatic filter adjustment performed.

1	Press the	Adjustment Level	
	play FR (Automatic Filter Adjustment).	Automatic Filter Adjustment	
2	Press the or Key to select on (ON).  The TUNE indicator will light and the Input Digital Filter parameter will be set automatically.	FA	
3	When adjustments have been completed, the $\boxed{\text{TUNE}}$ indicator will go out. The Automatic Filter Adjustment parameter will automatically return to $\bar{a} \mathcal{F} \mathcal{F}$ (OFF).	FR öff	



# **Precautions for Correct Use**

- If you use automatic filter adjustment, do not use manual operation to change the PID constants that were automatically set by auto-tuning. It may not be possible to suppress hunting in some cases.
- If you perform automatic filter adjustment when there is a continuous deviation between the process temperature and set point\*, the input digital filter may not be adjusted correctly. Turn ON automatic filter adjustment when the process temperature is close to the set point.
  - Examples of continuous deviation are given below.
    - Example 1: Heat cannot escape, so the temperature declines only slowly.
    - Example 2: The power supply to the heater is not turned ON.
- If a MV change rate limit has been set, the input digital filter may not be adjusted correctly.
- If there are water drops or similar object on the temperature sensor, the input digital filter may not be adjusted correctly.

# 5-2 Automatically Adjusting a Water-cooling Output (for Water-cooled Extruders)

# Overview

Mainly, this function simultaneously suppresses temperature variations in water-cooled extruders for the following two factors to maintain stable performance.

- 1. When the heat of vaporization is used as a cooling method, such as in water-cooled extruders, the cooling performance is nonlinear, so temperature variations can occur.
  - The water-cooling output adjustment function automatically suppresses hunting that occurs due to a water-cooling output.
- 2. With traditional auto-tuning, temperature variations can occur when changes in conditions during operation cannot be handled.

The water-cooling output adjustment function constantly monitors temperature changes and updates the cooling-side proportional band to help suppress temperature variations. You can disable water-cooling output adjustment after temperature variations have subsided to continue control with the cooling-side proportional band that was being used.

We recommend that you use water-cooling output adjustment in the following cases.


- If temperature variation occurs due to changes in the water-cooling system
- If temperature variation occurs due to changes in the cooling valve settings
- · To reduce the amount of work required to adjust cooling valves

Water-cooling output adjustment works to suppress hunting by automatically increasing and decreasing the following value.

- Increasing the Cooling-side Proportional Band
   The Proportional Band (Cooling) parameter is adjusted to suppress the width of temperature variations.
- Decreasing the Cooling-side Proportional Band If disturbances results from heat generated by the material in the extruder or by screw friction, hunting will occur if the cooling capacity is too weak.

The Proportional Band (Cooling) parameter is adjusted to reduce the influence of hunting.

# Temperature



# Parameters Related to Water-cooling Output Adjustment

Parameter	Display	Set (monitor) values	Unit	Default	Level
Water-cooling Output Adjustment *1*2	W-HE	āFF: Disabled āN: Enabled		āFF	Adjustment Level
Water-cooling Proportional Band Increase Threshold *1	M-IL	Water-cooling proportional band decrease threshold + 0.1 to 200.0	°C or °F	1.4	Adjustment Level
Water-cooling Proportional Band Decrease Threshold *1	M-dL	OFF or 0.1 to Water-cooling increase threshold - 0.1	°C or °F	0.6	Adjustment Level
Water-cooling Proportional Band Increase Constant *1	M-IE	1.00 to 10.00		1.70	Advanced Function Setting Level
Water-cooling Proportional Band Decrease Constant *1	M-9E	0.10 to 0.99		0.90	Advanced Function Setting Level
Proportional Band (Cooling)	[-P	0.1 to 999.9	Temperature input (°C or °F)	8.0	Adjustment Level
			Analog input (%FS)*3	10.0	]

These parameters are displayed when 2-PID control is used, a temperature input is used, heating/cooling control is used, and the Heating/Cooling Tuning Method parameter is set to "Water cooling."

# Parameters

- Water-cooling Output Adjustment(W-HL) This parameter is used to enable or disable water-cooling output adjustment.
- Water-cooling Proportional Band Increase Threshold (W-LL) This parameter sets the threshold for the temperature variation that is used to detect hunting. If the variation exceeds this threshold, the cooling proportional band is adjusted to reduce hunting. Normally, use the default for this parameter.
- Water-cooling Proportional Band Decrease Threshold (W-dL)

This parameter sets the threshold to the temperature variation that is used to detect when disturbance response is not optimal.

If the variation is less than or equal to this threshold, the cooling-side proportional band is adjusted to optimize disturbance response.

Normally, use the default for this parameter.

• Water-cooling Proportional Band Increase Constant (#- [])

This parameter gives the increase constant when the value of the cooling proportional band is adjusted to reduce hunting.

This function works to suppress an excessive cooling output that may cause hunting when the cooling-side proportional band is increased

Normally, use the default for this parameter.

<sup>\*2</sup> You can allocate an event input to water-cooling output adjustment and use the event input to enable and disable the function.

<sup>\*3</sup> Water-cooling output adjustment will not work with an analog input.

• Water-cooling Proportional Band Decrease Constant (W-dL)

This parameter gives the decrease constant when the value of the cooling proportional band is adjusted to optimize disturbance response.

This function works to increase an insufficient cooling output that may reduce disturbance response when the cooling proportional band is decreased.

Normally, use the default for this parameter.

# Proportional Band (Cooling) (*L-P*)

The set value of this parameter is used to calculate the manipulated value of the cooling output in proportion to the deviation between the process value and the set value. The water-cooling output adjustment function automatically adjusts the Proportional Band (Cooling) parameter.

If you set the cooling proportional band manually, first turn OFF water-cooling output adjustment.

# Operating Conditions

Startup Conditions

Operation is possible when all of the following conditions are met.

- The input type must be set for a temperature input.
- The PID ON/OFF parameter must be set to "PID."
- The Standard or Heating/Cooling parameter must be set to "Heating/cooling."
- The Heating/Cooling Tuning Method must be set to "Water cooling."
- The Auto/Manual parameter must be set to "Automatic."
- The RUN/STOP parameter must be set to "Run."
- Reverse operation must be set.
- The AT Execute/Cancel parameter must be set to "AT Cancel."
- The Integral Time (Cooling) parameter must not be set to 0.
- The Water-cooling Output Adjustment parameter must be set to "ON."
- · A SP ramp must not be operating.
- The process value must be close to the set point.
- · There must be no input errors.

### • Cancellation Conditions


Water-cooling output adjustment is cancelled in the following cases. The cooling-side proportional band that was being calculated is not saved.

- When the Auto/Manual parameter is changed to "Manual"
- When the RUN/STOP parameter is set to "STOP"
- · When direct operation is used
- When the AT Execute/Cancel parameter is changed to "AT Execute"
- When the Integral Time (Cooling) parameter is changed to 0
- When the display is moved to the Initial Setting Level or Manual Control Level
- When a software reset is performed
- When a sensor error occurs

# Using Water-cooling Output Adjustment

Confirm that all of the previous startup conditions have been met. Execute auto-tuning in advance. Refer to 4-9-1 AT (Auto-tuning).

# **Operating Procedure**



<sup>\*</sup>For example, setting startup conditions.

• Setting Water-cooling Output Adjustment

Press the Key several times in the Adjustment Level to dis-Adjustment Level play ₩-₩₺ (Water-cooling Output Adjustment). ₩-HE Water-cooling This parameter is not displayed if an event input is allocated to Output Adjustment 5FF water-cooling output adjustment. Press the riangle or riangle Key to select  $\bar{a}N$  (Enabled). W-HF Water-cooling output adjustment is started. It will stop if the āΝ parameter is changed to  $\bar{a}FF$  (Disabled).



# **Precautions for Correct Use**

If you use water-cooling output adjustment, do not use manual operation to change the PID constants that were automatically set by auto-tuning. It may not be possible to suppress hunting in some cases.

# 5-3 Performing Adaptive Control

# 5-3-1 Overview

Adaptive control has the following two features.

- 1. You can increase control performance over traditional auto-tuning.
- Even if factors emerge during long-term equipment operation that cause temperature variations and influence system characteristics, such as changes in the operating environment or equipment deterioration, the changes can be followed to maintain high control performance.

We recommend adaptive control in the following cases.

- When satisfactory control is not possible with the PID constants calculated with auto-tuning
- When high control performance cannot be maintained due to temporal variations in system characteristics, such as changes in the environment or equipment deterioration

Broadly speaking, adaptive control provides the following two functions.

- · Control with PID constants that are optimum for the system characteristics
- · Maintenance of optimum status following changes in system characteristics


You can also use only the function to find the optimum PID constants for the system characteristics.

# Control with PID Constants That Are Optimum for the System Characteristics

To find the PID constants for adaptive control, set adaptive control (RdPE) for automatic updating ( $RUE\bar{a}$ ) and then perform the following procedure.

- **1** Perform auto-tuning to determine system characteristics.
- **2** Lower the temperature sufficiently.
- 3 Increase the temperature to the set point. While the temperature is rising, system performance will be evaluated and the PID constants for adaptive control will be calculated automatically. (The A indicator will flash during this process.)
- 4 From here on, control will be performed with the PID constants for adaptive control.


  The PID constants for adaptive control will reflect the system characteristics more than the PID constants calculated with auto-tuning to enable better control.



Note: When using adaptive control, turn ON power for the load (e.g., heater) at the same time as or before supplying power to the Digital Controller. If you turn ON the power supply to the load after you turn ON the power supply to the Digital Controller, correct system performance evaluation will not be possible, the PID constants for adaptive control will not be calculated correctly, and you will not achieve optimum control.

# 2. Maintenance of Optimum Status Following Changes in System Characteristics

After the PID constants for adaptive control are calculated, the system performance is evaluated each time the equipment is started and the PID constants for adaptive control are updated according to any changes. Therefore, even if the heater or other equipment deteriorates over time and system performance changes gradually, control with the optimum PID constants is possible.



- Note 1. The expected performance will not be achieved if heaters deteriorate to the point where there is insufficient capacity to reach the set point.
  - 2. This function cannot be used during any of the following: heating/cooling control, an analog input type, direct operation, and SP ramp operation.

# **Related Parameters**

Parameter	Display	Set (monitor) values	Default	Level
Adaptive Control	AdPt	āFF: Disabled F∑X: Fixed ∑NFā: Notification RUEā: Automatic update	āFF	Initial Setting Level
PID Update (adaptive control)	A-Ud	āFF: OFF āN: Updated	ōFF	Adjustment Level
Adaptive Control Operation Possible Deviation	A-dV	0.0% to 100.0% 0°C (32°F) to Set point = 100%	50.0	Advanced Function Setting Level
System Fluctuation Reference Deviation	R-5d	0.0% to 100.0%	15.0	Advanced Function Setting Level

The following parameters are also available. These parameters are set automatically, so there is no need to change the settings.

- Model Parameters: These parameters are set to determine the system characteristics with auto-tuning.
- SP response PID constants, disturbance PID constants, and SP Response Coefficient Number: These PID constants are used for adaptive control. Refer to 5-14.

# **Parameters**

# Adaptive Control (₽d₽Ł)

If the Adaptive Control parameter is set to anything except  $\bar{a}^{FF}$  (Disabled), control is performed with the PID constants for adaptive control.

After you set this parameter, perform either 40% or 100% auto-tuning.

After auto-tuning is completed, stop control (STOP or turn OFF the power supply), allow the temperature to drop sufficiently, and then start control (RUN) again.

If you do, operation will be performed according to the setting of the Adaptive Control parameter, as described below.

# • Setting Value of RULo (Automatic Update)

System performance is evaluated and the PID constants for adaptive control are updated automatically. This enables continuous control with the optimum PID constants. The  $\boxed{\mathbb{A}}$  indicator flashes during system performance evaluation and goes out when evaluation is completed.


# Set Value of <u>INF</u> (Notification)

If system fluctuations occur after system performance is evaluated, the PID constants for adaptive control are updated by the user.

This setting can be used so that the user can confirm changes in the environment or deterioration in equipment.

The  $\Box$  indicator flashes during system performance evaluation. If the PID constants need to be updated, the  $\Box$  indicator will light to provide notification of changes in the operating environment or deterioration in equipment. If the fluctuation in the system is small, the  $\Box$  indicator will not light, but the adaptive control PID constants will be calculated.

To update the PID constants, the user changes the setting of the R-Ud (PID Update) parameter described below to  $\bar{a}N$  (Update). The notification display ( $|\underline{A}|$  indicator) will appear the third time system performance is evaluated.



# Set Value of FLX (Fixed)

System performance is not evaluated.

Use this setting when you want to calculate the PID constants for adaptive control with  $\vec{R} = \vec{L} = \vec{L$ 

The A indicator will remain not lit.

# Set Value of <u>a</u>FF (Disabled)

Adaptive control is disabled. Operation uses 2-PID control.

# ● PID Update (Adaptive Control) (R-Ud)

This parameter is displayed if the Adaptive Control parameter is set to LNF a (Notification) and updateable PID constants are calculated.

This setting is used to manually update the PID constants to newly calculated PID constants. The parameters can be updated in the following two cases.

- When PID Update parameter is being displayed
- When the Enable PID Constants for Adaptive Control Bit in the communications status is ON.

If you use the  $\triangle$  Key to change the setting from  $\bar{a}FF$  (OFF) to  $\bar{a}N$  (Update), the PID values are updated to the values calculated with system performance evaluation. After the setting is updated, the R-Ud display disappears and the next parameter will be displayed.

After the setting is updated, the notification display ( A indicator) will appear the third time system performance is evaluated.

To prevent updating, perform one of the following operations. The A indicator will go out.

- Cycle the power supply.
- Set the Adaptive Control parameter for fixed operation (Fix).
- · Perform a software reset.

# ■ Adaptive Control Operation Possible Deviation (R-dV)


The set value of this parameter is used to determine if system performance evaluation for adaptive control is possible based on the relationship between the process value and set point when control is started.

This parameter gives the temperature range over which system performance evaluation is performed using the temperature width from 0°C to the set point as 100%. The default is 50.0 (%). To ensure the performance of adaptive control, do not set a value less than 50%.

If the Adaptive Control Operation Possible Deviation parameter is set to 50%, system performance evaluation for adaptive control will not be performed if the starting temperature is 50% of the set point or higher from 0°C. (The A indicator will not flash and will not be lit.)

Example: If the set point is 280°C, the temperature range at which adaptive control is possible is 140°C.

If the temperature is 140°C or lower when adaptive control is enabled, adaptive control will be performed. If the temperature is greater than 140°C, adaptive control will not be performed.



# System Fluctuation Reference Deviation (R-5d)

This parameter is displayed when the Adaptive Control parameter is set to LNF a (Notification). If the rate of change in the proportional band\* that is calculated for system performance evaluation exceeds this reference value, the A indicator lights to provide notification of a temperature variation in the system.

The default is 15.0%.

This is the rate of change in the proportional band calculated for the second system evaluation.

# Model Parameters

These parameters express the characteristics of the system.


These parameters are displayed when the Adaptive Control parameter is not set to  $\bar{a}FF$  (Disabled).

The model parameters are calculated automatically if auto-tuning is performed when the Adaptive Control parameter is set to  $\text{RUE}_{\bar{a}}$  (Automatic update) or  $\text{LNE}_{\bar{a}}$  (Notification). They do not need to be set by the user. Also, this parameter is copied so that another Digital Controller can inherit the measured system characteristics.

Parameter	Display	Setting range	Unit	Default	Level
Model Creation PV Amplitude	M-PV	0.00 to 99.99	%FS	0.00	Initial Setting Level
Model Creation MV Amplitude	M-MV	0.0 to 100.0	%FS	0.0	Initial Setting Level
Model Creation ON Time	M-āN	0 to 9999		0	Initial Setting Level
Model Creation OFF Time	M-āF	0 to 9999		0	Initial Setting Level

# SP Response PID Constants, Disturbance PID Constants, and SP Response Coefficient Number

These parameters are necessary to perform adaptive control. Adaptive control is performed with different PID constants for transient control states and steady states. These two sets of PID constants (SP response PID constants and disturbance PID constants) are used with the SP Response Coefficient Number to automatically calculate the optimum values following changes in the equipment based on system performance evaluation. It is not necessary for you to set these parameters.



These parameters are displayed only when the Adaptive Control parameter is set to  $F \subset \mathcal{F}$  (Fixed).

They are not displayed while the Adaptive Control parameter is set to  $\exists \exists \bot \bar{a}$  (Automatic update) or  $\bar{\bot}NF\bar{a}$  (Notification).

The following parameters are available.

Parameter	Display	Setting range	Unit		Default	Level
SP Response	5P-P	0.1 to 999.9	Temperature	°C	8.0	Adjustment
Proportional Band			input	°F	14.4	Level
SP Response	5P-I	Integral/Derivative Time	Seconds		233	Adjustment
Integral Time		Unit of 1 s: 0 to 9,999				Level
		Integral/Derivative Time			233.0	
		Unit of 0.1 s: 0.0 to 999.9				
SP Response	SP-d	Integral/Derivative Time	Seconds		40	Adjustment
Derivative Time		Unit of 1 s: 0 to 9,999				Level
		Integral/Derivative Time			40.0	
-		Unit of 0.1 s: 0.0 to 999.9				
SP Response	5P-N	0 to 9999			0	Adjustment
Coefficient Number						Level
Disturbance	d-P	Same as SP Response	Same as SP		Same as SP	Adjustment
Proportional Band		Proportional Band.	Response		Response	Level
			Proportional Ba	and.	Proportional Band.	
Disturbance Integral	d-ī	Same as SP Response	Same as SP		Same as SP	Adjustment
Time		Integral Time.	Response Integral		Response Integral	Level
			Time.		Time.	
Disturbance	d-d	Same as SP Response	Same as SP		Same as SP	Adjustment
Derivative Time		Derivative Time.	Response Integral		Response Integral	Level
			Time.		Time.	



# Additional Information

# Reducing Tuning Work for Replacing the E5□D or for Equipment Mass Production

If you replace the E5□D or are mass-producing the same equipment, you can copy model parameters to eliminate the need to repeat tuning (AT with system performance evaluation) and perform adaptive control with the same system performance.

Adaptive Control Set to Notification or Automatic Update

Copy source









### Model Parameters

- Model Creation PV Amplitude
- Model Creation MV Amplitude
- Model Creation ON Time
- Model Creation OFF Time



Copy the model parameters in the Initial Setting Level.

### Model Parameters

- Model Creation PV Amplitude
- Model Creation MV Amplitude
- Model Creation ON Time
- Model Creation OFF Time



Automatically Calculated Parameters\*

Parameters for Adaptive Control

- SP Response Proportional Band
- SP Response Integral Time
- SP Response Derivative Time
- SP Response Coefficient Number
- Disturbance Proportional Band
- Disturbance Integral Time
- Characteristics are determined from the model parameters and the adaptive control PID constants are automatically calculated. When system performance is evaluated, the PID constants are automatically updated to match the system at the copy destination.

Adaptive Control Set to Fixed

Parameters for Fixed Adaptive Control

- SP Response Proportional Band
- SP Response Integral Time
- SP Response Derivative Time
- SP Response Coefficient Number
- Disturbance Proportional Band
- Disturbance Integral Time
- Disturbance Derivative Time



Parameters for Fixed Adaptive Control

- SP Response Proportional Band
- SP Response Integral Time
- SP Response Derivative Time
- SP Response Coefficient Number
- Disturbance Proportional Band
- Disturbance Integral Time
- Disturbance Derivative Time

Copy the above parameters in the Adjustment Level.



# **Precautions for Correct Use**

- Before you copy the model parameters, set the input type and temperature unit. If you change these setting later, the model parameters will be initialized.
- If you have changed the AT Hysteresis or AT Calculated Gain parameters from their default values on the copy source Digital Controller, copy the AT Hysteresis and AT Calculated Gain parameters before you copy the model parameters. Calculation error will occur when calculating adaptive control PID constants from model parameters.

# **Operating Conditions**

Adaptive control is possible when all of the following conditions are met.

- Display Conditions for Adaptive Control Parameter
  - RdP는 (Adaptive Control) is displayed in the Initial Setting Level when all of the following conditions are met.
    - The Standard or Heating/Cooling parameter must be set to "Standard."
    - The input type must be set for a temperature input.
    - The PID ON/OFF parameter must be set to "PID."
- Conditions for System Performance Evaluation

System performance evaluation is performed when all of the following conditions are met.

- The Adaptive Control parameter must be set to "Automatic update" or "Notification."
- The Auto/Manual parameter must be set to "Auto."
- The Direct/Reverse Operation parameter must be set to "Reverse operation."
- The AT Execute/Cancel parameter must be set to "AT Cancel."
- The SP Ramp Set Value parameter must be set to "OFF."
- The SP Ramp Fall Value parameter must be set to "OFF" or "SAME."
- All of the model parameters must not be at the default values.
- The starting temperature must be separated from the set point by at least the adaptive control
  operation possible deviation.
- The starting temperature must be separated from the set point by at least 10°C.
- The starting temperature must be at least 0°C.
- System performance evaluation must not start immediately after recovery from an input error.

# **Startup Conditions**

- When power is turned ON with the RUN/STOP parameter set to RUN
- When the RUN/STOP parameter is changed from STOP to RUN after the power supply is turned ON

# Restrictions

# 1. Starting Temperature Restriction

If the control starting temperature is equal to or greater than the temperature set in the Adaptive Control Operation Possible Deviation parameter, system performance will not be evaluated.

# 2. Set Point Change Restriction

The set point can be changed, but if the change is too large, system characteristics will change and may influence control performance.

We recommend that you perform auto-tuning again if the set point is changed by more than the following range.

Set point calculated during AT ±30%

# 3. Changes to Parameters during System Performance Evaluation

If any of the following parameters is changed during system performance evaluation (i.e., when the A indicator is flashing or lit), system performance evaluation and notification will be cancelled. The PID constants will not be updated.

- · Set point currently being used
- Multi-SP
- SP Ramp Rise Value
- SP Ramp Fall Value
- PV Input Shift
- PV Input Slope Coefficient

- MV Upper Limit
- MV Lower Limit
- MV Change Rate Limit
- SP response PID constants
- SP Response Coefficient Number
- · Disturbance PID constants

# 4. Restrictions in Changes to Parameters after System Performance Evaluation

If any of the following parameters, which restrict inputs to the system or outputs from the system, are changed, they will be considered system fluctuations and system performance evaluation will be performed the next time control is started.

- Moving Average Count
- PV Input Shift
- PV Input Slope Coefficient
- Input Digital Filter
- MV Upper Limit/MV Lower Limit
   SP Response Coefficient
- MV Change Rate Limit
- Control Period
- SP response PID constants
- Disturbance PID constants

# 5. Display Conditions for SP Response PID Constants and Disturbance PID **Constants**

If the Adaptive Control parameter is set to AULa (Automatic update) or LNFa (Notification), you will not be able to display the SP response PID constants and disturbance PID constants in the Adjustment Level. Set the Adaptive Control parameter it Fix (Fixed) to display them. You can also confirm the settings with communications.

# 6. Initializing Model Parameters

The model parameters will be initialized if you change any of the following parameters, which are related to the input range. To use adaptive control, perform auto-tuning again.

- Input Type
- · Temperature Unit



# **Precautions for Correct Use**

The effectiveness of adaptive control may not be achieved under the following conditions.

- Heaters for which there is a large change in the resistance depending on the temperature
- Devices for which boiling or melting occurs
- Devices for which there is high thermal interference
- · Devices that reach the set point in 5 s or less
- Devices that have a set point near room temperature
- When large disturbances (temperature fluctuations) occur during system performance evaluation ( A flashing).
- When the MV upper limit is less than 100%
- When the MV lower limit is greater than 0%
- When an MW change rate limit is set
- When the MV is not 0% when stopping

# 5-3-2 Application Methods for Adaptive Control

You can set the following three operations for adaptive control.

Mode	Description
Automatic update	Control is performed with the PID constants for adaptive control and the PID constants are updated automatically according to system fluctuations.
Notification	Control is performed with the PID constants for adaptive control, notification is provided for the PID constants according to system fluctuations, and the user determines when to update the PID constants.
Fixed	The PID constants for adaptive control are used, but control is performed without changing the PID constants.

The setup and procedural flow is given below.

Power ON



Initial Setting Level

- Input type = Temperature input (default: thermocouple K (5) (Select a thermocouple, resistance thermometer, or infrared temperature sensor.)
   PID ON/OFF = PID (default)
   Standard or Heating/Cooling = Standard (default)
   Auto/Manual = Auto (default)
   Direct/Reverse Operation = Reverse operation (default)
   SP Ramp Set Value = OFF (default)
- Control Period
  - Alarm Type and other parameters

Setting Up Adaptive Control

\* To use the "Fixed" setting, first perform system performance evaluation by setting "Automatic update" or "Notification," and then change the setting to "Fixed."

Operating Procedure

- Setting Up Adaptive Control
- 1. Press the Key several times in the Initial Setting Level to display RdPŁ (Adaptive Control).

Initial Setting Level
Adaptive Control

2. Press the A > to select auto (Automatic update). The default is  $\tilde{a} FF$  (OFF).





Preparations for Adaptive Control

\* If you change the Input Type or Temperature Unit parameter during adaptive control, perform the operation again from this procedure.

Set the set point in Operation Level.



Execute 100% AT (AT-2, recommended) in the Adjustment Level.

The TUNE indicator will light.

\*The system characteristics are determined. (The model parameters are set automatically.)



After auto-tuning is completed, turn OFF the power supply or STOP and allow the temperature to drop sufficiently.\*3






Turn ON the power supply or RUN and increase the temperature.\*1

The A indicator will flash.

\*System performance is evaluated.



Go to Setting Up Adaptive Control (Automatic Update or Notification and Then Changing to Fixed Control When Necessary) on the next page.



<sup>\*1:</sup> System performance is evaluated if the temperature exceeds the set value of the Adaptive Control Operation Possible Deviation

<sup>\*2:</sup> You can use the following methods to determine if the PID constants for adaptive control can be updated or not.

Display the PID Update parameter.

<sup>·</sup> Turn ON the Enable Update PID Constants for Adaptive Control Bit in the communications status.

<sup>\*3:</sup> Do not change the PID constants for adaptive control with manual operation. If you do, error will occur in the PID calculations for system performance evaluation.

# **Indication Data**

# Overview of Functions

The E5DD contains indication data that can be used to help monitor trends in panel equipment, predict product service life, and determine replacement periods.

You can use this data to collect and analyze data and make predictions in the host system.

• Ambient temperature You can display the temperature around the terminals or read it with

monitor: communications. You can monitor trends in the ambient temperature to monitor

for abnormal heat generation in the panel.

· Power ON time data: You can display the total power ON time of the Digital Controller or read it with

communications.

The service life of the Digital Controller and equipment depends on the operating

environment.

You can collect power ON time data to clarify the relation between the operating environment and service life and use it to predict future machine maintenance

periods and to improve the operating environment.

• Control output ON/OFF

count monitors:

The contacts in the relays have a service life. You can display the number of

relay ON/OFF operations or read it with communications.

You can monitor this data to determine replacement periods before the service

life count to make maintenance more efficient.

### Power ON Time Data

You can display the power ON time of the E5□D or monitor it through communications.

The monitoring range is 0 to 99,990 hours. Power ON time is not recorded beyond that. The user cannot initialize the power ON time data.


There is no function to link this data with an alarm output.

Monitor data	Display	Monitor range	Unit	Default	Level
Power ON Time Monitor	PWEM	0 to 9999	10 hours	0	Advanced
					Function
					Setting
					Level

# Ambient Temperature Monitor

You can monitor the temperature around the terminals on the E5 D, but you cannot link this to an alarm output. This is a predictive value based on the temperature sensor element inside the E5 $\square$ D. Reference accuracy: Typically ±3°C

Monitor data	Display	Monitor range	Unit	Default	Level
Ambient Temperature	ЯЬЕМ	-30 to 75	°C		Advanced
Monitor		10 to 171	°F		Function
					Setting
					Level



# Control Output ON/OFF Count Monitors

With Control Output 1 and 2 ON/OFF outputs (relay outputs or voltage outputs for driving SSR), the number of times that a control output turns ON and OFF can be counted.

You can display the counts or monitor them through communications.

The monitor range is 0 to 999,900 times. The counts are not recorded beyond that.

There is no function to link this data with an alarm output.

There is a function to reset the control output ON/OFF counts. (Resetting is possible only with a key operation.)

Setting/monitor data	Display	Monitor range	Unit	Default	Level
Control Output 1	RA IM	0 to 9999	100 times	0	Advanced
ON/OFF Count Monitor					Function
					Setting
					Level
Control Output 2	RB2M	0 to 9999	100 times	0	Advanced
ON/OFF Count Monitor					Function
					Setting
					Level
ON/OFF Counter Reset	RRE	0: Resetting is		0	Advanced
		disabled.			Function
		1: Control Output 1			Setting
		ON/OFF Count			Level
		Monitor parameter is			
		reset.			
		2: Control Output 2			
		ON/OFF Count			
		Monitor parameter is			
		reset.			

# **Operating Procedure**

• Checking the Power ON Time Monitor

1	Press the @ Key several times in the Advanced Function Setting Level to display 무씨는데 (Power ON Time Monitor).	Advanced Function Setting Level Power ON Time
2	Check the power ON time.  Every 10 hours is one count.  Therefore, in the example on the right, the power ON time is between 10 hours and 19 hours 59 minutes.	PULM 000 I
• C	necking the Ambient Temperature Monitor	
1	Press the $m{\textcircled{P}}$ Key several times in the Advanced Function Setting Level to display $Bbbm$ (Ambient Temperature Monitor).	Advanced Function Setting Level  Ambient Temperature
2	Check the ambient temperature.  In the example on the right, the temperature would be 28°C if the temperature unit was °C.	<b>Abem</b>

• Checking and Resetting the Control Output 1 ON/OFF Count Monitor

1	Press the  Key several times in the Advanced Function Setting Level to display RR IM (Control Output 1 ON/OFF Count Monitor).	Advanced Function Setting Level  Control Output 1 ON/OFF Count
2	Check the control output 1 ON/OFF count.  Every 100 operations is one count.  Therefore, in the example on the right, the ON/OFF count is between 100 and 199 times.	RA IM 000 I
3	Press the  Key several times to select RRE (ON/OFF Counter Reset).  Press the  or  Key to select "1." The Control Output 1 ON/OFF Count Monitor parameter will be reset to 0. Press the  or  Key to select "2." The Control Output 2 ON/OFF Count Monitor parameter will be reset to 0. The display will return to 0 after the counter is reset.	Advanced Function Setting Level ON/OFF Counter Reset

# 5-5 Shifting Input Values

# Shifting Inputs


You can set the Process Value Slope Coefficient and Process Value Input Shift parameters to compensate the PV.

Parameter	Setting range	Unit	Default
Process Value Input Shift	Temperature input: -199.9 to 999.9	°C or °F	0.0
Frocess value input Stillt	Analog input: -1,999 to 9,999	EU	0
Process Value Slope Coefficient MASK8	0.001 to 9.999	None	1.000

Calculating the Process Value Slope Coefficient and Process Value Input Shift
 In the following equation, PVi is the input to the calculation, PVo is the result, INRT is the process
 value slope coefficient, and INS is the process value input shift: PVo = (PVi × INRT) + INS

# Moving Average

- The moving average operation reduces sudden changes in the input due to noise and other factors, and can be enabled separately for each input.
- The Moving Average Count parameter is used for the moving average. It can be set to OFF, 2, 4, 8, 16, or 32.
- The default is OFF (disabled).\*




Parameter	Setting range	Unit	Default
Moving Average Count	OFF, 2, 4, 8, 16, or 32	Times	OFF*

<sup>\*</sup> The default is 8 for models other than the  $E5\Box D-\Box -8\Box\Box$ .


# Input Digital Filter

You can use the input digital filter to help remove the noise component from input signals. If you set the Input Digital Filter parameter to any value other than 0.0, the filter works as a robust filter to reduce high-frequency noise.



Setting range	Unit	Default
0.0 to 999.9	Seconds	0.0

# Using the PV Input Shift



(1) Find the two points to shift and determine the PVs after the shifts are applied.

Example: Shift 500°C (temperature before shifting) to 550°C (temperature after shifting). Example: Shift 1,000°C (temperature before shifting) to 970°C (temperature after shifting).

(2) Find the process value slope coefficient from the above results.

$$(970 - 550) / (1,000 - 500) = 0.840$$

- \* Do not yet set the Process Value Slope Coefficient parameter in the Digital Controller.
- (3) Adjust the PV display on the Digital Controller to the point to be shifted. Example: Adjust the PV to 500°C.
- (4) Set the Process Value Slope Coefficient parameter to the value that you found in

Example: Set the Process Value Slope Coefficient parameter to 0.840.

(5) Read off the PV after the setting is changed.

Example: The PV will be displayed as 420°C.


(6) Find the difference between the anticipated PV (i.e., the PV after shifting) and the PV that you read off in step 5.

Example:  $550^{\circ}C - 420^{\circ}C = 130^{\circ}C$ 


(7) Set the Process Value Input Shift parameter to the value that you found in step 6. Example: Set the Process Value Input Shift parameter to 130°C.

# 5-6 Setting Scaling Upper and Lower Limits for Analog Inputs

# Analog Input



- When an analog input is selected, scaling can be performed as needed by the control application.
- Scaling is set in the Scaling Upper Limit, Scaling Lower Limit, and Decimal Point parameters (Initial Setting Level). These parameters cannot be used when a temperature input is selected.
- The Scaling Upper Limit parameter sets the physical quantity to be expressed
  by the upper limit value of input, and the Scaling Lower Limit parameter sets
  the physical quantity to be expressed by the lower-limit value of input. The
  Decimal Point parameter specifies the number of digits below the decimal
  point.
- The following figure shows a scaling example for a 4 to 20 mA input.
   After scaling, the temperature can be directly read. Here, one place below the decimal point is set.



In this example scaling is set to display 4 to 20 mA as 10.0% to 95.0%.

# **Operating Procedure**

- Setting the Input Type
- Move to the Initial Setting Level. ∠N-Ł (Input Type) will be displayed.

  Press the ♠ or ❤ Key to set the value to 25.
  The default is 5.

  Initial Setting Level

  LN-Ł
  Input Type

  Input Type
- Setting the Scaling Upper Limit
- Press the 
  Key several times in the Initial Setting Level to display 
  N-H (Scaling Upper Limit).

  Press the 
  or 
  Key to set the value to 950.

  The default is 100.

• Setting the Scaling Lower Limit

1	Press the  Key several times in the Initial Setting Level to	Initial Setting Level
	display EN-L (Scaling Lower Limit).	Scaling Lower Limit
2	Press the ♠ or ❤ Key to set the value to 100.	<u> </u>
	The default is 0.	<u>                                   </u>
		100
• Se	etting the Decimal Point	
1	Press the  Key several times in the Initial Setting Level to	Initial Setting Level
	display dP (Decimal Point).	<b>□</b> Decimal Point
2	Press the ♠ or ❤ Key to set the value to 1.	סר
	The default is 0.	

# 5-7 Executing Heating/Cooling Control

# 5-7-1 Heating/Cooling Control

Heating/cooling control can be used with control output 2 and auxiliary outputs 1 to 4. Heating/cooling control operates when H-L (heating/cooling) is selected for the Standard or Heating/Cooling parameter. The following functions are assigned to outputs in the default status.

Parameter name	Display	Initial status
Control Output 1 Assignment	āUE I	Control output for heating
Control Output 2 Assignment (E5ED or E5ED-B only)	ōUE2	Not assigned.
Auxiliary Output 1 Assignment	5Ub 1	Alarm 1 <sup>*1</sup>
Auxiliary Output 2 Assignment	5062	Alarm 2
Auxiliary Output 3 Assignment (E5ED or E5ED-B only)	5063	Alarm 3
Auxiliary Output 4 Assignment (E5ED or E5ED-B only)	5064	Alarm 4

Each output assignment is automatically initialized as shown below when changing between standard and heating/cooling control.

# **Assigned Output Functions**

Two Auxiliary Outputs (E5CD, E5ED, E5CD-B, or E5ED-B)

Parameter name	Display	Allocations		
raiailletei Ilaille	Display	Standard	Heating/cooling	
Control Output 1 Assignment	āUE I	Control output (heating)	Control output (heating)	
Auxiliary Output 1 Assignment	5U6 I	Alarm 1*	Alarm 1 <sup>*</sup>	
Auxiliary Output 2 Assignment	5062	Alarm 2	Control output (cooing)	

Four Auxiliary Outputs (E5ED or E5ED-B)


Parameter name Display		Without control output 2		With control output 2	
		Standard	Heating/cooling	Standard	Heating/cooling
Control Output 1 Assignment	āUE I	Control output (heating)	Control output (heating)	Control output (heating)	Control output (heating)
Control Output 2 Assignment	āUE2			Not assigned.	Control output (cooing)
Auxiliary Output 1 Assignment	SUb I	Alarm 1*	Alarm 1*	Alarm 1*	Alarm 1 <sup>*</sup>
Auxiliary Output 2 Assignment	SU62	Alarm 2	Alarm 2	Alarm 2	Alarm 2
Auxiliary Output 3 Assignment	SUb3	Alarm 3	Alarm 3	Alarm 3	Alarm 3
Auxiliary Output 4 Assignment	5064	Alarm 4	Control output (cooing)	Alarm 4	Alarm 4


- \* If the Digital Controller is equipped with HB/HS alarm detection, it is set by default to HB (Heater Alarm). If the Program Pattern parameter is changed to a setting other than OFF, the Auxiliary Output 1 Assignment parameter is set as the program end output.
  - The heating/cooling operation of the control outputs will switch when the Direct/Reverse Operation parameter is set to direct operation.

- When DRS (Invert Direct/Reverse Operation) is set for an Event Input Assignment 1 to 6 parameter, control will start with the opposite of the setting of the Direct/Reverse Operation parameter when the event input turns ON. When the event input turns OFF, control will return to operation according to the setting of the Direct/Reverse Operation parameter. For details on event inputs and control combined with the Direct/Reverse Operation parameter, refer to Control by Inverting Direct/Reverse Operation on page 5-36.
- If heating/cooling control is selected, also set the Dead Band, Proportional Band (Cooling), Integral Time (Cooling), Derivative Time (Cooling), and Heating/Cooling Tuning Method parameters.

# Dead Band

- For heating/cooling control, the dead band is set with the set point as its center. The dead band width is the set value of the Dead Band parameter (Adjustment Level). Setting a negative value produces an overlapping band.
- If an overlapping band is set, the bumpless function may not operate when switching between manual operation and automatic operation.
- The default is 0.0 EU for Digital Controllers with Temperature Inputs and 0.00% FS for Digital Controllers with Analog Inputs.





# Heating/Cooling PID Control

If heating/cooling PID control is used, you can set PID control separately for heating and cooling. The PID constants for both heating and cooling can be automatically set according to the cooling control characteristics by setting the Heating/Cooling Tuning Method parameter and then performing autotuning (AT).

Parameter	Setting range	Default	Level	
Heating/Cooling Tuning Method	0: Same as heating control			
	1: Linear	0	Advanced Function	
	2: Air cooling	0	Setting Level	
	3: Water cooling			

Parameter	Setting range		Unit	Default	Level
Proportional Band	Temperature input	0.1 to 999.9	°C or °F	8.0	
(Cooling)	Analog input	0.1 10 999.9	%FS	10.0	
Integral Time (Cooling)*	Integral/Derivative Time Unit of 1 s	0 to 9999	Seconds	233	
	Integral/Derivative Time Unit of 0.1 s	0.0 to 999.9	Seconds	233.0	Adjustment Level
Derivative Time (Cooling)*	Integral/Derivative Time Unit of 1 s	0 to 9999	Seconds	40	
	Integral/Derivative Time Unit of 0.1 s	0.0 to 999.9	Seconds	40.0	


The unit is determined by the setting of the Integral/Derivative Time Unit parameter. The Proportional Band (Cooling), Integral Time (Cooling), and Derivative Time (Cooling) parameters are initialized if the Integral/Derivative Time Unit parameter is changed.

# Air Cooling/Water Cooling Tuning

Control that is suitable for an application that does not have linear cooling characteristics (such as plastic molding machines) is performed. The response is fast and the response characteristics are stable.

# **Linear Tuning**

Control that is suitable for an application that has linear cooling characteristics is performed.



# Water-cooling Output Adjustment


If you set the Heating/Cooling Tuning Method parameter to 3 (Water Cooling), you can use water-cooling output adjustment. We recommend that you perform it in the following cases.

- · If the temperature varies due to fluctuations in the cooling system
- If the temperature varies due to changes in the cooling valve settings For details, refer to 5-2 Automatically Adjusting a Water-cooling Output (for Water-cooled Extruders).

# Three-position Control

- Set the PID ON/OFF parameter to aNaF and set the Standard or Heating/Cooling Parameter to H- $\Gamma$  to perform three-position control.
- A dead band (an area where the MV is 0) can be set for either heating or cooling control.





# 5-8 Using Event Inputs

# 5-8-1 Event Input Settings

- Events can be used on models that have event inputs.
  - The number of event inputs that is supported depends on the model of the Digital Controller.
  - E5CD or E5CD-B: Up to 2 event inputs
  - E5ED or E5ED-B: Up to 4 event inputs
- Event inputs can be used for switching between RUN and STOP, switching between automatic and
  manual operation, starting/resetting the program, inverting direct/reverse operation,
  executing/canceling 100% AT, executing/canceling 40% AT, enabling/disabling setting changes,
  enabling/disabling communications write, canceling the alarm latch, switching the multi-SP number,
  PID updating (adaptive control), automatic filter adjustment, and water-cooling output adjustment.

# 5-8-2 How to Use the Multi-SP Function

The multi-SP function allows you to set up to eight set points (SP 0 to 7) in the Adjustment Level. The set point can be switched by operating the keys on the front panel or by using external input signals (event inputs).

# Using Event Inputs

The following table shows the relationships between the ON/OFF status of multi-SP number switching bits 0 to 2 and the set point.

Salasted set point	Multi-SP No. switching bits			
Selected set point	Bit 0	Bit 1	Bit 2	
SP 0	OFF	OFF	OFF	
SP 1	ON	OFF	OFF	
SP 2	OFF	ON	OFF	
SP 3	ON	ON	OFF	
SP 4	OFF	OFF	ON	
SP 5	ON	OFF	ON	
SP 6	OFF	ON	ON	
SP 7	ON	ON	ON	

Note: Any bits that are not assigned to event inputs are treated as being OFF.

# Using Key Operations

You can select any of the set points 0 to 7 by changing the set value of the Multi-SP Uses parameter. The Multi-SP Uses parameter display conditions are as follows:

- Digital Controllers without event inputs for which the Number of Multi-SP Points parameter is not set to OFF
- Controllers with event inputs for which the Number of Multi-SP Points parameter is not set to OFF and the Event Input Assignment 1 to 6 parameters are not set to Multi-SP switching bits 0 to 2

The following table shows the relationship between the Multi-SP Uses parameter set value and the selected set point

Multi-SP	Selected set point
0	SP 0
1	SP 1
2	SP 2
3	SP 3
4	SP 4
5	SP 5
6	SP 6
7	SP 7

Note: The set point can also be switched using communications.

# 5-8-3 Operation Commands Other than Multi-SP

The following table shows the functions that can be assigned when an Event Input Assignment 1 or 6 parameter is displayed.

Setting	Function	Detection method <sup>*5</sup>
NāNE	None	
SEAP	RUN/STOP	Edge
MANU	Auto/Manual <sup>*4</sup>	Level
PR5Ł	Program Start*1	Level
dR5	Invert Direct/Reverse Operation	Level
NāNE	None	
AF - 5	100% AT Execute/Cancel	Edge
AF - 1	40% AT Execute/Cancel*2	Edge
WEPE	Setting Change Enable/Disable	Level
EMWE	Communications Write Enable/Disable*3	Level
LAF	Alarm Latch Cancel	Edge
MSP0	Multi-SP No. switching bit 0	Edge
MSP I	Multi-SP No. switching bit 1	Edge
MSP2	Multi-SP No. switching bit 2	Edge
RUN	STOP/RUN	Edge
R-Ud	PID Update (Adaptive Control)	Edge
FR	Automatic Filter Adjustment	Edge
W-HE	Water-cooling Output Adjustment	Edge

<sup>\*1</sup> PRST (Program Start) can be set even when the Program Pattern parameter is set to OFF, but the function will be disabled.

- \*3 This function can be set only for a Controller that supports communications. Also, when a work bit is selected as the event input data for a logic operation, Communications Write Enable/Disable cannot be assigned. If the Digital Controller is operating only on the power supply from the USB-Serial Conversion Cable, it will operate as if the event inputs remain OFF. Therefore, communications writing will be disabled and you will not be able to write data from Setup Tools, such as the CX-Thermo.
- \*4 If the same function is assigned to PF Key, it will be disabled for the PF Key and only the event input can be used to execute the function.
- \*5 For edge detection, the function will operate only when the status of the event input changes. Edges will be detected for edge-detection events when the power supply is turned ON.

Turn event inputs ON and OFF while the power is being supplied. Event input ON/OFF changes are detected for inputs of 50 ms or longer.

The functions are described in detail below.

<sup>\*2</sup> This function can be set for heating/cooling control, but the function will be disabled.

# Executing Run/Stop Control

When the Event Input Assignment parameter is set to STOP (RUN/STOP), control is started when event input turns OFF. Control is stopped when the input turns ON. However, alarms will operation regardless of the run/stop status.

The STOP indicator will light while control is stopped.

Setting	Input contact	Status
Event input	ON	STOP
Event input	OFF	RUN

Set the Event Input Assignment parameter to RUN (RUN/STOP) for the reverse logic.

Setting	Input contact	Status
Event input	ON	RUN
Event input	OFF	STOP

# Switching between Auto and Manual Control

When the Event Input Assignment parameter is set to MANU (auto/manual), manual control will start when event input turns ON. Auto control will start when the input turns OFF.

The MANU indicator will light during manual control.

Setting	Input contact	Status
Event input	OFF	Automatic
Event input	ON	Manual

# Controlling the Start of the Simple Program Function

When the Event Input Assignment parameter is set to PRST (program start), the program will start when the event input turns ON. The program will be reset when the input turns OFF and the RUN/STOP status will automatically switch to STOP mode. If the program END output is ON, the program END output will turn OFF.

Setting	Input contact	Status
Event input	OFF	Reset
Event input	ON	Start

#### Control by Inverting Direct/Reverse Operation

When the Event Input Assignment parameter is set to DRS (Invert Direct/Reverse Operation) and the Direct/Reverse Operation parameter is set for reverse operation, control starts with direct operation (cooling control) when the event input turns ON and control starts with reverse operation (heating control) when the event input turns OFF.

Setting	Input contact	Direct/Reverse Operation parameter	Status
Event input	OFF	Direct operation (cooling)	Direct operation (cooling)
		Reverse operation	Reverse operation
		(heating)	(heating)
Event input	ON	Direct operation (cooling)	Reverse operation
		Direct operation (cooling)	(heating)
		Reverse operation	Direct operation (cooling)
		(heating)	Direct operation (cooling)

## Switching 100% AT Execute/Cancel

When the Event Input Assignment parameter is set to AT-2 (100% AT Execute/Cancel), 100% AT will be executed when the event input turns ON and will be cancelled when the input turns OFF.

Setting	Input contact	Status
Event input	OFF	100% AT cancelled
Event input	ON	100% AT executed

# Switching 40% AT Execute/Cancel

When the Event Input Assignment parameter is set to AT-1 (40% AT Execute/Cancel), 40% AT will be executed when the event input turns ON and will be cancelled when the input turns OFF.

Setting	Input contact	Status
Event input	OFF	40% AT cancelled
Event input	ON	40% AT executed

# Switching Setting Change Enable/Disable

When the Event Input Assignment parameter is set to WTPT (Setting Change Enable/Disable), the setting change will be disabled when the event input turns ON and will be enabled when the input turns OFF.

Setting	Input contact	Status
Event input	OFF	Enabled
Event input	ON	Disabled

# Switching Communications Write Enable/Disable

When the Event Input Assignment parameter is set to CMWT (Setting Change Enable/Disable), writing with communications will be enabled when the event input turns ON and writing with communications will be disabled when the event input turns OFF.

Setting	Input contact	Status
Event input	OFF	Disabled
Event input	ON	Enabled

# Switching Alarm Latch Cancel

When the Event Input Assignment parameter is set to LAT (Alarm Latch Cancel), all alarm latches (alarms 1 to 4, heater burnout, HS alarm, latch) will be cancelled when event input turns ON.

Setting	Input contact	Status
Event input	OFF	
Event input	ON	Cancelled

# Performing PID Update (Adaptive Control)

When the Event Input Assignment parameter is set to A-UD (PID Update), updating PID constants for adaptive control is started when the event input turns ON.

Setting	Input contact	Status
Event input	OFF	
Event input	ON	Updated

# Performing Automatic Filter Adjustment

When the Event Input Assignment parameter is set to FA (Automatic Filter Adjustment), automatic filter adjustment is performed when the event input turns ON. It will be cancelled when the event input turns OFF.

Setting	Input contact	Status
Event input	OFF	Automatic filter
		adjustment
		cancelled.
Event input	ON	Automatic filter
		adjustment
		performed.

# Water-cooling Output Adjustment

When the Event Input Assignment parameter is set to W-HT (Water-cooling Output Adjustment), water-cooling output adjustment will be enabled when the event input turns ON.

Setting	Input contact	Status
Event input	OFF	Disabled.
Event input	ON	Enabled.


#### **Parameters**

Display Parameter		Description	Level
EV - 1	Event Input Assignment 1		Initial Setting Level
EV-2	Event Input Assignment 2		Initial Setting Level
EV-3	Event Input Assignment 3		Initial Setting Level
EV-4	Event Input Assignment 4	Function of event input	Initial Setting Level
EV-5	Event Input Assignment 5	T unotion of event input	Initial Setting Level
EV-6	Event Input Assignment 6		Initial Setting Level
M5PU	Number of Multi-SP Points		Advanced Function Setting Level

# 5-9 Setting the SP Upper and Lower Limit Values

## 5-9-1 Set Point Limiter

The setting range of the set point is limited by the set point limiter. This function can be used to prevent setting incorrect set points. The upper- and lower-limit values of the set point limiter are set using the Set Point Upper Limit and Set Point Lower Limit parameters in the Initial Setting Level. If the set point is not within the range set for the set point limiter as the result of changes to the Set Point Upper Limit or Set Point Lower Limit parameter, the set point will automatically be changed to a value within the set range. When the set point limiter is reset, the set point is forcibly changed to the upper- or lower-limit value of the set point limiter if the set point is out of the limiter range. Also, when the input type and the temperature unit, scaling upper-limit value, or lower-limit value are changed, the set point limiter is forcibly reset to the input setting range or the scaling upper- or lower-limit value.




### **Parameters**

Parameters	Parameter	Description	Level
SL - H	Set Point Upper Limit	To limit the SP setting	Initial Setting Level
SL-L	Set Point Lower Limit	To limit the SP setting	Initial Setting Level

#### 5-9-2 **Setting**

Set the set point upper and lower limits in the Set Point Upper Limit and Set Point Lower Limit parameters in the Initial Setting Level. In this example, it is assumed that the input type is set to a K thermocouple with a temperature range of -200 to 1300°C.



Set the upper and lower limits for the set point.

Set Point Upper Limit = 1000

Set Point Lower Limit = -100

# **Operating Procedure**

· Setting the Set Point Upper Limit


	- Getting the Get 1 Girlt Opper Limit			
1	Press the  Key several times in the Initial Setting Level to display 5L-H (Set Point Upper Limit).	Initial Setting Level		
	diopidy 32 77 (oct 1 oint oppor Linit).	Set Point Upper-limit		
2	Press the ♠ or ❤ Key to set the value to 1000.	SI -H		
	The default is 1300.	1000		
• Se	Setting the Set Point Lower Limit			
1	Press the	Initial Setting Level		
	display 5L -L (Set Point Lower Limit).	5L -L Set Point Lower Limit		
2	Press the ♠ or ❤ Key to set the value to –100.  The default is –200.	5L - L - 100		

# 5-10 Using the SP Ramp Function to Limit the SP Change Rate

# 5-10-1 SP Ramp

The SP ramp function is used to restrict the width of changes in the set point as a rate of change. When the SP ramp function is enabled and the change width exceeds the specified rate of change, an area where the set point is restricted will be created, as shown in the following diagram.

During the SP ramp, control will be performed not for the specified set point but rather for the set point restricted by the rate of change set for the SP ramp function.



The rate of change during an SP ramp is specified using the SP Ramp Set Value, SP Ramp Fall Value, and SP Ramp Time Unit parameters. The SP Ramp Set Value parameter is set to OFF by default and the SP Ramp Fall Value parameter is set to SAME by default, i.e., the SP ramp function is disabled. Changes in the ramp set point can be monitored in the Set Point During SP Ramp parameter (Operation Level). Use this parameter when monitoring SP ramp operation.


The SP ramp function operates in the same way when switching the set point using the multi-SP function.

#### **Parameters**

Display	Parameter	Description	Level
SPRE	SP Ramp Set Value	To limit the SP rate of change	Adjustment Level
SPRL MASK8	SP Ramp Fall Value	To limit the SP rate of change	Adjustment Level
SPRU	SP Ramp Time Unit	Unit for setting the SP	Advanced Function Setting Level
RLSP MASK8	Alarm SP Selection	Alarm SP selection	Advanced Function Setting Level

# Operation at Startup

If the SP ramp function is enabled when the Digital Controller is turned ON or when switching from STOP to RUN mode, the process value reaches the set point using the SP ramp function in the same way as when the set point is changed. In this case, operation is carried out with the process value treated as the set point before the change was made. The direction of the SP ramp changes according to the relationship between the process value and the set point.




# Restrictions during SP Ramp Operation

- Execution of auto-tuning starts after the end of the SP ramp.
- When control is stopped or an error occurs, the SP ramp function is disabled.

# Alarms during SP Ramp Operation

The operation of alarms during SP ramp operation depends on whether alarms are set to be based on the ramp set point or the target set point (refer to the following diagrams). The set point to be used is set in the Alarm SP Selection parameter.



# 5-11 Using the Key Protect Level

## 5-11-1 Protection

- To move to the Protect Level, press the and Keys simultaneously for at least three seconds in Operation Level or Adjustment Level.\*
  - \* The key pressing time can be changed in the Move to Protect Level Time parameter (Advanced Function Setting Level).
- The Protect Level protects parameters that are not changed during Digital Controller operation until operation is started to prevent them from being modified unintentionally.
  - There are four types of protection: operation/adjustment protect, initial setting/communications protect, setting change protect, and PF Key protect.
- The protect level settings restrict the range of parameters that can be used.

# Operation/Adjustment Protect

Displaying and changing settings in Operation Level and moving to Adjustment Level are restricted. The following table shows the relationship between set values and the range of protection.



Level		Set value			
		0	1	2	3
	PV	Can be dis- played	Can be dis- played	Can be dis- played	Can be dis- played
Operation	PV/SP	Can be dis- played and changed	Can be dis- played and changed	Can be dis- played and changed	Can be dis- played
Level	Others	Can be dis- played and changed	Can be dis- played and changed	Cannot be dis- played and moving to other levels is not possible	Cannot be displayed and moving to other levels is not possible
Adjustment Level		Can be displayed and changed	Cannot be displayed and moving to other levels is not possible	Cannot be dis- played and moving to other levels is not possible	Cannot be displayed and moving to other levels is not possible

- Parameters are not protected when the set value is set to 0.
- The default is 0.

## Initial Setting/Communications Protect

This protect level restricts movement to the Initial Setting Level, Communications Setting Level, and Advanced Function Setting Level.

[[P	Ŀ
	1

Set value	Initial Setting Level	Communications Setting Level	Advanced Function Setting Level
0	Possible to reach	Possible to reach	Possible to reach
1	Possible to reach	Possible to reach	Not possible to reach
2	Not possible to reach	Not possible to reach	Not possible to reach

• The default is 1.

Application Example: To enable setting only the SP, set both the Operation/Adjustment Protect parameter and the Initial Setting/Communications Protect parameter to 2.

# Setting Change Protect

This protect level restricts key operations



Set value	Description
OFF	Settings can be changed using key operations.
ON	Settings cannot be changed using key operations. (The protect level settings, however, can be changed.)

- The default is OFF.
- The setting change protection indicator (On) will light when the Setting Change Protect parameter is set to ON.

# PF Key Protect

This protect level enables or disables PF Key operations.



Set value	Description
OFF	PF Key enabled.
ON	PF Key disabled (Operation as function key prohibited).

· The default is OFF.

# 5-11-2 Entering the Password to Move to the Protect Level

· The Protect Level can be moved to only by displaying the password display and entering the correct password. (The user can set any password in the Password to Move to Protect Level parameter.) If no password is set (i.e., if the password is set to 0 in the Password to Move to Protect Level parameter), the password input display to move to the Protect Level will not be displayed and the Protect Level can be moved to directly.

Move to the Protect Level and set the password.

Example password: 1234

## **Operating Procedure**

#### Password Not Yet Set

1	Press the and Reys simultaneously for at least 3 seconds (default) in the Operation Level.*1  If a password is not set, the Protect Level will be entered and aRPL (Operation/Adjustment Protect) will be displayed.	Protect Level Operation/ Adjustment Protect
2	Press the	Password to Move to Protect Level
3	Press the  and  Keys simultaneously and set the value to 1234. (This enters the password.)  To prevent setting the password incorrectly, the  and  Keys or  and  Keys must be pressed simultaneously to set the password.	PRLP 1234 MASK8

The key pressing time can be changed in PRLE (Move to Protect Level Time) in the Advanced Function Setting Level. (Setting range: 1 to 30 seconds, Default: 3 seconds)

## Password Already Set

• Deleting the Password (Password Deletion Example: 5678)

1	Press the  and  Keys simultaneously for at least 3 seconds (default) in the Operation Level.*1  PMaV (Move to Protect Level) will be displayed.	Protect Level  Move to Protect Level
<i>2</i>	Press the $ extstyle  ext$	PMaV 5678
<i>3</i>	Move to the Operation/Adjustment Protect parameter in the Protect Level by pressing the  or  Key or leaving the setting for at least two seconds. (This deletes the password.)	Operation/Adjustment Protect
• Se	etting the Password Again (Password Example: 1234)	
1	Set the password to 1234 again.  Press the  Key several times in the Protect Level to display PRLP (Password to Move to Protect Level).	Password to Move to Protect Level  MASK8
2	Press the and Keys simultaneously and set the value to 1234. (This enters the password.)  To prevent setting the password incorrectly, the and Keys or and Keys must be pressed simultaneously to set the password.	<b>PRLP</b> 1234 MASK8

The key pressing time can be changed in PRLE (Move to Protect Level Time) in the Advanced Function Setting Level. (Setting range: 1 to 30 seconds, Default: 3 seconds)



### **Precautions for Correct Use**

Protection cannot be cleared or changed without the password. Be careful not to forget it. If you forget the password, contact your OMRON sales representative.

### Communications Operation Command to Move to the Protect Level

- The Write Variable operation command can be used via communications to write the password to
  the Move to Protect Level parameter. When the correct password is written, the display will
  change to the Operation/Adjustment Protect parameter and writing the parameters in the Protect
  Level will be enabled.
  - Note 1: If the Write Variable operation command is used to write the wrong password to the Move to Protect Level parameter after the correct parameter has been written, the Move to Protect Level parameter will be displayed and any Write Variable operation commands to write parameters in the Protect Level will result in operation errors.
    - 2: If a password is not set or if it is set to 0, the display will change to the Operation/Adjustment Protect parameter and writing the parameters in the Protect Level will be enabled immediately.

# 5-12 Hiding and Displaying Parameters

# 5-12-1 Parameter Mask Setting


You can use a key operation to hide parameters that do not need to be displayed. This allows you to prevent incorrect settings for parameters or to simplify the parameter configuration according to the application.

#### Parameters

Display	Parameter	Description	Level
PMSE	Parameter Mask Setting	Moves you to the Parameter Mask Mode.	Advanced Function Setting Level
PM5I(	Parameter Mask Enable	Enables and disables parameter masks.	Protect Level

## Description

- If you set the Parameter Mask Setting parameter (Advanced Function Setting Level) to ON, Parameter Mask Mode is entered.
- When you enter Parameter Mask Mode, the first parameter in the Operation Level is displayed.
- When you press the 
   Key, the setting level changes as shown below.



- You cannot mask parameters in the Manual Control Level, Monitor/Setting Item Level, and Protect Level.
  - Press the 
    Rey once for less than one second to move to the next parameter in the current setting level.
    - Press the Key for at least one second to move to the previous parameter in the current setting
  - Press the ♠ or ♥ Key to set the parameter to d̄5P (disable mask (show)) or MP5K (enable mask (hide)).
  - Perform one of the following operations to end Parameter Mask Mode.
    - 1. Cycle the power supply.
    - 2. Send a Software Reset command with communications.
    - 3. Press the Key for at least 1 s.
  - · When you enter Parameter Mask Mode, the first parameter in the Operation Level is displayed. However, you cannot set a parameter mask for the Process Value/Set Point 1 and Process Value/Set Point 2 parameters.
- Some parameters are masked (mask: mask enable (hidden)) in the default Parameter Mask Settings. These parameters are indicated with the MASK mark.
  - Auto/Manual Switch (Operation Level)
  - MV Monitor (Heating) (Operation Level)
  - MV Monitor (Cooling) (Operation Level)
  - MV at Stop (Adjustment Level)
  - MV at PV Error (Adjustment Level)

Other than the above parameters, the  $\frac{MASK8}{MASK8}$  mark appears for parameters that are masked only for the E5 $\square$ D- $\square$ -8 $\square$ .

# **Masking (Hiding) Parameters**

# Setting Example

In this example, the Temperature Input Shift parameter in the Adjustment Level is set to MR5k (enable mask (hide)).

#### **Operating Procedure**

- Moving to Parameter Mask Mode (Advanced Function Setting Level)
- Press the 
  Key several times in the Advanced Function Setting Level to display the Parameter Mask Setting parameter.

  Parameter Mask Setting Parameter Mask Setting

  Parameter Mask Setting

  Parameter Mask Setting

  Parameter Mask Setting

  Parameter Mask Setting

  Parameter Mask Setting

  Parameter Mask Setting

  Parameter Mask Setting

  Parameter Mask Setting

Refer to 4-1-4 Moving to the Advanced Function Setting Level for information on entering the Advanced Function Setting Level.

- Hiding the SP Mode Parameter (Adjustment Level)

Refer to 4-1-2 Moving to the Adjustment Level for information on entering the Adjustment Level.

- Enabling Parameter Masks (Protect Level)
- 1 Press the ② Key several times in the Protect Level to display the Parameter Mask Enable parameter.

  Protect Level

  Parameter Mask Enable

  Parameter Mask Enable

Refer to 4-1-2 Moving to the Adjustment Level for information on entering the Protect Level.

# **Unmasking (Displaying) Parameters**

• Disabling Parameter Masks (Displaying) (Protect Level)

1	Press the	Protect Level  PM5// Parameter Mask Enable
2	Press the  or  Key to set the parameter to OFF (Disable). The default is ON.	PMSK äff

# 5-13 OR Output of Alarms

# 5-13-1 Integrated Alarm

You can use an integrated alarm to output an OR of alarms 1 to 4, the HB alarm, the HS alarm, and the input error. Set the Integrated Alarm Assignment parameter ( $\mathcal{H}LM\mathcal{H}$ ) and then assign the integrated alarm ( $\mathcal{H}LM\mathcal{H}$ ) to an auxiliary output or a control output.

### Parameters

Parameter	No. 1 display	Value	No. 2 display	Level
Control Output Assignment	āUŁ I to āUŁ2	ALM: Integrated alarm (The Integrated Alarm Assignment parameter must be set separately.)	ALM	Advanced Function Setting Level
Auxiliary Output 1 to 4 Assignment	5Ub / to 5Ub4	ALM: Integrated alarm (The Integrated Alarm Assignment parameter must be set separately.)	ALM	Advanced Function Setting Level
Integrated Alarm Assignment	AL MA	Set the sum of the following values for the alarms and errors to include in the OR output. 0 to 255 Alarm 1: +1 Alarm 2: +2 Alarm 3: +4 Alarm 4: +8 HB alarm: +16 HS alarm: +32 Input error: +64 (Default: 49 (i.e., an OR of alarm 1, the HB alarm, and the HS alarm))	0 to 255	Advanced Function Setting Level

# Operating Procedure

The following procedure outputs an OR of the following alarms on auxiliary output 2.

- Alarm 1
- HB alarm (Hb)

The settings are made in the Advanced Function Setting Level.

# **Operating Procedure**

• Assigning the Integrated Alarm to an Auxiliary Output

1	Press the <sup>□</sup> Key several times in the Advanced Function Setting Level to display 5Ub2 (Auxiliary Output 2 Assignment).	Advanced Function Setting Level  Auxiliary Output 2 Assignment
2	Press the  or  ➤ Key to select RLM (Integrated Alarm).  The default is RLM2 (Alarm 2).	SUB2 RLM
• Se	etting the Integrated Alarm Assignment Parameter	
1	Press the  Key several times in the Advanced Function Setting Level to display RLMR (Integrated Alarm Assignment).	Advanced Function Setting Level Integrated Alarm Assignment
2	Press the  or  Key to set the set value to 17 (i.e., the sum of 1 for alarm 1 and 16 for the HB alarm).  The default is 49.  (Alarm 1 (1) + HB alarm (16) + HS Alarm (32)= 49)	ALMA In



# **Additional Information**


For details on the integrated alarm, refer to Section 6 Parameters.

# 5-14 Alarm Delays

# 5-14-1 Alarm Delays

• Delays can be set for the alarm outputs. ON and OFF delays can be set separately for alarms 1, 2, 3, and 4. The ON and OFF delays for alarms 1, 2, 3, and 4 also apply to the individual SUB1, SUB2, SUB3, and SUB4 indicators and to communications status. The alarm ON delays will also function when power is turned ON or when moving from the Initial Setting Level to Operation Level (e.g., to software resets). All outputs will turn OFF and the OFF delays will not function when moving to the Initial Setting Level or when an alarm is output for an A/D converter error.

# Operation of Alarm ON and OFF Delays (for an Upper-limit Alarm)



- The alarm will not turn ON if the time that the alarm is ON is equal to or less than the ON delay set time. Also, the alarm will not turn OFF if the time that the alarm is OFF is equal to or less than the OFF delay set time.
- If an alarm turns OFF and then back ON during the ON delay time, the time will be remeasured
  from the last time the alarm turns ON. Also, if an alarm turns ON and then back OFF during the
  OFF delay time, the time will be remeasured from the last time the alarm turns OFF.

# Parameters Related to Alarm Delays

Parameter name	Display	Set (monitor) values	Level
Alarm 1 ON Delay	A IāN	0 to 999 (s)	
Alarm 2 ON Delay	R2āN	0 to 999 (s)	
Alarm 3 ON Delay	R3āN	0 to 999 (s)	
Alarm 4 ON Delay	RYāN	0 to 999 (s)	Advanced Function
Alarm 1 OFF Delay	R IGF	0 to 999 (s)	Setting Level
Alarm 2 OFF Delay	R25F	0 to 999 (s)	
Alarm 3 OFF Delay	R35F	0 to 999 (s)	
Alarm 4 OFF Delay	RYGF	0 to 999 (s)	

Note 1: The defaults are 0, i.e., the ON and OFF delays are disabled.

<sup>2:</sup> The parameters are displayed when alarm functions are assigned and when the alarm type is set to any type but 0 (none), 12: LBA, or 13: PV change rate alarm.

Use the following procedure to set ON and OFF delays for the alarm 1. An ON delay of 5 seconds and an OFF delay of 10 s will be set.

# **Operating Procedure**


• Setting the Alarm 1 ON Delay

• 30	Setting the Alaim 1 ON Delay					
1	Press the $lacktriangle$ Key several times in the Advanced Function Setting Level to display $H$ $I\bar{a}N$ (Alarm 1 ON Delay).	Advanced Function Setting Level  Alarm 1 ON Delay				
2	Press the ♠ or ❤ Key to set the value to 5. The default is 0.	A ION				
• Se	etting the Alarm 1 OFF Delay					
1	Press the $\  \   $ Key several times in the Advanced Function Setting Level to display $\  \   $ $\  \  $ (Alarm 1 OFF Delay).	Advanced Function Setting Level  Alarm 1 OFF Delay				
2	Press the ♠ or ❤ Key to set the value to 10.  The default is 0.	A lōF				

# 5-15 Loop Burnout Alarm

# 5-15-1 Loop Burnout Alarm (LBA)

- With a loop burnout alarm, there is assumed to be an error in the control loop if the control deviation (SP - PV) is greater than the threshold set in the LBA Level parameter and if the control deviation is not reduced by at least the value set in the LBA Detection Band parameter within the LBA detection time
- Loop burnout alarms are detected at the following times.



If the control deviation is reduced in the area between 1 and 2 (i.e., the set point is approached) and the amount the control deviation is reduced is at least equal to the LBA band, the loop burnout alarm will remain OFF.

The process value is within the LBA level between 3 and 4, and thus loop burnout alarms will not be detected. (The loop burnout alarm will remain OFF.)

If the process value is outside the LBA level between 4 and 5 and the control deviation is not reduced by at least the LBA band within the LBA detection time, the loop burnout alarm will turn ON. If the control deviation is reduced in the area between 5 and 6 (i.e., the set point is approached) and the amount the control deviation is reduced is at least equal to the LBA band, the loop burnout alarm will turn OFF.

If the control deviation is reduced in the area between 6 and 7 (i.e., the set point is approached) and the amount the control deviation is reduced is less than the LBA band, the loop burnout alarm will turn ON.

- If the LBA detection time, LBA level, LBA detection band, and PID settings are not appropriate, alarms may be detected inappropriately or alarms may not be output when necessary.
- Loop burnout alarms may be detected if unexpectedly large disturbances occur continuously and a large deviation does not decrease.
- If a loop burnout occurs when the set point is near the ambient temperature, the temperature deviation in a steady state may be less than the LBA level, preventing detection of the loop burnout.
- If the set point is so high or low that it cannot be reached even with a saturated manipulated variable, a temperature deviation may remain even in a steady state and a loop burnout may be detected.
- Detection is not possible if a fault occurs that causes an increase in temperature while control is being applied to increase the temperature (e.g., an SSR short-circuit fault).

 Detection is not possible if a fault occurs that causes a decrease in temperature while control is being applied to decrease the temperature (e.g., a heater burnout fault).

# Parameters Related to Loop Burnout Alarms

Parameter name	Display	Setting range		Remarks	Level
LBA Detection Time	LBR	0 to 9999 (s)		Setting 0 disables the LBA function.	
I BA Lovol	SA Level LBRL -	Temperature input	0.1 to 999.9 (°C/°F)	Default: 8.0 (°C/°F)	Advanced
LDA Levei		Analog input	0.01 to 99.99 (%FS)	Default: 10.00% FS	Function Setting Level
LBA Band	LbAb	Temperature input	0.0 to 999.9 (°C/°F)	Default: 3.0 (°C/°F)	
LDA Dalla	rono	Analog input	0.00 to 99.99 (%FS)	Default: 0.20% FS	


- A loop burnout alarm can be output by setting the alarm 1 type to 12 (LBA).
- A setting of 12 (LBA) can be set for alarms 2 to 4, but the setting will be disabled.
- Loop burnouts are not detected during SP ramp operation.
- · Loop burnouts are not detected during auto-tuning, manual operation, or while stopped.
- If the alarm 1 latch is set to ON, the latch will be effective for the loop burnout alarm.

## Automatically Setting the LBA Detection Time

- The LBA detection time is automatically set by auto-tuning. (It is not set automatically, however, for heating/cooling control.)
- If the optimum LBA detection time is not obtained by auto-tuning, set the LBA Detection Time parameter (Advanced Function Setting Level).

#### Determining the LBA Detection Time

- To manually set the LBA detection time, set the LBA Detection Time parameter to twice the LBA reference time given below.
  - (1) Set the output to the maximum value.
  - (2) Measure the time required for the width of change in the input to reach the LBA band.



(3) Set the LBA Detection Time parameter to two times the measured time.

# LBA Level

- Set the control deviation when the control loop is working properly.
- The default is 8.0 (°C/°F) for Digital Controllers with Temperature Inputs and 10.00% FS for Digital Controllers with Analog Inputs.

### LBA Band

- There is assumed to be an error in the control loop and the alarm output turns ON if the control deviation is greater than the threshold set in the LBA Level parameter and if the control deviation does not change by at least the value set in the LBA Band parameter.
- The default is 3.0 (°C/°F) for Digital Controllers with Temperature Inputs and 0.20% FS for Digital Controllers with Analog Inputs.

The LBA is used.

The related parameters are as follows:

LBA Detection Time: 10

LBA Level: 8.0 LBA Band: 3.0

# **Operating Procedure**

Setting the LBA	
1 Press the  Key several times in the Initial Setting Level to display RLE I (Alarm 1 Type).	Initial Setting Level  Alarm 1 Type
Press the ♠ or ♥ Key to select ½ (LBA). The default is ∠ (upper limit).	ALE I
Setting the LBA Detection Time	
<b>1</b> Press the <sup>□</sup> Key several times in the Advanced Function Setting Level to display <i>LbR</i> (LBA Detection Time).	Advanced Function Setting Level  LBA Detection Time
Press the ♠ or ❤ Key to set the value to 10. The default is 0 (s).	L b A
Setting the LBA Level	
<b>1</b> Press the <sup>®</sup> Key several times in the Advanced Function Setting Level to display <i>LbRL</i> (LBA Level).	Advanced Function Setting Level  LBA Level
Press the ♠ or ❤ Key to set the value to 8.0.  The default is 8.0 (°C/°F).	L <b>b A L</b> 8.0
Setting the LBA Band	
<b>1</b> Press the <sup>□</sup> Key several times in the Advanced Function Setting Level to display <i>LbRb</i> (LBA Band).	Advanced Function Setting Level  LBA Band  3.0
<b>2</b> Press the ♠ or ❤ Key to set the value to 3.0. The default is 3.0 (°C/°F).	L <i>bAb</i> 3.0

# 5-16 Performing Manual Control

Manual control can be used during PID control.


#### 5-16-1 Manual MV

If you change to Manual Mode, the Manual MV parameter will be displayed and the displayed value will be output as the MV. If you change the setting of the Manual MV parameter, you can set any required MV. (The new value will be applied immediately.) The default setting of the Manual MV parameter is determined by the setting of the Manual Output Method parameter as shown below.

HOLD: The MV from immediately before moving to Manual Mode INIT: The set value of the Manual MV Initial Value parameter

If the power supply is cycled during manual operation, operation will be restarted with the manual MV that was in effect before the power supply was interrupted. When the Manual MV Limit Enable parameter is set to ON (enable), the setting range will be from the MV lower limit to the MV upper limit. When operation is changed back to Automatic Mode, the MV from immediately before the change is inherited and then gradually changes to the value for Automatic Mode to prevent the MV from changing rapidly. (This is called balanceless-bumpless operation.)

The manual operation is illustrated in the following figure when the Manual Output Method parameter is set to HOLD.





### **Precautions for Correct Use**

- The automatic display return function will not operate in Manual Mode.
- Switching between automatic and manual operation is possible for a maximum of one million times.

### Related Displays and Parameters

Parameter name	Display	Setting range	Default	Level
Auto/Manual Switch*1		Switching between Automatic Mode and Manual Mode		Operation Level
PV/MV (Manual MV)*2		Standard control or position-proportional control: -5.0 to 105.0  Heating/cooling control: -105.0 to 105.0		Manual Control Level

Parameter name	Display	Setting range	Default	Level
Manual Output	MANE	HOLD	HOLD	
Method		INIT		
Manual MV Initial	MANI	Standard control: -5.0 to 105.0	0.0	Advanced
Value <sup>*2</sup>		Heating/cooling control: -105.0 to 105.0		Function Setting
Manual MV Limit	MANL	OFF: Disabled.	OFF	Level
Enable MASK8		ON: Enabled.		

<sup>\*1</sup> A mask is set to this parameter.


Refer to 5-12 Hiding and Displaying Parameters.

\*2 If the Manual MV Limit Enable parameter is set to ON, this value will be between the MV upper limit and the MV lower limit

Note: Refer to 5-18 Output Adjustment Functions for information on the order of priority for the MV.

# Moving to the Manual Control Level

- · Moving with a Key Operation
  - When the Key is pressed for at least 3 seconds in the Operation Level's auto/manual switching display\*, the Manual Mode will be entered and the Manual Control Level will be displayed. It is not possible to move to any displays except for the PV/MV parameter during manual operation. Press the Key for at least one second from the PV/MV parameter display in Manual Control Level to return to Automatic Mode and display the top parameter in the Operation Level.



- \* The Auto/Manual Switch parameter is masked (not displayed) by default. To display it, refer to *5-12 Hiding and Displaying Parameters*.
- Using the PF Key to Move to the Manual Control Level
  - When the PF Setting parameter is set to A-M (Auto/Manual), pressing the PF Key for at least one second while in the Adjustment or Operation Level will change the mode to Manual Mode and move to the Manual Control Level. During manual operation it is not possible to move to any displays other than PV/MV (Manual MV). Press the PV/MV display in the Manual Control Level to change the mode to Automatic Mode, move to the Operation Level, and display the top parameter in the Operation Level.

Note 1: Priority of Manual MV and Other Functions

Even when operation is stopped, the manual MV is given priority.

Auto-tuning will stop when Manual Mode is entered.

- 2: Manual MV and SP Ramp
  - If operating, the SP ramp function will continue even when Manual Mode is entered.
- · Moving to the Manual Control Level with an Event Input

• If an event input is set to MANU (auto/manual), you can use the event input to switch between Automatic Mode and Manual Mode.

We will set the PF Setting parameter to A-M (auto/manual).


-	rating Procedure	
• Se	etting PID Control	Initial Setting Level
•	Press the  Key several times in the Initial Setting Level to display [NLL (PID ON/OFF).	FINEL PID ON/OFF
2	Press the ♠ or ❤ Key to set PID.	ENEL
• Se	etting Auto/Manual Selection	
1	Press the  Key several times in the Advanced Function Setting Level to display <i>PF</i> (PF Setting).	Advanced Function Setting Level
		PF Setting 5HFL
2	Press the ♠ or ❤ Key to select R-M (auto/manual).	<b>PF</b> R-M
• Se	etting the Manual MV with the 🕼 Key	
1	Press the (F) Key in the Operation Level to enter the Manual	Operation Level
	Control Level.	25 0.0
2	Press the ♠ or ❤ Key to set the manual MV.	25
	(In this example, the MV is set to $50\%$ .)	<u>C 3</u>   50.0

The manual MV setting must be saved (see page Applying Changes to Numeric Values on page 3-7), but values changed with key operations are reflected in the control output immediately.

# 5-17 Using the Simple Program Function

# 5-17-1 Simple Program Function

 The simple program function can be used to execute program operation equivalent to two segments, like the operation shown below.



The program will start when the Program Start parameter is changed from RSET to STRT. P.END
will be displayed on the No. 2 display and, if one is assigned, the output assigned as the program end
output will turn ON after the time set in the Soak Time parameter has expired in the wait band. The
Program Pattern parameter can be used to select moving to STOP mode or continuing operation in
RUN mode after the program ends.

# Parameters Related to the Simple Program Function

Parameter name	Display	Set (monitor) values	Unit	Display level
Program Pattern MASK8	PERN	OFF, STOP, CONT		Initial Setting Level
Program Start	PR5Ł	RSET, STRT		Operation Level
Soak Time	SäRK	1 to 9999	min, h, or s	Adjustment Level
Soak Time Unit	E-U	s (seconds)/m (min- utes)/h (hours)		Advanced Function Setting Level
Wait Band	WE-P	OFF or 0.1 to 999.9*	°C or °F*	Adjustment Level
Soak Time Remain Monitor	SKER	0 to 9999	min, h, or s	Operation Level


<sup>\*</sup> The setting unit of the Wait Band parameter is %FS for Digital Controllers with Analog Inputs and the setting range is OFF or 0.01 to 99.99.

## Program Pattern

Either of two program patterns can be selected. The simple program operation will not be performed if the Program Pattern parameter is set to OFF.

#### (1) Pattern 1 (STOP)


Control will stop and the STOP mode will be entered when the program has ended.



Automatically switches from RUN to STOP mode

#### (2) Pattern 2 (CONT)

Control will continue in RUN mode when the program has ended.




RUN mode continues.

### Starting Method

Any of the following three methods can be used to start the simple program.

- Setting the Program Start parameter to STRT.
- Turning ON an event input. (The program start must be assigned to an event input.\*)
- · Starting with an Operation Command using communications. (When the program start is not assigned to an event input.)
- \* When the simple program is started and reset, writing is performed to non-volatile memory. Be sure to consider the write life (1 million writes) of the non-volatile memory in the system design. When the program start is assigned to an event input, the Program Start parameter will function as a monitor display, and the RSET/STRT displays can be used to check when the event input has started or reset the simple program. When this is done, the Program Start parameter functions as a monitor display only and cannot be changed using key operations. If the Program Pattern parameter is set to OFF, the event input assignment setting will be initialized to "None."

### Soak Time and Wait Band



The wait band is the band within which the process value is stable in respect to the set point. The soak time is measured within the wait band. The timer that measures the soak time operates only when the process value is within the wait band around the set point (i.e.,  $SP \pm$  wait band). In the above diagram, the timer will be stopped between the start and (1), (2) and (3), and (4) and (5) and will measure the time only between (1) and (2), (3) and (4), and (5) and the end.


<sup>\*</sup> If the wait band is set to OFF, the wait band will be treated as infinity and the timer will measure time continuously after changing from RSET to STRT.

# 5-17-2 Operation at the Program End

· Display at the Program End

When the program ends, the process value will be displayed on the No. 1 display\* and the set point and P.ENd will be alternately displayed on the No. 2 display at 0.5 s intervals.

\* One of the following displays: PV/SP, PV only, or PV/MV.



· Program End Output

The output assignment parameters can be used to assign the program END output to any output. The program END output can also be used in communications status.

When the Program Pattern parameter is changed from OFF to STOP or CONT, the Auxiliary Output 1 Assignment parameter will automatically be set to the P.END output. When the Program Pattern parameter is changed from STOP or CONT to OFF, the Alarm 1 Output Assignment parameter will automatically be initialized to ALM1 (or to HA for Digital Controllers that have HB or HS alarms).

Clearing the Program End Status

The program END output and display will be cleared when the Program Start parameter is changed from STRT to RSET. The setting is changed from STRT to RSET while the Program Start parameter is displayed.


The program END status can also be cleared using an event. If the program start function is assigned to an event, however, the program end status cannot be cleared from the Program Start parameter display, which will function only as a monitor display.

Simple programming is used.

The related parameters are as follows:

Program pattern: STOP Soak time = 10 min

Wait band: 3




## **Operating Procedure**

- Setting the Program Pattern
- Initial Setting Level Press the Key several times in the Initial Setting Level to display PERM (Program Pattern). PERN Program Pattern ōFF Press the ♠ or ❤ Key to select 5₺ aP (STOP). PERN The default is **5**FF. SEGP · Setting the Soak Time Adjustment Level play 55AK (Soak Time). Saak Soak Time Press the 🖎 or 💟 Key to set the value to 10. Saak The default is 1 (min or h). Setting the Wait Band Adjustment Level play WŁ-Ь (Wait Band). WF - P Wait Band 5FF **2** Press the ♠ or ♥ Key to set the value to 3.0. WE-6 The default is  $\overline{a}FF$ .

3.0

# 5-17-3 Application Example Using a Simple Program

The program will be started by changing the setting of the Program Start parameter. The following example shows using a simple program with the program pattern set to STOP.



Timing	Description
(1)	The Program Start parameter was changed from RSET to STRT using either an event or key operations.
	<ul> <li>The RUN/STOP status automatically changes to RUN mode when the above operation is performed.</li> </ul>
(2)	<ul> <li>The Program Start parameter was changed from STRT to RSET using either an event or key operations before the soak time expired.</li> </ul>
	<ul> <li>The RUN/STOP status automatically changes to STOP mode when the above operation is performed.</li> </ul>
(3)	• The Program Start parameter is again changed from RSET to STRT using either an event or key operations.
	• The RUN/STOP status will automatically change to RUN mode when the above operation is performed.
(4)	• The RUN/STOP status automatically changes to STOP mode when soak time expires.
	P.END flashes on the No. 2 display and the program END output turns ON.
(5)	• The Program Start parameter is changed from STRT to RSET using either an event or key operations.
	The P.END display is cleared and the program END output turns OFF.
(6)	• Key operations are used to switch the RUN/STOP status to RUN with the Program Start parameter set to RSET (stopped).
	Normal control operation is started.
(7)	• The Program Start parameter is changed from RSET to STRT using either an event or key operations after the process value stabilizes.
	The RUN/STOP status remains as RUN.
(8)	• Key operations are used to change the RUN/STOP status to STOP (during program operation).
	• Measuring the soak time is continued within the wait band. (Measuring the soak time stops when the process value leaves the wait band.)
(9)	Key operations are used to change the RUN/STOP status to RUN.
	• Measuring the soak time is continued within the wait band (continuing from the time between (7) and (9)).
(10)	• The RUN/STOP status automatically changes to STOP mode when the measured time reaches the soak time.
	P.END flashes on the No. 2 display and the program END output turns ON.

# 5-18 Output Adjustment Functions


# 5-18-1 Output Limits

- Output limits can be set to control the output using the upper and lower limits to the calculated MV.
- The following MV takes priority over the MV limits.


Manual MV\*

MV at stop

MV at PV error



- \* When the manual MV limit is enabled, the manual MV will be restricted by the MV limit.
  - For heating/cooling control, upper and lower limits are set for overall heating/cooling control. (They cannot be set separately for heating/cooling.)



# 5-18-2 MV at Stop

The MV when control is stopped can be set.

For heating/cooling control, the MV at stop will apply to the cooling side if the MV is negative and to the heating side if the MV is positive. The default is 0.0, so an MV will not be output for either standard or heating/cooling control.

Parameter	Setting range		Default
MV at Stop	Standard control: -5.0 to 105.0	0/	0.0
MASK	Heating/cooling control: -105.0 to 105.0	%	0.0

Note: The order of priority in respect to the manual MV and the MV at PV error is as follows: Manual MV > MV at stop > MV at PV error.

# 5-18-3 MV at PV Error


A fixed MV is output when there is an input error. The MV at stop takes priority when control is stopped and the manual MV takes priority in Manual Mode.

For heating/cooling control, the MV at PV Error will apply to the cooling side if the MV is negative and to the heating side if the MV is positive. The default is 0.0, so an MV will not be output for either standard or heating/cooling control.

Parameter	Setting range	Unit	Default
MV at PV Error	Standard control: -5.0 to 105.0	0/	0.0
MASK	Heating/cooling control: -105.0 to 105.0	%	0.0

Note: The order of priority with respect to the manual MV and the MV at Stop is as follows: Manual MV > MV at stop > MV at PV error.

The order of priority of the MV is illustrated in the following diagram.



\* When the Manual MV Limit Enable parameter is set to ON, the setting range will be the MV lower limit to the MV upper limit.

# 5-19 Using the Extraction of Square Root Parameter

# 5-19-1 Extraction of Square Roots


Extraction of Square Root Enable



Extraction of Square Root Low-cut Point



- For analog inputs, the Extraction of Square Root parameter is provided for inputs so that differential pressure-type flow meter signals can be directly input.
- The default setting for the Extraction of Square Root parameter is OFF. The
  Extraction of Square Root Enable parameter must be set to ON in order to use
  this function.
- If the PV input (i.e., the input before extracting the square root) is higher than 0.0% and lower than the low cut point set in the Extraction of Square Root Low-Cut Point parameter, the results of extracting the square root will be 0.0%. If the PV input is lower than 0.0% or higher than 100.0%, extraction of the square root will not be executed, so the result will be equal to the PV input. The low-cut point is set as normalized data for each input, with 0.0 as the lower limit and 100.0 as the upper limit for the input setting range.



Parameter name	Setting range	Unit	Default	Level
Extraction of Square	OFF: Disabled,		OFF	Initial Setting Level
Root Enable MASK8	ON: Enabled			
Extraction of Square Root Low-cut Point	0.0 to 100.0	%	0.0	Adjustment Level

This procedure sets the Extraction of Square Root Low-cut Point parameter to 10.0%.

The input type must be set for an analog input.

#### **Operating Procedure**

• Enabling Extraction of Square Roots

1	Press the	Extraction of Square Root Enable
2	Press the $\bigcirc$ or $\bigcirc$ Key to select $\bigcirc$ N (Enabled). The default is $\bigcirc$ FF (disabled).	SIR MASK8

• Setting the Extraction of Square Root Low-cut Point

1	Press the	Adjustment Level  Extraction of Square Root Low-cut Point
2	Press the  or  Key to set the value to 10.0.  The default is 0.0 (%).	50RP 10.0

# 5-20 Setting the Width of MV Variation

# 5-20-1 MV Change Rate Limit

MV Change Rate Limit



- The MV change rate limit sets the maximum allowable width of change per second in the MV. If the change in the MV exceeds this setting, the MV will be changed by the MV change rate limit until the calculated value is reached. This function is disabled when the setting is 0.0.
- The MV change rate limit does not function in the following situations:
  - In Manual Mode
  - During AT execution
  - During ON/OFF control
  - While stopped (during MV at Stop output)
  - During MV at PV Error output

Parameter name	Setting range	Unit	Default	Level
MV Change Rate Limit	0.0 to 100.0	%/s	0.0	Adjustment Level
MASK8				

This procedure sets the MV change rate limit to 5.0%/s. The related parameters are as follows:

PID ON/OFF = PID

### **Operating Procedure**

- Setting 2-PID Control
- Press the Key several times in the Initial Setting Level to display [NEL (PID ON/OFF).

  Confirm that the control is set to Pid (2-PID control).

  The default is aNaF (ON/OFF control).
- Setting the MV Change Rate Limit
- Press the Key several times in the Adjustment Level to display (MV Change Rate Limit).

  Press the or Key to set the value to 5.0.

  The default is 0.0 (%/s).

  Adjustment Level

  MV Change Rate Limit

  MASK8

## **Setting the PF Key** 5-21

# PF Setting (Function Key)

PF Setting (Advanced Function Setting Level) • Pressing the PF Key for at least one second executes the operation set in the PF Setting parameter. The default is 5HFE (digit shift).



Set value	Display	Setting	Function		
OFF	ōFF	Disabled	Does not operate as a function key.		
RUN	RUN	RUN	Specifies RUN status.		
STOP	SEOP	STOP	Specifies STOP status.		
R-S	R-5	RUN/STOP reverse operation	Specifies reversing the RUN/STOP operation status.		
AT-2	RE-2	100% AT Execute/Cancel	Specifies reversing the 100% AT Execute/Cancel status.*1		
AT-1	AE-I	40% AT Execute/Cancel	Specifies reversing the 40% AT Execute/Cancel status.*1 *4		
LAT	LAF	Alarm Latch Cancel	Specifies canceling all alarm latches.*2		
A-M	A-W	Auto/Manual	Specifies reversing the Auto/Manual status.*3 *5		
PFDP	PFdP	Monitor/Setting Item	Specifies the monitor/setting item display. Select the monitor setting item according to the Monitor/Setting Item 1 to 5 parameters (Advanced Function Setting Level).		
SHFT	SHFŁ	Digit Shift	Operates as a Digit Shift Key when settings are being changed.		
A-UD	R-Ud	PID Update	The PID is updated when PID constants that can be		
		(Adaptive Control)	updated are calculated for adaptive control.		
FA	FR	Automatic Filter	Specifies reversing between performing and stopping		
		Adjustment	operation after automatic filter adjustment.		
W-HT	W-HE	Water-cooling Output	Specifies reversing between performing and stopping		
V V -1 1 1		Adjustment	water-cooling output adjustment.		

When AT cancel is specified, it means that AT is cancelled regardless of whether the AT currently being executed is 100% AT or 40% AT.

Note1: Pressing the PF Key for at least one second executes operation according to the set value. (However, if Digit Shift is set, operation will be in less than one second.) When the Monitor/Setting Item parameter is selected, however, the display is changed in order from Monitor/Setting Item 1 to 5 each time the key is pressed.

2: This function is enabled when PF Key Protect is OFF.

<sup>\*2</sup> Alarms 1 to 4, the HB alarm, and the HS alarm are cancelled.


<sup>\*3</sup> For details on auto/manual operations using the PF Key, refer to 5-16 Performing Manual Control.

<sup>\*4</sup> AT-1 can be set for heating/cooling control or for floating position-proportional control, but the setting will be disabled.

<sup>\*5</sup> The function that is set for the PF Key is disabled if the same function is assigned to an event input. For the default event input assignments, refer to Event Input Assignment 1 to Event Input Assignment 6 on page 6-57.

#### Monitor/Setting Item MASK8

Monitor/Setting Item 1 (Advanced Function Setting Level)



Setting the PF Setting parameter to the Monitor/Setting Item makes it possible to display monitor/setting items using the FK Key. The following table shows the details of the settings. For setting (monitor) ranges, refer to the applicable parameter.

Set value	2 *2	Remarks	
Set value	Setting <sup>*2</sup>	Monitor/Setting	Display
0	Disabled		
1	PV/SP/Multi-SP	Can be set. (SP)*1	
2	PV/SP/MV (Heating)	Can be set. (SP)*1	
3	PV/SP /Soak time remain	Can be set. (SP)*1	
4	Proportional band (P)	Can be set.	Р
5	Integral time (I)	Can be set.	Ĺ.
6	Derivative time (D)	Can be set.	d
7	Alarm value 1	Can be set.	AL - I
8	Alarm value upper limit 1	Can be set.	AL IH
9	Alarm value lower limit 1	Can be set.	AL IL
10	Alarm value 2	Can be set.	RL - 2
11	Alarm value upper limit 2	Can be set.	AL 2H
12	Alarm value lower limit 2	Can be set.	AL 2L
13	Alarm value 3	Can be set.	RL - 3
14	Alarm value upper limit 3	Can be set.	AL 3H
15	Alarm value lower limit 3	Can be set.	RL 3L
16	Alarm value 4	Can be set.	AL-4
17	Alarm value upper limit 4	Can be set.	AL YH
18	Alarm value lower limit 4	Can be set.	RL YL
19	PV/SP/Internal SP	Can be set. (SP)*1	
20	PV/SP/Alarm Value 1	Can be set. (SP)*1	
21	Proportional Band (Cooling)	Can be set.	[-P
22	Integral Time (Cooling)	Can be set.	[-[
23	Derivative Time (Cooling)	Can be set.	[-d
24	PV/SP/MV (Cooling)	Can be set. (SP)*1	
	, ,,		

<sup>\*1</sup> With the E5CD or E5CD-B, only the PV and SP can be displayed.

<sup>\*2</sup> If the display condition is not met for even one of the set parameters, the monitor/setting item display will not appear.

#### **Setting Monitor/Setting Items**

Pressing the F Key in either the Operation or Adjustment Level displays the applicable monitor/setting items. Press the F Key to display in order Monitor/Setting Items 1 to 5. After Monitor/Setting Item 5 has been displayed, the display will switch to the top parameter in the Operation Level.

- Note 1: Items set as disabled in the Monitor/Setting Items 1 to 5 parameters will not be displayed, and the display will skip to the next enabled setting.
  - 2: While a monitor/setting item is being displayed, the display will be switched to the top parameter in the Operation Level if the Key or the Key is pressed.

This procedure sets the PF Setting parameter to PFDP, and the Monitor/Setting Item 1 parameter to 7 (Alarm Value 1).

#### **Operating Procedure** · Setting the PF Key Advanced Function Setting Press the Key several times in the Advanced Function Set-Level ting Level to display PF (PF Setting). PF Setting SHFL **2** Press the ♠ or ♥ Key to select *PFdP* (Monitor/Setting Item). PF The default is 5HFL (digit shift). PFdP Setting the Monitor/Setting Items Advanced Function Setting Level ting Level to display PFd | (Monitor/Setting Item 1). Monitor/Setting Item 1 MASK8 Press the ♠ or ❤ Key to select 7 (Alarm Value 1). The default is 1 (PV/SP/Multi-SP No.). Monitor/Setting Item Level Return to the Operation Level and press the (PF) Key to display RL - I (Alarm Value 1). Monitor/Setting Item Display 1

# 5-22 Displaying PV/SV Status

## 5-22-1 PV and SV Status Display Functions

#### PV Status Display Function (Advanced Function Setting Level)


The PV on the No. 1 display in the PV, PV/SP, PV/Manual MV, or PV/SP Manual MV Display and the control or alarm status specified for the PV status display function are alternately displayed in 0.5-s cycles.\*1

- PV
- PV/SP\*2
- PV/Manual MV
- PV/SP/Manual MV
- \*1 This includes the displays specified with the PV/SP No. 1 and PV/SP No. 2 Display Selection parameters.
- \*2 This includes when the PV/SP is selected for the Monitor/Setting Item parameter.

Set value	Display	Function	
OFF	ōFF	No PV status display	
Manual	MRNU	MANU is alternately displayed during manual control.	
Stop	SŁāP	STOP is alternately displayed while operation is stopped.	
Alarm 1	ALM I	ALM1 is alternately displayed during Alarm 1 status.	
Alarm 2	ALM2	ALM2 is alternately displayed during Alarm 2 status.	
Alarm 3	ALM3	ALM3 is alternately displayed during Alarm 3 status.	
Alarm 4	ALMY	ALM4 is alternately displayed during Alarm 4 status.	
Alarm 1 to 4 OR status	ALM	ALM is alternately displayed when Alarm 1, 2, 3, or 4 is set to ON.	
Heater Alarm	НЯ	HA is alternately displayed when an HB alarm or HS alarm is ON.	

Note: The default is OFF.

Example: When STOP Is Selected for the PV Status Display Function



#### SV Status Display Function (Advanced Function Setting Level)

The SP, Manual MV, or blank on the No. 2 display in the PV/SP, PV, or PV/Manual MV Display and the control or alarm status specified for the SV status display function are alternately displayed in 0.5-s cycles.\*1

- PV
- PV/SP\*2
- PV/Manual MV
- PV/SP/Manual MV
- \*1 This includes the displays specified with the PV/SP No. 1 and PV/SP No. 2 Display Selection parameters.
- \*2 This includes when the PV/SP is selected for the Monitor/Setting Item parameter.

Set value	Display	Function	
OFF	ōFF	No SV status display	
Manual	MRNU	MANU is alternately displayed during manual control.	
Stop	SEGP	STOP is alternately displayed while operation is stopped.	
Alarm 1	ALM I	ALM1 is alternately displayed during Alarm 1 status.	

Set value	Display	lay Function	
Alarm 2	RLM2	ALM2 is alternately displayed during Alarm 2 status.	
Alarm 3	RLM3	ALM3 is alternately displayed during Alarm 3 status.	
Alarm 4 ALM4 is alternately displayed during Alarm 4 status.			
Alarm 1 to 4 OR status RLM ALM is alternately displayed when Alarm 1, 2, 3, or 4 is s		ALM is alternately displayed when Alarm 1, 2, 3, or 4 is set to ON.	
Heater Alarm HA is alternately displayed when an HB alarm or HS alarm is ON			

Note: The default is OFF.

Example: When ALM1 Is Selected for the SV Status Display Function





#### **Additional Information**

#### Priority of Flashing and Alternating Displays on No. 2 Display

The priority for flashing and alternating displays is as follows:

- Alternating display with SV status display (1)
- (2) Alternating display during program end output


The following procedure sets the PV Status Display Function parameter to ALM1.

Ope	rating Procedure		
1	Press the  Key several times in the Advanced Function Setting Level to display PV 5Ł (PV Status Display Function).	Advanced Function Setting Level  PV Status Display Function	
2	Press the ♠ or ❤ Key to select RLM I (alarm 1).  The default is ōFF.	PVSE RLM I	
3	If the Alarm 1 status is ON in Operation Level, the PV and RLM (Alarm 1) will be alternately displayed.	Operation Level  25  100  100	

# 5-23 Logic Operations 000

## 5-23-1 The Logic Operation Function (CX-Thermo)

- The logic operation function logically calculates as 1 or 0 the Digital Controller status (alarms, SP ramp, RUN/STOP, auto/manual, etc.) and the external event input status, and outputs the results to work bits. The work bit status can be output to auxiliary or control outputs, and operating status can be switched according to the work bit status.
- Work bit logic operation can be set from 1 to 8. Set them to *No operation (Always OFF)* (the default) when the work bits are not to be used.
- When logic operations are being used, a dot will be displayed between the first two digits on the No.
   2 display of the Adjustment Level display



Note: The four numeric digits to identify the product code are displayed in the No. 2 display.


#### 5-23-2 Using Logic Operations

Logic operations are set using the CX-Thermo.


#### Starting Logic Operations

There are two ways to start logic operations.

• Select Logic Operation Editor from the CX-Thermo tree, and click the Start Button.




• Select Logic Operation Editor from the CX-Thermo Options Menu.



#### Making the Settings


The following display will appear on the Logic Operation Editor Setting Window. Set each of the parameters.



#### (1) Displaying the Library Import Dialog Box

Logic operation samples for specific cases are set in the library in advance. Examples of settings for specific cases are loaded by selecting them from the library list and clicking the OK Button.

Example: Selecting Library 1



#### (2) Switching Work Bit Operations

Select the work bit logic operations from the Operation of Work Bit 1 to Operation of Work Bit 8 Tab Pages.


#### (3) Selecting the Operation Type

From one to four operations are supported. If work bits are not to be used, set them to *No operation (Always OFF)* (the default).

 No operation (Always OFF)




· Operation 1




(A and B) or (C and D) When conditions A and B or conditions C and D are satisfied

• Operation 2




(A or C) and (B or D) When condition A or C and condition B or D are satisfied

Operation 3



A or B or C or D When condition A, B, C or D is satisfied

Operation 4



A and B and C and D When conditions A, B, C and D are all satisfied

#### (4) Selecting Input Assignments

Select the input assignment for the work bit logic operation from the following settings.

Parameter name	Setting range
	0. Always OFF
	1. Always ON
	2. ON for one cycle when power is turned
	ON
	3. Event input 1 (external input)*
	4. Event input 2 (external input)*
	5. Event input 3 (external input)*
	6. Event input 4 (external input)*
	7. Event input 5 (external input)*
	8. Event input 6 (external input)*
	9. Alarm 1
	10. Alarm 2
	11. Alarm 3
	12. Alarm 4
	13. Control output (heating)
	14. Control output (cooling)
	15. Input error
	16. Always OFF
	17. HB (heater burnout) alarm
	18. HS alarm
Made Dit 4 Is not Assistance and A	19. Auto/Manual
Work Bit 1 Input Assignment A	20. RUN/STOP
	21. Always OFF
	Program start     AT Execute/Cancel
	24. SP ramp operating
	25. Multi-SP No. switching bit 0
	26. Multi-SP No. switching bit 1
	27. Multi-SP No. switching bit 2
	28. Program end output
	29. Work bit 1
	30. Work bit 2
	31. Work bit 3
	32. Work bit 4
	33. Work bit 5
	34. Work bit 6
	35. Work bit 7
	36. Work bit 8
	37. Adaptive control in progress (system
	performance evaluation)
	38. Adaptive control notification in progress
	39. Automatic filter adjustment in progress
	40. Adaptive control PID update enabled
Work Bit 1 Input Assignment B	Same as for work bit 1 input assignment A
Work Bit 1 Input Assignment C	Same as for work bit 1 input assignment A
Work Bit 1 Input Assignment D	Same as for work bit 1 input assignment A
to	to
Work Bit 8 Input Assignment D	Same as for work bit 1 input assignment A

The event inputs that can be used depend on the Digital Controller model.

#### (5) Switching between Normally Open and Normally Closed for Inputs A to D

Click the condition to switch between normally open and normally closed inputs A to D.

Normally open	Normally closed
<del>-</del>    -	+

#### (6) Switching between Normally Open and Normally Closed for Work Bits

Click the condition to switch between normally open and normally closed work bits.

Normally open	Normally closed
<del>-</del>	<b>-</b> ∅-

#### (7) Setting ON Delay Times

When an input with ON delay turns ON, the output will turn ON after the set delay time has elapsed. The setting range is 0 to 9,999. The default is 0 (disabled).

#### (8) Setting OFF Delay Times

When an input with OFF delay turns OFF, the output will turn OFF after the set delay time has elapsed. The setting range is 0 to 9,999. The default is 0 (disabled).

#### (9) Switching ON/OFF Delay Time Unit

Select either seconds or minutes for the ON/OFF delay time unit. The default is seconds. If the Work Bit \* Operation Type is set to anything but OFF, the Work Bit \* ON Delay and Work Bit \* OFF Delay will be displayed in the Adjustment Level and the settings can be changed with key operations.

#### (10) Changing Event Input Data

Select the event input conditions from the following setting ranges.

Parameter name	Setting range
	0. Not assigned.
	Event input 1 (external input)
	2. Event input 2 (external input)
	3. Event input 3 (external input)
	4. Event input 4 (external input)
	5. Event input 5 (external input)
	6. Event input 6 (external input)
Internal event 1	7. Work bit 1
	8. Work bit 2
	9. Work bit 3
	10. Work bit 4
	11. Work bit 5
	12. Work bit 6
	13. Work bit 7
	14. Work bit 8
Internal event 2	Same as for Event Input Data 1.
Internal event 3	Same as for Event Input Data 1.
Internal event 4	Same as for Event Input Data 1.
Internal event 5	Same as for Event Input Data 1.
Internal event 6	Same as for Event Input Data 1.

Note: The internal event data can be changed from the default setting even if there is no event input terminal (external input). By changing the default setting, the event input assignment parameters will be displayed at the Digital Controller display and can be set from the Digital Controller.

#### (11) Changing the Event Input Assignment Function

Select the setting for the internal event assignment.

When a work bit is selected as event input data, Communications Write Enable/Disable cannot be assigned to an event input.

#### (12) Changing Control Output and Auxiliary Output Settings

Control output and auxiliary output assignments can be changed. The items that can be changed depend on the Digital Controller model. For details, refer to 4-6 Setting Output Specifications.

Assigning a work bit to either a control output or to an auxiliary output is also considered to be the same as assigning an alarm. For example, if work bit 1 is set for the Auxiliary Output 1 Assignment parameter, then alarms 1 to 4 have been assigned.

#### (13) Displaying Parameter Guides

A description of the parameters can be displayed.


#### (14) Displaying the Work Bit Use Destinations


Display a list of destinations where the work bits are used.

#### Operating Procedure


This procedure uses event input 2 to change to RUN or STOP.

Event input 2 ON: RUN Event input 2 OFF: STOP







1. Select Logic Operation Editor from the CX-Thermo tree, and click the Start Button.



 The Logic Operation Editor will be displayed. Confirm that the screen for work bit 1 is displayed, and select Operation 3 from the Operation Type Field.





- 3. Set the operation by selecting one of the following:
  Work bit 1 input assignment A = 4: Event input 2 (external input)
  Work bit 1 input assignment B = 0: Always OFF
  Work bit 1 input assignment C = 0: Always OFF
  Work bit 1 input assignment D = 0: Always OFF
- Invert work bit 1. Click (Normally open) to change it to (Normally closed).
- Assign RUN/STOP to event input 2. Set "7: Work bit 1" for the event input data for event input 2, and set "RUN/STOP" for the assignment function.
- 6. Closing the Logic Operation
  Editor Dialog Box
  Click the Close Button.
  This completes the
  procedure for setting
  parameters using the
  CX-Thermo. Transfer the
  settings to the Digital
  Controller to set the Digital
  Controller. Refer to
  CX-Thermo help for the
  procedure to transfer the
  settings.




#### **Operating Procedure**

This procedure outputs alarm 1 status to auxiliary output 1 during operation (RUN). A library object is used to make the setting.







1. Select Logic Operation Editor from the CX-Thermo tree, and click the Start Button.



2. Click the Import of Library Button.



3. Select Library 1 from the library list, and then click the **OK** Button.



4. Confirm the following settings, and then click the OK Button. Work bit 1 operation type: Operation 1 Work bit 1 input assignment A = 9: Alarm 1 Work bit 1 input assignment B = 20: Invert for **RUN/STOP** Work bit 1 input assignment C = 0: Always OFF Work bit 1 input assignment D = 0: Always OFF Auxiliary output 1 = Work bit Closing the Logic Operation **Editor Dialog Box** Click the **Close** Button. This completes the procedure for setting parameters using the CX-Thermo. Transfer the settings to the Digital Controller to set the Digital Controller. Refer to

CX-Thermo help for the

procedure to transfer the

settings.

# 5-24 Initializing Settings

You can set the Parameter Initialization parameter (Advanced Function Setting Level) to FRLL (initialize parameters to defaults given in the manual) to return all of the parameter settings to the factory defaults.

The default is OFF.

#### **Operating Procedure**

#### Moving to the Advanced Function Setting Level

Refer to 4-1-4 Moving to the Advanced Function Setting Level for the procedure to enter the Advanced Function Setting Level if you have not done so before.

	Tunction Setting Level if you have not done so before.	
1	Press the  Key for at least 3 seconds in the Operation Level.  The No. 1 display will flash when the key is pressed for 1 s or longer.  The display will change from the Operation Level to the Initial Setting Level.	Operation Level
2	Press the  Key several times in the Initial Setting Level to display the Move to Advanced Function Setting Level parameter.  RMaV (Move to Advanced Function Setting Level) will be displayed.	Initial Setting Level Input Type
<i>3</i>	Press the And Keys at the Move to Advanced Function Setting Level parameter and then enter - 169.  You can hold the Or Key to increment or decrement the set value quickly.	Initial Setting Level  Move to Advanced Function Setting Level
4	Press  Key once or wait for 2 seconds or longer without doing anything. You will move to the Advanced Function Setting Level and  ENEE (Parameter Initialization) will be displayed.	Move to Advanced Function Setting Level  - 169: Password to move to Advanced Function Setting Level
•	Parameter Initialization	
1	Display the first parameter, <code>INLE</code> (Parameter Initialization) in the Advanced Function Setting Level.	Advanced Function Setting Level Parameter Initialization
2	Press the or vec Key to select FRLL (initialize to the factory settings described in the manual). The parameter settings will be initialized.  The default is oFF.	ENEE FREE

The parameter mask settings are not initialized when other settings are initialized. Refer to Parameter Mask Enable on page 6-5.

# 5-25 Setting the Operating Status to Use When Power Is Turned ON

You can set the operating status to use when the power supply is turned ON (including software resets).

You can set this with the  $P - \bar{a}N$  (Operation After Power ON) parameter in the Initial Setting Level. The default setting is to continue (the same status as when power was interrupted).

You can set any of the following options.

Operating status	Description
Continue (default)	The status when power was interrupted is continued.  If operation (run) was in progress when power was interrupted, operation will start.  If control was stopped (stop) when power was interrupted, control will be stopped.  If Manual Mode was in progress when power was interrupted, Manual Mode will be entered.
Stop	Control will be stopped (stop).
Manual	Manual Mode will be entered.

#### Parameters

Parameter	Display	Setting range	Default	Level
Operation After	P-āN	£āNŁ: Continue (status at power OFF)         5£āP: Control stopped (stop)	EāNE	Initial Setting
Power ON		MRNU: Manual Mode		Level

Note: Priority of Event Inputs

- If an event input is assigned to RUN/STOP, the setting of the Operation After Power ON parameter (STOP) will be given priority.
- If an event input is assigned to Auto/Manual, the Auto/Manual specification of the event input will be given priority over the setting of the Operation After Power ON parameter (Manual).

#### **Operating Procedure**

The following example shows how to set the Digital Controller to stop control when the power supply is turned ON.

• Setting the Operation After Power ON Parameter

# 5-26 Using the Transfer Output for the **Process Value, Set Point, or other** Data 000

#### 5-26-1 **Transfer Output Function**

A transfer output can be used on models that have a transfer output.

#### Precision and User Calibration


Precision	User calibration
±0.3% FS	Supported.*

For details on calibration, refer to Section 7 User Calibration.

#### Transfer Output Signal (Initial Setting Level)

You can use the Transfer Output Signal parameter to specify whether to output a current or voltage from the transfer output.

#### **Terminal Arrangement**



Setting range	Default
୳-2⊞: 4 to 20mA	4-20
I-5⊬: 1-5 V	1 60

#### Transfer Output Type (Initial Setting Level)


You can use the Transfer Output Type parameter to specify any of six types of data to output.

Transfer output type	Display	Setting range
OFF (default)	ōFF	
Set point	SP	SP lower limit to SP upper limit
Set point during SP ramp	5P-M	SP lower limit to SP upper limit
PV	Pl'	Input setting range lower limit to input setting range upper limit or Scaling lower limit to scaling upper limit
MV monitor (heating)*	Ml'	-5.0 to 105.0 (heating/cooling control: 0.0 to 105.0)
MV monitor (cooling)	[-MV	0.0 to 105.0
Valve opening	1' - M	-10.0 to 110.0

This function can be set for a Standard Control Model, but the setting will be disabled.

#### Transfer Scaling

- Reverse scaling is possible by setting the Transfer Output Lower Limit parameter larger than the
  Transfer Output Upper Limit parameter. If the Transfer Output Lower Limit and Transfer Output
  Upper Limit parameters are set to the same value, the transfer output will be output continuously
  at 0%.
- If the SP, SP during SP ramp, or PV is selected, the Transfer Output Upper Limit and Transfer Output Lower Limit parameters will be forcibly initialized to the respective upper and lower setting limits if any of the following parameters is changed: Input Type, Scaling Upper Limit, Scaling Lower Limit, Set Point Upper Limit, Set Point Lower Limit, or Temperature Unit.
  If the MV for heating or MV for cooling is selected, the Transfer Output Lower Limit and Transfer Output Upper Limit parameters will be initialized to 100.0 and 0.0, respectively, when a switch is made between standard control and heating/cooling control using the Standard or Heating/Cooling parameter.
- The output current when transfer output signal is set to 4 to 20 mA, the transfer output upper limit is set to 90.0, and the transfer output lower limit is set to 10.0 is shown in the following graph.
- For scaling from 0.0% to 100.0%, the output for –5.0 to 0.0 will be the same value as for 0.0%, and the output for 100.0 to 105.0 will be the same value as for 100.0%.



(The above graph is for when transfer output signal is set to 4 to 20 mA.)

Setting Example to Output 1 to 5 V for the Process Value (–50 to 200 $^{\circ}$ C, Input Type 5)

## **Operating Procedure**

•	rating Procedure  etting the Transfer Output Signal Type	
1	Press the  Key several times in the Initial Setting Level to	Initial Setting Level
	display ERSE (Transfer Output Signal Type).	Transfer Output Signal Type
2	Press the ♠ or ❤ to select <i>I-5l</i> (1 to 5 V).  The default is 4-20.	LR5L 1-5V
• Se	tting the Transfer Output Type	
1	Press the	Initial Setting Level
	display <i>ER-E</i> (Transfer Output Type).	Transfer Output Type
2	Press the $\triangle$ or $\bigcirc$ Key to select $PV$ (Process Value). The default is $\vec{a}FF$ .	ER-E
• Se	tting the Transfer Output Upper Limit	
1	Press the   Key several times in the Initial Setting Level to	Initial Setting Level
	display <i>ER-H</i> (Transfer Output Upper Limit).	Transfer Output Upper Limit
2	Press the ♠ or ❤ Key to set the value to 200.	
	The default is 1300.	
		200
• Se	etting the Transfer Output Lower Limit	
<u>1</u>	Press the  Key several times in the Initial Setting Level to	Initial Setting Level
	display ER-L (Transfer Output Lower Limit).	Transfer Output Lower Limit
2	Press the ♠ or ❤ Key to set the value to –50.	
	The default is –200.	
		-50

# **Parameters**

6-1	Conventions Used in this Section 6-2
6-2	Protect Level
6-3	<b>Operation Level 6-7</b>
6-4	Adjustment Level 6-16
6-5	Monitor/Setting Item Level 6-37
6-6	Manual Control Level
6-7	Initial Setting Level 6-40
6-8	Advanced Function Setting Level 6-62
6-9	Communications Setting Level 6-97

#### Conventions Used in this Section 6-1

#### Meanings of Icons Used in this Section



Describes the functions of the parameter.



Describes the setting range and default of the parameter.



Used to indicate parameters used only for monitoring.




Describes the parameter settings, such as those for Operation Commands, and procedures.



Used to indicate information on descriptions in which the parameter is used or the names of related parameters.

#### About Related Parameter Displays

Parameters are displayed only when the conditions for use given on the right of the parameter heading are satisfied. Protected parameters are not displayed regardless of the conditions for use, but the settings of these parameters are still valid.



#### The Order of Parameters in This Section

Parameters are described level by level.

The first page of each level describes the parameters in the level and the procedure to switch between parameters.

#### Alarms

It will be specified in this section when alarms are set for the Control Output 1 or 2 Assignment parameters, or for the Auxiliary Output 1 to 4 Assignment parameters. For example, when alarm 1 is set for the Control Output 1 Assignment parameter, it will be specified that alarm 1 is assigned. Assigning a work bit to either control output 1 or 2 or to auxiliary output 1 to 4 is also considered to be the same as assigning an alarm. For example, if work bit 1 is set for the Auxiliary Output 1

Assignment parameter, then alarms 1 to 4 have been assigned.

#### Parameter Masking


The MASK mark appears for parameters that are masked in the default parameter mask settings.

Disable the mask to display the parameter. The MASK8 mark appears for parameters that are masked only for the E5 $\square$ D- $\square$ -8 $\square$ .

Refer to 5-12 Hiding and Displaying Parameters.

## 6-2 Protect Level

Four levels of protection are provided on the E5 D, operation/adjustment protect, initial setting/communications protect, setting change protect, and PF key protect. These protect levels prevent unwanted operation of the keys on the front panel in varying degrees.



Parameters that are protected will not be displayed and their settings cannot be changed.

PMoV Move to Protect Level

The Password to Move to Protect Level password must not be set to 0.

The password to move to the Protect Level is entered for this parameter.



 If the correct password is entered, the Operation/Adjustment Protect parameter is displayed.



#### Related Parameters

Password to Move to Protect Level (Protect Level): page 6-6

5RPL **Operation/Adjustment Protect** 

**Initial Setting/Communications I**[PŁ **Protect** 

These parameters specify the range of parameters to be protected.



## Operation/Adjustment Protect



Level		Set value			
	Level		1	2	3
	PV	Can be dis- played	Can be dis- played	Can be dis- played	Can be dis- played
Operation Level	PV/SP	Can be dis- played and changed	Can be dis- played and changed	Can be dis- played and changed	Can be dis- played
	Others	Can be dis- played and changed	Can be dis- played and changed	Cannot be displayed and moving to other lev- els is not possible	Cannot be displayed and moving to other lev- els is not possible
Adjustment Level		Can be dis- played and changed	Cannot be displayed and moving to other lev- els is not possible	Cannot be displayed and moving to other lev- els is not possible	Cannot be displayed and moving to other lev- els is not possible

• Parameters are not protected when the set value is set to 0.

#### Initial Setting/Communications Protect

This protect level restricts movement to the Initial Setting Level, Communications Setting Level, and Advanced Function Setting Level.

Set value	Initial setting level	Communications setting level	Advanced function setting level
0	Possible to reach	Possible to reach	Possible to reach
1 (default)	Possible to reach	Possible to reach	Not possible to reach
2	Not possible to reach	Not possible to reach	Not possible to reach

## WEPE Setting Change Protect

The Event Input Assignment 1 to Event Input Assignment 4 parameters must not be set to enable/disable setting changes.

Changes to settings using key operations are restricted.



#### Change Setting Protect

This parameter is not displayed if the Event Input Assignment 1 to Event Input Assignment 4 parameters are set to enable/disable setting changes.



Set value	Description	
OFF (default)	Settings can be changed using key operations.	
ON	Settings cannot be changed using key operations. (The protect level settings, however, can be changed.)	

• The all protect indication (On) will light when setting is ON.

## PFPL PF Key Protect



#### PF Key Protect

This parameter enables and disables PF Key operation.



Set value	Description	
OFF (default)	PF Key enabled	
ON PF Key disabled (Operation as a function key is prohibited.)		

#### PM5// Parameter Mask Enable



This parameter turns the parameter mask function ON and OFF.



Setting range	Default
āN: Enabled, āFF: Disabled	ōΝ

\* A parameter mask can be used to hide the displays of parameters that are not needed. You can set parameter masks with a key operation or with the Setup Tool. Setup Tool: CX-Thermo (EST2-2C-MV4)

#### PRLP **Password to Move to Protect Level**



This parameter is used to set the password to move to the Protect Level.



To prevent setting the password incorrectly, the ♠ and □ Keys or ♥ and □ Keys must be pressed simultaneously to set the password.



Setting range	Default
-1999 to 9999	0

Set this parameter to 0 when no password is to be set.



#### Related Parameters

Move to Protect Level (Protect Level): Page 6-3




#### **Precautions for Correct Use**

Protection cannot be cleared or changed without the password. Be careful not to forget it. If you forget the password, contact your OMRON sales representative.

# 6-3 Operation Level

Display this level to perform control operations on the E5 D. You can set alarm values, monitor the manipulated variable, and perform other operations in this level.



**Process Value/Set Point 1** PV/SP No. 1 Display Selection must not be set to 0.

**Process Value/Set Point 2** PV/SP No. 2 Display Selection must not be set to 0.



The following table shows the contents of the No. 1, 2, and 3 displays, according to the setting of the PV/SP Display Screen Selection parameter.



Set value	No. 1 display	No. 2 display	No. 3 display (E5ED or E5ED-B only)
0	Nothing is displayed.	Nothing is displayed.	Nothing is displayed.
1	Process value	Set point	Nothing is displayed.
2	Process value	Nothing is displayed.	Nothing is displayed.
3	Set point	SP (character display)	Nothing is displayed.
4	Process value	Set point	MV (heating)
5	Process value	Set point	Multi-SP No.*
6	Process value	Set point	Soak time remain *
7	Process value	Set point	Internal set point (ramp SP)
8	Process value	Set point	Alarm value 1*
9	Process value	Set point	MV (cooling)*

Nothing is displayed on the No. 1, 2, and 3 displays if the display conditions are not met.

	Monitor range	
Process value	Temperature input: The specified range for the specified sensor.  Analog input: Scaling lower limit –5% FS to Scaling upper limit +5% FS	EU

	Setting range	
Set point	SP lower limit to SP upper limit	EU

For a temperature input, the decimal point position depends on the currently selected sensor, and for an analog input it depends on the Decimal Point parameter setting.

#### PV/SP Display Selections

Parameter	Default
PV/SP No. 1 Display Selection	4*
PV/SP No. 2 Display Selection	0

The default is 1 for models other than the E5 D- -8 D.



#### Related Parameters

PV/SP Display Selection (Advanced Function Setting Level): Page 6-88

#### R-M Auto/Manual Switch

The Event Input Assignment 1 to 4 parameters must not be set to Auto/Manual.

The control must be set to 2-PID control.





- This parameter switches the Digital Controller between Automatic and Manual Modes.
- If the Key is pressed for at least 3 seconds when the Auto/Manual Switch parameter is displayed, the Manual Mode will be entered and the manual control level will be displayed.
- This parameter will not be displayed if an event input is set to "MANU" (auto/manual).
- The default parameter mask settings mask (hide) this parameter.



#### Related Parameters

PID ON/OFF (Initial Setting Level): Page 6-43
Parameter Mask Setting (Advanced Function Setting Level): Page 6-95
Parameter Mask Enable (Protect Level): 6-4

M-5P Multi-SP Set Point Selection (Set Points 0 to 7)

The Number of Multi-SP Points parameter must not be set to OFF and the Event Input Assignment 1 to Event Input Assignment 4 parameters must not be set to "Multi-SP No. switching bit 0" to "Multi-SP No. switching bit 2."



To use the multi-SP function, preset up to eight set points (SP 0 to 7) in the Adjustment Level, and then switch the set point either by operating the keys or by using external input signals (event inputs).

This parameter is used to select set points 0 to 7.

5P - M Set Point During SP Ramp

The SP Ramp Set Value parameter must not be set to OFF and the SP Ramp Fall Value parameter must not be set to SAME or OFF.

This parameter monitors the set point during SP ramp operation.



A ramp is used to restrict the change width of the set point as a rate of change.

This parameter is displayed when a set value is input for the SP Ramp Set Value parameter (Adjustment Level).

When not in ramp operation, the set point will be the same as the one displayed for the Process Value/Set Point parameter.



Monitor range	Unit
SP: SP lower limit to SP upper limit	EU



#### **Related Parameters**

Process Value/Set Point (Operation Level): Page 6-8 SP Ramp Set Value (Adjustment Level): Page 6-34 SP Ramp Fall Value (Adjustment Level): Page 6-34 Set Point Upper Limit (Initial Setting Level): Page 6-43 Set Point Lower Limit (Initial Setting Level): Page 6-43

#### $E \vdash I$ **Heater Current 1 Value Monitor**

HB and HS alarms must be supported. The HB ON/OFF parameter must be set to ON.

This parameter measures the heater current from the CT input used for detecting heater burnout.



This parameter measures and displays the heater current value.

· Heater burnout is not detected if the ON time for the control output for heating is 100 ms or less (30 ms or less if the control period is 0.1 or 0.2 s).



Monitor range	Unit
0.0 to 55.0	Α

- FFFF is displayed when 55.0 A is exceeded.
- If an alarm is output for the Heater Burnout Detection 1 parameter, the No. 1 display will flash the Heater Current 1 Value Monitor parameter.



#### Related Parameters

Heater Burnout Detection 1 (Adjustment Level): Page 6-20 HB ON/OFF (Advanced Function Setting Level): Page 6-66

Error Display [ L 1: Page A-18

#### $I\Gamma RI$ **Leakage Current 1 Monitor**

HB and HS alarms must be supported. The HS Alarm Use parameter must be set to ON.

This parameter measures the heater current from the CT input used for detecting SSR short-circuits.



The heater current is measured and the leakage current 1 monitor is displayed.

 The HS alarm is not detected if the OFF time for the control output for heating is 100 ms or less (38 ms or less if the control period is 0.1 or 0.2 s).



Monitor range	Unit
0.0 to 55.0	Α

- FFFF is displayed when 55.0 A is exceeded.
- If an alarm is output for the HS Alarm 1 parameter, the No. 1 display will flash the Leakage Current 1 Monitor parameter.



#### Related Parameters

HS Alarm 1 (Adjustment Level): Page 6-21 HS Alarm Use (Advanced Function Setting Level): Page 6-76 Error Display LER 1: Page A-18

PRSE Program Start

The Program Pattern parameter must not be set to OFF.

This parameter starts and stops the simple program function.



- The RUN/STOP status will automatically switch to RUN when this parameter is set to STRT.
- The simple program will stop when this parameter is set to RSET.
- This parameter will function as a monitor display for the start/stop status of the simple program if an event input is selected to start the simple program.



	Setting range	Default
RSET	Stops the simpler program.	RSEŁ
STRT	Starts the simpler program.	



#### Related Parameters

Soak Time Remain (Operation Level): Page 6-12

RUN/STOP (Operation Level): Page 6-12 Soak Time (Adjustment Level): Page 6-32 Wait Band (Adjustment Level): Page 6-32

Program Pattern (Initial Setting Level): Page 6-48

Soak Time Unit (Advanced Function Setting Level): Page 6-83

#### SKER **Soak Time Remain**

The Program Pattern parameter must not be set to OFF.



This parameter measures and displays the remaining time of the soak time for the simple program function.



Monitor range	Unit	
0 to 9999	min, h, or s	



#### Related Parameters

Program Start (Operation Level): Page 6-11 Soak Time (Adjustment Level): Page 6-32 Wait Band (Adjustment Level): Page 6-32

Program Pattern (Initial Setting Level): Page 6-48

Soak Time Unit (Advanced Function Setting Level): Page 6-83

#### R-5 **RUN/STOP**

This parameter starts and stops the control operation.



When PUN (RUN) is selected, control is started. When 5½ aP (STOP) is selected, control is stopped. The STOP indicator will light when control is stopped.

The default is RUN.



#### **Precautions for Correct Use**

For models with event inputs, the Event Input Assignment 2 parameter is set to RUN/STOP in the default settings. Even if you use key operations to set STOP, the Digital Controller will start in Run Mode when the power supply is turned ON if the event terminals are not connected.

RL - | Alarm Value 1

Alarm Value 2

Alarm 1 to alarm 4 must be assigned. The Alarm 1 to 4 Type parameters must not be set to 0, 1, 4, 5, or 12.

RL - 3 Alarm Value 3

用L - Y Alarm Value 4

This parameter is set to one of the input values "X" in 4-10-1 Alarm Types.



- These parameters set the alarm values for alarms 1 to 4.
- During temperature input, the decimal point position depends on the currently selected sensor, and during analog input it depends on the Decimal Point parameter setting.

Alarms Other Than an MV Alarm

Setting range	Unit	Default
-1999 to 9999	EU	0

#### MV Alarms

Setting range	Unit	Default
-199.9 to 999.9	%	0.0



#### Related Parameters

Input Type (Initial Setting Level): Page 6-41

Scaling Upper Limit, Scaling Lower Limit (Initial Setting Level), and Decimal Point (Initial Setting Level): Page 6-42

Alarm 1 to 4 Type (Initial Setting Level): Page 6-50

Alarm 1 to 4 Hysteresis (Initial Setting Level): Page 6-54

Standby Sequence Reset (Advanced Function Setting Level): Page 6-65

Auxiliary Output 1 to 4 Open in Alarm (Advanced Function Setting Level): Page 6-66

Alarm 1 to 4 Latch (Advanced Function Setting Level): Page 6-71

AL IH	Alarm Value Upper Limit 1	
AL SH	Alarm Value Upper Limit 2	
AL 3H	Alarm Value Upper Limit 3	
AL 4H	Alarm Value Upper Limit 4	Alarm 1 to alarm 4 must be assigned.
AL IL	Alarm Value Lower Limit 1	The Alarm 1 to 4 Type parameter must be set to 1, 4, or 5.
AL 2L	Alarm Value Lower Limit 2	
AL 3L	Alarm Value Lower Limit 3	
AL 4L	Alarm Value Lower Limit 4	

These parameters individually set the alarm value upper and lower limits when a mode for setting the upper and lower limits is selected for the Alarm 1 to 4 Type parameter (Initial Setting Level).



- These parameters set the upper and lower limits for alarms 1 to 4.
- · During temperature input, the decimal point position depends on the currently selected sensor, and during analog input it depends on the Decimal Point parameter setting.



Setting range	Unit	Default
-1999 to 9999	EU	0



#### Related Parameters

Input Type (Initial Setting Level): Page 6-41

Scaling Upper Limit, Scaling Lower Limit, and Decimal Point (Initial Setting Level): Page 6-42

Alarm 1 to 4 Type (Initial Setting Level): Page 6-50

Alarm 1 to 4 Hysteresis (Initial Setting Level): Page 6-54

Standby Sequence Reset (Advanced Function Setting Level): Page 6-65

Auxiliary Output 1 to 4 Open in Alarm (Advanced Function Setting Level): Page 6-66

Alarm 1 to 4 Latch (Advanced Function Setting Level): Page 6-71

## MV Monitor (Heating)



This parameter is used to monitor the manipulated variable for the heating control output during operation.



- During standard control, the manipulated variable is monitored. During heating/cooling control, the manipulated variables on the control output (heating) is monitored.
- The default parameter mask settings mask (hide) this parameter.



Control	Monitor range	Unit
Standard	-5.0 to 105.0	%
Heating/cooling	0.0 to 105.0	%



#### Related Parameters

Parameter Mask Setting (Advanced Function Setting Level): Page 6-95 Parameter Mask Enable (Protect Level): Page 6-4

[ -  $\bar{a}$  MV Monitor (Cooling)

The control system must be set to heating/cooling control.




This parameter is used to monitor the manipulated variable for the cooling control output during operation.



- During heating/cooling control, the manipulated variable on the control output (cooling) is monitored.
- The default parameter mask settings mask (hide) this parameter.








#### Related Parameters

Standard or Heating/Cooling (Initial Setting Level): Page 6-44 Parameter Mask Enable (Protect Level): Page 6-4


#### **Adjustment Level** 6-4

This level is for executing AT (auto-tuning) and other operations, and for set control parameters. This level provides the basic Digital Controller parameters for PID control (proportional band, integral time, derivative time) and heating/cooling control.



To move to the Adjustment Level from the Operation Level, press the Key once.

- The set points 0 to 7 in the Adjustment Level are the set values for switching the set point during multi-SP input.
- The following items are displayed for Digital Controllers with CT Inputs: Heater current monitors, Leakage current monitors, HB alarm detection, and HS alarm detection.
- · Adjustment level parameters can be changed after setting the Operation/Adjustment Protect parameter to 0. Displays changing levels are not possible Operation/Adjustment Protect parameter is set to 1 to 3. Protection is set in the Protect Level.



#### L.RdJ **Adjustment Level Display**



This parameter is displayed after moving to the Adjustment Level. The four numeric digits to identify the product code are displayed in the No. 2 display.

When a logic operation is set, a period "." will be displayed on the No. 2. display.



 This parameter indicates that the Adjustment Level has been entered. (The Adjustment Level parameter will not be displayed again even if the 

Rey is pressed in the Adjustment Level to scroll through the parameters.)

RŁ

AT Execute/Cancel

The RUN/STOP parameter must be set to RUN (default: RUN), control must be 2-PID control (default: PID).

This parameter executes auto-tuning (AT).



- The MV is forcibly increased and decreased around the set point to find the characteristics of the control object. From the results, the PID constants are automatically set in the Proportional Band (P), Integral Time (I), and Derivative Time (D) parameters.
- Both 100% AT and 40% AT are supported for AT. Only 100% AT can be executed for heating and cooling control.
- · For heating/cooling control, select the tuning methods that is suitable for the cooling control characteristics in the Heating/Cooling Tuning Method parameter.
- If autotuning is performed with the default settings, the cooling PID constants (i.e., Proportional Band (Cooling), Integral Time (Cooling), and Derivative Time (Cooling) parameters) have the same values as the heating PID constants.



Setting range		Default
OFF:	AT Cancel	
AT-2:	100%AT Execute	OFF
AT-1:	40%AT Execute	

- This parameter is normally  $\bar{a}FF$ . Press the  $ext{ } ext{ } ext$ AT. AT cannot be executed when control is stopped or during ON/OFF control.
- The TUNE indicator will light during autotuning.
- When AT execution ends, the parameter setting automatically returns to αFF.



#### Related Parameters

RUN/STOP (Operation Level): Page 6-12

Proportional Band, Integral Time, and Derivative Time (Adjustment Level): Page 6-26 Proportional Band (Cooling), Integral Time (Cooling), and Derivative Time (Cooling) (Adjustment Level): Page 6-27

PID ON/OFF (Initial Setting Level): Page 6-43

Heating/Cooling Tuning Method (Advanced Function Setting Level): Page 6-85

## **EMUL** Communications Writing

Communications must be supported.
The Event Input Assignment 1 to Event Input Assignment 4 parameters must not be set to enable/disable communications writing.



- This parameter enables/disables writing of parameters to the E5□D from the host (personal computer) using communications.
- This parameter is not displayed if the Event Input Assignment 1 to Event Input Assignment 4 parameters are set to enable/disable communications writing.



	Setting range	Default
ON:	Writing enabled	OFF
OFF:	Writing disabled	OFF

• Writing with communications is enabled if you set the Protocol Setting parameter to Host Link (FINS), MC protocol (format 4), or dedicated protocol (format 4).



#### Related Parameters

Communications Setting Level: Page 6-97
Protocol Setting, Communications Unit No., Communications Baud Rate,
Communications Data Length, Communications Parity, and Communications Stop Bits

## [ Heater Current 1 Value Monitor

HB and HS alarms must be supported.

The HB ON/OFF parameter must be set to ON.

This parameter measures the heater current from the CT input used for detecting heater burnout.



This parameter measures and displays the heater current value.

 Heater burnout is not detected if the ON time for the control output for heating is 100 ms or less (30 ms or less if the control period is 0.1 or 0.2 s).



Monitor range	Unit
0.0 to 55.0	Α

- FFFF is displayed when 55.0 A is exceeded.
- If an alarm is output for the Heater Burnout Detection 1 parameter, the No. 1 display will flash the Heater Current 1 Value Monitor parameter.



#### Related Parameters

Heater Burnout Detection 1 (Adjustment Level): Page 6-20 HB ON/OFF (Advanced Function Setting Level): Page 6-66 Error Displays ££ 1: Page A-18

#### Hh I **Heater Burnout Detection 1**

HB and HS alarms must be supported. The HB ON/OFF parameter must be set to ON.

This parameter sets the current for the heater burnout alarm to be output.



- · The heater burnout alarm is output when the heater current value falls below the setting of this parameter.
- When the set value is 0.0, the heater burnout alarm output is turned OFF. When the set value is 50.0, the heater burnout alarm output is turned ON.



Setting range	Unit	Default
0.0 to 50.0	Α	0.0



#### Related Parameters

Heater Current 1 Value Monitor (Adjustment Level): Page 6-19 Heater Burnout Detection (Advanced Function Setting Level): Page 6-66 Heater Burnout Latch (Advanced Function Setting Level): Page 6-67

Heater Burnout Hysteresis (Advanced Function Setting Level): Page 6-67

#### LERI **Leakage Current 1 Monitor**

HB and HS alarms must be supported. The HS Alarm Use parameter must be set to ON.

This parameter measures the heater current from the CT input used for detecting SSR short-circuits.



This parameter measures and displays the heater current when the heater is OFF.

 The HS alarm is not detected if the OFF time for the control output for heating is 100 ms or less (38 ms or less if the control period is 0.1 or 0.2 s).



Monitor range	Unit
0.0 to 55.0	Α

- FFFF is displayed when 55.0 A is exceeded.
- If an alarm is output for the HS Alarm 1 parameter, the No. 1 display will flash the Leakage Current 1 Monitor parameter.



#### Related Parameters

HS Alarm 1 (Adjustment Level): Page 6-21

HS Alarm Use (Advanced Function Setting Level): Page 6-76

Error Displays LER 1: Page A-18

## H5 / HS Alarm 1

HB and HS alarms must be supported.

The HS Alarm Use parameter must be set to ON.

This parameter sets the current for the HS alarm to be output.



- An HS alarm is output when the leakage current value exceeds the setting of this parameter.
- When the set value is 50.0, the HS alarm output is turned OFF. When the set value is 0.0, the HS alarm output is turned ON.



Setting range	Unit	Default
0.0 to 50.0	Α	50.0



#### Related Parameters

Leakage Current 1 Monitor (Adjustment Level): Page 6-20 HS Alarm (Advanced Function Setting Level): Page 6-76 HS Alarm Latch (Advanced Function Setting Level): Page 6-77 HS Alarm Hysteresis (Advanced Function Setting Level): Page 6-77

5P-0	SP 0	
5P- I	SP 1	
5P-2	SP 2	
5P-3	SP 3	The Number of Multi-SP Points parameter must be set to 2 to 8 and the Event Input 1 Assignment to
5P-4	SP 4	Event Input 4 Assignment parameters must not be set to "Multi-SP No. switching bit 0" to "Multi-SP No. switching bit 2."
5P-5	SP 5	
5P-6	SP 6	
5P-7	SP 7	

These parameters set the set points when the multi-SP function is used.



The values set in these parameters can be selected by operating the keys on the front panel or by using event inputs.

- When the set point has been changed, the set value of the set point (0 to 7) selected by the multi-SP inputs is also changed to the same value.
- The decimal point position depends on the selected sensor. During analog input, it depends on the Decimal Point parameter setting.



Setting range	Unit	Default
SP lower limit to SP upper limit	EU	0



### Related Parameters

Process Value/Set Point (Operation Level): Page 6-8

Input Type (Initial Setting Level): Page 6-41

Event Input Assignment (Initial Setting Level): Page 6-57

Number of Multi-SP Points (Advanced Function Setting Level): Page 6-64

## Process Value Input Shift



Sometimes an error occurs between the process value and the actual temperature. To offset this, a compensated value can be obtained by adding an input shift value to the input. The compensated value is displayed as the process value and used for control. The entire input range is shifted by a fixed rate. If the input shift value is set to  $-1^{\circ}$ C, control will be performed for a value  $1^{\circ}$ C lower than the measured temperature.



Setting range	Unit	Default
Temperature input: -199.9 to 999.9	°C or °F	0.0
Analog input: -1,999 to 9,999*	EU	0

<sup>\*</sup> The decimal point position depends on the Decimal Point parameter setting.



#### Related Parameters

Input Type (Initial Setting Level): Page 6-41

### **INPL** Process Value Slope Coefficient





This parameter sets a factor to apply to the input to compensate the process value. The resulting value is displayed as the process value and used in control.



Setting range	Default
0.001 to 9.999	1.000

# FR Automatic Filter Adjustment

The Digital Controller must be in Run Mode (default: Run) and control must be standard control and 2-PID control.

This parameter performs automatic filter adjustment.



Automatic filter adjustment is used to reduce temperature fluctuations in systems where there is cyclic disturbance, such as packaging machines.

The set value of the Input Digital Filter parameter is automatically adjusted.



Setting range	Default
āFF: OFF / āN: ON	ōFF

### Related Parameters




Input Digital Filter (Adjustment Level): Page 6-24

Automatic Filter Adjustment Seal Period (Advanced Function Setting Level): Page 6-92 Automatic Filter Adjustment Hunting Monitor Period (Advanced Function Setting Level): Page 6-93

#### INF **Input Digital Filter**



This parameter sets the time constant for the input digital filter. The following diagram shows the effect on data after passing through the digital filter.



If the Automatic Filter Adjustment parameter in the Adjustment Level is set to ON, automatic filter adjustment will automatically set this parameter.



Setting range	Unit	Default
0.0 to 999.9	Seconds	0.0

#### R-Ud **PID Update (Adaptive Control)**

The control must be standard control and 2-PID control.

The input type must be set for a temperature input. The Adaptive Control parameter must be set to "Notification."

It must be possible to update the PID constants with the values calculated by adaptive control.

This parameter updates the PID constants with values that are calculated with adaptive control.



This parameter is displayed if the Adaptive Control parameter is set to "Notification" and updateable PID constants are calculated. The PID constants are updated to the values calculated with system performance evaluation.



Setting range	Default
ōFF: OFF / ōN: Update	ōFF

# See

#### Related Parameters

Adaptive Control (Initial Setting Level): Page 6-45

W-HE

**Water-cooling Output Adjustment** 

The control must be set to heating/cooling control and 2-PID control.

The input type must be set for a temperature input. The Heating/Cooling Tuning Method must be set to "Water cooling."

This parameter is used to enable or disable water-cooling output adjustment.



- This parameter is used to suppress hunting caused by the water-cooling output from a water-cooled extrusion press.
- The set value of the Proportional Band (Cooling) parameter is automatically adjusted.



Setting range	Default	
āFF: Disabled, āN: Enabled	ŏFF	



#### Related Parameters

Water-cooling Proportional Band Increase Threshold (Adjustment Level): Page 6-25 Water-cooling Proportional Band Decrease Threshold (Adjustment Level): Page 6-26

W-IL

Water-cooling Proportional Band Increase Threshold

The control must be set to heating/cooling control and 2-PID control.

The input type must be set for a temperature input. The Heating/Cooling Tuning Method must be set to "Water cooling."

This parameter sets the threshold to detect hunting for water-cooling output adjustment.



- This parameter sets the threshold for the temperature variation that is used to detect
  hunting. If the variation exceeds this threshold, the cooling proportional band is adjusted
  to reduce hunting.
- Normally, use the default for this parameter.



Setting range	Unit	Default
Water-cooling proportional band decrease	°C or °F	1.4
threshold + 0.1 to 200.0		

# Related Parameters



Water-cooling Output Adjustment (Adjustment Level): Page 6-25

## W-dL

**Water-cooling Proportional Band Decrease Threshold** 

The control must be set to heating/cooling control and 2-PID control.

The input type must be set for a temperature input. The Heating/Cooling Tuning Method must be set to "Water cooling".

This parameter sets the threshold to optimize disturbance response for water-cooling output adjustment.



- This parameter sets the threshold to the temperature variation that is used to detect when disturbance response is not optimal.
- If the variation is less than or equal to this threshold, the cooling proportional band is adjusted to optimize disturbance response.
- Normally, use the default for this parameter.



Setting range	Unit	Default
0 to Water-cooling proportional band increase	°C or °F	0.6
threshold - 0.1		



See

### Related Parameters

Water-cooling Output Adjustment (Adjustment Level): Page 6-25

Р	Proportional Band	
		Control must be set to 2-PID control. Either the
ī	Integral Time	Standard or Heating/Cooling parameter must be set to heating/cooling control or, if the Standard or Heating/Cooling parameter is set to standard
Ь	Derivative Time	control, adaptive control must be disabled.

These parameters set PID control constants. PID constants are automatically set when AT is executed.



Refers to control in which the MV is proportional to the deviation (control error). action:

action:

Refers to a control action that is proportional to the time integral of the deviation. With proportional control, there is normally an offset (control error). Proportional action is thus used in combination with integral action. As time passes, this control error disappears, and the control temperature (process value) comes to agree with the set point.

D action: Refers to a control action that is proportional to the time derivative of the control error. The proportional control and integral control correct for errors in the control result, and thus the control system is late in responding to sudden changes in temperature. The derivative action increases the MV in proportion to the slope of the change in the temperature as a corrective action.



Parameter	Setting range			Unit	Default
Proportional	Temperature input		0.1 to 999.9	°C	8.0
Band				°F	14.4
	Analog input		]	%FS	10.0
Integral Time *	Integral/ Derivative Time Unit of 1 s	Standard or heating/cooling control	0 to 9999	Seconds	233
	Integral/ Derivative Time Unit of 0.1 s	Standard or heating/cooling control	0.0 to 999.9	Seconds	233.0
Derivative	Integral/Derivative Time Unit of 1 s		0 to 9999	Seconds	40
Time *	Integral/Derivative Time Unit of 0.1 s		0.0 to 999.9	Seconds	40.0

\* The unit is determined by the setting of the Integral/Derivative Time Unit parameter. The Proportional Band, Integral Time, and Derivative Time parameters are initialized if the Integral/Derivative Time Unit parameter is changed.



#### Related Parameters

AT Execute/Cancel (Adjustment Level): Page 6-18
Integral/Derivative Time Unit (Advanced Function Setting Level): Page 6-68

- [-P Proportional Band (Cooling)
- The control must be set to heating/cooling control and 2-PID control.



These parameters set the PID constants for cooling control. These parameters are automatically set according to the Heating/Cooling Tuning Method parameter when AT is executed.



Parameter	Setting range	Unit	Default	
Proportional	Temperature input	0.1 to 999.9	°C	8.0
Band (Cooling)			°F	14.4
	Analog input		%FS	10.0
Integral Time	Integral/Derivative Time Unit of 1 s	0 to 9999	Seconds	233
(Cooling) *	Integral/Derivative Time Unit of 0.1 s	0.0 to 999.9	Seconds	233.0
Derivative Time	Integral/Derivative Time Unit of 1 s	0 to 9999	Seconds	40
(Cooling)*	Integral/Derivative Time Unit of 0.1 s	0.0 to 999.9	Seconds	40.0

\* The unit is determined by the setting of the Integral/Derivative Time Unit parameter. The Proportional Band (Cooling), Integral Time (Cooling), and Derivative Time (Cooling) parameters are initialized if the Integral/Derivative Time Unit parameter is changed.



#### Related Parameters

AT Execute/Cancel (Adjustment Level): Page 6-18
Integral/Derivative Time Unit (Advanced Function Setting Level): Page 6-68

SP-P	SP Response Proportional Band	
, ,	or mospensor repertiental Zama	The control must be standard control and 2-PID
		control.
5P-Z	SP Response Integral Time	The input type must be set for a temperature input.
		The Adaptive Control parameter must be set to
rn ı	00 D	"Fixed."
5P-d	SP Response Derivative Time	

These parameters set the PID constants for set point response for use in adaptive control.



- These parameters set the PID constants that are used during a transitional state in PID control.
- The set values of these parameters are automatically calculated when autotuning is executed while the Adaptive Control parameter is set to "Notification" or "Automatic update."
- This parameter is not displayed while the Adaptive Control parameter is set to "Notification" or "Automatic update." You can check the set value through communications.
- Do not change the set value of this parameter after it is calculated.



Parameter name	Setting range		Unit	Default
SP Response	0.1 to 999.9		°C	8.0
Proportional Band			°F	14.4
SP Response Integral	Integral/Derivative Time	0 to 9999	Seconds	233
Time	Unit of 1 s			
	Integral/Derivative Time	0.0 to 999.9	Seconds	233.0
	Unit of 0.1 s			
SP Response	Integral/Derivative Time	0 to 9999	Seconds	40
Derivative Time	Unit of 1 s			
	Integral/Derivative Time	0.0 to 999.9	Seconds	40.0
	Unit of 0.1 s			

#### Related Parameters



Adaptive Control (Initial Setting Level): Page 6-45

# 5P-N SP Response Coefficient Number

The control must be standard control and 2-PID control.

The input type must be set for a temperature input. The Adaptive Control parameter must be set to "Fixed."

This parameter is used for adaptive control.



- This parameter sets the coefficient that is used during a transitional state in adaptive control.
- The set value of this parameter is automatically calculated when autotuning is executed while the Adaptive Control parameter is set to "Notification" or "Automatic update."
- This parameter is not displayed while the Adaptive Control parameter is set to "Notification" or "Automatic update." You can check the set value through communications.
- Do not change the set value of this parameter after it is calculated.



Setting range	Default
0 to 9999	0

# See /

#### Related Parameters

Adaptive Control (Initial Setting Level): Page 6-45

d-P	Disturbance Proportional Band	
. ,		The control must be standard control and 2-PID
		control.
d-ī	Disturbance Integral Time	The input type must be set for a temperature input.
	_	The Adaptive Control parameter must be set to
		"Fixed."
d-d	Disturbance Derivative Time	11704.

These parameters set the PID constants for disturbance for use in adaptive control.



- These parameters set the PID constants that are used during a steady state in adaptive control.
- The set values of these parameters are automatically calculated when autotuning is executed while the Adaptive Control parameter is set to "Notification" or "Automatic update."
- This parameter is not displayed while the Adaptive Control parameter is set to "Notification" or "Automatic update." You can check the set value through communications.
- Do not change the set value of this parameter after it is calculated.



Parameter name	Setting range		Unit	Default
Disturbance	0.1 to 999.9		°C	8.0
Proportional Band			°F	14.4
Disturbance Integral	Integral/Derivative	0 to 9999	Seconds	233
Time	Time Unit of 1 s			
	Integral/Derivative	0.0 to 999.9	Seconds	233.0
	Time Unit of 0.1 s			
Disturbance	Integral/Derivative	0 to 9999	Seconds	40
Derivative Time	Time Unit of 1 s			
	Integral/Derivative	0.0 to 999.9	Seconds	40.0
	Time Unit of 0.1 s			

#### Related Parameters



Adaptive Control (Initial Setting Level): Page 6-45

C-db	Dead Band
------	-----------

The control system must be set to heating/cooling control.

This parameter sets the output dead band width for heating/cooling control. A negative setting sets an overlapping band.



This parameter sets an area in which the control output is 0 centering around the set point for a heating/cooling control.



Setting range		Unit	Default
Temperature input	-199.9 to 999.9	°C	0.0
		°F	0.0
Analog input	-19.99 to 99.99	%FS	0.00

## ōF-R Ma

**Manual Reset Value** 

The control must be standard control and 2-PID control. The integral time must be 0.



This parameter sets the required manipulated variable to remove offset during stabilization of P or PD control.



Setting range	Unit	Default
0.0 to 100.0	%	50.0



#### Related Parameters

Integral Time (Adjustment Level): Page 6-26 PID ON/OFF (Initial Setting Level): Page 6-43

445 CH45

Hysteresis (Heating) Hysteresis (Cooling) The control must be ON/OFF control. For the Hysteresis (Cooling) parameter, the control must be heating/cooling control.

This parameter sets the hysteresis for ensuring stable operation at the ON/OFF switching point.



- For standard control, use the Hysteresis (Heating) parameter. The Hysteresis (Cooling) parameter cannot be used.
- For heating/cooling control, the hysteresis can be set independently for heating/cooling. The Hysteresis (Heating) parameter is used for the heating side, and the Hysteresis (Cooling) parameter is used for the cooling side.



Parameter name	Setting r	ange	Unit	Default
Hysteresis	Temperature input	0.1 to 999.9	°C	1.0
(Heating)			°F	1.8
	Analog input	0.01 to 99.99	%FS	0.10
Hysteresis	Temperature input	0.1 to 999.9	°C	1.0
(Cooling)			°F	1.8
	Analog input	0.01 to 99.99	%FS	0.10



#### Related Parameters

PID ON/OFF (Initial Setting Level): Page 6-43

Standard or Heating/Cooling (Initial Setting Level): Page 6-44

#### 55RK **Soak Time**

The Program Pattern parameter must not be set to OFF.



This parameter sets the time for the control operation when using the simple program function.



Setting range	Unit	Unit
1 to 9999	s, min, or h	1



#### Related Parameters

Program Start (Operation Level): Page 6-11

Soak Time Remain (Operation Level): Page 6-12

Wait Band (Adjustment Level): Page 6-32

Program Pattern (Initial Setting Level): Page 6-48

Soak Time Unit (Advanced Function Setting Level): Page 6-83

#### WE-B **Wait Band**

The Program Pattern parameter must not be set to OFF.



This parameter sets the stable band within which the soak time is measured for the simple program function.



Setting range		Unit	Unit
Temperature input	OFF or 0.1 to 999.9	°C or °F	off
Analog input	OFF or 0.01 to 99.99	%FS	



#### Related Parameters

Program Start (Operation Level): Page 6-11

Soak Time Remain (Operation Level): Page 6-12

Soak Time (Adjustment Level): Page 6-32

Program Pattern (Initial Setting Level): Page 6-48

Soak Time Unit (Advanced Function Setting Level): Page 6-83

# MV - 5 MV at Stop

The control must be set to 2-PID control.





- This parameter sets the MV to use when the RUN/STOP status changes from RUN to STOP.
- The default parameter mask settings mask (hide) this parameter.



Control method	Setting range	Unit	Default
Standard	-5.0 to 105.0	%	0.0
Heating and cooling	-105.0 to 105.0		



#### Related Parameters

RUN/STOP (Operation Level): Page 6-12

Parameter Mask Setting (Advanced Function Setting Level): Page 6-95

Parameter Mask Enable (Protect Level): Page 6-4

## MV - E MV at PV Error

The control must be set to 2-PID control.





- This parameter sets the MV to use when an input error occurs.
- The default parameter mask settings mask (hide) this parameter.



Control method	Setting range	Unit	Default
Standard	-5.0 to 105.0	%	0.0
Heating and cooling	-105.0 to 105.0		



### Related Parameters

Parameter Mask Setting (Advanced Function Setting Level): Page 6-95 Parameter Mask Enable (Protect Level): Page 6-4

5PR<sub>E</sub> **SP Ramp Set Value** 

**SPRL** SP Ramp Fall Value MASK8



- · These parameters set the rate of change during SP ramp operation. They set the maximum permissible change width per unit of time as the SP ramp set value and the SP ramp fall value. The SP ramp function is disabled if this parameter is set to OFF.
- For a temperature input, the decimal point positions of the SP ramp set value and SP ramp fall value depend on the currently selected sensor, and for an analog input they depend on the Decimal Point parameter.



Parameter	Setting range	Unit	Default
SP Ramp Set Value	OFF or 1 to 9,999	EU/s, EU/ min, EU/h	OFF
SP Ramp Fall Value	SAME (Same as SP ramp set value), OFF or 1 to 9,999	EU/s, EU/ min, EU/h	SAME

āL-H **MV Upper Limit** 

The control must be set to 2-PID control.

ōL-L **MV Lower Limit** 



The MV Upper Limit and MV Lower Limit parameters set the upper and lower limits of the manipulated variable. When the calculated manipulated variable exceeds the upper or lower limit value, the upper or lower limit value will be the output level.



#### • MV Upper Limit

Control method	Setting range	Unit	Default
Standard	MV lower limit + 0.1 to 105.0	%	100.0
Heating/cooling control	0.0 to 105.0		

#### MV Lower Limit

The MV for the cooling control output during heating/cooling control is expressed as a negative value.

Control method	Setting range	Unit	Default
Standard	-5.0 to MV upper limit - 0.1	%	0.0
Heating/cooling control	-105.0 to 0.0		-100.0



#### **Related Parameters**

PID ON/OFF (Initial Setting Level): Page 6-43

## āRL.

**MV Change Rate Limit** 

The control must be set to 2-PID control.





- The MV Change Rate Limit parameter sets the maximum allowable variation in the MV per second. If the change in the MV exceeds this setting, the MV will be changed by the MV change rate limit until the calculated value is reached. If the limit is set to 0.0, this function will be disabled.
- The MV Change Rate Limit parameter will not operate in the following situations.
  - In Manual Mode
  - During AT execution
  - During ON/OFF control
  - While stopped (MV output during STOP)
  - · During MV output when error occurs



Setting range	Unit	Default
0.0 to 100.0	%/s	0.0



#### Related Parameters

Proportional Band (Adjustment Level): Page 6-26


## **SDRP**

Extraction of Square Root Low-cut Point

The input type must be an analog input, and the Extraction of Square Root Enable parameter must be set to ON.



- This parameter sets the extraction of square root low-cut point used for the inputs. The data after extracting the square root is shown below.
- The low-cut point is used for extracting the square root for flowrate sensors.





Setting range	Unit	Default
0.0 to 100.0	%	0.0



### Related Parameters

Extraction of Square Root Enable (Initial Setting Level): Page 6-59

WI to Ban Work Bit 1 to 8 ON Delay 000 WI to BoF Work Bit 1 to 8 OFF Delay 000

The work bit operation type must not be set to OFF.



ON Delay

When the results of a work bit logic operation is ON, the work bit is turned ON after the time specified in the parameter elapses.

OFF Delay

When the results of a work bit logic operation is OFF, the work bit is turned OFF after the time specified in the parameter elapses.



Setting range	Unit	Default
0 to 9999	Seconds*	0

The unit can be changed to minutes on the CX-Thermo Logic Operation Editor Setting Window.



#### **Related Parameters**

Auxiliary Output 1 to 4 Assignment (Advanced Function Setting Level): Page 6-81

#### PLEM **Communications Monitor**

Communications must be supported. The Protocol Setting parameter must be set to Host Link (FINS) or the MC Protocol.



- · The Communications Monitor parameter displays the communications cycle time of the E5□D.
- If communications are not possible with the PLC, L.ERR is displayed. When communications are restored, the cycle time is displayed again.




Monitoring range	Default
Normal: 0 to 9999 ms, If 9999 ms is exceeded: בבבב	
Error: C.ERR	

Also refer to the E5 D Digital Controllers Communications Manual (Cat. No. H225) for information on communications.

#### 6-5 Monitor/Setting Item Level

Monitor/setting items can be displayed by means of the function key when the PF Setting parameter (Advanced Function Setting Level) is set to PFDP: Monitor/Setting Item.



The PF Setting parameter must be set to PFDP, and PFd I to 5 Monitor/Setting Item Display 1 to 5 the Monitor/Setting Item 1 to 5 parameters must not be set to OFF.

• When the PF Key is set to display monitor/setting items, pressing the PF Key will display in order the contents of the Monitor/Setting Item 1 to 5 parameters. The contents of these parameters are shown in the following table. For the setting (monitor) ranges, refer to the applicable parameters.


Set value Setting*2		Remarks		
Set value	Setting*2	Monitor/Setting	Display	
0	Disabled			
1	PV/SP/Multi-SP	Can be set. (SP)*1		
2	PV/SP/MV (Heating)	Can be set. (SP)*1		
3	PV/SP /Soak time remain	Can be set. (SP)*1		
4	Proportional band (P)	Can be set.	Р	
5	Integral time (I)	Can be set.	L	
6	Derivative time (D)	Can be set.	В	
7	Alarm value 1	Can be set.	AL - I	
8	Alarm value upper limit 1	Can be set.	AL IH	
9	Alarm value lower limit 1	Can be set.	AL IL	
10	Alarm value 2	Can be set.	AL-2	
11	Alarm value upper limit 2	Can be set.	AL2H	
12	Alarm value lower limit 2	Can be set.	AL2L	
13	Alarm value 3	Can be set.	AL - 3	
14	Alarm value upper limit 3	Can be set.	RL 3H	
15	Alarm value lower limit 3	Can be set.	AL 3L	
16	Alarm value 4	Can be set.	AL-4	
17	Alarm value upper limit 4	Can be set.	RL YH	
18	Alarm value lower limit 4	Can be set.	ALYL	
19	PV/SP/Internal SP	Can be set. (SP)*1		
20	PV/SP/Alarm Value 1	Can be set. (SP)*1		
21	Proportional Band (Cooling)	Can be set.	[-P	
22	Integral Time (Cooling)	Can be set.	[-[	
23	Derivative Time (Cooling)	Can be set.	[-d	
24	PV/SP/MV (Cooling)	Can be set. (SP)*1		

With the E5CD or E5CD-B, only the PV and SP can be displayed.

<sup>\*2</sup> If the display condition is not met for even one of the set parameters, the monitor/setting item display will not appear.

#### **Manual Control Level** 6-6

If you change to Manual Mode, the Manual MV parameter will be displayed and the displayed value will be output as the MV. You must first display the Auto/Manual Switch parameter (R-M). The Auto/Manual Switch parameter is masked by default. Refer to 5-12 Hiding and Displaying Parameters.



For details on the setting method, refer to 5-16 Performing Manual Control.

- The MANU indicator will light during manual control.
- It is not possible to move to any parameters except for the PV/MV parameter during manual operation.

#### PV/MV (Manual MV)

The control must be set to 2-PID control.



• The manual control level display appears as shown below.

#### E5ED or E5ED-B

E5CD or E5CD-B





	Monitor range	Unit
Process value	Temperature: According to indication range for each sensor.	EU
	Analog: Scaling lower limit –5% FS to Scaling upper limit +5% FS (Refer to <i>A-8 Sensor Input Setting Range, Indication Range, Control Range.</i> )	
Set point	SP lower limit to SP upper limit	EU

	Setting range		Default	Unit
MV (Manual MV)	Standard control	-5.0 to 105.0*	0.0	%
	Heating/cooling control	-105.0 to 105.0*		

When the Manual MV Limit Enable parameter is set to ON, the setting range will be the MV lower limit to the MV upper limit.




## Related Parameters

5-16 Performing Manual Control: Page 5-56

Standard or Heating/Cooling (Initial Setting Level): Page 6-44

# **Initial Setting Level**


This level is used to set up the basic Digital Controller specifications. In this level, you can set the Input Type parameter to set the sensor input to be connected, limit the setting range of set points, set the alarm modes, and perform other operations.



To move from the Operation Level or Adjustment Level to the Initial Setting Level, press the 

Key for at least three seconds with any parameter displayed except for the Auto/Manual Switch parame-

- The Initial Setting Level is not displayed when the Initial Setting/Communications Protect parameter is set to 2. It can be used when the Initial Setting/Communications Protect parameter is set to 0 or 1.
- If the Input Type parameter is set for an analog input, the following parameters will be set: Scaling upper limit, Scaling lower limit, and Decimal point.



## Input Type Input Type



- The Input Type parameter is used to set the input type.
- When this parameter is changed, the set point limiter is changed to the defaults. If the limiter must be specified, set the SP Upper Limit and SP Lower Limit parameters (Initial Setting Level) again.
- If a resistance thermometer is mistakenly connected while a setting for other than a resistance thermometer is in effect, 5.ERR will be displayed. To clear the 5.ERR display, check the wiring and then cycle the power.



	Input type	Sensor	Set value	Temperature	Temperature
		specification	001 14140	range in °C	range in °F
		Pt100	0	-200 to 850	-300 to 1500
	Resistance		1	-199.9 to 500.0	-199.9 to 900.0
	thermometer		2	0.0 to 100.0	0.0 to 210.0
	thermometer	JPt100	3	-199.9 to 500.0	-199.9 to 900.0
		01 1100	4	0.0 to 100.0	0.0 to 210.0
		K	5 (default)	-200 to 1300	-300 to 2300
		K	6	-20.0 to 500.0	0.0 to 900.0
=		J	7	-100 to 850	-100 to 1500
nbr		3	8	-20.0 to 400.0	0.0 to 750.0
Temperature input		Т	9	-200 to 400	-300 to 700
atu		1	10	-199.9 to 400.0	-199.9 to 700.0
per		Е	11	-200 to 600	-300 to 1100
e.	Thermocouple	L	12	-100 to 850	-100 to 1500
-	Thermocouple	U	13	-200 to 400	-300 to 700
			14	-199.9 to 400.0	-199.9 to 700.0
		N	15	-200 to 1300	-300 to 2300
		R	16	0 to 1700	0 to 3000
		S	17	0 to 1700	0 to 3000
		В	18	0 to 1800	0 to 3200
		C/W	19	0 to 2300	0 to 3200
		PLII	20	0 to 1300	0 to 2300
	Infrared	10 to 70°C	21	0 to 90	0 to 190
	Temperature	60 to 120°C	22	0 to 120	0 to 240
	Sensor	115 to 165°C	23	0 to 165	0 to 320
hdi	ES1B	140 to 260°C	24	0 to 260	0 to 500
. <u>⊨</u>	Current input	4 to 20 mA	25	One of the following ranges according	
ES1B  Current input		0 to 20 mA	26	to the scaling:	
		1 to 5 V	27	-1999 to 9999	
	Voltage input	0 to 5 V	28		
	, , , , , , , , , , , , , , , , , , ,	0 to 10V	29	-19.99 to 99.99 -1.999 to 9.999	

# See

#### Related Parameters

Temperature Unit (Initial Setting Level): Page 6-42 Set Point Upper Limit and Set Point Lower Limit (initial Setting Level): Page 6-43 IN-H **Scaling Upper Limit** 

IN-L **Scaling Lower limit** 

The input type must be set for an analog input.

dР **Decimal Point** 



• The Decimal Point parameter specifies the decimal point position of parameters (set point, etc.) whose unit is EU.



• Scaling Upper Limit, Scaling Lower Limit

Parameter name	Setting range	Default
Scaling Upper Limit	Scaling lower limit + 1 to 9999	100
Scaling Lower Limit	-1999 to scaling upper limit - 1	0

#### · Decimal Point

Parameter name	Setting range	Default
Decimal Point	0 to 3	0

Set value	Settings	Example
0	0 digits past decimal point	1234
1	1 digits past decimal point	123.4
2	2 digits past decimal point	12.34
3	3 digits past decimal point	1.234



## Related Parameters

Input Type (Initial Setting Level): Page 6-41

#### 4-11 **Temperature Unit**

The input type must be set for a temperature input.



- Set the temperature input unit to either °C or °F.
- If you change the temperature unit, the units of temperature set values (e.g., the alarm values) will be automatically converted.



Setting range	Default
Ľ: °C, F: °F	Ε



#### Related Parameters

Input Type (Initial Setting Level): Page 6-41

## 5L - H SP Upper Limit

## 5L -L SP Lower Limit



- These parameters set the upper and lower limits of the set points. A set point can be set
  within the range defined by the upper and lower limit set values in the SP Upper Limit and
  SP Lower Limit parameters. If these parameters are reset, any set point that is outside of
  the new range will be forcibly changed to either the upper limit or the lower limit.
- When the temperature input type and temperature unit have been changed, the set point upper limit and set point lower limit are forcibly changed to the upper and lower limits of the sensor.
- For a temperature input, the decimal point position depends on the currently selected sensor, and for an analog input it depends on the Decimal Point parameter setting.



Parameter	name	Setting range	Unit	Default
Set Point Upper Limit	Temperature input	SP lower limit + 1 to Input setting range upper limit	EU	1300
	Analog input	SP lower limit + 1 to scaling upper limit	EU	100
Set Point Lower Limit	Temperature input	Input setting range lower limit to SP upper limit - 1	EU	-200
	Analog input	Scaling lower limit to SP upper limit - 1	EU	0



#### Related Parameters

Input Type (Initial Setting Level): Page 6-41

Temperature Unit (Initial Setting Level): Page 6-42

### ENEL PID ON/OFF



- This parameter selects 2-PID control or ON/OFF control.
- Auto-tuning can be used in 2-PID control.



Setting range	Default
Pīd: 2-PID, āNāF: ON/OFF	Pīd



#### Related Parameters

AT Execute/Cancel (Adjustment Level): Page 6-18 Manual Reset Value (Adjustment Level): Page 6-31

Hysteresis (Heating) and Hysteresis (Cooling) (Adjustment Level): Page 6-31

#### 5-HE Standard or Heating/Cooling



- This parameter selects standard control or heating/cooling control.
- If heating/cooling control is selected for the E5CD or E5CD-B, the auxiliary output 2 terminal is assigned as the control output for cooling.
- If heating/cooling control is selected for the E5ED or E5ED-B when there is only one control output, the auxiliary output 4 terminal is assigned as the control output for cooling.

Note: If standard control is selected, set the Control Output 1 Assignment to a (control output (heating)) for either direct (cooling) or reverse (heating) operation.



Setting range	Default
5ŁNd: Standard, H-E: Heating/cooling	5ENd



#### **Related Parameters**

MV Monitor (Heating) (Operation Level): Page 6-15 MV Monitor (Cooling) (Operation Level): Page 6-15

Dead Band (Adjustment Level): Page 6-30

Hysteresis (Heating) and Hysteresis (Cooling) (Adjustment Level): Page 6-31 Control Period (Heating) and Control Period (Cooling) (Initial Setting Level): Page 6-49 Control Output 1 and 2 Assignment (Advanced Function Setting Level): Page 6-80 Auxiliary Output 1 to 4 Assignment (Advanced Function Setting Level): Page 6-81

## RdPL Adaptive Control

The control must be set to standard control and 2-PID control and the input type must be a temperature input.

This parameter sets the operation of adaptive control.



- Disabled: Adaptive control is disabled. Operation uses 2-PID control.
- Fixed: System performance evaluation is not performed. Use this setting when you do not want to update adaptive control PID values.
- Notification: System performance evaluation is performed and if temperature variations occur in the system, the A indicator will light to notify the user. If the fluctuation is small, the A indicator will not light, but the calculated adaptive control PID constants will be used. To update the adaptive control PID values, set the PID Update parameter to "Update (ON)."
- Automatic update: System performance evaluation is performed and the adaptive control PID constants are updated automatically.



	Setting range	Default
ōFF	Disabled.	
FZX	Fixed	ōEE
ī NF ā	Notification	יום
RUEō	Automatic update	

### Related Parameters



PID Update (Adaptive Control) (Adjustment Level): Page 6-24

Adaptive Control Operation Possible Deviation (Advanced Function Setting Level): Page 6-91

System Fluctuation Reference Deviation (Advanced Function Setting Level): Page 6-92

Model Creation PV Amplitude (Adjustment Level): Page 6-46

Model Creation MV Amplitude (Adjustment Level): Page 6-46

Model Creation ON Time (Adjustment Level): Page 6-47

Model Creation OFF Time (Adjustment Level): Page 6-47

SP Response Proportional Band (Adjustment Level): Page 6-28

SP Response Integral Time (Adjustment Level): Page 6-28

SP Response Derivative Time (Adjustment Level): Page 6-28

Disturbance Proportional Band (Adjustment Level): Page 6-29

Disturbance Integral Time (Adjustment Level): Page 6-30

Disturbance Derivative Time (Adjustment Level): Page 6-30

M-PV **Model Creation PV Amplitude**  The control must be standard control and 2-PID

The input type must be set for a temperature input. The Adaptive Control parameter must not be set to "Disabled."

This is one of the model parameters used for adaptive control. It expresses the PV variation characteristic of the system.

This parameter is copied so that another Digital Controller can inherit the measured system characteristics.



- The set value of this parameter is automatically calculated when autotuning is executed while the Adaptive Control parameter is set to "Notification" or "Automatic update."
- Do not change the set value of this parameter after it is calculated.



Setting range	Unit	Default
0.00 to 99.99	%FS	0.00



#### Related Parameters

Adaptive Control (Initial Setting Level): Page 6-45

M-MV **Model Creation MV Amplitude**  The control must be standard control and 2-PID

The input type must be set for a temperature input. The Adaptive Control parameter must not be set to "Disabled."

This is one of the model parameters used for adaptive control. It expresses the MV variation characteristic of the system.

This parameter is copied so that another Digital Controller can inherit the measured system characteristics.



- The set value of this parameter is automatically calculated when autotuning is executed while the Adaptive Control parameter is set to "Notification" or "Automatic update."
- Do not change the set value of this parameter after it is calculated.



Setting range	Unit	Default
0.0 to 100.0	%FS	0.0

# See

#### Related Parameters

Adaptive Control (Initial Setting Level): Page 6-45

## M- N Model Creation ON Time

The control must be standard control and 2-PID control.

The input type must be set for a temperature input. The Adaptive Control parameter must not be set to "Disabled."

This is one of the model parameters used for adaptive control. It expresses the ON time characteristic of the system.

This parameter is copied so that another Digital Controller can inherit the measured system characteristics.



- The set value of this parameter is automatically calculated when autotuning is executed while the Adaptive Control parameter is set to "Notification" or "Automatic update."
- Do not change the set value of this parameter after it is calculated.



Setting range	Unit	Default
0 to 9999		0

# See

#### Related Parameters

Adaptive Control (Initial Setting Level): Page 6-45

 $M - \bar{O}F$  Model Creation OFF Time

The control must be standard control and 2-PID control.

The input type must be set for a temperature input. The Adaptive Control parameter must not be set to "Disabled."

This is one of the model parameters used for adaptive control. It expresses the OFF time characteristic of the system.

This parameter is copied so that another Digital Controller can inherit the measured system characteristics.



- The set value of this parameter is automatically calculated when autotuning is executed while the Adaptive Control parameter is set to "Notification" or "Automatic update."
- Do not change the set value of this parameter after it is calculated.



Setting range	Unit	Default
0 to 9999		0
	!	

# See

#### Related Parameters

Adaptive Control (Initial Setting Level): Page 6-45

#### PERN **Program Pattern**



This parameter sets the type of control when using the simple program function.



- If the program pattern is set to  $\bar{a}FF$ , the simple program will not operate.
- If the program pattern is set to 5½ 5P, the RUN/STOP status will change to STOP after the soak time has expired. If the program pattern is set to £aNŁ, control will continue in RUN status after the soak time has expired.



	Setting range	Default
ōFF	Simple program function turned OFF	ōFF
SŁōP	Go to STOP mode at end of program.	
EāNE	Continue in RUN mode at end of program.	



### **Related Parameters**

Program Start (Operation Level): Page 6-11

Soak Time Remain (Operation Level): Page 6-12

RUN/STOP (Operation Level): Page 6-12 Soak Time (Adjustment Level): Page 6-32 Wait Band (Adjustment Level): Page 6-32

Soak Time Unit (Advanced Function Setting Level): Page 6-83

[P [-[P

Control Period (Heating)
Control Period (Cooling)

The heating and cooling control outputs must be assigned to relay or voltage outputs (for driving SSR).

The control must be set to 2-PID control.

For the Control Period (Cooling) parameter, the control must be set to heating/cooling control.



- These parameters set the output periods. Set the control periods taking the control characteristics and the electrical life of the relay into consideration.
- For standard control, use the Control Period (Heating) parameter. The Control Period (Cooling) parameter cannot be used.
- When the heating control output is a current output, the Control Period (Heating) parameter cannot be used. Also, when the cooling control output is a current output, the Control Period (Cooling) parameter cannot be used.
- For heating/cooling control, the control period can be set independently for heating and cooling. The Control Period (Heating) parameter is used for the heating control output, and the Control Period (Cooling) parameter is used for the cooling control output.



Parameter name	Setting range	Unit	Default
Control Period	0.1, 0.2, 0.5, 1 to 99	Seconds	20 for relay output
(Heating)			2 for voltage output (for driving SSR)
Control Period	0.1, 0.2, 0.5, 1 to 99	Seconds	20 for relay output
(Cooling)			2 for voltage output (for driving SSR)



#### Related Parameters

PID ON/OFF (Initial Setting Level): Page 6-43

#### **GREV Direct/Reverse Operation**



"Direct operation" refers to control where the manipulated variable is increased when the process value increases. Alternatively, "reverse operation" refers to control where the manipulated variable is increased when the process value decreases.



Setting range	Default
$\bar{a}R - \bar{R}$ : Reverse operation, $\bar{a}R - d$ : Direct operation	ōR-R

ALE I	Alarm 1 Type	Alarm 1 must be assigned.
ALE2	Alarm 2 Type	Alarm 2 must be assigned.
ALŁ3	Alarm 3 Type	Alarm 3 must be assigned.
ALLY	Alarm 4 Type	Alarm 4 must be assigned.



- Set the alarm type independently for each alarm in the Alarm 1 to 4 Type parameters in the Initial Setting Level.
- The alarms that can be set are listed in the following table.
- You can use an LBA (12) only for alarm 1.
- If the Controller is equipped with HB/HS alarm detection, the Alarm Type 1 is not displayed for the default settings. To use alarm 1, set an output assignment to alarm 1. (Refer to 4-6-3 Assigned Output Functions.)


Set		Alarm outp	ut operation	
value	Alarm type	When alarm value	When alarm value	Description of function
value		X is positive	X is negative	
0	Alarm function OFF	Outpu	it OFF	No alarm
1	Upper- and	ON → L   H ←	*2	Set the upward deviation in
	lower-limit*1	OFF SP PV		the set point for the alarm
		58		upper limit (H) and the
				lower deviation in the set
				point for the alarm lower
				limit (L). The alarm is ON
				when the PV is outside this
				deviation range.
2	Upper-limit	ON →   X  ←	ON →   X   ←	Set the upward deviation in
(default)		OFF SP PV	OFF SP PV	the set point by setting the
				alarm value (X). The alarm
				is ON when the PV is higher
				than the SP by the
				deviation or more.

	Alarm output operation			
Set value	Alarm type	When alarm value	When alarm value	Description of function
3	Lower-limit	X is positive  ON X PPV	X is negative  ON	Set the downward deviation in the set point by setting the alarm value (X). The alarm is ON when the PV is lower than the SP by the deviation or more.
4	Upper- and lower-limit range <sup>*1</sup>	ON OFF SP PV	*3	Set the upward deviation in the set point for the alarm upper limit (H) and the lower deviation in the set point for the alarm lower limit (L). The alarm is ON when the PV is inside this deviation range.
5	Upper- and lower-limit with standby sequence*1	ON OFF SP PV	*4	A standby sequence is added to the upper- and lower-limit alarm (1). *6
6	Upper-limit with standby sequence	ON X PV	ON OFF SP PV	A standby sequence is added to the upper-limit alarm (2). *6
7	Lower-limit with standby sequence	ON X PV	ON X PV	A standby sequence is added to the lower-limit alarm (3). *6
8	Absolute-value upper-limit	ON	ON	The alarm will turn ON if the process value is larger than the alarm value (X) regardless of the set point.
9	Absolute-value lower-limit	ON → X → OFF 0 PV	ON OFF OPV	The alarm will turn ON if the process value is smaller than the alarm value (X) regardless of the set point.
10	Absolute-value upper-limit with standby sequence	ON	ON	A standby sequence is added to the absolute-value upper-limit alarm (8). *6
11	Absolute-value lower-limit with standby sequence	ON ⊢ X → OFF 0 PV	ON OFF O PV	A standby sequence is added to the absolute-value lower-limit alarm (9). *6
12	LBA (alarm 1 type only)			*7
13	PV change rate alarm			*8
14	SP absolute-value upper-limit alarm	ON ← X → SP	ON SP	This alarm type turns ON the alarm when the set point (SP) is higher than the alarm value (X).
15	SP absolute-value lower-limit alarm	ON	ON OFF O PV	This alarm type turns ON the alarm when the set point (SP) is smaller than the alarm value (X).


Set		Alarm output operation			
value	Alarm type	When alarm value	When alarm value	Description of function	
Value		X is positive	X is negative		
16	MV absolute-value	Standard Control	Standard Control	This alarm type turns ON	
	upper-limit alarm <sup>*9</sup>	ON X → MV	ON ← X → O MV	the alarm when the manipulated variable (MV) is higher than the alarm	
		Heating/Cooling	Heating/Cooling	value (X).	
		Control (Heating	Control (Heating	,	
		MV)	MV)		
		ON	Always ON		
17	MV absolute-value	Standard Control	Standard Control	This alarm type turns ON	
	lower-limit alarm <sup>*9</sup>	ON OFF 0 MV	ON OFF O MV	the alarm when the manipulated variable (MV) is lower than the alarm	
		Heating/Cooling	Heating/Cooling	value (X).	
		Control (Cooling	Control (Cooling	, ,	
		MV)	MV)		
		ON	Always ON		

<sup>\*1</sup> With set values 1, 4 and 5, the upper- and lower- limit values can be set independently for each alarm type, and are expressed as "L" and "H."

\*2 Set value: 1 (Upper- and lower-limit alarm)



\*3 Set value: 4 (Upper- and lower-limit range)



- \*4 Set value: 5 (Upper- and lower-limit alarm with standby sequence)
  - For the upper- and lower-limit alarms in cases 1 and 2 above, the alarm is always OFF if upper- and lower-limit hysteresis overlaps.
  - In case 3, the alarm is always OFF.
- \*5 Set value: 5 (Upper- and lower-limit alarm with standby sequence)
  - The alarm is always OFF if upper- and lower-limit hysteresis overlaps.
- \*6 Refer to Standby Sequence Reset on page 6-65 for information on the operation of the standby sequence.
- \*7 Refer to 5-15-1 Loop Burnout Alarm (LBA).
- \*8 Refer to PV Change Rate Alarm on page 4-35.

\*9 When heating/cooling control is performed, the MV absolute-value upper-limit alarm functions only for the heating operation and the MV absolute-value lower-limit alarm functions only for the cooling operation.

# See

#### Related Parameters

Alarm Value 1 to 4 (Operation Level): Page 6-13

Alarm Value Upper Limit 1 to 4 and Alarm Value Lower Limit 1 to 4 (Operation Level): Page 6-14

Alarm 1 to 4 Hysteresis (Initial Setting Level): Page 6-54

Standby Sequence Reset (Advanced Function Setting Level): Page 6-65

Auxiliary Output 1 to 4 Open in Alarm (Advanced Function Setting Level): Page 6-66

Alarm 1 to 4 Latch (Advanced Function Setting Level): Page 6-71

ALH I	Alarm 1 Hysteresis	Alarm 1 must be assigned. The alarm 1 type must not be 0, 12, or 13.
ALH2	Alarm 2 Hysteresis	Alarm 2 must be assigned. The alarm 2 type must not be 0, 12, or 13.
ALH3	Alarm 3 Hysteresis	Alarm 3 must be assigned. The alarm 3 type must not be 0, 12, or 13.
ЯLНЧ	Alarm 4 Hysteresis	Alarm 4 must be assigned. The alarm 4 type must not be 0, 12, or 13.



• These parameters set the hysteresis for alarms 1, 2, 3, and 4.



#### Alarms Other Than an MV Alarm

Setting range		Unit	Default
Temperature input	0.1 to 999.9	°C	0.2
		°F	0.4
Analog input	0.01 to 99.99	%FS	0.02

#### **MV Alarms**

Setting range	Unit	Unit
0.01 to 99.99	%	0.50



#### Related Parameters

Alarm Value 1 to 4 (Operation Level): Page 6-13

Alarm Value Upper Limit 1 to 4 and Alarm Value Lower Limit 1 to 4 (Operation Level): Page 6-14

Alarm 1 to 4 Type (Initial Setting Level): Page 6-50

Standby Sequence Reset (Advanced Function Setting Level): Page 6-65

Auxiliary Output 1 to 4 Open in Alarm (Advanced Function Setting Level): Page 6-66

Alarm 1 to 4 Latch (Advanced Function Setting Level): Page 6-71

# □ 15L Control Output 1 Signal

Control output 1 must be a linear current output.



These parameters set the output signal for linear current outputs.

• Select 4 to 20 mA or 0 to 20 mA for the signal.



Setting range	Default
ਮ-2⊡: 4 to 20 mA	4-20
᠒-2᠒: 0 to 20 mA	7-60

# **LRSL**

Transfer Output Signal 000

There must be a transfer output.



This parameter sets the output signal for the transfer output.

• Select 4 to 20 mA or 1 to 5 V.



Setting range	Default
੫-2⊡: 4 to 20 mA	4-20
/-5⊮: 1 to 5 V	7-60

# LR-L

Transfer Output Type 000

There must be a transfer output.



• This parameter sets the transfer output type.



Transfer output type		Default
OFF	ōFF	ōFF
Set point	SP	
Set point during SP ramp	5P-M	
PV	Pl'	
MV (heating)	Ml'	
MV (cooling) *1	[-MV	

\*1 This function can be set for standard control Model, but the setting will be disabled.



### Related Parameter

Transfer Output Upper Limit and Transfer Output Lower Limit (Initial Setting Level): Page 6-56

ER-H Transfer Output Upper Limit 000

There must be a transfer output. The transfer output type must not be set to OFF.

LR-L

Transfer Output Lower Limit 000



• This parameter sets the upper and lower limit values of transfer outputs.



	Default				
Transfer	Set	ting range	Transfer	Transfer	Unit
output type			output lower limit	output upper limit	
Set point	SP lower limit	to SP upper limit	SP lower limit	SP upper limit	EU
Set point during SP ramp	SP lower limit	to SP upper limit			
PV	Temperature input	Input setting range lower limit to input setting range upper limit	Input setting range lower limit	Input setting range upper limit	
	Analog input	Analog scaling lower limit to analog scaling upper limit	Scaling lower limit	Scaling upper limit	
MV	Standard	-5.0 to 105.0	0.0	100.0	%
(heating)	Heating/	0.0 to 105.0			
MV	cooling				
(cooling)					
Valve opening*1	Position- proportional control	-10.0 to 110.0			

This function can be set for standard control Model, but the setting will be disabled.



## Related Parameter

Transfer Output Type (Initial Setting Level): Page 6-55

```
EV - | Event Input Assignment 1
```

- EV-2 Event Input Assignment 2
- Event Input Assignment 3

There must be event inputs.

- EV-4 Event Input Assignment 4
- EV-5 Event Input Assignment 5
- EVent Input Assignment 6



• The following functions can be assigned to event inputs 1 to 6.

**RUN/STOP** 

Auto/Manual Switch

**Program Start** 

Invert Direct/Reverse Operation

100% AT Execute/Cancel

40% AT Execute/Cancel

Setting Change Enable/Disable

Communications Writing Enable/Disable

Alarm Latch Cancel

Multi-SP No. Switching Bit 0

Multi-SP No. Switching Bit 1

Multi-SP No. Switching Bit 2

**RUN/STOP** 

PID Update (Adaptive Control)

Automatic Filter Adjustment

Water-cooling Output Adjustment

• Default: Event Input Assignment 1: M5₽₽

Event Input Assignment 2: 5½āP
Event Input Assignment 3: NāNE
Event Input Assignment 4: NāNE
Event Input Assignment 5: NāNE
Event Input Assignment 6: NāNE

• Do not assign the same function to more than one event input.



Setting	Function
NāNE	None
SEāP	RUN/STOP
MANU	Auto/Manual
PRSE	Program Start*1
dR5	Invert Direct/Reverse Operation
NāNE	None
BF - 5	100% AT Execute/Cancel
AE-1	40% AT Execute/Cancel*2
WEPE	Setting Change Enable/Disable
ЕМИЕ	Communications Writing Enable/Disable*3
LAF	Alarm Latch Cancel
MSPO	Multi-SP No. Switching Bit 0 <sup>*4</sup>
MSP I	Multi-SP No. Switching Bit 1*4
MSP2	Multi-SP No. Switching Bit 2 <sup>*4</sup>
RUN	RUN/STOP
A-Ud	PID Update (Adaptive Control)
FA	Automatic Filter Adjustment
W-HE	Water-cooling Output Adjustment

- PRST (Program Start) can be set even when the Program Pattern parameter is set to OFF, but the function will be disabled.
- \*2 This function can be set for heating/cooling control, but the function will be disabled.
- This function can be set only for a Controller that supports communications. Also, when a work bit is selected as the event input data for a logic operation, Communications Write Enable/Disable cannot be assigned. If the Digital Controller is operating only on the power supply from the USB-Serial Conversion Cable, it will operate as if the event inputs remain OFF. Therefore, communications writing will be disabled and you will not be able to write data from Setup Tools, such as the CX-Thermo.
- The following table shows the relationships between the ON/OFF status of multi-SP number switching bits 0 to 2 and the set point.

Salasted set point	Multi-SP No. switching bits		
Selected set point	Bit 0	Bit 1	Bit 2
SP 0	OFF	OFF	OFF
SP 1	ON	OFF	OFF
SP 2	OFF	ON	OFF
SP 3	ON	ON	OFF
SP 4	OFF	OFF	ON
SP 5	ON	OFF	ON
SP 6	OFF	ON	ON
SP 7	ON	ON	ON

Note: Any bits that are not assigned to event inputs are treated as being OFF.



#### Related Parameter

SP 0 to 7 (Adjustment Level): Page 6-22

# SOR

#### 





This parameter enables and disables square root extraction.



Setting range	Default
āN: Enabled, āFF: Disabled	OFF



#### Related Parameter

Extraction of Square Root Low-cut Point (Adjustment Level): Page 6-35

# P- N Operation After Power ON



This parameter sets the operating status when the power is turned ON.

You can set any of the following options.

- Continue (default): The status when power was interrupted is continued.
- Stop: Control will be stopped (stop).
- Manual: Manual Mode will be entered.

The specified operation is also used for software resets and when moving from initial setting level to operation level.



Parameter s	Setting range	Default
Eane	Continue	Eane
SŁōP	Stop	
MANII	Manual	



### Related Parameters

RUN/STOP (Operation Level): Page 6-12 PV/MV (Manual MV) (Manual Control Level): Page 6-39

**HRR Bar Display Data BRRH Bar Display Scaling Upper Limit** 

**LARL Bar Display Scaling Lower Limit** 



- These parameters specify the data to use in the bar display.
- These parameters scale the values specified for the bar display data.



Parameter name	Setting range	Unit	Default
Bar Display Data	āFF: Nothing displayed.		MV *1
	ੀਂ/∵: MV (heating)		
	[ -M//: MV (cooling)		
	[ E - 1: Heater current		
Bar Display Scaling	-199.9 to 999.9	For MV (heating) or MV	100.0 <sup>*2</sup>
Upper Limit		(cooling): %	
Bar Display Scaling		For heater current 1: A	0.0
Lower Limit			

- \*1 The default value for the E5 $\square$ D- $\square$ -8 $\square$  is [L-1].
- The default value for the E5 $\square$ D- $\square$ -8 $\square$  is 50.0.

There are ten bars in the display.



Operation Example: If the scaling values are set for 0.0% to 100%, seven bars will be lit for a manipulated value of 70% (65.0% to 74.9%).



### **Precautions for Correct Use**

If the heater current is displayed on the bar graph, the display will not be correct in the following

- · When the control period is 1 s or less
- When the ON time for control output is 100 ms or lesst

Example: If the control period is 2 s and the MV is 5%, the display will not be correct (2,000 ms × 0.05 = 100 ms).

RMāV

Move to Advanced Function Setting Level

The Initial Setting/Communications Protect parameter must be set to 0.



- Set the Move to Advanced Function Setting Level parameter set value to "-169."
- Move to the advanced function setting level either by pressing Key or Key or waiting or two seconds to elapse.



## Related Parameter

Initial Setting/Communication Protect (Protect Level): Page 6-4

## **Advanced Function Setting Level** 6-8

The Advanced Function Setting Level is used for optimizing Digital Controller performance. To move to this level, input the password ("-169") from the Initial Setting Level.


To be able to enter the password, the Initial Setting/Communications Protect parameter in the Protect Level must be set to 0.

# Moving to Advanced Function Setting Level


Move from the Operation Level to the Protect

Refer to 6-2 Protect Level.

**2** Display the Initial Setting/Communications Protect parameter.



- Change the set value to 0.
- Move from the Protect Level to the Operation Level to the Initial Setting Level.
- **5** Display the Move to Advanced Function Setting Level parameter.





- Change the set value to -169.
- The Advanced Function Setting Level is displayed.

- The parameters in the Advanced Function Setting Level can be used when the Initial Setting/Communications Protect parameter is set
- To switch between setting levels, press the
- To change set values, press the 

   and 

   Keys.





<sup>\*1</sup> The default value for the E5 $\square$ D- $\square$ -8 $\square$  is 8.

<sup>\*2</sup> The default value for the E5 $\square$ D- $\square$ -8 $\square$  is 1.

#### INTE **Parameter Initialization**



- This parameter returns all parameter settings to their defaults.
- After the initialization, the set value automatically turns OFF.



	Setting range	Default
ōFF:	Initialization is not executed.	ōFF
FACE:	Initializes to the factory settings described in the manual.	

#### M5PU **Number of Multi-SP Points**

The Digital Controller must not have event inputs or the Event Input Assignment 1 to Event Input Assignment 4 parameters must not be set to "Multi-SP No. switching bit 0" to "Multi-SP No. switching bit 2."



This parameter sets the number of Multi-SP points that will be used with key operations (none or 2 to 8).



Setting range	Default
OFF, 2 to 8	OFF

#### **SPRU SP Ramp Time Unit**



• This parameter sets the time unit for the rate of change during SP ramp operation.



Setting range	Default
5: EU/s, ∦: EU/min, ∦: EU/h	М



### Related Parameters

Ramp SP Monitor (Operation Level): 6-9 SP Ramp Set Value and SP Ramp Fall Value (Adjustment Level): Page 6-34

# RESE Standby Sequence Reset

Alarm 1 to 4 type must be 5, 6, 7, 10, or 11.




- This parameter selects the conditions for enabling reset after the standby sequence of the alarm has been canceled.
- Output is turned OFF when switching to the Initial Setting Level, Communications Setting Level, Advanced Function Setting Level, or Calibration Level.
- Condition A
   Control started (including when the power supply is turned ON), and an alarm value (alarm value upper/lower limit), the process value input shift, the process value slope.

(alarm value upper/lower limit), the process value input shift, the process value slope coefficient, or the SP changed.

Condition B
 Power ON

• The following example shows the reset action when the alarm type is lower-limit alarm with standby sequence.





Setting range	Default
⊞: Condition A, b: Condition B	R



### Related Parameters

Alarm 1 to 4 Type (Initial Setting Level): Page 6-50
Alarm 1 to 4 Latch (Advanced Function Setting Level): Page 6-71

56 IN	Auxiliary Output 1 Open in Alarm	Auxiliary output 1 must be assigned.
562N	Auxiliary Output 2 Open in Alarm	Auxiliary output 2 must be assigned.
563N	Auxiliary Output 3 Open in Alarm	Auxiliary output 3 must be assigned.
564N	Auxiliary Output 4 Open in Alarm	Auxiliary output 4 must be assigned.



- This parameter sets the output status of auxiliary outputs 1 to 4.
- · When Close in Alarm is set, the status of the auxiliary output function is output unchanged. When Open in Alarm is set, the status of the auxiliary output function is reversed before being output. The following table shows the relationship between the auxiliary output function, auxiliary output, and operation displays (SUB1 to SUB4).



	Auxiliary output function	Auxiliary output	Operation display (SUB1 to SUB4)
Close in	ON	ON	Lit
Alarm	OFF	OFF	Not lit
Open in	ON	OFF	Lit
Alarm	OFF	ON	Not lit

Setting range	Default
N-a: Close in alarm, N-E: Open in alarm	N-ō



### Related Parameters

Auxiliary Output 1 to 4 Assignment (Advanced Function Setting Level): Page 6-81

НЬЦ **HB ON/OFF**  HB and HS alarms must be supported. A Control Output Assignment or Auxiliary Output Assignment must be set to a heater alarm or heater burnout alarm.



- Set to use the heater burnout alarm.
- This parameter is displayed when a Control Output Assignment or an Auxiliary Output Assignment is set to a heater alarm or heater burnout alarm.



Setting range	Default
āN: Enabled, āFF: Disabled	āΝ



#### **Related Parameters**

Control Output 1 and 2 Assignment (Advanced Function Setting Level): Page 6-80 Auxiliary Output 1 to 4 Assignment (Advanced Function Setting Level): Page 6-80

## HL Heater Burnout Latch

HB and HS alarms must be supported.

The HB ON/OFF parameter must be set to ON.



- When this parameter is set to ON, the heater burnout alarm is held until either of the following conditions is satisfied.
  - a Heater burnout detection is set to 0.0 A.
  - b The power is cycled.
  - c The latch is cancelled by the PF Key.(PF Setting = LAT: Alarm Latch Cancel)
  - d The latch is cancelled by an event input.
     (Event Input Assignment 1 to Event Input Assignment 6 = LAT: Alarm Latch Cancel)
- Output is turned OFF when switching to the Initial Setting Level.



Setting range	Default
$\bar{a}N$ : Enabled, $\bar{a}FF$ : Disabled	ōFF



#### Related Parameters

Heater Burnout Detection 1 (Adjustment Level): Page 6-20 Event Input Assignment 1 to 4 (Initial Setting Level): Page 6-57 HB ON/OFF (Advanced Function Setting Level): Page 6-66 PF Setting (Advanced Function Setting Level): Page 6-86

# HbH Heater Burnout Hysteresis

HB and HS alarms must be supported. The HB ON/OFF parameter must be set to ON. The Heater Burnout Latch parameter must be set to OFF.



This parameter sets hysteresis for heater burnout detection.



Setting range	Unit	Default
0.1 to 50.0	Α	0.1



# Related Parameters

HB ON/OFF (Advanced Function Setting Level): Page 6-66

RLFR

Control must be set to 2-PID control. Either the Standard or Heating/Cooling parameter must be set to heating/cooling control or, if the Standard or Heating/Cooling parameter is set to standard control, adaptive control must be disabled.



- Normally, use the default for this parameter.
- This parameter sets the 2-PID control a constant.



Setting range	Default
0.00 to 1.00	0.65



#### Related Parameters

PID ON/OFF (Initial Setting Level): Page 6-43

FIGU

**Integral/Derivative Time Unit** 

Control must be set to 2-PID control.



This parameter sets the time unit for the Integral Time, Integral Time (Cooling), Derivative Time, and Derivative Time (Cooling) parameters.



Setting range	Unit	Default
1 to 0.1	Seconds	1

Note: The Integral/Derivative Time Unit parameter changes to 0.1 when the RT (robust tuning) parameter is changed from OFF to ON.



## Related Parameters

Integral Time and Derivative Time (Adjustment Level): Page 6-26 Derivative Time (Cooling) and Integral Time (Cooling) (Adjustment Level): Page 6-27 Rヒーロ AT Calculated Gain MASK8

Control must be set to 2-PID control.

RE-H AT Hysteresis MASK8

Limit Cycle MV Amplitude MASK8

The control must be standard control and 2-PID control.



- Normally use the default values for these parameters.
- The AT Calculated Gain parameter sets the gain for when PID constants are calculated using AT. When emphasizing response, decrease the set value. When emphasizing stability, increase the set value.
- The AT Hysteresis parameter sets the hysteresis for limit cycle operation during autotuning when switching ON and OFF.
- The Limit Cycle MV Amplitude parameter sets the MV amplitude for limit cycle operation during autotuning.



Parameter name	Setting range	Unit	Default
AT Calculated Gain	0.1 to 10.0		0.8
AT Hysteresis	Temperature	°C	0.8
	input: 0.1 to 999.9	°F	1.4
	Analog input: 0.01 to 9.99	%FS	0.20
Limit Cycle MV Amplitude	5.0 to 50.0	%	20.0




# Related Parameters

AT Execute/Cancel (Adjustment Level): Page 6-18

#### MAV **Moving Average Count**



 This parameter sets the number of inputs to include in the moving average. The data after moving average processing is illustrated in the following figure.



• Use a moving average to suppress rapid changes in the input.



Setting range	Unit	Default
OFF, 2, 4, 8, 16, or 32	Times	OFF*

The default is 8 for models other than the E5 $\square$ D- $\square$ -8 $\square$ .

#### REL **Automatic Display Return Time**



- In the Operation Level, Adjustment Level, or Monitor/Setting Item Level, the display automatically returns to the PV/SP if there are no key operations for the time set for this parameter.
- The automatic display return time is disabled when the parameter is set to OFF. (In that case, the display will not be automatically switched.)



Setting range	Unit	Default
OFF, 1 to 99	Seconds	ōFF

#### PLOF **Display Brightness**





This parameter sets the display brightness to one of three levels. Adjust the level if the display is too bright.



Setting range	Default
1 (dark) to 3 (bright)	3

A ILE	Alarm 1 Latch	Alarm 1 must be assigned, and the alarm 1 type must not be 0.
ASLF	Alarm 2 Latch	Alarm 2 must be assigned, and the alarm 2 type must not be 0 or 12.
R3LE	Alarm 3 Latch	Alarm 3 must be assigned, and the alarm 3 type must not be 0 or 12.
RYLE	Alarm 4 Latch	Alarm 4 must be assigned, and the alarm 4 type must not be 0 or 12.



- When this parameter is set to ON, the alarm function is held until one of the following conditions is satisfied.
  - a The power is cycled.
  - b The latch is cancelled by the PF Key. (PF Setting = LAT: Alarm Latch Cancel)
  - The latch is cancelled by an event input.
     (Event Input Assignment 1 to Event Input Assignment 4 = LAT: Alarm Latch Cancel)
- The output is turned OFF when switching to the Initial Setting Level, Communications Setting Level, Advanced Function Setting Level, or Calibration Level.
- If an auxiliary output is set to close in alarm, the output is kept closed. If it is set to open in alarm, it is kept open.
- If an alarm OFF delay is set, the alarm latch will not be canceled immediately even if condition b or c is met. It will be canceled after the time set for the OFF delay has expired.



Setting range	Default
$\bar{a}N$ : Enabled, $\bar{a}FF$ : Disabled	ōFF



#### Related Parameters

Alarm Value 1 to 4 (Operation Level): Page 6-13

Alarm Value Upper Limit 1 to 4 and Alarm Value Lower Limit 1 to 4 (Operation Level): Page 6-14

Alarm 1 to 4 Type (Initial Setting Level): Page 6-50

Standby Sequence Reset (Advanced Function Setting Level): Page 6-65

Event Input Assignment 1 to 4 (Initial Setting Level): Page 6-57

Auxiliary Output 1 to 4 Open in Alarm (Initial Setting Level): Page 6-66

Alarm 1 to 4 Hysteresis (Initial Setting Level): Page 6-54 HB ON/OFF (Advanced Function Setting Level): Page 6-66 PF Setting (Advanced Function Setting Level): Page 6-86

#### PRLE **Move to Protect Level Time**



• This parameter sets the key pressing time required to move to the Protect Level from the Operation Level, the Adjustment Level, or Monitor/Setting Item Level.



Setting range	Unit	Default
1 to 30	Seconds	3

## ЕЛЕ

**Cold Junction Compensation** Method

Input type must be thermocouple or infrared temperature sensor



- This parameter specifies whether cold junction compensation is to be performed internally by the Digital Controller or to be performed externally when the input type setting is 5 to 24.
- The cold junction compensation external setting is enabled when the temperature difference is measured using two thermocouples or two ES1B Sensors.



Setting range	Default
āN: Internally, āFF: Externally	ōΝ



#### Related Parameters

Input Type (Initial Setting Level): Page 6-41

A IōN	Alarm 1 ON Delay	Alarm 1 must be assigned, and the alarm 1 type must not be 0, 12, or 13.
A59N	Alarm 2 ON Delay	Alarm 2 must be assigned, and the alarm 2 type must not be 0, 12, or 13.
Rāēn	Alarm 3 ON Delay	Alarm 3 must be assigned, and the alarm 3 type must not be 0, 12, or 13.
AYōN	Alarm 4 ON Delay	Alarm 4 must be assigned, and the alarm 4 type must not be 0, 12, or 13.

The alarm 1, 2, 3, or 4 output is prevented from turning ON until after the delay times set in these parameters have elapsed.



- Set the time for which the ON delay is to be enabled.
- To disable the ON delay, set 0.



Setting range	Unit	Default
0 to 999	Seconds	0



## Related Parameters

Alarm 1 to 4 Type (Initial Setting Level): Page 6-50

A lõF	Alarm 1 OFF Delay	Alarm 1 must be assigned, and the alarm 1 type must not be 0, 12, or 13.
R2ōF	Alarm 2 OFF Delay	Alarm 2 must be assigned, and the alarm 2 type must not be 0, 12, or 13.
R3ōF	Alarm 3 OFF Delay	Alarm 3 must be assigned, and the alarm 3 type must not be 0, 12, or 13.
ЯЧāF	Alarm 4 OFF Delay	Alarm 4 must be assigned, and the alarm 4 type must not be 0, 12, or 13.

The alarm 1, 2, 3, or 4 output is prevented from turning OFF until after the delay times set in these parameters have elapsed.



- Set the time for which the OFF delay is to be enabled.
- To disable the OFF delay, set 0.



Setting range	Unit	Default
0 to 999	Seconds	0



#### Related Parameters

Alarm 1 to 4 Type (Initial Setting Level): Page 6-50

MRNE	Manual Output Method	The control must be set to 2-PID control.
	aa oaspasooa	



If this parameter is set to HOLD when control moves from Automatic Mode to Manual Mode, the final MV from Automatic Mode will be used as the initial manual MV. If this parameter is set to INT, the setting of the Manual MV Initial Value parameter will be used as the initial manual MV.



Setting range	Default
HāLd: HOLD, ĒNĒE: INIT	HōLd



#### Related Parameters

Manual MV Initial Value (Advanced Function Setting Level): 6-75

# MRNE

**Manual MV Initial Value** 

The control must be set to 2-PID control.



This parameter sets the initial value of the manual MV to use after control moves from Automatic Mode to Manual Mode.



Setting range	Unit	Default
Standard control: -5.0 to 105.0	%	0.0
Heating/cooling control: -105.0 to 105.0		

If the Manual MV Limit Enable parameter is set to ON, the setting range will be the MV lower limit to the MV upper limit.



#### Related Parameters

Manual Output Method (Advanced Function Setting Level): Page 6-74 Manual MV Limit Enable (Advanced Function Setting Level): Page 6-84 RŁ RT The control must be set to 2-PID control. The input type must be set for a temperature input. The Adaptive Control parameter must be set to "Disabled." Either the Standard or Heating/Cooling parameter must be set to standard control or, if the Standard or Heating/Cooling parameter is set to heating/cooling control, the Heating/Cooling Tuning Method parameter must not be set to air or

MASK8

This parameter executes robust tuning (RT).



. When AT is executed with RT selected, PID constants are automatically set that make it hard for control performance to deteriorate even when the characteristics of the controlled object are changed.

water cooling.

• Even when hunting occurs for PID constants when AT is executed in normal mode, it is less likely to occur when AT is executed in RT Mode.



Setting range	Default
āN: RT function ON, āFF: RT function OFF	ōFF

Note: The Integral/Derivative Time Unit parameter changes to 0.1 when the RT (Robust Tuning) parameter is changed from OFF to ON.



### Related Parameters

AT Execute/Cancel (Adjustment Level): Page 6-18

Proportional Band, Integral Time, and Derivative Time (Adjustment Level): Page 6-26 Proportional Band (Cooling), Derivative Time (Cooling), and Integral Time (Cooling) (Adjustment Level): Page 6-27

PID ON/OFF (Initial Setting Level): Page 6-43

Integral/Derivative Time Unit (Advanced Function Setting Level): Page 6-68

H5U **HS Alarm Use**  HB and HS alarms must be supported. A Control Output Assignment or Auxiliary Output Assignment must be set to a heater alarm or HS alarm.



- Set this parameter to use HS alarms.
- This parameter is displayed when a Control Output Assignment or Auxiliary Output Assignment is set to a heater alarm or HS alarm.



Setting range	Default
$\bar{a}N$ : Enabled, $\bar{a}FF$ : Disabled	āΝ



#### **Related Parameters**

Control Output 1 and 2 Assignment (Advanced Function Setting Level): Page 6-80 Auxiliary Output 1 to 4 Assignment (Advanced Function Setting Level): Page 6-81

# HS Alarm Latch

HB and HS alarms must be supported.

The HS Alarm Use parameter must be set to ON.



- When this parameter is set to ON, the HS alarm is held until any of the following conditions is satisfied.
  - a The HS alarm current is set to 50.0 A.
  - b The power is cycled.
  - c The latch is cancelled by the PF Key.(PF Setting = LAT: Alarm Latch Cancel)
  - d The latch is cancelled by an event input.
     (Event Input Assignment 1 to Event Input Assignment 4 = LAT: Alarm Latch Cancel)
- Output is turned OFF when switching to the Initial Setting Level, Communications Setting Level, Advanced Function Setting Level, or Calibration Level.



Setting range	Default
āN: Enabled, āFF: Disabled	ōFF



#### Related Parameters

HS Alarm Use (Advanced Function Setting Level): Page 6-76 Event Input Assignment 1 to 4 (Initial Setting Level): Page 6-57 HB ON/OFF (Advanced Function Setting Level): Page 6-66 PF Setting (Advanced Function Setting Level): Page 6-86

HSH

**HS Alarm Hysteresis** 

HB and HS alarms must be supported.

The HS Alarm Use parameter must be set to ON.

The HS Alarm Latch parameter must be set to OFF.



• This parameter sets the hysteresis for HS alarms.



Setting range	Unit	Default
0.1 to 50.0	Α	0.1



# Related Parameters

HS Alarm Use (Advanced Function Setting Level): Page 6-76

LBR **LBA Detection Time**  Alarm 1 must be assigned. The alarm type must be set to 12 (LBA).

This parameter enables or disables the LBA function and sets the detection time interval.



• To disable the LBA function, set 0.



Setting range	Unit	Default
0 to 9999	Seconds	0



### Related Parameters

Alarm 1 to 4 Type (Initial Setting Level): Page 6-50 LBA Level (Advanced Function Setting Level): Page 6-78 LBA Band (Advanced Function Setting Level): Page 6-79

LBAL **LBA** Level

Alarm 1 must be assigned. The alarm type must be set to 12 (LBA). The LBA detection time must not be 0.



- This parameter sets the LBA level.
- If the deviation between the SP and PV exceeds the LBA level, a loop burnout is detected.



Setting	g range	Unit	Default
Temperature input	0.1 to 999.9	°C	8.0
		°F	14.4
Analog input	0.01 to 99.99	%FS	10.00



### Related Parameters

Process Value/Set Point (Operation Level): Page 6-8 Alarm 1 to 4 Type (Initial Setting Level): Page 6-50

LBA Detection Time (Advanced Function Setting Level): Page 6-78

LBA Band (Advanced Function Setting Level): Page 6-79

LBA Band

Alarm 1 must be assigned.
The alarm type must be set to 12 (LBA).
The LBA detection time must not be 0.



- This parameter sets the LBA band.
- If a control deviation greater than the LBA band is not reduced when the LBA level is exceeded, an loop burnout is detected.



Setting	ı range	Unit	Default
Temperature input	0.0 to 999.9	°C	3.0
		°F	5.4
Analog input	0.00 to 99.99	%FS	0.20



### Related Parameters

Process Value/Set Point (Operation Level): Page 6-8 Alarm 1 to 4 Type (Initial Setting Level): Page 6-50

LBA Detection Time (Advanced Function Setting Level): Page 6-78

LBA Level (Advanced Function Setting Level): Page 6-78

#### āUŁ I **Control Output 1 Assignment**

#### ant5 **Control Output 2 Assignment**

A Standard Model with two control outputs must be used.



• These parameters set the function to assign to control outputs 1 and 2.



	Setting range	Default
NāNE:	Disabled	Control Output 1 Assignment: ā
ō:	Control output (heating)	Control Output 2 Assignment: NaNE*4
[ -ō:	Control output (cooling)*1	
ALM I:	Alarm 1 <sup>*5</sup>	
ALM2:	Alarm 2 <sup>*5</sup>	
ALM3:	Alarm 3 <sup>*5</sup>	
ALMY:	Alarm 4 <sup>*5</sup>	
НЯ:	Heater alarm <sup>*5</sup>	
НЬ:	HB alarm <sup>*5</sup>	
H5:	HS alarm <sup>*5</sup>	
S.ERR:	Input error <sup>*5</sup>	
NāNE:	Disabled <sup>*5</sup>	
P.ENd:	Program end output*2*5	
RUN:	RUN output <sup>*5</sup>	
ALM:	Integrated Alarm <sup>*5</sup>	
WR I:	Work bit 1 <sup>*3*5</sup>	
WR2:	Work bit 2 <sup>*3*5</sup>	
W₽∃:	Work bit 3 <sup>*3*5</sup>	
W₽4:	Work bit 4*3*5	
WRS:	Work bit 5*3*5	
WR5:	Work bit 6 <sup>*3*5</sup>	
WP7:	Work bit 7 <sup>*3*5</sup>	
WRB:	Work bit 8 <sup>*3*5</sup>	

<sup>\*1</sup> If  $\mathcal{L}$  -  $\bar{a}$  is assigned for standard control, a value equivalent to 0% is output.

<sup>\*2</sup> Can be selected when the Program Pattern parameter is set to OFF, but the function will be

<sup>\*3</sup> WR1 to WR8 are not displayed when the logic operation function is not used.

<sup>\*4</sup> If the Standard or Heating/Cooling parameter is set to heating/cooling control, control automatically switches to  $\mathcal{L} - \bar{a}$ .

<sup>\*5</sup> Can be selected for relay and voltage outputs (for driving SSR) only.

5Ub 1	Auxiliary Output 1 Assignment	There must be an auxiliary output 1.
5Ub2	Auxiliary Output 2 Assignment	There must be an auxiliary output 2.
5Ub3	Auxiliary Output 3 Assignment	There must be an auxiliary output 3.
5U64	Auxiliary Output 4 Assignment	There must be an auxiliary output 4.

• These parameters set the function to assign to auxiliary outputs 1 to 4.

	Setting range	Default
NāNE:	Disabled	Auxiliary Output 1 Assignment: FLM I*5
<u>ā:</u>	Control output (heating)	Auxiliary Output 2 Assignment: #LM2*2
Ε-ā:	Control output (cooling)*1	Auxiliary Output 3 Assignment: ₹LM∃
ALM I:	Alarm 1	Auxiliary Output 4 Assignment: #L MY*2
ALM2:	Alarm 2	
RLM3:	Alarm 3	
ALMY:	Alarm 4	
HR:	Heater alarm	
НЬ:	HB alarm	
H5:	HS alarm	
S.ERR:	Input error	
NāNE:	Disabled	
P.ENd:	Program end output*3	
RUN:	RUN output	
ALM:	Integrated Alarm	
WR I:	Work bit 1 <sup>*4</sup>	
WRZ:	Work bit 2 <sup>*4</sup>	
WR∃:	Work bit 3 <sup>*4</sup>	
WRY:	Work bit 4 <sup>*4</sup>	
WR5:	Work bit 5 <sup>*4</sup>	
WR5:	Work bit 6 <sup>*4</sup>	
WR7:	Work bit 7 <sup>*4</sup>	
WR8:	Work bit 8 <sup>*4</sup>	

- \*1 If  $\mathcal{L} \bar{a}$  is assigned for standard control, a value equivalent to 0% will be output.
- \*2 · When heating/cooling control is selected for the E5CD or E5CD-B, auxiliary output 2 is assigned as the control output for cooling.
  - · If heating/cooling control is selected for the E5ED or E5ED-B when there is only one control output, the auxiliary output 4 terminal is assigned as the control output for cooling. (However, if the Digital Controller has two auxiliary outputs, auxiliary output 2 is the cooling control output.)
- \*3 Can be selected when the Program Pattern parameter is set to OFF, but the function will be disabled.
- \*4 WR1 to WR8 are not displayed when the logic operation function is not used.
- \*5 If the Digital Controller is equipped with HB/HS alarm detection, it is set by default to HR (Heater Alarm).

## ALMA

**Integrated Alarm Assignment** 

The integrated alarm must be assigned.



You can use the integrated alarm to output an OR of alarm 1, alarm 2, alarm 3, alarm 4, the HB alarm, the HS alarm, and the input alarm. Set this parameter to the sum of the codes of the status for which to output an OR.

The default is 49 (i.e., an OR of alarm 1, the HB alarm, and the HS alarm is output). The alarm 1 code is 1, the HB alarm code is 16, and the HS alarm code is 32: 1 + 16 + 32 = 49.



Code	Status
+1	Alarm 1
+2	Alarm 2
+4	Alarm 3
+8	Alarm 4
+16	HB alarm
+32	HS alarm
+64	Input error
+128	(Spare)

Setting range	Default
0 to 255	49



### Related Parameters

Alarm Value 1 to 4 (Operation Level): Page 6-13

MV at Error (Adjustment Level): Page 6-33

HB ON/OFF (Advanced Function Setting Level): Page 6-66 HS Alarm Use (Advanced Function Setting Level): Page 6-76

# **L** − **U** Soak Time Unit

The Program Pattern parameter must not be set to OFF.



Set the soak time unit for the simple program function.



Setting range	Default
s: Seconds, m: Minutes, h: Hours	М



#### Related Parameters

Program Start (Operation Level): Page 6-11 Soak Time Remain (Operation Level): Page 6-12

Soak Time (Adjustment Level): Page 6-32 Wait Band (Adjustment Level): Page 6-32

Program Pattern (Initial Setting Level): Page 6-48

# RL 5P Alarm SP Selection

Alarm 1 to alarm 4 must be assigned.

The SP Ramp Set Value parameter must not be set to OFF and the SP Ramp Fall Value parameter must not be set to SAME or OFF.

The alarm type must be set to 1, 2, 3, 4, 5, 6, 7, 14, or 15.

This parameter sets whether the set point that triggers the alarm is the ramp SP or target SP.



Setting range	Default
5 <i>P</i> - M: Ramp SP, 5 <i>P</i> : SP	5P-M



#### Related Parameters

SP Ramp Set Value and SP Ramp Fall Value (Adjustment Level): Page 6-34

## MRNL

**Manual MV Limit Enable** 

The control must be set to 2-PID control.





This parameter sets whether the MV Upper Limit and MV Lower Limit parameters are to be enabled for manual MV in Manual Mode.



Setting range	Default
$\bar{a}N$ : Enabled, $\bar{a}FF$ : Disabled	ōFF



#### Related Parameters

MV Upper Limit (Adjustment Level): Page 6-34 MV Lower Limit (Adjustment Level): Page 6-34

## Pl'RP

**PV Rate of Change Calculation Period** 

Alarms 1, 2, 3, and 4 must be assigned. The alarm type must be set to 13.



- The change width can be found for PV input values in any set period. Differences with previous values in each set period are calculated, and an alarm is output if the results exceed the alarm value.
- The PV rate of change calculation period can be set in units of 50 ms (sampling period).



Setting range	Unit	Default
1 to 999	Sampling periods	20 (1 s)



#### Related Parameters

Process Value/Set Point (Operation Level): Page 6-8 Alarm 1 to 4 Type (Initial Setting Level): Page 6-50

# HEFW

**Heating/Cooling Tuning Method** 

The control must be set to heating/cooling control and 2-PID control.



This parameter sets the tuning method that is suitable for the cooling control characteristics.




Setting range	Default
0: Same as heating control	
1: Linear	
2: Air cooling	0
3: Water cooling	

## • Air Cooling/Water Cooling

Control that is suitable for an application that does not have linear cooling characteristics (such as plastic molding machines) is performed. The response is fast and the response characteristics are stable.

Linear

Control that is suitable for an application that has linear cooling characteristics is performed.



# **a**MPW

**Minimum Output ON/OFF Band** 

The control must be set to 2-PID control.



This parameter sets the minimum ON/OFF width of the outputs that are assigned for the heating and cooling control outputs. You can set this parameter to prevent deterioration of a relay output.



Setting range	Unit	Default
0.0 to 50.0	%	1.0

#### PF **PF Setting**



• This parameter sets the function of the PF Key.



• The default is SHFT (Digit Shift).

Set value	Setting	Function
OFF: ōFF	Disabled	Does not operate as a function key.
RUN: PUN	RUN	Specifies RUN status.
STOP: 5Ł6P	STOP	Specifies STOP status.
R-S: <i>R-5</i>	Reversing RUN/STOP opera- tion	Specifies reversing RUN/STOP operation status.
AT-2: ∄Ł - ᢓ	100%AT Execute/Cancel	Specifies reversing 100% AT Execute/Cancel status. *1
AT-1: #E - 1	40%AT Execute/Cancel	Specifies reversing 40% AT Execute/Cancel status. *1 *4
LAT: LAL	Alarm Latch Cancel	Specifies canceling alarm latches. *2
A-M: Я-М	Auto/Manual	Specifies reversing Auto/Manual status. *3 *5
PFDP:PFdP	Monitor/Setting Item	Specifies the monitor/setting item display. Select the monitor/setting item using the Monitor/Setting Item 1 to 5 parameters (Advanced Function Setting Level).
SHFT: 5HFE	Digit Shift	Operates as a Digit Shift Key when settings are being changed.
A-UD: 뭐-Ud	PID Update	The PID is updated when PID constants that can be
	(Adaptive Control)	updated are calculated for adaptive control.
FA: <i>FR</i>	Automatic Filter	Specifies reversing between performing and stopping
	Adjustment	operation after automatic filter adjustment.
W-HT: ฝ <i>-H</i> Ł	Water-cooling Output	Specifies reversing between performing and stopping
	Adjustment	water-cooling output adjustment.

- \*1 When AT cancel is specified, it means that AT is cancelled regardless of whether the AT currently being executed is 100% AT or 40% AT.
- \*2 Alarms 1 to 4, the HB alarm, and the HS alarm are cancelled.
- \*3 For details on auto/manual operations using the PF Key, refer to 5-16 Performing Manual
- \*4 This setting is disabled for heating/cooling control.
- \*5 The function that is set for the PF Key is disabled if the same function is assigned to an event input.



#### Related Parameters

Monitor/Setting Item 1 to 5 (Advanced Function Setting Level): Page 6-87

PFd / Monitor/Setting Item 1

PFd2 Monitor/Setting Item 2

PFd3 Monitor/Setting Item 3 The PF Setting parameter must be set to PFDP.

PFd4 Monitor/Setting Item 4

PFd5 Monitor/Setting Item 5





- When the PF Key is set to display monitor/setting items, pressing the PF Key will display
  in order the contents of the Monitor/Setting Item 1 to 5 parameters. The contents of these
  parameters are shown in the following table. Refer to the relevant parameters for the
  setting/monitor ranges.
- The default value for the Monitor/Setting Item Display 1 parameter is 1.

  The default value for the Monitor/Setting Item Display 2 to 5 parameters is 0.

Set	Remarks		rks
value	Setting*2	Monitor/Setting	Display
0	Disabled		
1	PV/SP/Multi-SP No.	Can be set. (SP)*1	
2	PV/SP/MV (Heating)	Can be set. (SP)*1	
3	PV/SP/Soak time remain	Can be set. (SP)*1	
4	Proportional band	Can be set.	Р
5	Integral time	Can be set.	Ī.
6	Derivative time	Can be set.	d
7	Alarm value 1	Can be set.	AL - I
8	Alarm value upper limit 1	Can be set.	AL IH
9	Alarm value lower limit 1	Can be set.	AL IL
10	Alarm value 2	Can be set.	RL - 2
11	Alarm value upper limit 2	Can be set.	RL2H
12	Alarm value lower limit 2	Can be set.	AL 2L
13	Alarm value 3	Can be set.	AL - 3
14	Alarm value upper limit 3	Can be set.	RL 3H
15	Alarm value lower limit 3	Can be set.	AL 3L
16	Alarm value 4	Can be set.	AL-4
17	Alarm value upper limit 4	Can be set.	RL YH
18	Alarm value lower limit 4	Can be set.	AL YL
19	PV/SP/Internal SP	Can be set. (SP)*1	
20	PV/SP/Alarm Value 1	Can be set. (SP)*1	
21	Proportional Band (Cooling)	Can be set.	[-P
22	Integral Time (Cooling)	Can be set.	[- <u>-</u>
23	Derivative Time (Cooling)	Can be set.	[-d
24	PV/SP/MV (Cooling)	Can be set. (SP)*1	

<sup>\*1</sup> With the E5CD or E5CD-B, only the PV and SP can be displayed.

<sup>\*2</sup> If the display condition is not met for even one of the set parameters, the monitor/setting item display will not appear.

SPd I PV/SP No. 1 Display Selection

5Pd2 PV/SP No. 2 Display Selection



These parameters set the items to display on the No. 1 display, No. 2 display, and No. 3 dis-



Set value	No. 1 display	No. 2 display	No. 3 display (E5ED or E5ED-B only)
0	Nothing is displayed.	Nothing is displayed.	Nothing is displayed.
1	Process value	Set point	Nothing is displayed.
2	Process value	Nothing is displayed.	Nothing is displayed.
3	Set point	SP (character display)	Nothing is displayed.
4	Process value	Set point	MV (heating)
5	Process value	Set point	Multi-SP No.*
6	Process value	Set point	Soak time remain *
7	Process value	Set point	Internal set point (ramp SP)
8	Process value	Set point	Alarm value 1*
9	Process value	Set point	MV (cooling)*

Nothing is displayed on the No. 1, 2, and 3 displays if the display conditions are not met.

Parameter	Setting range	Default
PV/SP No. 1 Display Selection	0 to 9	4*
PV/SP No. 2 Display Selection	0 10 9	0

The default value for the E5 $\square$ D- $\square$ -8 $\square$  is 0.

# PV 5L PV Status Display Function



- This parameter sets a control or alarm status that is displayed alternately in 0.5-s cycles on the No. 1 display when the PV is set to be displayed in the No. 1 display.\*1
- PV
- PV/SP\*2
- PV/Manual MV
- PV/SP/Manual MV
- \*1 This includes the displays specified with the PV/SP No. 1 and PV/SP No. 2 Display Selection parameters.
- \*2 This includes when the PV/SP is selected for the Monitor/Setting Item parameter.



	Setting range	Default
ōFF:	No PV status display	ōFF
MANU:	MANU is alternately displayed during manual control.	
SŁōP:	STOP is alternately displayed while operation is stopped.	
ALM I:	ALM1 is alternately displayed during Alarm 1 status.	
ALM2:	ALM2 is alternately displayed during Alarm 2 status.	
RLM3:	ALM3 is alternately displayed during Alarm 3 status.	
ALMY:	ALM4 is alternately displayed during Alarm 4 status.	
ALM:	ALM is alternately displayed when Alarm 1, 2, 3, or 4 is set to ON.	
HA:	HA is alternately displayed when an HB alarm or HS alarm is ON.	



### Related Parameters

Process Value/Set Point (Operation Level): Page 6-8 PV/MV (Manual MV) (Manual Control Level): Page 6-39

#### 51/5E **SV Status Display Function**



- This parameter sets a control or alarm status that is displayed alternately in 0.5-s cycles on the No. 2 display when the PV is set to be displayed in the No. 1 display.\*1
- PV
- PV/SP\*2
- PV/Manual MV
- PV/SP/Manual MV
- This includes the displays specified with the PV/SP No. 1 and PV/SP No. 2 Display Selection parameters.
- \*2 This includes when the PV/SP is selected for the Monitor/Setting Item parameter.



	Setting range	Default
ōFF:	No SV status display	ōFF
MANU:	MANU is alternately displayed during manual control.	
SE GP:	STOP is alternately displayed while operation is stopped.	
ALM I:	ALM1 is alternately displayed during Alarm 1 status.	
ALM2:	ALM2 is alternately displayed during Alarm 2 status.	
ALM3:	ALM3 is alternately displayed during Alarm 3 status.	
ALMY:	ALM4 is alternately displayed during Alarm 4 status.	
ALM:	ALM is alternately displayed when Alarm 1, 2, 3, or 4 is set to ON.	
HA:	HA is alternately displayed when an HB alarm or HS alarm is ON.	



#### Related Parameters

Process Value/Set Point (Operation Level): Page 6-8 PV/MV (Manual MV) (Manual Control Level): Page 6-39

#### d.REF **Display Refresh Period**



- This parameter delays the display refresh period for monitor values. Only display refreshing is delayed, and the refresh period for process values used in control is not changed.
- This function is disabled by setting the parameter to OFF. If this function is disabled, the display refresh period will be the same as the sampling period, 50 ms.



Setting range	Unit	Default
OFF, 0.25, 0.5, 1.0	Seconds	0.25

### LEME

LCT Cooling Output Minimum ON Time

The control output on the cooling side must be a relay or voltage output.

Heating/cooling control must be used, 2-PID control must be used, and the Heating/Cooling Tuning Method parameter must be set to air or water cooling.



- This parameters sets the minimum output ON time for the cooling-side control output during autotuning.
- Set the time in seconds that is required for the operation of the actuator that is connected to the cooling-side control.

Example: The following calculation is used when the configuration consists of the E5DD (with a relay output), a relay, and a solenoid valve.

 $(0.02 \text{ s (fixed)} + 0.02 \text{ s} + 0.06 \text{ s}) \times 2 \text{ (safety factor)} = 0.2 \text{ s}$ 

\* The default setting of this parameter is based on the operating time of an actuator on a standard extruder.



Setting range	Unit	Default
0.1 to 1.0	Seconds	0.2

### R-dV

Adaptive Control Operation Possible Deviation

The control must be standard control and 2-PID control.


The input type must be set for a temperature input. The Adaptive Control parameter must not be set to "Disabled."

This parameter gives the possible deviation between the process value (PV) and set point (SP) for adaptive control.



If the PV at the start of adaptive control is beyond this deviation, evaluation of the adaptive control system performance operates.

To ensure the performance of adaptive control, do not set a value less than 50%.





Setting range	Unit	Default
0.0 to 100.0	%	50.0
	0°C (32°F) to Set point = 100%	

### Related Parameters



Adaptive Control (Initial Setting Level): Page 6-45

### R-5d

**System Fluctuation Reference** Deviation

The control must be standard control and 2-PID

The input type must be set for a temperature input. The Adaptive Control parameter must not be set to "Disabled."



- When the Adaptive Control parameter is set to "Notification," the value set for this parameter is used to determine when to provide notification.
- · If the rate of change in the proportional band that is calculated for system performance evaluation exceeds this reference value, the A indicator lights to provide notification of a temperature variation in the system.



Setting range	Unit	Default
0.0 to 100.0	%	15.0



### **Related Parameters**

Adaptive Control (Initial Setting Level): Page 6-45

### FR5P

**Automatic Filter Adjustment Seal Period** 

The control must be standard control and 2-PID control.

The parameter gives the seal period of the automatic filter adjustment.



- This is the period of small temperature variations (up to several seconds) that occur in
- Normally, use the default for this parameter.



Setting range	Unit	Default
0.1 to 10.0	Seconds	2.0



### Related Parameters

Automatic Filter Adjustment (Adjustment Level): Page 6-23

FRHP

Automatic Filter Adjustment Hunting Monitor Period

The control must be standard control and 2-PID control.

This parameter gives the hunting monitor period of automatic filter adjustment.



- This is the period of large temperature variations (several tens of seconds or longer) when packaging.
- Normally, use the default for this parameter.



Setting range	Unit	Default
10 to 1999	Seconds	200



### Related Parameters

Automatic Filter Adjustment (Adjustment Level): Page 6-23

W-IE

Water-cooling Proportional Band Increase Constant

The control must be set to heating/cooling control and 2-PID control.

The input type must be set for a temperature input. The Heating/Cooling Tuning Method must be set to "Water cooling."

This parameter is used for water-cooling output adjustment.



- This parameter gives the increase constant when the value of the cooling proportional band is adjusted to reduce hunting. This function works to suppress an excessive cooling output that may cause hunting when the cooling proportional band is increased
- Normally, use the default for this parameter.



Setting range	Default
1.00 to 10.00	1.70



### Related Parameters

Water-cooling Output Adjustment (Adjustment Level): Page 6-25

### M-4E

### **Water-cooling Proportional Band Decrease Constant**

The control must be set to heating/cooling control and 2-PID control.

The input type must be set for a temperature input. The Heating/Cooling Tuning Method must be set to "Water cooling."

This parameter is used for water-cooling output adjustment.



- This parameter gives the decrease constant when the value of the cooling proportional band is adjusted to optimize disturbance response.
  - This function works to increase an insufficient cooling output that may reduce disturbance response when the cooling proportional band is decreased.
- · Normally, use the default for this parameter.



Setting range	Default
0.10 to 0.99	0.90



### Related Parameters



Water-cooling Output Adjustment (Adjustment Level): Page 6-25

#### PWEM **Power ON Time Monitor**



- This parameter gives the total time that the power supply has been ON.
- You cannot initialize the power ON time data.



Monitor range	Unit	Default
0 to 9999	10 hours	0

#### Rbem **Ambient Temperature Monitor**



The parameter monitors the ambient temperature around the Digital Controller terminals.

This temperature is for reference only.



Monitor range	Unit
-30 to 75	°C
10 to 171	°F

## RR IM RR2M

**Control Output 1 ON/OFF Count** Monitor **Control Output 2 ON/OFF Count** 

Control outputs 1 and 2 must be supported. Relay or voltage outputs (for driving SSR) must be used.



- These parameters monitor the number of times that control outputs 1 and 2 are turned ON and OFF.
- These parameters are not initialized for the Parameter Initialization parameter. To initialize them, reset (initialize) them with the ON/OFF Counter Reset parameter.



Monitor range	Unit	Default
0 to 9999	100 times	0



### Related Parameters

Monitor

ON/OFF Counter Reset (Advanced Function Setting Level): Page 6-95

#### RRL **ON/OFF Counter Reset**

Control outputs 1 and 2 must be supported. Relay or voltage outputs (for driving SSR) must be used.



This parameter resets the ON/OFF counter for specified control outputs.



Setting range		Default
0:	Resetting is disabled.	0
1:	Control Output 1 ON/OFF Count Monitor parameter is reset.	
2:	Control Output 2 ON/OFF Count Monitor parameter is reset.	



### **Related Parameters**

Control Output 1 ON/OFF Count Monitor (Advanced Function Setting Level): Page 6-95 Control Output 2 ON/OFF Count Monitor (Advanced Function Setting Level): Page 6-95

#### PM5E **Parameter Mask Setting**



- You can use a key operation to hide parameters that do not need to be displayed.
- · This allows you to prevent incorrect operations for parameters or to change the parameter display configuration according to the application.



If you set the Parameter Mask Setting parameter to ON, Parameter Mask Mode is entered. Refer to 5-12-1 Parameter Mask Setting for information on masking parameters after you enter Parameter Mask Mode.

# Operation

### Related Parameters



Parameter Mask Enable (Protect Level): Page 6-6

EMar

Move to Calibration Level

Initial setting/communications protect must MASK8



This parameter sets the password to move to the Calibration Level.



- Set the password to move to the Calibration Level. The password is 1201.
- Move to the Calibration Level either by pressing the <sup>(2)</sup> Key or <sup>(2)</sup> Key or by waiting for two seconds to elapse.



### Related Parameter

Initial Setting/Communications Protect (Protect Level): Page 6-4

# 6-9 Communications Setting Level

P5EL	Protocol Setting	Communications must be supported.
U-Nā	Communications Unit No.	
<i> bP</i> 5	Communications Baud Rate	
LEN	Communications Data Length	CompoWay/F must be selected as the protocol.
SbīŁ	Communications Stop Bits	CompoWay/F must be selected as the protocol.
PRLY	Communications Parity	CompoWay/F or Modbus must be selected as the protocol.
SAWE	Send Data Wait Time	protocoi.
RAMM	Write Mode	
	Highest Communications Unit	
MAXU	No.	FINS, MCP4, or FXP4 must be selected as the protocol.
RRER	Area	FINS, MCP4, or FXP4 must be selected as the protocol.
RdRH	First Address Upper Word	FINS, MCP4, or FXP4 must be selected as the protocol.
RdRL	First Address Lower Word	FINS, MCP4, or FXP4 must be selected as the protocol.
RUAL	Receive Data Wait Time	FINS, MCP4, or FXP4 must be selected as the protocol.
UNIE	Communications Node Number	FINS, MCP4, or FXP4 must be selected as the protocol.
UP∗	Upload Setting * (* = 1 to 13)	FINS, MCP4, Modbus, or FXP4 must be selected as the protocol.
dNP∗	Download Setting * (* = 1 to 13)	FINS, MCP4, Modbus, or FXP4 must be selected as the protocol.
СаРУ	Copying Parameter Settings	FINS, MCP4, or FXP4 must be selected as the protocol and the communications unit number must be set to 0.



- Each parameter is enabled when the power is reset.
- Match the communications specifications of the E5□D and the host computer. If multiple devices are connected, ensure that the communications specifications for all devices in the system (except the Communications unit number) are the same.
- Parameters in the Communications Level are displayed only for models that support communications. Refer to the E5 ID Digital Controllers Communications Manual (Cat. No. H225) for details.



Item	Display	Set values	Settings	Default
Protocol setting	PSEL	EWF	CompoWay/F	EWF
		Mod	Modbus	
		NāNE	Disabled	
		FIN5	Component communications	
		MEPY	Host Link (FINS)	
		FXPY	MC Protocol (format 4)	
			Dedicated protocol (format 4)	
Communications	U-Nā	0 to 99	0 to 99	1
Unit No.				
Communications	<i>6P5</i>	9.6/19.2/38.4/57.6/	9.6/19.2/38. 4/57.6/115.2	9.6
baud rate		115.2 (Kbps)	(kbps)	
Communications	LEN	7 or 8 bits	7 or 8 bits	7
data length				
Stop bits	56īt	1 or 2 bits	1 or 2 bits	2
Communications	PRES	Nane even add	None, Even, Odd	EVEN
parity				
Send data wait	SdWE	0 to 99	0 to 99 (ms)	20
time				
Write Mode	RAMM	ЬКИР	Backup Mode	ЫКИР
		RAM	RAM Write Mode	

Writing with communications is enabled if you set the Protocol Setting parameter to Host Link (FINS), MC protocol (format 4), or dedicated protocol (format 4).



### Related Parameter

Communications Writing (Adjustment Level): Page 6-19

If the Protocol Setting parameter is set to one of the following settings, the setting parameters for programless communications are displayed. Refer to the E5 D Digital Controllers Communications Manual (Cat. No. H225) for details.

Protocol Setting = Host Link (FINS), MC Protocol (Format 4), or Dedicated Protocol (Format 4))

Parameter	Parameter display	Display	Settings	Default
Highest Communications	MRXU	🛮 to 99	0 to 99	0
Unit No.				
Area	RRER	0 to 25	0 to 25	0
First Address Upper Word	AGRH	🛮 to 99	0 to 99	0
First Address Lower Word	RdRL	🛮 to 9999	0 to 9999	0
Receive Data Wait Time	RWRE	100 to 9999	100 to 9999 ms	1000
Communications Node	UNIE	🛮 to 99	0 to 99	0
Number				
Upload Settings 1 to 13*	<i>ЦР</i> Д / to /3	🛮 to 🖽	0 to 108	
Download Settings 1 to 13	dN0   to  3	30 to 108	30 to 108	
Сору	CaPy	āFF, ALL, I to 199		OFF

You cannot use Upload Setting 13 parameter if you set the dedicated protocol (format 4).
If the Protocol Setting parameter is set to Modbus, only the above Upload Settings 1 to 13 and Download Settings 1 to 13 are displayed.



# **User Calibration**

7-1	User Calibration	7-2
7-2	Parameter Structure	7-3
7-3	Thermocouple Calibration	7-4
7-4	Resistance Thermometer Calibration	7-7
7-5	Calibrating Analog Input	7-9
7-7	Checking Indication Accuracy	7-15

### **User Calibration** 7-1

The E5DD is correctly calibrated before it is shipped from the factory. Normally it does not need to be calibrated by the user.

If, however, it must be calibrated by the user, use the parameters for calibrating temperature input and analog input. OMRON, however, cannot ensure the results of calibration by the user. Also, calibration data is overwritten with the latest calibration results. The default calibration settings cannot be restored after user calibration. Perform user calibration with care.

### Calibrating Inputs

The input type selected in the parameter is used for calibration. The input types are as follows:

16 types • Thermocouple: • Infrared temperature sensor: 4 types Resistance thermometer: 5 types · Current input: 2 types • Voltage input: 3 types

### Registering Calibration Data

The new calibration data for each item is temporarily registered. It can be officially registered as calibration data only when all items have been calibrated to new values. Therefore, be sure to temporarily register all items when you perform the calibration. When the data is registered, it is also recorded that user calibration has been performed.

Prepare separate measuring devices and equipment for calibration. For details on how to handle measuring devices and equipment, refer to the respective instruction manuals.

### Wiring the E5□D-B (Models with Push-In Plus Terminal Blocks)

When connecting two wires to one terminal to calibrate the E5 D-B, do so as given below.

· Using Stranded Wire

Use AWG24 to AWG20 (0.25 to 0.5 mm<sup>2</sup>) stranded wires and connect two wires to the terminal.

Using Twin Ferrules

Use AWG22 to AWG18 (0.5 to 0.75 mm<sup>2</sup>) wires.


Attach the two wires to the twin ferrule first, and then connect the ferrule to the terminal.

### **Recommended Twin Ferrules**


Manufacturer	Model number
Phoenix Contact	AL-TWIN2 × 0.5-8WH
	AL-TWIN2 × 0.75-8GY
Weidmuller	H0.5/14
	H0.75/14
Wago	FE-0.5-8W-WH
	FE-0.75-8W-GY

## 7-2 Parameter Structure

- To execute user calibration, enter the password "1201" at the Move to Calibration Level parameter in the Advanced Function Setting Level. The mode will be changed to the calibration mode, and RdJ will be displayed.
- The Move to Calibration Level parameter may not be displayed when the user is doing the calibration for the first time. If this happens, set the Initial Setting/Communications Protect parameter in the Protect Level to 0 before moving to the Advanced Function Setting Level.
- The calibration mode is ended by turning the power OFF.
- The parameter calibrations in the calibration mode are structured as shown below.




When calibration has been performed after purchase, the user calibration information shown in the following illustration will be displayed when moving to the Calibration Level.



# Thermocouple Calibration

- Calibrate according to the type of thermocouple: thermocouple group 1 (input types 5, 7, 11, 12, 15, 19, and 20) and thermocouple group 2 (input types 6, 8, 9, 10, 13, 14, 16, 17, 18, 21, 22, 23, and 24).
- When calibrating, do not cover the bottom of the Digital Controller.
- If you perform user calibration of the thermocouple, the temperature on the ambient temperature monitor will also be affected.

### Preparations



The terminal numbers are as follows:

Input Terminals (Negative and Positive)

E5CD: 5 and 6 E5ED: 23 and 24

• Input Power Supply (C and D)

E5CD: 11 and 12 E5ED: 1 and 2

The terminal numbers are as follows:

• Input Terminals (Negative and Positive)

E5CD-B: 7 and 8

E5ED-B: 31 and 32

• Input Power Supply (C or C', and D or D')

E5CD-B: 13 or 14, and 15 or 16 E5ED-B: 1 or 2, and 3 or 4


- Set the cold junction compensator designed for compensation of internal thermocouples to 0°C. Make sure that internal thermocouples are disabled (i.e., that tips are open).
- In the above figure, STV indicates a standard DC current/voltage source.
- Use the compensating conductor designed for the selected thermocouple. When thermocouples R, S, E, B, C/W, or PLII or an infrared temperature sensor is used, the cold junction compensator and the compensating conductor can be substituted with the cold junction compensator and the compensating conductor for thermocouple K.



### Additional Information


### **Connecting the Cold Junction Compensator**

Correct process values cannot be obtained if you touch the contact ends of the compensating conductor during calibration of a thermocouple. Accordingly, short-circuit (enable) or open (disable) the tip of the thermocouple inside the cold junction compensator as shown in the figure below to create a contact or non-contact state for the cold junction compensator.



In this example, calibration is shown for a Digital Controller with thermocouple/infrared temperature sensor set as the input type.

- 1. Connect the power supply.
- 2. Connect a standard DC current/voltage source (STV), precision digital multimeter (DMM), and contact junction compensator (e.g., a zero controller as in the figure) to the thermocouple input terminals, as shown in the figure below.



Use K thermocouple compensating conductor for E, R, S, B, W, and PLII thermocouples and for an infrared temperature sensor.

- 3. Turn the power ON.
- 4. Move to the Calibration Level. This starts the 30-minute aging timer. This timer provides an approximate timer for aging. After 30 minutes have elapsed, the No. 2 display changes to 0. You can advance to the next step in this procedure even if 0 is not displayed.
- Input types 5, 7, 11, 12,
   When the Key is pressed, the status changes as shown to the left. The No. 2 display at this time shows the currently entered count value in hexadecimal. Set the STV as follows:
  - Input types 5, 7, 11, 12, 15, 19, 20: Set to 54 mV.
  - Input types 6, 8, 9, 10, 13, 14, 16, 17, 18, 21, 22, 23, 24: Set to 24 mV. Allow the count value on the No. 2 display to fully stabilize, then press the ♥ Key to temporarily register the calibration settings.

If this count value is outside of the specified range, the No. 2 display will flash and the count value will not be temporarily registered.



15, 19, 20;



 Input types 6, 8, 9, 10, 13, 14, 16, 17, 18, 21, 22, 23, 24:








6. When the Key is pressed, the status changes as shown to the left. Set the STV to -6 mV.

Allow the count value on the No. 2 display to fully stabilize, then press the W Key to temporarily register the calibration settings.

If this count value is outside of the specified range, the No. 2 display will flash and the count value will not be temporarily registered.

- 7. When the Key is pressed, the status changes as shown to the left.
- 8. Change the wiring as follows:



Compensating conductor of currently selected thermocouple

Use K thermocouple compensating conductor for E, R, S, B, W, and PLII thermocouples and for an infrared temperature sensor.

Disconnect the STV to enable the thermocouple of the cold junction compensator. When doing this, be sure to disconnect the wiring on the STV side.


- Allow the count value on the No. 2 display to fully stabilize, then press the ♥ Key to temporarily register the calibration settings.
- 10. When the Key is pressed, the status changes as shown to the left. The data to be temporarily registered is not displayed if it is not complete. Press the Key. The No. 2 display changes to 45. Release the key and wait two seconds or press the <a> Key</a>. This stores the temporarily registered calibration data to non-volatile memory. To cancel the saving of temporarily registered calibration data to non-volatile memory, press the Rey (while No is displayed in the No. 2 display) without pressing the A Key.
- 11. The calibration mode is ended by turning the power OFF. For Digital Controllers that have a transfer output, you can continue by calibrating the transfer output. For detailed setting methods, refer to 7-6 Calibrating the Transfer Output.



## 7-4 Resistance Thermometer Calibration

In this example, calibration is shown for Digital Controller with a resistance thermometer set as the input type. Use connecting wires of the same thickness

- 1. Connect the power supply.
- 2. Connect a precision resistance box (called a "6-dial variable resistor" in this manual) to the resistance thermometer input terminals, as shown in the following diagram.




The terminal numbers are as follows:

• Input Terminals (A/B/B)

E5CD: 4, 5, and 6 E5ED: 22, 23, and 24 Input Power Supply (C/D)

E5CD: 11 and 12 E5ED: 1 and 2



\* Common terminals are indicated with asterisks (\*).

The terminal numbers are as follows:

Input Terminals (A/B/B)
 E5CD-B: 6, 7, and 8

E5ED-B: 30, 31, and 32

• Input Power Supply (C or C', and D or D')

E5CD-B: 13 or 14, and 15 or 16

E5ED-B: 1 or 2, 3 or 4

- 3. Turn the power ON.
- 4. Move to the Calibration Level.

This starts the 30-minute aging timer. This timer provides an approximate timer for aging. After 30 minutes have elapsed, the No. 2 display changes to 0. You can advance to the next step in this procedure even if 0 is not displayed.

5. Execute calibration for the main input.

Press the Key to display the count value for each input type.

The No. 2 display at this time shows the currently entered count value in hexadecimal. Set the 6-dial as follows:

- Input type 0:  $390 \Omega$ • Input type 1, 2, 3 or 4:  $280 \Omega$
- Allow the count value on the No. 2 display to fully stabilize, then press the ❤ Key to temporarily register the calibration settings.

If this count value is outside of the specified range, the No. 2 display will flash and the count value will not be temporarily registered.



• Input type 0:



• Input types 1, 2, 3, 4:








- 6. When the Key is pressed, the status changes as shown to the left. Set the 6-dial to 10  $\Omega$ .
  - Allow the count value on the No. 2 display to fully stabilize, then press the W Key to temporarily register the calibration settings.
  - If this count value is outside of the specified range, the No. 2 display will flash and the count value will not be temporarily registered.
- 7. When the Key is pressed, the status changes as shown to the left. The data to be temporarily registered is not displayed if it is not complete. Press the A Key. The No. 2 display changes to 45. Release the key and wait two seconds or press the <sup>1</sup> Key. This stores the temporarily registered calibration data to non-volatile memory.
  - To cancel the saving of temporarily registered calibration data to non-volatile memory, press the  $\ \ \, \ \ \,$  Key (while  $\ \ \, N \bar{a}$  is displayed in the No. 2 display) without pressing the Key.
- 8. The calibration mode is quit by turning the power OFF. For Digital Controllers that have a transfer output, you can continue by calibrating the transfer output. For detailed setting methods, refer to 7-6 Calibrating the Transfer Output.

# 7-5 Calibrating Analog Input

### Calibrating a Current Input

In this example, calibration is shown for a Digital Controller with an analog input, with a current input set as the input type.

- 1. Connect the power supply.
- 2. Connect an STV and DMM to the current input terminals, as shown in the following diagram.



The terminal numbers are as follows:

• Input Terminals (Negative and Positive)

E5CD: 5 and 4 E5ED: 23 and 22

Input Power Supply (C/D)

E5CD: 11 and 12 E5ED: 1 and 2

\* Common terminals are indicated with asterisks (\*).

The terminal numbers are as follows:

Input Terminals (Negative and Positive)

E5CD-B: 7 and 6 E5ED-B: 31 and 30

• Input Power Supply (C or C', and D or D')

E5CD-B: 13 or 14, and 15 or 16 E5ED-B: 1 or 2, and 3 or 4

3. Turn the power ON.



4. Move to the Calibration Level.

This starts the 30-minute aging timer. This timer provides an approximate timer for aging. After 30 minutes have elapsed, the No. 2 display changes to 0. You can advance to the next step in this procedure even if 0 is not displayed.



5. When the Key is pressed, the status changes as shown to the left.

The No. 2 display at this time shows the currently entered count value in hexadecimal. Set the STV to 20 mA.

Allow the count value on the No. 2 display to fully stabilize, then press the 
Key to temporarily register the calibration settings.

If this count value is outside of the specified range, the No. 2 display will flash and the count value will not be temporarily registered.



When the Key is pressed, the status changes as shown to the left. Set the STV to 1 mA.

Allow the count value on the No. 2 display to fully stabilize, then press the  $\ensuremath{\,\boxtimes\,}$  Key to temporarily register the calibration settings.

If this count value is outside of the specified range, the No. 2 display will flash and the count value will not be temporarily registered.



7. When the Key is pressed, the status changes as shown to the left.

The data to be temporarily registered is not displayed if it is not complete.


To cancel the saving of temporarily registered calibration data to non-volatile memory, press the  $\ \ \,$  Key (while  $\ \ \,$   $\ \ \,$  is displayed in the No. 2 display) without pressing the  $\ \ \,$  Key.

8. The calibration mode is ended by turning the power OFF. For Digital Controllers that have a transfer output, you can continue by calibrating the transfer output. For detailed setting methods, refer to 7-6 Calibrating the Transfer Output.

### Calibrating a Voltage Input

In this example, calibration is shown for a Digital Controller with an analog input, with a voltage input set as the input type.

- 1. Connect the power supply.
- 2. Connect an STV and DMM to the voltage input terminals, as shown in the following diagram.



Input power supply STV DMM

\* Common terminals are indicated with asterisks (\*).

The terminal numbers are as follows:

• Input Terminals (Negative and Positive)

E5CD-B: 7 and 8 E5ED-B: 31 and 32

• Input Power Supply (C or C', and D or D')

E5CD-B: 13 or 14, and 15 or 16 E5ED-B: 1 or 2, and 3 or 4

The terminal numbers are as follows:

· Input Terminals (Negative and Positive)

E5CD: 5 and 6 E5ED: 23 and 24

• Input Power Supply (C/D)

E5CD: 11 and 12 E5ED: 1 and 2

3. Turn the power ON.



4. Move to the Calibration Level.

This starts the 30-minute aging timer. This timer provides an approximate timer for aging. After 30 minutes have elapsed, the No. 2 display changes to 0. You can advance to the next step in this procedure even if 0 is not displayed.

• Input type 27 or 5. When the @ Key is pressed, the status changes as shown to the left.

The No. 2 display at this time shows the currently entered count value in hexadecimal. Set the STV as follows:

[7[3

• Input type 27 or 28: 5 V 10 V • Input type 29:

• Input type 29:

6 ID4

Allow the count value on the No. 2 display to fully stabilize, then press the ⊌ Key to temporarily register the calibration settings.

If this count value is outside of the specified range, the No. 2 display will flash and the count value will not be temporarily registered.

 Input type 27 or 6. When the Key is pressed, the status changes as shown to the left. 28: Set the STV as follows:



• Input type 27, 28, or 29: 1 V

Input type 29:



Allow the count value on the No. 2 display to fully stabilize, then press the W Key to temporarily register the calibration settings.

If this count value is outside of the specified range, the No. 2 display will flash and the count value will not be temporarily registered.




7. When the Key is pressed, the status changes as shown to the left. The data to be temporarily registered is not displayed if it is not complete. Press the  $ilde{R}$  Key. The No. 2 display changes to extstyle 4E5. Release the key and wait two seconds or press the  $\ \ \ \ \$  Key. This stores the temporarily registered calibration data to non-volatile

To cancel the saving of temporarily registered calibration data to non-volatile memory, press the  $\ \ \, \ \ \,$  Key (while  $\ \ \, \ \ \,$  Key is displayed in the No. 2 display) without pressing the  $\ \ \,$  Key.

8. The calibration mode is ended by turning the power OFF. For Digital Controllers that have a transfer output, you can continue by calibrating the transfer output. For detailed setting methods, refer to 7-6 Calibrating the Transfer Output.


# 7-6 Calibrating the Transfer Output



For Digital Controllers that have a transfer output, the transfer output calibration display will be displayed after input calibration has been completed.

Use the following procedure to calibrate the transfer output for 4 to 20 mA.

1. Connect a DMM to the transfer output terminals.



The terminal numbers are as follows:

 Transfer Output Terminals (Positive and Negative)

E5CD: 17 and 18 E5ED: 32 and 33

• Input Power Supply (C/D)

E5CD: 11 and 12 E5ED: 1 and 2 The terminal numbers are as follows:

Transfer Output Terminals (Positive and Negative)

E5CD-B: 23 and 24 E5ED-B: 43 and 44

• Input Power Supply (C or C', and D

or D')

E5CD-B: 13 or 14, and 15 or 16 E5ED-B: 1 or 2, and 3 or 4

- 2. Press the Key to display the parameter for the transfer output.
- SER Nā
- **R20.L** 52RC
- **A4.**E
- 3. The calibration display for 20 mA will be displayed. Press the riangle or riangle Key until the DMM monitor value changes to 20 mA.

Press the Key. The calibration settings will be temporarily registered.

4. The calibration display for 4 mA will be displayed. Press the ♠ or ❤ Key until the DMM monitor value changes to 4 mA.

Press the Key. The calibration settings will be temporarily registered.




5. To cancel saving the temporarily registered calibration data to non-volatile memory, press the  $\bigcirc$  Key without pressing the  $\bigcirc$  Key, i.e., while  $N_{\bar{a}}$  is displayed in the No. 2 display.

Press the ♠ Key. The No. 2 display changes to ₹5. Release the key and wait 2 seconds or press the 
Key. This saves the temporarily registered calibration data in non-volatile memory.

6. The Calibration Mode is ended by turning OFF the power supply.

Use the following procedure to calibrate the transfer output for 1 to 5 V.

1. Connect a DMM to the transfer output terminals.



\* Common terminals are indicated with asterisks (\*).

The terminal numbers are as follows:

• Transfer Output Terminals (Positive and Negative)

E5CD: 16 and 18 E5ED: 31 and 33

• Input Power Supply (C/D)

E5CD: 11 and 12 E5ED: 1 and 2

The terminal numbers are as follows:

• Transfer Output Terminals (Positive and Negative)

E5CD-B: 22 and 24 E5ED-B: 42 and 44

• Input Power Supply (C or C', and D

or D')

E5CD-B: 13 or 14, and 15 or 16 E5ED-B: 1 or 2, and 3 or 4

- 5680
- 1.}-000 1
- SERE

- 2. Press the Key to display the parameter for the transfer output.
- 3. The calibration display for 5 V will be displayed. Press the ♠ or ❤ Key until the DMM monitor value changes to 5 V.

Press the Key. The calibration settings will be temporarily registered.

4. The calibration display for 1 V will be displayed. Press the ♠ or ❤ Key until the DMM monitor value changes to 1 V.

Press the Key. The calibration settings will be temporarily registered.

5. To cancel saving the temporarily registered calibration data to non-volatile memory, press the Rey without pressing the Key, i.e., while  $N_{\bar{a}}$  is displayed in the No. 2 display.

Press the ♠ Key. The No. 2 display changes to ₹5. Release the key and wait 2 seconds or press the Tkey. This saves the temporarily registered calibration data in non-volatile memory.

6. The Calibration Mode is ended by turning OFF the power supply.


# 7-7 Checking Indication Accuracy

- After calibrating the input, be sure to check the indication accuracy to make sure that the calibration has been executed correctly.
- Operate the E5□D in the process value/set point monitor mode.
- · Check the indication accuracy at the following three values: upper limit, lower limit, and mid-point.
- To check the range of an infrared sensor, set the input type parameter to 6 (i.e., a K thermocouple) and input a voltage that is equivalent to the starting power of a K thermocouple.

### • Thermocouple or Infrared Temperature Sensor

Preparations

The diagram below shows the required device connections. Make sure that the E5DD and cold junction compensator are connected by a compensating conductor for the thermocouple that is to be used during actual operation.



Compensating conductor


The terminal numbers are as follows:

• Input Terminals (Negative and Positive)

E5CD: 5 and 6 E5ED: 23 and 24 • Input Power Supply (C/D)

E5CD: 11 and 12 E5ED: 1 and 2

### E5□D-B



Compensating conductor

\* Common terminals are indicated with asterisks (\*).

The terminal numbers are as follows:

• Input Terminals (Negative and Positive)

E5CD-B: 7 and 8 E5ED-B: 31 and 32 • Input Power Supply (C or C', and D or D')

E5CD-B: 13 or 14, and 15 or 16 E5ED-B: 1 or 2, and 3 or 4

### Operation

Make sure that the cold junction compensator is at 0°C, and set the STV output to the voltage equivalent of the starting power of the check value.


The cold junction compensator and compensation conductor are not required when an external cold junction compensation method is used.

### • Resistance Thermometer

Preparations

The diagram below shows the required device connections.

### E5□D




The terminal numbers are as follows:

• Input Terminals (A/B/B)

E5CD: 4, 5, and 6 E5ED: 22, 23, and 24 • Input Power Supply (C/D)

E5CD: 11 and 12 E5ED: 1 and 2

### E5□D-B



\* Common terminals are indicated with asterisks (\*).

The terminal numbers are as follows:

• Input Terminals (A/B/B) E5CD-B: 6, 7, and 8

E5ED-B: 30, 31, and 32

• Input Power Supply (C or C', and D or D')

E5CD-B: 13 or 14, and 15 or 16 E5ED-B: 1 or 2, and 3 or 4

### Operation

Set the 6-dial variable resistor to the resistance that is equivalent to the test value.


### Analog Input

Preparations

The diagram below shows the required device connections. (The connection terminals depend on the model and input type.)


### **Current Input**





The terminal numbers are as follows:

- Input Terminals
   Input Power Supply
   (C/D)




\* Common terminals are indicated with asterisks (\*).

The terminal numbers are as follows:

- Input Terminals (Positive and Negative)
   E5CD-B: 6 and 7
   Input (C or E5CD-B)
- Input Power Supply (C or C', and D or D')
   E5CD-B: 13 or 14, and

### **Voltage Input**

### E5□D




The terminal numbers are as follows:

- Input Terminals Input Power Supply

  (Negative and Positive) (C/D)
  - (Negative and Positive) (C/D)
- E5CD: 5 and 6 E5CD: 11 and 12 E5ED: 23 and 24 E5ED: 1 and 2

### E5□D-B



\* Common terminals are indicated with asterisks (\*).

The terminal numbers are as follows:

- Input Terminals (Negative and Positive)
   E5CD-B: 7 and 8
- Input Power Supply (C or C', and D or D') E5CD-B: 13 or 14, and
- E5ED-B: 31 and 32
- 15 or 16 E5ED-B: 1 or 2, and 3 or 4

Operation

Set the STV output to the voltage or current test value.



# **Appendices**

A-1	Specif	fications	A-2
	A-1-1	Ratings	
	A-1-2	Characteristics	
	A-1-3	Rating and Characteristics of Options	A-5
	A-1-4	Waterproof Packing	A-5
	A-1-5	Setup Tool Port Cover for Front Panel 000	A-6
	A-1-6	Draw-out Jig	A-7
A-2	Curre	nt Transformer (CT)	<b>A</b> -8
	A-2-1	Specifications	
	A-2-2	Dimensions (Unit: mm)	A-8
A-3	USB-S	Serial Conversion Cable and Conversion Cable 000	A-11
	A-3-1	E58-CIFQ2 USB-Serial Conversion Cable	A-11
	A-3-2	E58-CIFQ2-E Conversion Cable	A-12
<b>A-4</b>	Temp	erature Sensor for Packing Machines	A-13
	A-4-1	Model Number Legend	
	A-4-2	Dimensions	<b>A-1</b> 4
	A-4-3	Mounting Brackets	A-15
A-5	Error	Displays	A-16
		Displays	
A-6	Troub	leshooting	A-20
A-6	Troub		A-20 A-23
A-6	Troub Param	leshooting	<b>A-20</b> <b>A-23</b> A-23
A-6	<b>Param</b> A-7-1 A-7-2 A-7-3	leshooting neter Operation Lists Operation Level Adjustment Level Initial Setting Level	<b>A-20</b> <b>A-23</b> A-23 A-24
A-6	<b>Param</b> A-7-1 A-7-2 A-7-3 A-7-4	leshooting	A-20 A-23 A-24 A-24 A-26 A-30
A-6	Param A-7-1 A-7-2 A-7-3 A-7-4 A-7-5	leshooting neter Operation Lists Operation Level Adjustment Level Initial Setting Level Manual Control Level Monitor/Setting Item Level	A-20 A-23 A-24 A-24 A-26 A-30
A-6	<b>Param</b> A-7-1 A-7-2 A-7-3 A-7-4 A-7-5 A-7-6	leshooting neter Operation Lists Operation Level Adjustment Level Initial Setting Level Manual Control Level Monitor/Setting Item Level Advanced Function Setting Level	A-20 A-23 A-24 A-26 A-30 A-30 A-30
A-6	Param A-7-1 A-7-2 A-7-3 A-7-4 A-7-5 A-7-6 A-7-7	leshooting neter Operation Lists Operation Level Adjustment Level Initial Setting Level Manual Control Level Monitor/Setting Item Level Advanced Function Setting Level Protect Level	A-20 A-23 A-24 A-26 A-30 A-30 A-30 A-36
A-6	<b>Param</b> A-7-1 A-7-2 A-7-3 A-7-4 A-7-5 A-7-6 A-7-7	leshooting neter Operation Lists Operation Level Adjustment Level Initial Setting Level Manual Control Level Monitor/Setting Item Level Advanced Function Setting Level Protect Level Communications Setting Level	A-20 A-23 A-24 A-26 A-30 A-30 A-36 A-36 A-35 A-35
A-6 A-7	<b>Param</b> A-7-1 A-7-2 A-7-3 A-7-4 A-7-5 A-7-6 A-7-7 A-7-8 A-7-9	leshooting  neter Operation Lists Operation Level Adjustment Level Initial Setting Level Manual Control Level Monitor/Setting Item Level Advanced Function Setting Level Protect Level Communications Setting Level Initialization According to Parameter Changes	A-20 A-23 A-24 A-26 A-30 A-30 A-35 A-36 A-36
A-6 A-7	Param A-7-1 A-7-2 A-7-3 A-7-4 A-7-5 A-7-6 A-7-7 A-7-8 A-7-9 Senso	leshooting neter Operation Lists Operation Level Adjustment Level Initial Setting Level Manual Control Level Monitor/Setting Item Level Advanced Function Setting Level Protect Level Communications Setting Level Initialization According to Parameter Changes or Input Setting Range, Indication Range, Control Range	A-20 A-23 A-24 A-26 A-30 A-30 A-35 A-36 A-36 A-36 A-36 A-36
A-6 A-7	Param A-7-1 A-7-2 A-7-3 A-7-4 A-7-5 A-7-6 A-7-7 A-7-8 A-7-9 Senso	leshooting  neter Operation Lists Operation Level Adjustment Level Initial Setting Level Manual Control Level Monitor/Setting Item Level Advanced Function Setting Level Protect Level Communications Setting Level Initialization According to Parameter Changes	A-20 A-23 A-24 A-26 A-30 A-30 A-35 A-36 A-36 A-36 A-36 A-36
A-6 A-7 A-8 A-9	Param A-7-1 A-7-2 A-7-3 A-7-4 A-7-5 A-7-6 A-7-7 A-7-8 A-7-9 Senso Settin	leshooting neter Operation Lists Operation Level Adjustment Level Initial Setting Level Manual Control Level Monitor/Setting Item Level Advanced Function Setting Level Protect Level Communications Setting Level Initialization According to Parameter Changes or Input Setting Range, Indication Range, Control Range	A-20 A-23 A-24 A-26 A-30 A-30 A-36 A-36 A-38 A-38 A-38 A-39 A-40

### **A-1 Specifications**

#### A-1-1 Ratings

Supply voltage			100 to 240 VAC, 50/60 Hz 24 VAC, 50/60 Hz/24 VDC		
Operating volt	age range		85% to 110% of rated supply voltage		
Power	E5CD or E5CD-B		Option number 000, 800: 5.2 VA max. Other option numbers: 6.5 VA max.	Option number 000, 800: 3.1 VA max./1.6 W max. Other option numbers: 4.1 VA max./2.3 W max.	
consumption E5ED or E5ED-B		E5ED-B	Option number 000, 800: 6.6 VA max. Other option numbers: 8.3 VA max. Other option numbers: 5.5 VA max./2		
Sensor input *1			Thermocouple: K, J, T, E, L, U, N, R, S, B, Platinum resistance thermometer: Pt100, C Infrared temperature sensor: 10 to 70°C, 6 Current input *2: 4 to 20 mA, 0 to 20 mA (In Voltage input *2: 1 to 5 V, 0 to 5 V, 0 to 10	JPt100 0 to 120°C, 115 to 165°C, 140 to 260°C 0nput impedance: 150 $0$ max.)	
	Relay	E5CD or E5CD-B	SPST-NO, 250 VAC, 3 A (resistive load), 6 Min. applicable load: 5 V, 10 mA (reference		
	output	E5ED or E5ED-B	SPST-NO, 250 VAC, 5 A (resistive load), 6 Min. applicable load: 5 V, 10 mA (reference	e values)	
Control output 1/2*3	Voltage output (for driving SSR)	E5CD or E5CD-B	circuit	load current 21 mA, with short-circuit protection	
output 1/2		E5ED or E5ED-B	Output voltage 12 VDC ±20% (PNP), max. circuit (21 mA if there are two control outputs)	load current 40 mA, with short-circuit protection	
	Linear current output		4 to 20 mA DC, 0 to 20 mA DC, Load: 500 $\Omega$ max. Resolution: Approx. 10,000		
	Relay outputs	E5CD	2 auxiliary outputs SPST-NO, 250 VAC, 3 A (resistive load), Electrical life: 100,000 operations, Minimur	m applicable load: 10 mA at 5 V (reference values)	
Auxiliary output		E5CD-B	2 auxiliary outputs SPST-NO, 250 VAC, 2 A (resistive load), Electrical life: 100,000 operations, Minimur	m applicable load: 10 mA at 5 V (reference values)	
		E5ED or E5ED-B	4 auxiliary outputs SPST-NO, 250 VAC, 2 A (resistive load), Electrical life: 100,000 operations, Minimur	n applicable load: 10 mA at 5 V (reference values)	
Control metho	d		ON/OFF or 2-PID control (with autotuning)		
Setting metho	d		Digital setting using front panel keys		
Indication met	hod		11-segment digital display, individual indicators, and bar display		
Other functions			Depend on the model		
Ambient temperature			$-10$ to $55^{\circ}$ C (with no condensation or icing), For 3-year warranty: Mounted individually at $-10$ to $50^{\circ}$ C (with no condensation or icing)		
Ambient humi	Ambient humidity		25% to 85%		
Storage temperature			-25 to 65°C (with no condensation or icing)		
Altitude			2,000 m max.		
Recommende	d fuse		T2A, 250 VAC, time lag, low shut-off capacity		
Installation environment		1	Overvoltage Category II, Pollution Class 2 (EN/IEC/UL 61010-1)		

For input setting ranges, refer to A-8 Sensor Input Setting Range, Indication Range, Control Range.

When connecting the ES2-HB/THB, connect it 1:1.

The E5CD or E5CD-B does not have control output 2.

### • HB and HS Alarms

(E5□D Models with HB and HS Alarms)

Max. heater current	50 A AC		
Input current readout	±5% FS ±1 digit max.		
accuracy			
Heater burnout alarm setting range	0.1 to 49.9 A (0.1 A units) 0.0 A: Heater burnout alarm output turns OFF. 50.0 A: Heater burnout alarm output turns ON.  Min. detection ON time *1: 30 ms for a control period of 0.1 s or 0.2 s  100 ms for a control period of 0.5 s or 1 to 99 s		
Heater short alarm setting range  0.1 to 49.9 A (0.1 A units) 0.0 A: Heater short alarm output turns ON. 50.0 A: Heater short alarm output turns OFF.  Min. detection OFF time *2: 38 ms for a control period of 0.1 s or 0.2 s 100 ms for a control period of 0.5 s or 1 to			

<sup>\*1</sup> HB alarms are not detected and the heater power is not measured if the ON time for the control output for heating is 100 ms or less (30 ms or less if the control period is 0.1 or 0.2 s).

<sup>\*2</sup> HS alarms are not detected and the leakage power is not measured if the OFF time for the control output for heating is 100 ms or less (38 ms or less if the control period is 0.1 or 0.2 s).

### A-1-2 Characteristics

Indication Thermocouple *1		( $\pm 0.3\%$ of indication value or $\pm 1^{\circ}$ C, whichever is greater) $\pm 1$ digit max.	
accuracy	Resistance	(±0.2% of indication value or ±0.8°C, whichever is greater) ±1 digit max.	
(when mounted	thermometer		
individually,	Analog input	±0.2% FS ±1 digit max.	
ambient temperature of 23°C)		±5% FS ±1 digit max.	
Temperature		Thermocouple (R, S, B, C/W, PLII)	
variation influence  *2  Voltage variation  Thermocouple		( $\pm 1\%$ of indication value or $\pm 10^{\circ}$ C, whichever is greater) $\pm 1$ digit max.	
		Other thermocouples:  (±1% of indication value or ±4°C, whichever is greater) ±1 digit max.	
Electromagnetic	Resistance	$(\pm 1\% \text{ of indication value or } \pm 2^{\circ}\text{C}$ , whichever is greater) $\pm 1$ digit max.	
interference	thermometer		
influence	Analog input	±1% FS ±1 digit max.	
(according to EN	OT immed	±5% FS ±1 digit max.	
61326-1)	CT input		
Hysteresis	Temperature input	0.1 to 999.9°C or °F (in units of 0.1°C or °F)	
	Analog input	0.01% to 99.99% FS (in units of 0.01% FS)	
Proportional	Temperature input	0.1 to 999.9°C or °F (in units of 0.1°C or °F)	
band (P)		0.1% to 999.9% FS (in units of 0.1% FS)	
Proportional	Analog input		
band (P) for			
cooling		Standard or heating/cooling control: 0 to 9,999 s (in 1-s increments) or 0.0 to	
Integral time (I) *3		999.9 s (in 0.1-s increments)	
Integral time (I) for cooling *3		, '	
Derivative time (D) *3		0 to 9,999 s (in units of 1 s)	
Derivative time (D)	for cooling *3	0.0 to 999.9 s (in units of 0.1 s)	
Control Period		0.1, 0.2, 0.5, or 1 to 99 s (in units of 1 s)	
	SP response proportional band (P)	Temperature input: 0.1 to 999.9°C or °F (in units of 0.1°C or °F)	
	SP response integral time (I)	0 to 9999 s (in units of 1 s), 0.0 to 999.9 s (in units of 0.1 s) *3	
	SP response derivative time (D)	0 to 9999 s (in units of 1 s), 0.0 to 999.9 s (in units of 0.1 s) *3	
Adaptive control	Disturbance response	Temperature input: 0.1 to 999.9°C or °F (in units of 0.1°C or °F)	
	proportional band (P)		
	Disturbance response integral time (I)	0 to 9999 s (in units of 1 s), 0.0 to 999.9 s (in units of 0.1 s) *3	
	Disturbance	0 to 9999 s (in units of 1 s), 0.0 to 999.9 s (in units of 0.1 s) *3	
	response	, , , , , , , , , , , , , , , , , , , ,	
	derivative time (D)		
Manual reset value		0.0% to 100.0% (in units of 0.1%)	
Alarm setting range		<ul> <li>-1,999 to 9,999 (except for MV alarm)</li> <li>Temperature input: The decimal point is automatically set when the sensor is selected.</li> <li>Analog input: The decimal point depends on the Decimal Point parameter setting.</li> <li>-199.9 to 999.9 (MV alarm)</li> </ul>	
		-199.9 to 999.9 (MV alarm)	

Sampling cycle		50 ms			
Insulation resistance		20 MΩ min. (at	20 MΩ min. (at 500 VDC)		
Dielectric strength		100 to 240 VAC: 3,000 VAC, 50/60 Hz for 1 min between terminals of different charge 24 VAC/DC: 3,000 VAC,* 50/60 Hz for 1 min between terminals of different charge			
Malfunction vibra	tion	10 to 55 Hz, 20	m/s $^2$ for 10 min each in X, Y	and Z directions	
Vibration resistance		10 to 55 Hz, 20	10 to 55 Hz, 20 m/s <sup>2</sup> for 2 hr each in X, Y, and Z directions		
Malfunction shock		100 m/s <sup>2</sup> , 3 times each in X, Y, and Z directions			
Shock resistance		300 m/s <sup>2</sup> , 3 times each in X, Y, and Z directions			
	E5CD	Approx. 120 g	Adapter: Approx. 10 g	Terminal cover: Approx. 0.5 g each	
Weight	E5ED	Approx. 210 g	Adapter: Approx. 4 g × 2	Terminal Cover: Approx. 1 g each	
	E5CD-B	Approx. 120 g	Adapter: Approx. 10 g		
	E5ED-B	Approx. 210 g	Adapter: Approx. 4 g × 2		
Degree of protection		Front panel: IP66, rear case: IP20, terminals: IP00			
Memory protection		Non-volatile memory (number of writes: 1,000,000)			

The indication accuracy of K, T, and N thermocouples at a temperature of -100°C or less is ±2°C ±1 digit maximum. The indication accuracy of U and L thermocouples is  $\pm 2^{\circ}$ C  $\pm 1$  digit maximum.

The indication accuracy of B thermocouples at a temperature of 400°C or less is not specified.

The indication accuracy of B thermocouples at a temperature of 400 to 800°C is ±3°C maximum.

The indication accuracy of R and S thermocouples at a temperature of 200°C or less is ±3°C ±1 digit maximum.

The indication accuracy of C/W thermocouples is (±0.3% of PV or ±3°C, whichever is greater) ±1 digit maximum.

The indication accuracy of PLII thermocouples is (±0.3% of PV or ±2°C, whichever is greater) ±1 digit maximum.

Ambient temperature: -10°C to 23°C to 55°C

Voltage range: -15 to +10% of rated voltage

#### A-1-3 **Rating and Characteristics of Options**

	Contact Input
Event innute	ON: 1 k $\Omega$ max., OFF: 100 k $\Omega$ min.
Event inputs	Non-contact Input
	ON: Residual voltage 1.5 V max.; OFF: Leakage current 0.1 mA max.
	Transmission path: RS-485: Multidrop
	Communications method: RS-485 (2-wire, half duplex)
Communications	Synchronization: Start-stop
	Protocol: CompoWay/F or Modbus
	Baud rate: 9.6, 19.2, 38.4,57.6, or 115.2 kbps
Transfer autnut	Current output: 4 to 20 mA DC, Load: 500 Ω max., Resolution: 10,000, Accuracy: ±0.3% FS
Transfer output	Linear voltage output: 1 to 5 VDC, Load: 1 kΩ min., Resolution: 10,000, Accuracy: ±0.3% FS

#### A-1-4 **Waterproof Packing**

If the Waterproof Packing is lost or damage, order one of the following models.

Y92S-P8 (for DIN 48 × 48)	Y92S-P9 (for DIN 48 × 96)

The unit is determined by the setting of the Integral/Derivative Time Unit parameter.

A Y92S-P7 Setup Tool Port Cover for the front panel is included with the E5ED or E5ED-B. Order this Port Cover separately if the Port Cover on the front-panel Setup Tool port is lost or damaged. The Waterproof Packing must be periodically replaced because it may deteriorate, shrink, or harden depending on the operating environment.



Use the following procedure to replace the Setup Tool Port Cover for the front panel.


### • Replacement Procedure

1	Open the Setup Tool Port Cover on the front panel.	
2	Pull gently on the Setup Tool Port Cover to remove it from the Digital Controller.	
3	Insert the stopper on the Setup Tool Port Cover into the hole at the bottom of the port.	Insertion hole
4	Make sure that the Setup Tool Port Cover is closed.	


### A-1-6 Draw-out Jig

You can use a Draw-out Jig to remove the interior body of the Digital Controller from the case to perform maintenance without removing the terminal leads. Refer to 2-1-4 Drawing Out the Interior Body of the Digital Controller to Replace It for the application method.

### • Y92F-58 (for E5CD)



### • Y92F-59 (for E5ED)



# **A-2** Current Transformer (CT)


## A-2-1 Specifications


Item	Specifications			
Model number	E54-CT1	E54-CT3	E54-CT1L	E54-CT3L
Max. continuous current	50 A AC	120 A AC *1	50 A AC	120 A AC <sup>*1</sup>
Dielectric strength	1,000 VAC (for 1 min)		1,500 VAC (1 min)	
Vibration resistance	50 Hz, 98 m/s <sup>2</sup>			
Weight	Approx. 11.5 g	Approx. 50 g	Approx. 14 g	Approx. 57 g
Accessories	None	Armature (2), Plug (2)	None	None


<sup>\*1</sup> The maximum continuous current of the E5□D is 50 A.

## A-2-2 Dimensions (Unit: mm)


• E54-CT1









# • E54-CT1L




# • E54-CT3



# • E54-CT3L





# A-3 USB-Serial Conversion Cable and Conversion Cable ...

A USB-Serial Conversion Cable is used to connect the E5□D to a computer. The E58-CIFQ2-E Conversion Cable is also required to connect to the Setup Tool port on the front panel of the E5ED or E5ED-B. The following table lists the cables and ports that are used.

Connection port	Cable
Setup Tool port (card edge type)	E58-CIFQ2 USB-Serial Conversion Cable
Setup Tool port (pin jack)	E58-CIFQ2 USB-Serial Conversion Cable and E58-CIFQ2-E Conversion
	Cable

Refer to 2-5 Using the Setup Tool Port for the connection procedure.

# A-3-1 E58-CIFQ2 USB-Serial Conversion Cable


# Specifications

Item	Specifications
Applicable OS	Windows XP, Vista, 7, 8, or 10 <sup>*2</sup>
Applicable software	E5CD/E5ED: CX-Thermo Ver, 4.66 or higher
	E5CD-B/E5ED-B: CX-Thermo Ver, 4.67 or higher
Applicable models	E5CB Series, E5□C Series, E5□C-T Series, and E5□D Series
USB interface rating	Conforms to USB Specification 2.0
DTE speed	38,400 bps
Connector	Computer end: USB (type A plug)
specifications	Digital Controller: Special serial connector
Power supply	Bus power (Supplied from USB host controller)*1
Power supply voltage	5 VDC
Current consumption	450 mA max.
Output voltage	4.7±0.2 VDC (Supplied through USB-Serial Conversion Cable to the Digital
	Controller.)
Output current	250 mA max. (Supplied through USB-Serial Conversion Cable to the Digital
	Controller.)
Ambient temperature	0 to 55°C (with no condensation or icing)
Ambient humidity	10% to 80%
Storage temperature	-20 to 60°C (with no condensation or icing)
Storage humidity	10% to 80%
Altitude	2,000 m max.
Weight	Approx. 120 g

Windows is a registered trademark of Microsoft Corporation in the United States and other countries.

- \*1 Use a high-power port for the USB port.
- \*2 CX-Thermo version 4.65 or higher runs on Windows 10.

# Dimensions



# **LED Indicator Display**

Indicator	Color	Status	Meaning	
PWR	Green	Lit.	USB bus power is being supplied.	
		Not lit.	USB bus power is not being supplied.	
SD	Yellow	Lit	Sending data from USB-Serial Conversion Cable	
		Not lit	Not sending data from USB-Serial Conversion Cable	
RD	Yellow	Lit	Receiving data from the USB-Serial Conversion Cable	
		Not lit	Not receiving data from the USB-Serial Conversion Cable	


#### E58-CIFQ2-E Conversion Cable A-3-2

# Specifications

Item	Specification
Applicable models	E5EC/E5EC-B/E5AC/E5DC/E5GC Series, E5EC-T/E5AC-T Series, and
	E5ED/E5ED-B
Connector	Digital Controller: 4-pin plug
specifications	E58-CIFQ2: Small special connector
Ambient temperature	0 to 55°C (with no condensation or icing)
Ambient humidity	10% to 80%
Storage temperature	-20 to 60°C (with no condensation or icing)
Storage humidity	10% to 80%
Altitude	2,000 m max.
Weight	Approx. 60 g


# Dimensions

# E58-CIFQ2-E Conversion Cable



Note: Always use the E58-CIFQ2-E together with the E58-CIFQ2.

# Connected to the E58-CIFQ2 USB-Serial Conversion Cable




# A-4 Temperature Sensor for Packing Machines

Туре	Name	Model number and appearance	Temperatur e range	Element type	Method	Class	Protective material	Terminal form
Specialized	Sheathed	E52-CA□□A□	0 to 650°C	K(CA)	Grounded	Class 2	ASTM316	Prewired
Type for	Thermocouple	D=1□S□				(0.75)	L	lead
Packaging								wires
Machines								

# A-4-1 Model Number Legend


The protective tubing length and lead length can be specified as shown below. Use the model number legend to specify the model and inquire about delivery times and prices.




# Example:

Element: K, protective tube length: 12 cm, exposed lead wires, Y-type crimp terminals for M3.0, protective tubing diameter: 1 cm, flexible and heat resistant, lead wire length: 2 m E52-CA12AY D=1 S2 2M

# Y-type crimp terminals for M3.0



# Ferrules



- \*1 Lead wires (compensating wires) (excluding Y-type crimp terminals and ferrules)
  Heat-resistance model (0 to 200°C): PFA glass-wool sheath with stainless outer shield
  Flexible, heat-resistance model (0 to 200°C): PFA glass-wool sheath with stainless outer shield
- \*2 Temperature range of sleeve: 0 to 260°C
- \*3 The sheath can be easily bent. Performance will not be adversely affected even if the sheath is bent somewhat.

Do not bend the sheath beyond the following values.

Minimum bending radius: 2 mm


Bendable section: 8 mm or father from the end

# A-4-3 Mounting Brackets

Use the following brackets or the equivalent to mount a Temperature Sensor for Packaging Machines to a hot plate.

Mounting bracket	Application	Manufacturer	Model number
(1)	1-mm-dia. protective	Misumi Corporation	Square Shims
	tube bracket		ASFCS-series
(2)	Sleeve bracket (S1)	Misumi Corporation	Cable Clips
			COPU3-20P
		Digi-Key	Cable Clamp
			RPC1156-ND
	Sleeve bracket (S2)	Misumi Corporation	Cable Clips
			COPU4-20P
		Digi-Key	Cable Clamp
			RPC1474-ND

Note: All of the above mounting brackets are SUS304.



When an error occurs, the error contents are shown on the No. 1 or the No. 2 display.

This section describes how to check error codes on the display, and the actions to be taken to remedy the problems.

S.ERR

**Input Error** 

# Meaning

The input value has exceeded the control range. \*

The input type setting is not correct.

The sensor is disconnected or shorted.

The sensor wiring is not correct.

The sensor is not wired.

\* Control Range

Resistance thermometer, Temperature setting lower limit  $-20^{\circ}$ C to temperature setting upper limit  $+20^{\circ}$ C thermocouple input: (Temperature setting lower limit  $-40^{\circ}$ F to temperature setting upper limit  $+40^{\circ}$ F)

ES1B input: Same as input indication range
Analog input: -5% to +105% of scaling range

## Action

Check the wiring of inputs for miswiring, disconnections, and short-circuits and check the input type. If no abnormality is found in the wiring and input type, turn the power OFF then back ON again. If the display remains the same, the Digital Controller must be replaced. If the display is restored, then the probable cause is electrical noise affecting the control system. Check for electrical noise. Note: With resistance thermometer input, a break in the A, B, or B line is regarded as a disconnection.

## Operation

After an error occurs, the error is displayed and the alarm outputs function as if the upper limit has been exceeded.

It will also operate as if transfer output exceeded the upper limit. If an input error is assigned to a control output or auxiliary output, the output will turn ON when the input error occurs.

If an input error is assigned to a control output or auxiliary output, the output will turn ON when the input error occurs. The error message will appear in the display for the PV.

Note: The heating and cooling control outputs will turn OFF. When the manual MV, MV at stop, or MV at error is set, the control output is determined by the set value.

Display Range Exceeded

# Meaning

Though this is not an error, it is displayed if the process value exceeds the display range when the control range is larger than the display range.

The display ranges are shown below (with decimal points omitted).

- When less than -1,999: ccc
- When more than 9,999: בבבב

# Operation

Control continues, allowing normal operation. The value will appear in the display for the PV.

Resistance thermometer input (Except for models with a Resistance thermometer input (Except for models with a setting range of -199.9 to 500.0°C) setting range of -1999. to 500.0°C) Thermocouple input (Except for models with a setting range of Thermocouple input (Except for models with a setting range of -199.9 to 400.0°C) -199.9 to 400.0°C) ES1B -Control range-Control range 5.ERR display cccc display 5.ERR display Numeric display 5.ERR display Numeric display 5.ERR display Input indication rang Input indication range Analog Input Analog Input • When display range ≥ control range • When display range < control range Control range Control range Numeric display 5.ERR display cccc display display ככככ 5.ERR display 5.ERR display Numeric display 5.ERR display Input indication range Input indication range

\*The display range is shown in numbers with decimal points omitted.

-1999 ← Display range\* → 9999

# E333 AD Converter Error

-1999 ← Display range\* → 9999

# Meaning

There is an error in internal circuits.

## Action

First, turn the power OFF then back ON again. If the display remains the same, the Digital Controller must be repaired. If the display is restored, then the probable cause is electrical noise affecting the control system. Check for electrical noise.

# Operation

The control, auxiliary, and transfer outputs turn OFF. (A linear current output will be approx. 0 mA.)

# E !!! Memory Error

# Meaning

Internal memory operation is in error.

## Action

First, turn the power OFF then back ON again. If the display remains the same, the Digital Controller must be repaired. If the display is restored, then the probable cause is electrical noise affecting the control system. Check for electrical noise.

# Operation

The control, auxiliary, and transfer outputs turn OFF. (A linear current output will be approx. 0 mA.)

# FFFF Current Value Exceeds

## Meaning

This error is displayed when the heater current value exceeds 55.0 A.

# Operation

Control continues, allowing normal operation. An error message is displayed when the following items are displayed.

Heater current 1 value monitor

Leakage current 1 monitor

[上 | HB Alarm |[戸 | HS Alarm

# Meaning

If there is an HB or HS alarm, the relevant parameter will flash on the No. 1 display.

# Operation

The relevant Heater Current 1 Value Monitor or Leakage Current 1 Monitor parameters in the Operation or Adjustment Level will flash on the No. 1 display. However, control continues and operation is normal.

# - - - - Ambient Temperature Monitor Out of Range

# Meaning

If the temperature is out of range for the Ambient Temperature Monitor parameter, ---- is displayed.

- If the temperature unit is °C, this error occurs when the ambient temperature is less than -30°C or greater than 75°C.
- If the temperature unit is °F, this error occurs when the ambient temperature is less than 10°F or greater than 171°F.

# Action

Make sure that the ambient temperature of the Digital Controller is within the rated range.

- The Controller is subjected to heat radiated from heating equipment.
- The Controller is subjected to direct sunlight.
- The Controller is subjected to icing or condensation.

# Operation

Control continues and operation is normal.

# **Troubleshooting A-6**

# **Checking Problems**

If the Digital Controller is not operating normally, check the following points before requesting repairs. If the problem persists, contact your OMRON representative for details on returning the product.

Timing	Status	Meaning	Countermeasures	Page
Turning	Temperature error is	Input type mismatch	Check the sensor type and reset the input type correctly.	4-12
ON the power for	large. Input error (S.Err display)	Thermometer is not installed properly.	Check the thermometer installation location and polarity and install correctly.	2-10, 2-18
the first time	Communications are not possible.	Non-recommended adapter is being used.	Make sure that the connected device is not faulty.	*
During operation	Hunting ON/OFF control selected).		4-24	
		Control period is longer compared with the speed of rise and fall in temperature.	Shorten the control period. A shorter control period improves control performance, but a cycle of 20 ms minimum is recommended in consideration of the service life of the relays.	4-15
		Unsuitable PID constant	Set appropriate PID constants using either of the following methods.  • Execute AT (autotuning).  • Set PID constants individually using manual settings.	4-24
		HS alarm operation fault	Use breeder resistance if the problem is due to leakage current. Also investigate the errors detected by the HS alarm function.	4-41
		The power supply to the load (e.g., heater) was turned ON or OFF during tuning.	During tuning,* ensure that the power for the load (e.g., heater) is ON. Otherwise, the correct tuning result cannot be calculated and optimal control will not be possible.  * "Tuning" refers to the following functions: AT, adaptive control, automatic filter adjustment, and water-cooling output adjustment.	
	Temperature is not rising	Specified operation is unsuitable for required control (default: Reverse operation).	Select either forward or reverse operation depending on the required control. Reverse operation is used for heating operations.	4-15
		Heater is burnt out or deteriorated.	Check whether heater burnout or deterioration have occurred. Also investigate the errors detected by the heater burnout alarm.	4-38
		Insufficient heater capacity	Check whether the heater's heating capacity is sufficient.	
		Cooling system in operation.	Check whether a cooling system is operating.	
		Peripheral devices have heat prevention device operating.	Set the heating prevention temperature setting to a value higher than the set temperature of the Digital Controller.	
	The AT Execute/Cancel parameter (#E) is not	ON/OFF control is enabled.	Set the PID ON/OFF parameter to PID.	6-43
	displayed.	The Controller is stopped.	Set the RUN/STOP parameter to RUN.	6-12
	The Alarm 1 Type parameter (RLE I) is not displayed.	The Auxiliary Output 1 Assignment parameter is set to a heater alarm for a Controller with heater burnout detection.	Set the Auxiliary Output 1 Assignment parameter to Alarm 1. The default setting is for a heater alarm (HA).	6-82

Refer to the E5 D Digital Controllers Communications Manual (Cat. No. H225) for details.

Timing	Status	Mooning	Countermonaures	Dogo
Timing During	Output will not turn ON	Meaning Set to STOP (default:	Countermeasures  Set the RUN/STOP mode to RUN. If STOP is lit on the	<b>Page</b> 5-36
operation	Output will not turn ON	RUN)	display, control is stopped.	3-30
(continued)		Specified operation is unsuitable for required control (default: Reverse operation).	Select either forward or reverse operation depending on the required control. Reverse operation is used for heating operations.	4-15
		A high hysteresis is set for ON/OFF operation (default: 1.0°C)	Set a suitable value for the hysteresis.	4-21
		The specified power is not being supplied from the terminals.	The output will not turn ON while the Digital Controller is being operated with power supplied through the USB-Serial Conversion Cable. Supply the specified power from the terminals.	
	Digital Controller will not operate	Set to STOP (default: RUN)	Set the RUN/STOP mode to RUN. If STOP is lit on the display, control is stopped.	5-36
	Temperature error is large	Thermometer has burnt out or short-circuited.	Check whether the thermometer has burnt out or short-circuited.	
	Input error (S.err display)	Thermometer lead wires and power lines are in the same conduit, causing noise from the power lines (generally, display values will be unstable).	Wire the lead wires and power lines in separate conduits, or wire them using a more direct path.	
		Connection between the Digital Controller and thermocouple is using copper wires.	Connect the thermocouple's lead wires directly, or connect compensating conductors that are suitable for the thermocouple.	
		Installation location of thermometer is unsuitable.	Make sure that the location that is being measured with the temperature sensor is suitable.	
		Input shift is not set correctly (default: 0.0°C)	Set a suitable input shift. If input shift is not required, set the input shift value to 0.0.	5-25
	Keys will not operate	Setting change protect is ON.	Turn OFF setting change protect.	5-43
	Cannot shift levels	Operations limited due to protection.	Set the operation/adjustment protect, initial setting/communications protect, and setting change protect values as required.	5-44
After long service life	Control is unstable	Terminal screws may be loose.	Retighten terminal screws to a torque of 0.43 to 0.58 N·m.	2-25
		The internal components have reached the end of their service life.	The Digital Controller's internal electrolytic capacitor depends on the ambient temperature, and load rate. The structural life depends on the ambient environment (shock, vibration). The life expectancy of the output relays varies greatly with the switching capacity and other switching conditions. Always use the output relays within their rated load and electrical life expectancy. If an output relay is used beyond its life expectancy, its contacts may become welded or burned. Replace the Digital Controller and all other Digital Controllers purchased in the same time period.	

# **Symptom: Cannot Communicate or a Communications Error Occurs**

Meaning	Countermeasures
The communications wiring is not correct.	Correct the wiring.
The communications line has become disconnected.	Connect the communications line securely and tighten the screws.
The communications cable is broken.	Replace the cable.
The communications cable is too long.	The total cable length for RS-485 is 500 m max.
The wrong communications cable has been used.	Use shielded twisted-pair cable for the communications cable. For detailed wire specifications, refer to 2-2-5 Precautions when Wiring.
More than the specified number of	When 1:N communications are used, a maximum of 32 nodes may be
communications devices are connected to the same communications path.	connected, including the host node.
An end node has not been set at each end of the communications line.	Set or connect terminating resistance at each end of the line. If the E5 $\square$ D is the end node, 120- $\Omega$ (1/2-W) terminating resistance is used. Be sure that the combined resistance with the host device is 54 $\Omega$ minimum.
The specified power supply voltage is not being supplied to the Digital Controller.	Supply the specified power supply voltage.
The specified power supply voltage is not being supplied to an Interface Converter (such as the K3SC).	Supply the specified power supply voltage.
The same baud rate and communications method are not being used by all of the Digital Controllers, host devices, and other devices on the same communications line.	Set the same values for the baud rate, protocol, data length, stop bits, and parity on all nodes.
The unit number specified in the command frame is different from the unit number set by the Digital Controller.	Use the same unit number.
The same unit number as the Digital Controller is being used for another node on the same communications line.	Set each unit number for only one node.
There is a mistake in programming the host device.	Use a line monitor to check the commands. Check operation using a sample program.
The host device is detecting the absence of a response as an error before it receives the response from the Digital Controller.	Shorten the send data wait time in the Digital Controller or increase the response wait time in the host device.
The host device is detecting the absence of a response as an error after broadcasting a command.	The Digital Controller does not return responses for broadcast commands.
The host device sent another command before receiving a response from the Digital Controller.	The response must always be read after sending a command (except for broadcast commands).
The host device sent the next command too soon after receiving a response from the Digital Controller.	After receiving a response, wait at least 2 ms before sending the next command.
The communications line became unstable when Digital Controller power was turned ON or interrupted, and the host device read the unstable status as data.	Initialize the reception buffer in the host device before sending the first command and after turning OFF the power to the Digital Con troller.
The communications data was corrupted from noise from the environment.	Try using a slower baud rate. Separate the communications cable from the source of noise. Use a shielded, twisted-pair cable for the communications cable. Use as short a communications cable as possible, and do not lay or loop extra cable. To prevent inductive noise, do not run the communications cable parallel to a power line. If noise countermeasures are difficult to implement, use an Optical Interface.

Refer to the *E5*\_D Digital Controllers Communications Manual (Cat. No. H225) for details on errors.

# **A-7** Parameter Operation Lists

# A-7-1 Operation Level

Parameters	Characters	Setting (monitor) value	Display	Default	Unit
Process Value		Temperature: According to indication range for each sensor.  Analog: Scaling lower limit  -5% FS to Scaling upper limit +5% FS			EU
Set Point		SP lower limit to SP upper limit		0	EU
Multi-SP Set Point Selection	M-5P	0 to 7		0	None
Set Point During SP Ramp	SP-M	SP lower limit to SP upper limit			EU
Heater Current 1 Value Monitor	[F I	0.0 to 55.0			Α
Leakage Current 1 Monitor	LERI	0.0 to 55.0			Α
Program Start	PRSE	RSET, STRT	RSEE, SERE	RSET	None
Soak Time Remain	SKER	0 to 9999			s, min, or h
RUN/STOP	R-5	RUN/STOP	RUN, SEGP	Run	None
Alarm Value 1	AL - I	All alarms except for MV absolute-value upper-limit or lower-limit alarms: –1,999 to 9,999		0	EU
		MV absolute-value upper-limit or lower-limit alarms: –199.9 to 999.9		0.0	%
Alarm Value Upper Limit 1	AL IH	-1,999 to 9,999		0	EU
Alarm Value Lower Limit 1	AL IL	-1,999 to 9,999		0	EU
Alarm Value 2	AL - 2	All alarms except for MV absolute-value upper-limit or lower-limit alarms: -1,999 to 9,999		0	EU
		MV absolute-value upper-limit or lower-limit alarms: -199.9 to 999.9		0.0	%
Alarm Value Upper Limit 2	RL2H	-1,999 to 9,999		0	EU
Alarm Value Lower Limit 2	RL2L	-1,999 to 9,999		0	EU
Alarm Value 3	RL - 3	All alarms except for MV absolute-value upper-limit or lower-limit alarms: -1,999 to 9,999		0	EU
		MV absolute-value upper-limit or lower-limit alarms: –199.9 to 999.9		0.0	%
Alarm Value Upper Limit 3	AL 3H	-1,999 to 9,999		0	EU
Alarm Value Lower Limit 3	RL3L	-1,999 to 9,999		0	EU
Alarm Value 4	AL - 4	All alarms except for MV absolute-value upper-limit or lower-limit alarms: -1,999 to 9,999		0	EU
		MV absolute-value upper-limit or lower-limit alarms: -199.9 to 999.9		0.0	%
Alarm Value Upper Limit 4	AL YH	-1,999 to 9,999		0	EU
Alarm Value Lower Limit 4	AL YL	-1,999 to 9,999		0	EU
MV Monitor (Heating)	ō	-5.0 to 105.5 (standard) 0.0 to 105.0 (heating/cooling)			%
MV Monitor (Cooling)	E-ā	0.0 to 105.0			%

## A-7-2 **Adjustment Level**

Parameters	Characters	Setting (monitor) value	Display	Default	Unit
Adjustment Level	L.AdJ				
Display					
AT Execute/Cancel	RE	OFF, AT Cancel AT-2: 100%AT Execute	āFF, AĿ-2, AĿ- I	OFF	None
		AT-1: 40%AT Execute  AT-1: 40%AT Execute*  AT-1: 40%AT Execute*  AT-1: 40%AT Execute*	חביו		
Communications	EMWE	OFF, ON	ōFF, ōN	OFF	None
Writing	LIIME	OFF, ON	ן נו ו , נווי	OFF	None
Heater Current 1 Value	EE I	0.0 to 55.0			Α
Monitor					
Heater Burnout	НЬ І	0.0 to 50.0		0.0	Α
Detection 1					
Leakage Current 1 Monitor	LERI	0.0 to 55.0			Α
HS Alarm 1	H5 I	0.0 to 50.0		50.0	Α
SP 0	5P-0	SP lower limit to SP upper limit		0	EU
SP 1	5P-1	SP lower limit to SP upper limit		0	EU
SP 2	5P-2	SP lower limit to SP upper limit		0	EU
SP 3	5P-3	SP lower limit to SP upper limit		0	EU
SP 4	5P-4	SP lower limit to SP upper limit		0	EU
SP 5	5P-5	SP lower limit to SP upper limit		0	EU
SP 6	5P-6	SP lower limit to SP upper limit		0	EU
SP 7	5P-7	SP lower limit to SP upper limit		0	EU
Process Value Input	īN5	Temperature input: -199.9 to 999.9		0.0	°C or °F
Shift		Analog input: –1,999 to 9,999		0	EU
Process Value Slope	INRE	0.001 to 9.999		1.000	None
Coefficient					
Automatic Filter	FR	OFF, ON	āFF, āN	OFF	None
Adjustment					
Input Digital Filter	INF	0.0 to 999.9		0.0	Seconds
PID Update (Adaptive Control)	R-Ud	OFF, ON	āFF,āN	OFF	None
Water-cooling Output Adjustment	W-HE	OFF, ON	āFF, āN	OFF	None
Water-cooling	M-IL	Water-cooling proportional band decrease		1.4	°C or °F
Proportional Band		threshold + 0.1 to 200.0			
Increase Threshold		0. 14			
Water-cooling Proportional Band	W-dL	0 to Water-cooling proportional band increase threshold - 0.1		0.6	°C or °F
Decrease Threshold		uneshold - 0.1			
Proportional Band	Р	Temperature input: 0.1 to 999.9		8.0	°C
·				14.4	°F
		Analog input: 0.1 to 999.9		10.0	%FS
Integral Time	L	Integral/Derivative Time Unit of 1 s: 0 to 9,999		233	Seconds
		Integral/Derivative Time Unit of 0.1 s: 0.0 to 999.9		233.0	
Derivative Time	В	Integral/Derivative Time Unit of 1 s: 0 to 9,999		40	Seconds
		Integral/Derivative Time Unit of 0.1 s: 0.0 to 999.9		40.0	
Proportional Band	[-P	Temperature input: 0.1 to 999.9		8.0	°C
(Cooling)				14.4	°F
		Analog input: 0.1 to 999.9		10.0	%FS
Integral Time (Cooling)	[-[	Integral/Derivative Time Unit of 1 s: 0 to 9,999		233	Seconds
		Integral/Derivative Time Unit of 0.1 s: 0.0 to 999.9		233.0	
Derivative Time	[-d	Integral/Derivative Time Unit of 1 s: 0 to 9,999		40	Seconds
(Cooling)		Integral/Derivative Time Unit of 0.1 s: 0.0 to 999.9		40.0	
SP Response	5P-P	0.1 to 999.9		8.0	°C
Proportional Band				14.4	°F
SP Response Integral	5P-Z	Integral/Derivative Time Unit of 1 s: 0 to 9,999		233	Seconds
Time		Integral/Derivative Time Unit of 0.1 s: 0.0 to 999.9		233.0	

Parameters	Characters	Setting (monitor) value	Display	Default	Unit
SP Response	5P-d	Integral/Derivative Time Unit of 1 s: 0 to 9,999		40	Seconds
Derivative Time		Integral/Derivative Time Unit of 0.1 s: 0.0 to 999.9		40.0	
SP Response Coefficient Number	5P-N	0 to 9999		0	None
Disturbance	d-P	0.1 to 999.9		8.0	°C
Proportional Band				14.4	°F
Disturbance Integral	d-ī	Integral/Derivative Time Unit of 1 s: 0 to 9,999		233	Seconds
Time		Integral/Derivative Time Unit of 0.1 s: 0.0 to 999.9		233.0	
Disturbance Derivative	d-d	Integral/Derivative Time Unit of 1 s: 0 to 9,999		40	Seconds
Time		Integral/Derivative Time Unit of 0.1 s: 0.0 to 999.9		40.0	
Dead Band	[-db	Temperature input: -199.9 to 999.9		0.0	°C or °F
		Analog input: -19.99 to 99.99		0.00	%FS
Manual Reset Value	ōF-R	0.0 to 100.0		50.0	%
Hysteresis (Heating)	H42	Temperature input: 0.1 to 999.9		1.0	°C
				1.8	°F
		Analog input: 0.01 to 99.99		0.10	%FS
Hysteresis (Cooling)	CH95	Temperature input: 0.1 to 999.9		1.0	°C
				1.8	°F
		Analog input: 0.01 to 99.99		0.10	%FS
Soak Time	SāAK	1 to 9999		1	min, h, or s
Wait Band	ME-P	Temperature input: OFF or 0.1 to 999.9	āFF, 0. I to 999.9	OFF	°C or °F
		Analog input: OFF, 0.01 to 99.99	ōFF, 0.0 I to 99.99	OFF	%FS
MV at Stop	MV -5	Standard: -5.0 to 105.0 Heating/cooling: -105.0 to 105.0		0.0	%
MV at PV Error	MV -E	Same as the MV at Stop parameter.		0.0	%
SP Ramp Set Value	SPRE	OFF, 1 to 9,999	ōFF, I to 9999	OFF	EU/s, EU/min, EU/h
SP Ramp Fall Value	SPRL	SAME, OFF, or 1 to 9,999	5AME, öff, I to 9999	SAME	EU/s, EU/min, EU/h
MV Upper Limit	ōL -H	Standard control: MV lower limit + 0.1 to 105.0 Heating/cooling control: 0.0 to 105.0		100.0	%
MV Lower Limit	āL-L	Standard control: -5.0 to MV upper limit - 0.1		0.0	%
		Heating/cooling control: -105.0 to 0.0		-100.0	
MV Change Rate Limit	āRL	0.0 to 100.0 (0.0: MV Change Rate Limit Disabled)		0.0	%/s
Extraction of Square Root Low-cut Point	SORP	0.0 to 100.0		0.0	%
Work Bit * ON Delay	₩ I to BāN	0 to 9999		0	Seconds
Work Bit * OFF Delay	₩ I to 8āF	0 to 9999		0	Seconds
Communications Monitor	PLEM	0 to 9999			ms

<sup>\*1</sup> This parameter is not displayed for heating/cooling control.

Parameters	Characters	Setting (monitor) value		Display	Default	Unit
Input Type	EN-E	Temperature input	0: Pt100 1: Pt100 2: Pt100 3: JPt100 4: JPt100 5: K 6: K 7: J 8: J 9: T 10: T 11: E 12: L 13: U 14: U 15: N 16: R 17: S 18: B 19: C/W 20: PLII 21: 10 to 70°C 22: 60 to 120°C 23: 115 to 165°C	Display	5	None
		Analog input	24: 140 to 260°C 25: 4 to 20 mA 26: 0 to 20 mA 27: 1 to 5 V 28: 0 to 5 V 29: 0 to 10 V		5	None
Scaling Upper Limit	ĪN-H	Scaling lower I	imit + 1 to 9,999		100	None
Scaling Lower Limit	īN-L	-	ng upper limit –1		0	None
Decimal Point	dР	0 to 3			0	None
Temperature Unit	d-U	°C, °F		[,F	°C	None
SP Upper Limit	SL -H	range upper lir	nput: SP lower limit + 1 to Input setting mit SP lower limit + 1 to scaling upper limit		1300	EU
SP Lower Limit	5L -L	Temperature in SP upper limit	nput: Input setting range lower limit to		-200 0	EU
PID ON/OFF	ENEL	ON/OFF 2-PID	)	ōNōF, Pīd	2-PID control	None
Standard or Heating/Cooling	5-HE	Standard or he		SENd, H-C	Standard	None
Adaptive Control	RdPt	OFF: Disabled FIX: Fixed INFO: Notificat AUTO: Automa	tion	ōFF,Fī×, ∑NFō,RUĿō	OFF	None
Model Creation PV Amplitude	M-PV	0.00 to 99.99			0.00	%FS
Model Creation MV Amplitude	M-MV	0.0 to 100.0			0.0	%FS
Model Creation ON Time	M-āN	0 to 9999			0	
Model Creation OFF Time	M-ōF	0 to 9999			0	
Program Pattern	PERN	OFF, STOP, C	CONT	ōFF, SŁōP, CōNŁ	OFF	None

Parameters Characters		Setting (monitor) value	Display	Default	Unit
Control Period (Heating)	EP .	0.1, 0.2, 0.5, or 1 to 99	0.1,0.2,0.5,1 to 99	Relay output: 20 Voltage output (for driving SSR): 2	Seconds
Control Period (Cooling)	Е-ЕР	0.1, 0.2, 0.5, or 1 to 99	0. I, 0.2, 0.5, I to 99	Relay output: 20 Voltage output (for driving SSR): 2	Seconds
Direct/Reverse Operation	āREV	Reverse operation, direct operation	āR-R, āR-d	Reverse operation	None
Alarm 1Type	RLE I	O: Alarm function OFF  1: Upper and lower-limit alarm  2: Upper-limit alarm  3: Lower-limit alarm  4: Upper and lower-limit range alarm  5: Upper- and lower-limit alarm with standby sequence  6: Upper-limit alarm with standby sequence  7: Lower-limit alarm with standby sequence  8: Absolute-value upper-limit alarm  9: Absolute-value lower-limit alarm  10: Absolute-value upper-limit alarm with standby sequence  11: Absolute-value lower-limit alarm with standby sequence  12: LBA (Loop Burnout Alarm)  13: PV change rate alarm  14: SP absolute-value upper-limit alarm  15: SP absolute-value lower-limit alarm  16: MV absolute-value upper-limit alarm  17: MV absolute-value lower-limit alarm		2	None
Alarm 1 Hysteresis	ALH I	Temperature input: 0.1 to 999.9 for all alarms except		0.2	°C
·		for MV absolute-value upper-limit or MV lower-limit alarms		0.4	°F
		Analog input: 0.01 to 99.99 for all alarms except for MV absolute-value upper-limit or MV lower-limit alarms		0.02	%FS
		0.01 to 99.99 for MV absolute-value upper-limit or MV lower-limit alarms		0.50	%
Alarm 2 Type	ALE2	Same as Alarm 1 Type except that 12 (LBA) cannot be set.		2	None
Alarm 2 Hysteresis	ALH2	Temperature input: 0.1 to 999.9 for all alarms except for MV absolute-value upper-limit or MV lower-limit alarms		0.2	°C °F
		Analog input: 0.01 to 99.99 for all alarms except for MV absolute-value upper-limit or MV lower-limit alarms		0.02	%FS
		0.01 to 99.99 for MV absolute-value upper-limit or MV lower-limit alarms		0.50	%
Alarm 3 Type	ALE3	Same as Alarm 1 Type except that 12 (LBA) cannot be set.		2	None
Alarm 3 Hysteresis	ALH3	Temperature input: 0.1 to 999.9 for all alarms except for MV absolute-value upper-limit or MV lower-limit alarms		0.2	°C °F
		Analog input: 0.01 to 99.99 for all alarms except for MV absolute-value upper-limit or MV lower-limit alarms		0.02	%FS
		0.01 to 99.99 for MV absolute-value upper-limit or MV lower-limit alarms		0.50	%
Alarm 4 Type	ALEY	Same as Alarm 1 Type except that 12 (LBA) cannot be set.		2	None

Parameters	Characters	Setting (monitor) value	Display	Default	Unit	
Alarm 4 Hysteresis	ALHY	Temperature input: 0.1 to 999.9 for all alarms except		0.2	°C	
		for MV absolute-value upper-limit or MV lower-limit alarms		0.4	°F	
		Analog input: 0.01 to 99.99 for all alarms except for		0.02	%FS	
		MV absolute-value upper-limit or MV lower-limit alarms				
		0.01 to 99.99 for MV absolute-value upper-limit or MV lower-limit alarms		0.50	%	
Control Output 1 Signal	ā 15E	4-20: 4-20 mA 0-20: 0-20 mA	4-20, 0-20	4-20	None	
Transfer Output Signal	ER5E	4-20: 4-20 mA 1-5: 1-5 V	4-20, I-SV	OFF	None	
Transfer Output Type	ŁR-Ł	OFF: OFF	ōFF			
000		SP: Set point	5 <i>P</i>			
		SP-M: Ramp set point	5P-M			
		PV: Process value	Pl' Ml'			
		MV: MV (heating)	E-MV			
		CMV: MV (cooling) (Supported only for heating/cooling control.)	[ - 11v			
Transfer Output Upper	ER-H	*5		*5	*5	
Limit 000						
Transfer Output Lower	ER-L	*5		*5	*5	
Limit 000	Eu '	NONE No.	N-NE	MODO	l N	
Event Input	EV - 1	NONE: None	NANE	MSP0	None	
Assignment 1		STOP: RUN/STOP	SE GP			
		MANU: Auto/Manual Switch	MRNU			
		PRST: Program Start *1	PR5E			
		DRS: Invert Direct/Reverse Operation	dR5			
		NONE: None	NāNE			
		AT-2: 100% AT Execute/Cancel	AF-5			
		AT-1: 40% AT Execute/Cancel *2	AL-I			
		WTPT: Setting Change Enable/Disable	WEPE			
		Communications Writing Enable/Disable (Communi-	EMWE			
		cations must be supported.)				
		LAT: Alarm Latch Cancel	LAE			
		MSP0: Multi-SP No. switching bit 0	MSPO			
		MSP1: Multi-SP No. switching bit 1	MSP I			
		MSP2: Multi-SP No. switching bit 2	MSP2			
		RUN: STOP/RUN	RUN			
		A-UD: PID Update (Adaptive Control)	A-Ud			
		FA: Automatic Filter Adjustment	FA			
		W-HT: Water-cooling Output Adjustment	W-HE		1	
Event Input Assignment 2	EV-2	Same as Event Input Assignment 1.	Same as Event Input	STOP	None	
2 <b>32</b>			Assignment 1.			
Event Input	EV - 3	Same as Event Input Assignment 1.	Same as	NONE	None	
Assignment 3			Event Input Assignment 1.			
Event Input	EV-4	Same as Event Input Assignment 1.	Same as	NONE	None	
Assignment 4		-	Event Input Assignment 1.			
Event Input Assignment 5	EV -5	Same as Event Input Assignment 1.	Same as Event Input Assignment 1.	NONE	None	
Event Input Assignment 6	EV - 6	Same as Event Input Assignment 1.	Same as Event Input	NONE	None	
			Assignment 1.			
Extraction of Square Root Enable	SOR	OFF: ON	āFF, āN	OFF(0)	None	

Parameters	Characters	Setting (monitor) value	Display	Default	Unit
Operation After Power ON	P-ōN	CONT: Continue STOP: Stop MANU: Manual	CōNŁ SŁōP MANU	CONT	None
Bar Display Data	ЬAR	OFF: Nothing displayed. MV: MV (heating) C-MV: MV (cooling) CT-1: Heater current 1	ōFF MV E-MV EE-1	MV*3	
Bar Display Scaling Upper Limit	ЬЯРH	-199.9 to 999.9		100.0*4	• For MV (heating) or MV (cooling):
Bar Display Scaling Lower Limit	6ARL	-199.9 to 999.9		0.0	% • For heater current: A
Move to Advanced function Setting Level	AMēV	-1,999 to 9,999		0	None

- \*1 PRST (Program Start) can be set even when the Program Pattern parameter is set to OFF, but the function will be disabled.
- \*2 This function can be set for heating/cooling control, but the function will be disabled.
- \*3 The default value for the E5 $\square$ D- $\square$ -8 $\square$  is [-1] (Heater current 1).
- \*4 The default value for the E5 $\square$ D- $\square$ -8 $\square$  is 50.0.

\*5

Transfer output type	Setting (monitor) range	Default*3.1 (transfer output upper/lower limits)	Unit
Set Point	SP lower limit to SP upper limit	SP upper limit/lower limit	EU
Set Point During SP Ramp	SP lower limit to SP upper limit	SP upper limit/lower limit	EU
PV	Temperature input: Input setting range lower limit to Input setting range upper limit	Input setting range upper/lower limit	EU
	Analog input: Scaling lower limit to Scaling upper limit	Scaling upper/lower limit	
MV (Heating)	Standard: -5.0 to 105.0 Heating/cooling: 0.0 to 105.0	100.0/0.0	%
MV (Cooling)	0.0 to 105.0	100.0/0.0	%

<sup>\*3.1</sup> Initialized when the transfer output type is changed.

Initialized if the input type, temperature unit, scaling upper/lower limit, or SP upper/lower limit is changed when the transfer output type is SP, ramp SP, or PV.

(When initialized by the initializing settings, it is initialized to 100.0/0.0.)

#### **Manual Control Level** A-7-4

Parameters	Setting (monitor) value	Default	Unit
Manual MV	-5.0 to 105.0 (standard)*	0.0	%
	-105.0 to 105.0 (heating/cooling)*		

When the Manual MV Limit Enable parameter is set to ON, the setting range will be the MV lower limit to the MV upper

#### **Monitor/Setting Item Level** A-7-5

The contents displayed vary depending on the Monitor/Setting 1 to 5 (advanced function setting level) setting.

#### **Advanced Function Setting Level** A-7-6

Parameters	Characters	Setting (monitor) value	Display	Default	Unit	
Parameter Initialization	īNīE	OFF, FACT	ōFF, FRCŁ	OFF	None	
Number of Multi-SP	MSPU	OFF, 2 to 8	ōFF, 2 to 8	OFF	None	
Points						
SP Ramp Time Unit	SPRU	S: EU/second	5, M, H	М	None	
		M: EU/minute				
	0.7.5	H: EU/hour				
Standby Sequence Reset	RESE	Condition A, condition B	Я, Ь	Condition A	None	
Auxiliary Output 1	Sb IN	N-O: Close in alarm	N-ā, N-E	N-O	None	
Open in Alarm		N-C: Open in alarm				
Auxiliary Output 2	562N	N-O: Close in alarm	N-ā, N-E	N-O	None	
Open in Alarm		N-C: Open in alarm				
Auxiliary Output 3	563N	N-O: Close in alarm	N-ā, N-E	N-O	None	
Open in Alarm		N-C: Open in alarm				
Auxiliary Output 4	SBYN	N-O: Close in alarm	N-ā, N-E	N-O	None	
Open in Alarm		N-C: Open in alarm				
HB ON/OFF	НЬШ	OFF, ON	ōFF, ōN	ON	None	
Heater Burnout Latch	HЬL	OFF, ON	ōFF, ōN	OFF	None	
Heater Burnout Hysteresis	НЬН	0.1 to 50.0		0.1	А	
α	ALFA	0.00 to 1.00		0.65	None	
Integral/Derivative Time Unit	FīdU	1, 0.1	1, 0.1	1	Second	
AT Calculated Gain	AF-0	0.1to 10.0		0.8	None	
AT Hysteresis	AF - H	Temperature input: 0.1 to 999.9		0.8	°C	
,				1.4	°F	
		Analog input: 0.01 to 9.99		0.20	%FS	
Limit Cycle MV	LEMA	5.0 to 50.0		20.0	%	
Amplitude  Moving Average Count	MAV	OFF, 2, 4, 8, 16, or 32		o==*5	Times	
<u> </u>			755 / 88	OFF <sup>*5</sup>		
Automatic Display Return Time	REŁ	OFF, 1 to 99	ōFF, 1 to 99	OFF	Second	
Display Brightness	<i><b>LRGE</b></i>	1 to 3		3	None	
Alarm 1 Latch	AILE	OFF, ON	āFF, āN	OFF	None	
Alarm 2 Latch	R2LE	OFF, ON	āFF, āN	OFF	None	
Alarm 3 Latch	R3LE	OFF, ON	ōFF, ōN	OFF	None	
Alarm 4 Latch	RYLE	OFF, ON	āFF, āN	OFF	None	
Move to Protect Level Time	PRLE	1 to 30	-	3	Second	
Cold Junction Compensation Method	ЕЛЕ	OFF, ON	āFF, āN	ON	None	
Alarm 1 ON Delay	A IāN	0 to 999 (0: ON delay disabled)		0	Second	
Alarm 2 ON Delay	RZāN	0 to 999 (0: ON delay disabled)		0	Second	

Parameters Characters		Setting (monitor) value	Display	Default	Unit
Alarm 3 ON Delay	RaōN	0 to 999 (0: ON delay disabled)		0	Second
Alarm 4 ON Delay	RYŌN	0 to 999 (0: ON delay disabled)		0	Second
Alarm 1 OFF Delay	R IĞF	0 to 999 (0: OFF delay disabled)		0	Second
Alarm 2 OFF Delay	R26F	0 to 999 (0: OFF delay disabled)	0	Second	
Alarm 3 OFF Delay	R36F	0 to 999 (0: OFF delay disabled)	0	Second	
Alarm 4 OFF Delay	RYōF	0 to 999 (0: OFF delay disabled)	0	Second	
Manual Output Method	MANE	HOLD or INIT	HāLd, īNīŁ	HOLD	None
Manual MV Initial	MANE	-5.0 to 105.0 for standard control *1		0.0	%
Value		-105.0 to 105.0 for heating/cooling control *1			
RT	RE	OFF, ON	āFF, āN	OFF	None
HS Alarm Use	н50	OFF, ON	āFF, āN	ON	None
HS Alarm Latch	HSL	OFF, ON	āFF, āN	OFF	None
HS Alarm Hysteresis	Н5Н	0.1 to 50.0	,	0.1	A
LBA Detection Time	LЬЯ	0 to 9999 (0: LBA function disabled)		0	Second
LBA Level	LBAL	Temperature input: 0.1 to 999.9		8.0	°C
				14.4	°F
		Analog input: 0.01 to 99.99		10.00	%FS
LBA Band	LBAB	Temperature input: 0.0 to 999.9		3.0	°C
		·		5.4	°F
		Analog input: 0.00 to 99.99		0.20	%FS
Control Output 1	ōUE I	Relay Output or Voltage Output (for Driving SSR) *4		0	None
Assignment		NONE: None	NāNE		
		O: Control output (heating)	ō		
		C-O: Control output (cooling)	E-ā		
		ALM1: Alarm 1	ALM I		
		ALM2: Alarm 2	ALM2		
		ALM3: Alarm 3	RLM3		
		ALM4: Alarm 4	ALM4		
		HA: Heater alarm (HB + HS)	HR		
		HB: Heater burnout alarm (HB)	НЬ		
		HS: Heater short alarm (HS)	HS		
		S.ERR: Input error	S.ERR		
		NONE: None	NāNE		
		P.END: Program End output *2	P.ENd		
		RUN: RUN output	RUN		
		ALM: Integrated alarm	RLM		
		WR1: Work bit 1 *3	WR I		
			WR2		
		WR2: Work bit 2 *3			
		WR3: Work bit 3 *3	WR3		
		WR4: Work bit 4 *3	WRY		
		WR5: Work bit 5 *3	WR5		
		WR6: Work bit 6 *3	WRE		
		WR7: Work bit 7 *3	WR7		
			WR8		
		WR8: Work bit 8 *3	MUCI		
		For Linear Current Output *4			
		NONE : Not assigned.	NāNE		
		O: Control output (heating)	ō		
	]	C-O: Control output (cooling)	[-ō		

Parameters Characters		Setting (monitor) value	Display	Default	Unit	
Control Output 2	gNF5	Same as for the Control Output 1 Assignment	Same as for	NONE	None	
Assignment		parameter except for the setting (monitor) value	the Control			
		marked with *2.	Output 1 Assignment			
			parameter			
			except for the			
			setting			
			(monitor)			
			value marked			
			with *2.			
Auxiliary Output 1	5U6 I	NONE: None	NāNE	ALM1	None	
Assignment		O: Control output (heating)	ō	*Digital		
		C-O: Control output (cooling)	[ -ā	Controllers without HB		
		ALM1: Alarm 1	ALM I	and HS		
		ALM2: Alarm 2	ALM2	alarm		
		ALM3: Alarm 3	ALM3	detection:		
		ALM4: Alarm 4	ALMY	HA		
		HA: Heater alarm (HB + HS)	HR			
		HB: Heater burnout alarm (HB)	НЬ			
		HS: Heater short alarm (HS)	н5			
		S.ERR: Input error	5.E.R.R			
		NONE: None	NāNE			
			P.ENd			
		P.END: Program end output *2				
		RUN: RUN output	RUN			
		ALM: Integrated alarm	ALM			
		WR1: Work bit 1 *3	WR I			
		WR2: Work bit 2 *3	WR2			
		WR3: Work bit 3 *3	WR3			
			WR4			
		WR4: Work bit 4 *3				
		WR5: Work bit 5 *3	WR5			
		WR6: Work bit 6 *3	WR5			
		WR7: Work bit 7 *3	WR7			
		WR8: Work bit 8 *3	WR8			
Associtions Output 0	SU62	Same as the Auxiliary Output 1 Assignment		ALM2	None	
Auxiliary Output 2 Assignment	3000	parameter.	Same as the Auxiliary	ALIVIZ	None	
Assignment		parameter.	Output 1			
			Assignment			
			parameter.			
Auxiliary Output 3	SU63	Same as the Auxiliary Output 1 Assignment	Same as the	ALM3	None	
Assignment		parameter.	Auxiliary			
			Output 1			
			Assignment			
	5.0.0		parameter.		1	
Auxiliary Output 4	5064	Same as the Auxiliary Output 1 Assignment	Same as the	ALM4	None	
Assignment		parameter.	Auxiliary Output 1			
			Assignment			
			parameter.			
Integrated Alarm	ALMA	0 to 255		49	None	
Assignment		Alarm 1: +1				
-		Alarm 2: +2				
		Alarm 3: +4				
		Alarm 4: +8				
		HB alarm: +16				
		HS alarm: +32 Input error: +64				
		+128: (Not used)				
Soak Time Unit	E-U	M: Minutes	M, H, 5	M	None	
Soak Time Utill	E - U	H: Hours	11, 11, 12	IVI	INOTIE	
		S: Seconds				
Alarm SP Selection	AL SP	SP-M: Ramp set point	5P-M, 5P	SP-M	None	
		SP: Set point	= · · · · · · · · · · ·	1	1	

Parameters Characters		Setting (monitor) value	Display	Default	Unit	
Manual MV Limit Enable	MANL	OFF, ON	ōFF, ōN	OFF	None	
PV Rate of Change Calculation Period	PI; RP	1 to 999		20 (1S)	Sampling period	
Heating/Cooling Tuning Method	HEFW	0: Same as heating control 1: Linear 2: Air cooling 3: Water cooling		0	None	
Minimum Output ON/OFF Band	ōMPU	0.0 to 50.0		1.0	%	
PF Setting	PF	OFF: OFF RUN: RUN STOP: STOP R-S: RUN/STOP AT-2: 100% AT execute/cancel AT-1: 40% AT execute/cancel LAT: Alarm Latch Cancel A-M: Auto/manual PFDP: Monitor/setting item SHFT: Digit Shift Key A-UD: PID Update (Adaptive Control) FA: Automatic Filter Adjustment W-HT: Water-cooling Output Adjustment	FR  FR  FR  FR  FR  FR  FR  W-HE	SHFT	None	
Monitor/Setting Item 1	PFd I	0: Disabled 1: PV/SP/Multi-SP 2: PV/SP/MV (Heating) 3: PV/SP/Soak time remain 4: Proportional band (P) 5: Integral time (I) 6: Derivative time (D) 7: Alarm value 1 8: Alarm value upper limit 1 9: Alarm value lower limit 1 10: Alarm value 2 11: Alarm value upper limit 2 12: Alarm value lower limit 2 13: Alarm value lower limit 3 14: Alarm value upper limit 3 15: Alarm value lower limit 3 16: Alarm value lower limit 4 18: Alarm value upper limit 4 18: Alarm value lower limit 4 19: PV/SP/Internal SP 20: PV/SP/Alarm value 1 21: Proportional Band (Cooling) (C-P) 22: Integral Time (Cooling) (C-D) 24: PV/SP/MV (Cooling)		1	None	
Monitor/Setting Item 2	PFd2	Same as Monitor/Setting Item 1.		0	None	
Monitor/Setting Item 3	PFd3	Same as Monitor/Setting Item 1.		0	None	
Monitor/Setting Item 4	PFd4	Same as Monitor/Setting Item 1.		0	None	
Monitor/Setting Item 5	PFdS	Same as Monitor/Setting Item 1.		0	None	
PV/SP No. 1 Display Selection	SPd I	0: Nothing is displayed. 1: PV/SP/Nothing displayed 2: PV/Nothing displayed/Nothing displayed 3: SP/SP (character display)/Nothing displayed 4: PV/SP/MV (heating) 5: PV/SP/Multi-SP No. 6: PV/SP/Soak time remain 7: PV/SP/Internal SP (ramp SP) 8: PV/SP/Alarm value 1 9: PV/SP/MV (cooling)		* The default value for the E5□D-□-8□□ is 1.	None	
PV/SP No. 2 Display Selection	SPd2	Same as PV/SP No. 1 Display Selection.		0	None	

PV Status Display	Parameters Characters		Setting (monitor) value	Display	Default	Unit	
STOP: Stop	PV Status Display	ay PVSŁ OFF: OFF		ōFF	OFF	None	
ALMS: Alarm 1   ALMS: Alarm 2   R, R   R   ALMS: Alarm 3   R, R   R   R   R   R   R   R   R   R	Function		MANU: Manual				
ALMS: Alarm 2			' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' '				
ALMS: Alarm 3							
ALM: Alarm 4   ALM: OR of alarms 1 to 4   ALM: Cho of alarms 1 to 4   ALM: Healer alarm 1 to 4   Ril to 1							
ALM: OR of alarms 1 to 4   Rt H							
HA: Heater alarm							
SV Status Display   Si St.							
MANU-Manual   STOP: Stop   St-6P   ALM1: Alarm 1   ALM2: Alarm 2   Rt M1   Rt M1   ALM2: Alarm 3   Rt M2   Rt M3   ALM4: Alarm 3   Rt M3   Rt M1   Rt M2   Rt M3   ALM4: Alarm 4   ALM4: CR of alarms 1 to 4   Rt M1   Rt M2   Rt M3							
STOP: Stop		5%5E	0		OFF	None	
ALM: Alarm 1	Function						
ALM2: Alarm 2							
ALMS: Alarm 3							
ALM4: Alarm 4							
ALM: OR of alarms 1 to 4   RLft   H/R							
HA: Heater alarm							
Display Refresh Period   d/PEF   OFF, 0.25, 0.5, 1.0   aFF, 0.25, 0.25   Second   DFF, 0.25, 0.5, 1.0   aFF, 0.25, 0.25   Second   DFF, 0.25, 1.0   aFF, 0.25   aS, 1.0   aS,							
LCT Cooling Output   LEME   0.1 to 1.0   0.2   Second							
LCT Cooling Output   Minimum ON Time   Adaptive Control   Adaptive Control   Ap-dV   0.0 to 100.0   50.0   % 0°C (32°F) to Set point = 100%	Display Refresh Period	d.REF	OFF, 0.25, 0.5, 1.0		0.25	Second	
Minimum ON Time   Adaptive Control Operation Possible   Povision   R-dV   O.0 to 100.0   Sol.0   O°C (32°F) to Seption   E100%   System Fluctuation   R-5d   O.0 to 100.0   System Fluctuation   R-5d   O.0 to 100.0   Seconds   R-5d   O.1 to 10.0   Seconds   Adjustment Seal Period   R-BP   O.1 to 10.0   Adjustment Seal Period   Automatic Filter   Adjustment Hunting   Adjustment Hunting   Adjustment Hunting   Monitor Period   Mater-cooling   M-cE   1.00 to 10.00   1.70   Proportional Band Increase Constant   Mater-cooling   Proportional Band Decrease Constant   Public Mater-cooling   Proportional Band Decrease Constant   Public Monitor   Public Monitor   RBEH   O to 9999   O 10 hours   ON/OFF Count Monitor   RBEH   O to 9999   O 100 hours   ON/OFF Count Monitor   RBEH   O to 9999   O 100 hours   ON/OFF Count Monitor   OFF   OFF ON/OFF Count Monitor   ON/OFF Count Monitor   ON/OFF Count Monitor   ON/OFF Count Monitor   OFF ON/OFF Count Monitor   ON/OFF Count Monitor   ON/OFF Count Monitor   OFF ON/OFF Count Monitor   ON/OFF Count Monitor   OFF ON/OFF Count Monitor   OFF ON/OFF Count Monitor   ON/OFF Count Monitor   OFF ON/OFF Count Monitor   ON/OFF Count Monitor   ON/OFF Count Monitor   OFF ON/OFF Count Monitor   ON/OFF Count Monitor   OFF ON/OFF Count Monitor   ON/OFF	-			0.5, 1.0			
Adaptive Control Operation Possible Deviation   R - dV   0.0 to 100.0   50.0   6°C (32°F) to Set point to		LEME	0.1 to 1.0		0.2	Second	
Operation Possible Deviation         R-5d         0.0 to 100.0         15.0         %           System Fluctuation Reference Deviation         R-5d         0.0 to 100.0         15.0         %           Automatic Filter Adjustment Seal Period         FR5P         0.1 to 10.0         2.0         Seconds           Automatic Filter Adjustment Hunting Monitor Period         FRHP         10 to 1999         200         Seconds           Water-cooling Proportional Band Increase Constant         H- L         1.00 to 10.00         1.70         1.70           Water-cooling Proportional Band Decrease Constant         H- dL         0.10 to 0.99         0.90         0.90           Power ON Time Monitor         PBE M         0 to 9999         0         10 hours           Ambient Temperature Monitor         RBE M         °C: –30 to 75, °F: 10 to 171         °C           Control Output 1         NO/OFF Count Monitor         0         100 times           Control Output 2         ON/OFF Count Monitor         0         100 times           ON/OFF Counter Reset         2: Control Output 1 ON/OFF Count Monitor parameter is reset.         2: Control Output 2 ON/OFF Count Monitor parameter is reset.         2: Control Output 2 ON/OFF Count Monitor parameter is reset.         0         FF, ōN         OFF         None           Perameter Mask Se		0 11/	0.04-100.0		50.0	0/	
Deviation   System Fluctuation   R - 5d   0.0 to 100.0   15.0   %		H-dï	0.0 to 100.0		50.0		
System Fluctuation   R - 5d   0.0 to 100.0   15.0   %						, ,	
System Fluctuation Reference Deviation Reference Deviation   Ref	Deviation						
Reference Deviation							
Automatic Filter         FRSP         0.1 to 10.0         2.0         Seconds           Period         Automatic Filter         FRHP         10 to 1999         200         Seconds           Automatic Filter         FRHP         10 to 1999         200         Seconds           Adjustment Hunting Monitor Period         Water-cooling Proportional Band Increase Constant         H~EE         1.00 to 10.00         1.70           Water-cooling Proportional Band Decrease Constant         H~dE         0.10 to 0.99         0.90           Power ON Time Monitor         PHEM         0 to 9999         0         10 hours           Monitor         RBEM         °C: ~30 to 75, °F: 10 to 171         °C         °C           Control Output 1 ON/OFF Count Monitor         RR2H         0 to 9999         0         100 times           ON/OFF Count Monitor Onlore Count Monitor         RR2H         0: Resetting is disabled.         0         0           ON/OFF Count Monitor Darameter is reset.         2: Control Output 2 ON/OFF Count Monitor parameter is reset.         0         0           Parameter Mask Setting         PMSE         OFF, ON         aFF, aN         OFF         None           Parameter Mask Setting         —1999 to 9999         0         0         None		R-5d	0.0 to 100.0		15.0	%	
Adjustment Seal   Period   Automatic Filter   Adjustment Hunting   Monitor Period   200   Seconds		roro	0.1 += 10.0	1	0.0	Casarda	
Period		rnor	0.1 to 10.0		2.0	Seconds	
Automatic Filter         FRHP         10 to 1999         200         Seconds           Adjustment Hunting Monitor Period         1.00 to 10.00         1.70         1.70           Water-cooling Proportional Band Increase Constant         # - dE         0.10 to 0.99         0.90           Proportional Band Decrease Constant         0 to 9999         0.90         0.90           Power ON Time Monitor         PHEM         0 to 9999         0         10 hours           Ambient Temperature Monitor         RBEM         °C: -30 to 75, °F: 10 to 171         °C         °F           Control Output 1         CN/OFF Count Monitor         RRI III         0 to 9999         0         100 times           ON/OFF Count Monitor Control Output 2         ON/OFF Count Monitor         RRE         0: Resetting is disabled.         1: Control Output 1 ON/OFF Count Monitor parameter is reset.         0         0           Parameter Mask Setting         PM5E         OFF, ON         aFF, aN         OFF         None           Move to Calibration         Emäl V         -1999 to 9999         0         0         None							
Adjustment Hunting   Monitor Period   Mater-cooling   Proportional Band   Increase Constant   Mater-cooling   Proportional Band   Increase Constant   Mater-cooling   Proportional Band   Decrease Constant   Mater-cooling   Proportional Band   Decrease Constant   Mater-cooling   Mater		50.10					
Monitor Period         Water-cooling Proportional Band Increase Constant         H − E		FHHP	10 to 1999		200	Seconds	
Water-cooling Proportional Band Increase Constant         H − E   1.00 to 10.00         1.70           Water-cooling Proportional Band Decrease Constant         0.10 to 0.99         0.90           Power ON Time Monitor         PHEM   0 to 9999         0 10 hours           Ambient Temperature Monitor         RbEM   °C: −30 to 75, °F: 10 to 171         °C           Control Output 1 ON/OFF Count Monitor Control Output 2 ON/OFF Count Monitor         0 to 9999         0 100 times           ON/OFF Count Monitor Control Output 2 ON/OFF Count Monitor         0: Resetting is disabled. 1: Control Output 1 ON/OFF Count Monitor parameter is reset. 2: Control Output 2 ON/OFF Count Monitor parameter is reset.         0           Parameter Mask Setting         PM5E   OFF, ON   0FF   OFF, 0N	,						
Proportional Band   Increase Constant							
Nater-cooling		M-IE	1.00 to 10.00		1.70		
Water-cooling         W − dE         0.10 to 0.99         0.90           Proportional Band         Decrease Constant         0 to 9999         0 10 hours           Power ON Time Monitor         PWEM         0 to 9999         0 10 hours           Ambient Temperature Monitor         RBEM         °C: −30 to 75, °F: 10 to 171         °C           Control Output 1         ON/OFF Count Monitor         0 to 9999         0 100 times           ON/OFF Count Monitor         RREM         0: Resetting is disabled.         0 to 9999         0 to 9999           ON/OFF Count Monitor         0: Resetting is disabled.         0 to 000 times         0 to 000 times           ON/OFF Count Monitor         0: Resetting is reset.         0 to 000 times         0 to 000 times           Parameter Mask Setting         PM5E         OFF, ON         0 to 000 times         0 to 000 times           Move to Calibration         EMāV         -1999 to 9999         0 None         0 None	•						
Proportional Band Decrease Constant  Power ON Time Monitor  Ambient Temperature Monitor  Control Output 1 ON/OFF Count Monitor  ON/OFF Count Monitor  ON/OFF Count Monitor  ON/OFF Count Monitor  RRE  O: Resetting is disabled. 1: Control Output 1 ON/OFF Count Monitor parameter is reset. 2: Control Output 2 ON/OFF Count Monitor parameter is reset.  Parameter Mask Setting  Move to Calibration  D to 9999  O to 9999  O 100 times  O 100	Increase Constant						
Decrease Constant   Power ON Time   PWEM   O to 9999   O   10 hours	Water-cooling	M-9E	0.10 to 0.99		0.90		
Power ON Time   PWEM   O to 9999   O   10 hours	Proportional Band						
Monitor       Ambient Temperature Monitor       RBEM       °C: -30 to 75, °F: 10 to 171       °C         Control Output 1 ON/OFF Count Monitor Control Output 2 ON/OFF Count Monitor       0 to 9999       0 100 times         ON/OFF Count Monitor Control Output 2 ON/OFF Count Monitor       0: Resetting is disabled.       0         1: Control Output 1 ON/OFF Count Monitor parameter is reset.       0: Control Output 1 ON/OFF Count Monitor parameter is reset.       0         Parameter Mask Setting       PM5Ł OFF, ON       □ FF, □ N       OFF       None         Move to Calibration       EM□V       −1999 to 9999       0 None       None	Decrease Constant						
Monitor       Ambient Temperature Monitor       RBEM       °C: -30 to 75, °F: 10 to 171       °C         Control Output 1 ON/OFF Count Monitor Control Output 2 ON/OFF Count Monitor       0 to 9999       0 100 times         ON/OFF Count Monitor Control Output 2 ON/OFF Count Monitor       0: Resetting is disabled.       0         1: Control Output 1 ON/OFF Count Monitor parameter is reset.       0: Control Output 1 ON/OFF Count Monitor parameter is reset.       0         Parameter Mask Setting       PM5Ł OFF, ON       □ FF, □ N       OFF       None         Move to Calibration       EM□V       −1999 to 9999       0 None       None	Power ON Time	PWEM	0 to 9999		0	10 hours	
Monitor       PR IM ON/OFF Count Monitor Control Output 1 ON/OFF Count Monitor Control Output 2 ON/OFF Count Monitor       0 to 9999       0 100 times         ON/OFF Count Monitor ON/OFF Count Monitor Parameter is reset.       0: Resetting is disabled. 1: Control Output 1 ON/OFF Count Monitor parameter is reset. 2: Control Output 2 ON/OFF Count Monitor parameter is reset.       0         Parameter Mask Setting       PM5Ł OFF, ON OFF OFF OFF OFF OFF OFF OFF OFF OFF	Monitor						
Monitor       PR IM ON/OFF Count Monitor Control Output 1 ON/OFF Count Monitor Control Output 2 ON/OFF Count Monitor       0 to 9999       0 100 times         ON/OFF Count Monitor ON/OFF Count Monitor Parameter is reset.       0: Resetting is disabled. 1: Control Output 1 ON/OFF Count Monitor parameter is reset. 2: Control Output 2 ON/OFF Count Monitor parameter is reset.       0         Parameter Mask Setting       PM5Ł OFF, ON OFF OFF OFF OFF OFF OFF OFF OFF OFF	Ambient Temperature	Bh+M	°C: –30 to 75 °F: 10 to 171	1		°C	
Control Output 1 ON/OFF Count Monitor Control Output 2 ON/OFF Count Monitor ON/OFF Count Monitor ON/OFF Count Monitor  ON/OFF Count Monitor Reset  O: Resetting is disabled. 1: Control Output 1 ON/OFF Count Monitor parameter is reset. 2: Control Output 2 ON/OFF Count Monitor parameter is reset.  Parameter Mask Setting  PMSE  OFF, ON  FF  None  None	·	1,102,1	G. 66 to 76, 1. 16 to 171				
ON/OFF Count Monitor Control Output 2 ON/OFF Count Monitor  ON/OFF Counter Reset  RRE  0: Resetting is disabled. 1: Control Output 1 ON/OFF Count Monitor parameter is reset. 2: Control Output 2 ON/OFF Count Monitor parameter is reset.  Parameter Mask Setting  PMSE  OFF, ON  TAFF, TAN  OFF  None  None		88.44			+_		
Control Output 2 ON/OFF Count Monitor  ON/OFF Counter Reset  Reset  O: Resetting is disabled. 1: Control Output 1 ON/OFF Count Monitor parameter is reset. 2: Control Output 2 ON/OFF Count Monitor parameter is reset.  Parameter Mask Setting  Move to Calibration  P: Mone  O: Resetting is disabled. 1: Control Output 1 ON/OFF Count Monitor parameter is reset.  OFF, ON  Fig. 1  OFF  None  None	•		0 to 9999		0	100 times	
ON/OFF Counter Reset  ON/OFF Counter Reset  O: Resetting is disabled. 1: Control Output 1 ON/OFF Count Monitor parameter is reset. 2: Control Output 2 ON/OFF Count Monitor parameter is reset.  Parameter Mask Setting  OFF, ON  OFF None  Move to Calibration  O: Resetting is disabled. 1: Control Output 1 ON/OFF Count Monitor parameter is reset.  OFF, ON  OFF None  None		KHCM					
ON/OFF Counter Reset  0: Resetting is disabled. 1: Control Output 1 ON/OFF Count Monitor parameter is reset. 2: Control Output 2 ON/OFF Count Monitor parameter is reset.  Parameter Mask Setting  OFF, ON  Fig. 0  OFF  None  OFF  None  OFF  None	•						
1: Control Output 1 ON/OFF Count Monitor parameter is reset.   2: Control Output 2 ON/OFF Count Monitor parameter is reset.							
parameter is reset. 2: Control Output 2 ON/OFF Count Monitor parameter is reset.  Parameter Mask Setting  Move to Calibration  Parameter is reset.  OFF, ON  OFF  None  OFF  None  OFF  None	ON/OFF Counter	RRE	· · · · · · · · · · · · · · · · · · ·	1	0		
2: Control Output 2 ON/OFF Count Monitor parameter is reset.   Parameter Mask Setting	Reset						
parameter is reset.  Parameter Mask PM5E OFF, ON OFF None Setting  Move to Calibration EMaV -1999 to 9999  Description of the parameter is reset.  OFF, ON OFF None O							
Parameter Mask PM5Ł OFF, ON GFF, GN OFF None Setting OFF OFF, GN OFF None O			· ·				
Setting         Image: Control of the properties of			parameter is reset.	<u> </u>			
Setting         Image: Control of the properties of	Parameter Mask	PM5Ł	OFF, ON	ōFF, ōN	OFF	None	
	Setting						
		EMāV	-1999 to 9999		0	None	
	Level	1			1		

<sup>\*1</sup> If the Manual MV Limit Enable parameter is set to ON, the setting range will be the MV lower limit to the MV upper limit.

<sup>\*2</sup> This parameter can be set when the Program Pattern parameter is set to OFF, but the function will be

WR1 to WR8 are not displayed when the logic operation function is not used. \*3

<sup>\*4</sup> The setting ranges are different for relay and voltage outputs (for driving SSR) and for linear current

<sup>\*5</sup> The default value for the E5 $\square$ D- $\square$ -8 $\square$  is 8.

# A-7-7 Protect Level

Parameters	Characters	Setting (monitor) value	Display	Default	Unit
Move to Protect level	PMāV	-1999 to 9999		0	None
Operation/Adjustment Protect	āRPŁ	0 to 3		0	None
Initial Setting/Communications Protect	I E P E	0 to 2		1	None
Setting Change Protect	WEPE	OFF, ON	ōFF, ōN	OFF	None
PF Key Protect	PFPŁ	OFF, ON	ōFF, ōN	OFF	None
Parameter Mask Enable	PMSK	OFF, ON	ōFF, ōN	ON	None
Password to Move to Protect Level	PRLP	-1,999 to 9,999		0	None

# A-7-8 Communications Setting Level

Parameters	Characters	Setting (monitor) value	Display	Default	Unit
Protocol Setting	PSEL	CWF: CompoWay/F	EWF	CompoWay/	None
		MOD: Modbus	Mād	F	
		NONE: Disabled	NāNE		
		FINS: Host Link (FINS)	FINS		
		MCP4: MC Protocol (format 4)	MEPY		
		FXP4: Dedicated protocol (format 4)	FXPY		
Communications Unit No.	U-Nō	0 to 99		1	None
Communications Baud Rate	<i>6P5</i>	9.6, 19.2, 38.4, 57.6, or 115.2	9.5, 9.2, 38.4, 57.6, 115.2	9.6	kbps
Communications Data Length	LEN	7, 8		7	Bit
Communications Stop Bits	Shit	1, 2		2	Bit
Communications Parity	PRES	NONE: None EVEN: Even ODD: Odd	NāNE, EVEN, ādd	Even	None
Send Data Wait Time	SdWE	0 to 99		20	ms
Write Mode	RAMM	BKUP: Backup Mode RAM: RAM Write Mode	ЬКUP, RAM	BKUP	None
Highest Communications Unit No.	MRXU	0 to 99		0	None
Area	AREA	0 to 25		0	None
First Address Upper Word	AGRH	0 to 99		0	None
First Address Lower Word	AdRL	0 to 9999		0	None
Receive Data Wait Time	RWAF	100 to 9999		1000	ms
Communications Node Number	UNTE	0 to 99		0	None
Upload Settings 1 to 13	UP   to  3	0 to 108			None
Download Settings 1 to 13	dN   to  3	30 to 108			None
Сору	CōPY	OFF, ALL, or 1 to 199		OFF	None

## **Initialization According to Parameter Changes** A-7-9

The parameters that are initialized when parameters are changed are shown under Related initialized parameters.

Changed parameter  Related initialized parameters	Input Type	Temperature Unit	_imit _imit	SP Lower Limit SP Upper Limit	PID ON/OFF	Standard or Heating/Cooling	RT	Integral/Derivative Time Unit	Alarm 1 to 4 Type	Heating/Cooling Tuning Method	Program Pattern	Adaptive Control	AT Calculated Gain Model Creation OFF Time Model Creation ON Time Model Creation MV Amplitude Model Creation PV Amplitude	Number of Multi-SP Points	Password to Move to Protect Level	Transfer Output Type
Related parameter initialization execution condition		Temperat ure input	Analo g input				Temperat ure input									
SP Upper Limit	*1	*15	*1													
SP Lower Limit SP,Multi-SP Set Points 0 to 7	•	•	•	•												
Selection	*2	*2 *15	*2	*2												
RT	*3											•				
Integral/Derivative Time Unit							• *8									
MV at Stop						•										
MV at PV Error						•										
Manual MV Initial Value Control Output 1 Assignment						•					•					
Control Output 2 Assignment						•					•					
Auxiliary Output 1 Assignment						*5 • *6					*5 • *6					
Auxiliary Output 2 Assignment						*5					*5					
Auxiliary Output 3 Assignment						•					•					
Auxiliary Output 4 Assignment						*5					• *5					
Move to Protect Level															*9	
Dead Band	*10	◆ *15														
Hysteresis (Heating)	*10	*15														
Hysteresis (Cooling)	*10	*15														
Wait Band	*10	*15														
Alarm 1 to 4 Hysteresis	*11	*15							*12							
AT Hysteresis	*10	*15														
LBA Level	*10	*15														
LBA Band	*10	*15														
Operation After Power ON					•											
Proportional Band	*10	*15					*8	*14								
Proportional Band (Cooling)	*10	*15					*8	*14								
Integral Time	*10						*8	*14								
Integral Time (Cooling)	*10						*8	*14								
Derivative Time	*10						*8	*14								
Derivative Time (Cooling)	*10						*8	*14								

Changed parameter  Related initialized parameters	Input Type	Temperature Unit	Scaling Lower Limit Scaling Upper Limit	SP Lower Limit SP Upper Limit	PID ON/OFF	Standard or Heating/Cooling	RT	Integral/Derivative Time Unit	Alarm 1 to 4 Type	Heating/Cooling Tuning Method	Program Pattern	Adaptive Control	AT Calculated Gain Model Creation OFF Time Model Creation ON Time Model Creation MV Amplitude Model Creation PV Amplitude	Number of Multi-SP Points	Password to Move to Protect Level	Transfer Output Type
MV Upper Limit, MV Lower Limit						*4										
RUN/STOP																
Auto/Manual Switch					•											
Minimum Output ON/OFF Band						•				•						
Alarm Values 1 to 4		*15														
Alarm Upper Values 1 to 4		*15														
Alarm Lower Values 1 to 4		*15														
PV Input Shift		*15														
SP Ramp Set Value (Rise Value)		◆ *15														
SP Ramp Fall Value		*15														
Event Input Assignments 1 to 6											• *7					
Model Creation PV Amplitude	•	•														
Model Creation MV Amplitude	•	•														
Model Creation ON Time	•	•														
Model Creation OFF Time	•	•														
SP Response Proportional Band	•	• *15						*16					◆ *17			
SP Response Integral Time	•							*16					◆ *17			
SP Response Derivative Time	•							◆ *16					● *17			
SP Response Coefficient Number	•	•						•					•			
Disturbance Proportional Band	•	◆ *15						◆ *16					● *17			
Disturbance Integral Time	•							◆ *16					◆ *17			
Disturbance Derivative Time	•							*16					● *17			
Water-cooling Proportional Band Increase Threshold		*15														
Water-cooling Proportional Band Decrease Threshold		◆ *15														
Multi-SP														● *13		
Transfer Output Upper Limit and Transfer Output Lower Limit *18  *1 Initialized to input setting	*18.1	*18.1	*18.1	*18.1		*18.2										*18.3

<sup>\*1</sup> Initialized to input setting range upper and lower limits, or scaling upper and lower limits.

<sup>\*2</sup> Clamped by SP upper and lower limits.

<sup>\*3</sup> This parameter is initialized only when the input type is changed to analog input. The RT parameter turns OFF.

<sup>\*4</sup> Initialized as follows according to the Standard or Heating/Cooling parameter setting.

<sup>•</sup> MV Upper Limit: 100.0

<sup>•</sup> MV Lower Limit: Standard 0.0, heating/cooling -100.0

- \*5 Initialized to control output (cooling) for heating and cooling control, according to the following.
  - (The defaults for standard control are the defaults in the parameter list.)
  - · With control output 2: The Control Output 2 Assignment parameter is initialized to control output (cooling).
  - If the Digital Controller does not have control output 2 but has four auxiliary outputs, the Auxiliary Output 4 Assignment parameter is initialized to Control Output (Cooling).
  - Otherwise, the Auxiliary Output 2 Assignment parameter is initialized to Control Output (Cooling).
- \*6 If the Program Pattern parameter is set to OFF, the Auxiliary Output 1 Assignment parameter is initialized as follows:
  - Digital Controllers with HB and HS alarms: Heater alarm
  - Digital Controllers without HB and HS alarms: Alarm 1

If the Program Pattern parameter is not set to OFF, the Auxiliary Output 1 Assignment parameter is initialized to the program end output.

- \*7 If the Program Start parameter is assigned when the program pattern is changed to OFF, the Program Start parameter will be initialized to "not assigned."
- \*8 The Integral/Derivative Time Unit parameter is initialized only when the RT parameter is turned ON. The default is as follows:
  - Integral/Derivative Time Unit: 0.1 s (The PID parameters are also initialized when the Integral/Derivative Time Unit parameter is initialized.) \*14
- \*9 This parameter is initialized to the new Password to Move to Protect Level password.
- \*10 These parameters are initialized when the Input Type parameter is changed from a temperature input to an analog input or from an analog input to a temperature input.
- \*11 This parameter is initialized when the Input Type parameter is changed from a temperature input to an analog input or from an analog input to a temperature input. However, it is not initialized if the applicable alarm is an MV absolute-value upper-limit alarm or an MV absolute-value lower-limit alarm.
- \*12 This parameter is initialized to 50 (0.50%) if a non-MV alarm is changed to an MV alarm. This parameter is initialized to 2 (0.2°C or 0.02%FS) if an MV alarm is changed to a non-MV alarm.
- \*13 If the number of multi-SP points is decreased, the multi-SPs will be initialized to 0.
- \*14 The proportional band is initialized to 8.0 for a temperature input and to 10.0 for an analog input. (The same thing applies to the cooling side.)

Integral time and derivative time are initialized as follows:

- Integral/Derivative Time Unit of 1 s: integral time to 233, and derivative time to 40. (This applies to both the heating and cooling constants.)
- Integral/Derivative Time Unit of 0.1 s: integral time to 233.0, and derivative time to 40.0. (This applies to both the heating and cooling constants.)
- \*15 If the temperature unit is changed, the value is converted to the new temperature unit.
- \*16 If all of the model parameters are not 0, they will be initialized for model parameter calculations. However, if any of the model parameters is 0, they will be initialized to the defaults.
- \*17 If all of the model parameters are not 0, they will be initialized for model parameter calculations.
- \*18 Initialization is performed as shown below if the Control Output 1 Assignment parameter is set to a transfer output. The initialization differs depending on the changed parameter and the transfer output setting.
  - Transfer SP: SP upper and lower limits
  - Transfer Ramp SP: SP upper and lower limits
  - Transfer PV: Input setting range upper and lower limits or scaling upper and lower limits
  - Transfer MV (Heating): 100.0/0.0
  - Transfer MV (Cooling): 100.0/0.0
  - \*18.1 Initialized only when the transfer output is set to Transfer SP, Transfer Ramp SP, or Transfer PV.
  - \*18.2 Initialized only when the transfer output is set to Transfer MV (Heating) or Simple Transfer MV (Cooling).
  - \*18.3 Initialized to the above default values regardless of the settings for changing the transfer output.

# A-8 Sensor Input Setting Range, Indication Range, Control Range

Voltage input     1 to 5 V     27       0 to 5 V     28   -1999 to 9999 -1999 to 9999 -1999 omitted).  -1999 to 9999 (numeric range with decimal point omitted).		Specificati ons	Set value	Input setting range	Input indication range
1	Resistance	Pt100	0	–200 to 850 (°C)/–300 to 1500 (°F)	-220 to 870 (°C)/-340 to 1540 (°F)
JPt100   3	thermometer		1	-199.9 to 500.0 (°C)/-199.9 to 900.0 (°F)	-199.9 to 520.0 (°C)/-199.9 to 940.0 (°F)
A			2	0.0 to 100.0 (°C)/0.0 to 210.0 (°F)	-20.0 to 120.0 (°C)/-40.0 to 250.0 (°F)
Thermocouple   K		JPt100	3	-199.9 to 500.0 (°C)/-199.9 to 900.0 (°F)	-199.9 to 520.0 (°C)/-199.9 to 940.0 (°F)
6			4	0.0 to 100.0 (°C)/0.0 to 210.0 (°F)	-20.0 to 120.0 (°C)/-40.0 to 250.0 (°F)
J	Thermocouple	К	5	−200 to 1300 (°C)/−300 to 2300 (°F)	−220 to 1320 (°C)/−340 to 2340 (°F)
B			6	-20.0 to 500.0 (°C)/0.0 to 900.0 (°F)	-40.0 to 520.0 (°C)/-40.0 to 940.0 (°F)
T		J	7	-100 to 850 (°C)/-100 to 1500 (°F)	-120 to 870 (°C)/-140 to 1540 (°F)
10			8	-20.0 to 400.0 (°C)/0.0 to 750.0 (°F)	-40.0 to 420.0 (°C)/-40.0 to 790.0 (°F)
E 11 -200 to 600 (°C)/-300 to 1100 (°F) -220 to 620 (°C)/-340 to 1140 (°F)  L 12 -100 to 850 (°C)/-100 to 1500 (°F) -120 to 870 (°C)/-140 to 1540 (°F)  U 13 -200 to 400 (°C)/-300 to 700 (°F) -220 to 420 (°C)/-340 to 740 (°F)  14 -199.9 to 400.0 (°C)/-199.9 to 700.0 (°F) -199.9 to 420.0 (°C)/-199.9 to 740 (°F)  N 15 -200 to 1300 (°C)/-300 to 2300 (°F) -220 to 1320 (°C)/-340 to 2340 (°F)  R 16 0 to 1700 (°C)/0 to 3000 (°F) -20 to 1720 (°C)/-40 to 3040 (°F)  S 17 0 to 1700 (°C)/0 to 3000 (°F) -20 to 1720 (°C)/-40 to 3040 (°F)  B 18 0 to 1800 (°C)/0 to 3200 (°F) -20 to 1720 (°C)/-40 to 3240 (°F)  C/W 19 0 to 2300 (°C)/0 to 3200 (°F) -20 to 1320 (°C)/-40 to 3240 (°F)  PLII 20 0 to 1300 (°C)/0 to 2300 (°F) -20 to 1320 (°C)/-40 to 3240 (°F)  ES1B Infrared Temperature Sensor 115 to 23 0 to 165 (°C)/0 to 3200 (°F) -20 to 130 (°C)/-40 to 320 (°F)  115 to 120 °C 110 to 90 (°C)/0 to 240 (°F) -20 to 130 (°C)/-40 to 320 (°F)  115 to 23 0 to 165 (°C)/0 to 320 (°F) -20 to 130 (°C)/-40 to 320 (°F)  120 °C 140 to 24 0 to 260 (°C)/0 to 500 (°F) -20 to 130 (°C)/-40 to 320 (°F)  Current input 4 to 20 mA 26 -1999 to 9999 -1999 to 9999 (numeric range with decimal poir omitted).		Т	9	-200 to 400 (°C)/-300 to 700 (°F)	-220 to 420 (°C)/-340 to 740 (°F)
L			10	-199.9 to 400.0 (°C)/-199.9 to 700.0 (°F)	-199.9 to 420.0 (°C)/-199.9 to 740.0 (°F)
U		E	11	−200 to 600 (°C)/−300 to 1100 (°F)	-220 to 620 (°C)/-340 to 1140 (°F)
14		L	12	-100 to 850 (°C)/-100 to 1500 (°F)	-120 to 870 (°C)/-140 to 1540 (°F)
N		U	13	−200 to 400 (°C)/−300 to 700 (°F)	-220 to 420 (°C)/-340 to 740 (°F)
R			14	-199.9 to 400.0 (°C)/-199.9 to 700.0 (°F)	−199.9 to 420.0 (°C)/−199.9 to 740 (°F)
S 17 0 to 1700 (°C)/0 to 3000 (°F) —20 to 1720 (°C)/–40 to 3040 (°F)  B 18 0 to 1800 (°C)/0 to 3200 (°F) —20 to 1820 (°C)/–40 to 3240 (°F)  C/W 19 0 to 2300 (°C)/0 to 3200 (°F) —20 to 2320 (°C)/–40 to 3240 (°F)  PLII 20 0 to 1300 (°C)/0 to 2300 (°F) —20 to 1320 (°C)/–40 to 2340 (°F)  ES1B Infrared Temperature Sensor		N	15	−200 to 1300 (°C)/−300 to 2300 (°F)	-220 to 1320 (°C)/-340 to 2340 (°F)
B 18 0 to 1800 (°C)/0 to 3200 (°F) —20 to 1820 (°C)/—40 to 3240 (°F)  C/W 19 0 to 2300 (°C)/0 to 3200 (°F) —20 to 2320 (°C)/—40 to 3240 (°F)  PLII 20 0 to 1300 (°C)/0 to 2300 (°F) —20 to 1320 (°C)/—40 to 2340 (°F)  ES1B Infrared Temperature Sensor 60 to 120 °C)/0 to 190 (°F) —20 to 130 (°C)/—40 to 270 (°F)  115 to 120 °C 0 to 120 (°C)/0 to 240 (°F) —20 to 160 (°C)/—40 to 320 (°F)  115 to 23 0 to 165 (°C)/0 to 320 (°F) —20 to 160 (°C)/—40 to 320 (°F)  115 to 165 °C 0 140 to 240 (°F) —20 to 205 (°C)/—40 to 400 (°F)  Current input 4 to 20 mA 25 Any of the following ranges, by scaling: —1999 to 9999 —1999 to 9999 (numeric range with decimal poir omitted).  Voltage input 1 to 5 V 27 —1999 to 9999 —1.999 to 9.999 —		R	16	0 to 1700 (°C)/0 to 3000 (°F)	-20 to 1720 (°C)/-40 to 3040 (°F)
C/W         19         0 to 2300 (°C)/0 to 3200 (°F)         -20 to 2320 (°C)/-40 to 3240 (°F)           PLII         20         0 to 1300 (°C)/0 to 2300 (°F)         -20 to 1320 (°C)/-40 to 2340 (°F)           ES1B Infrared Temperature Sensor         10 to 70°C         21         0 to 90 (°C)/0 to 190 (°F)         -20 to 130 (°C)/-40 to 270 (°F)           120°C         0 to 120 (°C)/0 to 240 (°F)         -20 to 160 (°C)/-40 to 320 (°F)           115 to 165°C         140 to 24         0 to 260 (°C)/0 to 500 (°F)         -20 to 205 (°C)/-40 to 400 (°F)           Current input 260°C         4 to 20 mA         25         Any of the following ranges, by scaling: -1999 to 9999         -5% to 105% of setting range. The display show -1999 to 9999 (numeric range with decimal poir omitted).           Voltage input Voltage input 160 to 5 V         1 to 5 V         27         -19.99 to 99.99 (numeric range with decimal poir omitted).		S	17	0 to 1700 (°C)/0 to 3000 (°F)	-20 to 1720 (°C)/-40 to 3040 (°F)
PLII   20    0 to 1300 (°C)/0 to 2300 (°F)   -20 to 1320 (°C)/-40 to 2340 (°F)		В	18	0 to 1800 (°C)/0 to 3200 (°F)	-20 to 1820 (°C)/-40 to 3240 (°F)
ES1B Infrared Temperature Sensor		C/W	19	0 to 2300 (°C)/0 to 3200 (°F)	-20 to 2320 (°C)/-40 to 3240 (°F)
Temperature Sensor		PLII	20	0 to 1300 (°C)/0 to 2300 (°F)	-20 to 1320 (°C)/-40 to 2340 (°F)
Sensor   120°C   115 to   123   0 to 165 (°C)/0 to 320 (°F)   -20 to 205 (°C)/-40 to 400 (°F)   -20 to 205 (°C)/-40 to 400 (°F)		10 to 70°C	21	0 to 90 (°C)/0 to 190 (°F)	−20 to 130 (°C)/−40 to 270 (°F)
165°C	•		22	0 to 120 (°C)/0 to 240 (°F)	-20 to 160 (°C)/-40 to 320 (°F)
260°C			23	0 to 165 (°C)/0 to 320 (°F)	-20 to 205 (°C)/-40 to 400 (°F)
Voltage input 1 to 5 V 27			24	0 to 260 (°C)/0 to 500 (°F)	-20 to 300 (°C)/-40 to 580 (°F)
Voltage input 1 to 5 V 27 -199.9 to 999.9 -19.99 to 99.99 -1.999 to 9.999	Current input	4 to 20 mA	25	Any of the following ranges, by scaling:	-5% to 105% of setting range. The display shows
O to 5 V 28 —19.99 to 99.99 —1.999 to 9.999	-	0 to 20 mA	26		-1999 to 9999 (numeric range with decimal point
0 to 5 V 28	Voltage input	1 to 5 V	27		omitted).
		0 to 5 V	28		
		0 to 10 V	29	-1.333 10 3.333	

- The default is 5.
- The applicable standards for each of the above input ranges are as follows:

K, J, T, E, N, R, S, B: JIS C1602-2015, IEC 60584-1

L: Fe-CuNi, DIN 43710-1985

U: Cu-CuNi, DIN 43710-1985

C/W: W5Re/W26Re, JIS C 1602-2015, ASTM E988-1990

JPt100: JIS C 1604-1989, JIS C 1606-1989


Pt100: JIS C 1604-1997, IEC 60751

PLII: According to Platinel II Electromotive Force Table by Engelhard Corp.

# **A-9 Setting Levels Diagram**

This diagram shows all of the setting levels. To move to the Advanced Function Setting Level and Calibration Level, you must enter passwords. Some parameters are not displayed depending on the protect level setting and the conditions of use.


Control stops when you move from the Operation Level to the Initial Setting Level.




- \*1 Set the PF Setting parameter to R-M (Auto/Manual).
- \*2 The No. 1 display will flash when the keys are pressed for 1 s or longer.
- Set the PF Setting parameter to PFdP (monitor/setting items).

# A-10 Parameter Flow con


This section describes the parameters set in each level. Pressing the ( (Mode) Key at the last parameter in each level returns to the top parameter in that level. Hold down the ( Key to move through the parameters in reverse. Some parameters may not be displayed depending on the model and other settings.







# A-11 Parameter Flow (For E5□D-□-80□)

This section describes the parameters set in each level. Pressing the (Mode) Key at the last parameter in each level returns to the top parameter in that level. Hold down the Key to move through the parameters in reverse. Some parameters may not be displayed depending on the model and other settings.







# Index

#### СТ **Numerics** dimensions E54-CT1/CT1L ......A-8 2-PID control .......4-14, 6-43 specifications ......A-8 Α current transformer (CT) ......4-43, A-8 AD Converter Error ......A-17 Adjustment Level ......6-16, A-24 D Advanced Function Setting Level ......6-62, A-30 air cooling/water cooling tuning ......5-31 dedicated protocol (format 4) ......6-98, A-35 alarm delays ...... 5-51 derivative time .......4-30 alarm hysteresis ......4-37 detection current values .......4-44 alarm latches ......4-38 Digit Shift Key ...... 3-7 alarm operation ......4-38 dimensions ......2-2 alarm outputs ......4-31 direct and reverse operation ...... 4-15 alarm types ...... 4-31 Display Range Exceeded ......A-17 alarm values ......4-34 Disturbance Derivative Time ...... 6-30 alarms ...... 4-17 Disturbance Integral Time .......6-30 alarms (standard alarms) ...... 1-5 Disturbance Proportional Band ......6-30 analog inputs ......5-27, 7-9 assigning outputs ......4-16 drawing out the interior body ......2-7 auto/manual control ......5-36 E auto-tuning (AT) ......4-24, 6-18 auxiliary output opening and closing in alarm ......4-19 error displays ......A-16 auxiliary outputs 1 to 4 ......2-31 event input assignment ......5-35, 6-57 В event inputs .......1-6, 2-31, 5-33 extraction of square roots ...... 5-67 Bar Display Scaling Lower Limit ......6-60 F Bar Display Scaling Upper Limit ...... 6-60 front panel .......3-4 C calibrating a current input ......7-9 calibrating a voltage input ......7-11 Н calibrating inputs ......7-2 calibrating the transfer output ......7-13 HB alarm ......4-39. A-3. A-18 characteristics .......A-4 heater burnout alarm ......6-66, A-3 checking indication accuracy ......7-15 heater short alarm ......4-39, A-3 analog input ......7-17 heating/cooling control ......5-29, 6-44 infrared temperature sensor .......7-15 HS alarm .......4-41. A-3. A-18 resistance thermometer .......7-16 HS alarms ...... 1-5 clearing the program end status ...... 5-62 I communications operation command ...... 5-45 I/O configuration ......1-7 Communications Setting Level ......6-97, A-35 indication ranges .......A-39 component communications ......1-6, 6-98 CompoWay/F ......6-98, A-35 infrared temperature sensor .......7-15 connecting the cold junction compensator .......7-5 initial setting example example 1 ...... 4-9 control outputs ......1-5, 4-18 example 2 ...... 4-10 control outputs 1 and 2 ......2-29 control periods ......4-15 initial setting examples ...... 4-8 Initial Setting Level ......3-4, 6-40, A-26 initialization ....... 5-84, 6-64 controlling the start of the simple program function ..... 5-36 input digital filter ...... 5-25 Input Error ......A-16

input error	6-33	N	
input sensor types			
input type		No. 1 display	3-4 4-46 6-8
inputs		No. 2 display	
installation	2-2	No. 3 display	
E5CD		110. 0 diopidy	0 1, 1 10, 0 0
mounting to the Terminal Cover . E5CD, E5CD-B, and E5CD-U	2-5	0	
mounting to the panel	2-5	ONI/OFF control	4 4 4 4 04 6 40
E5ED or E5AD		ON/OFF control	
mounting to the Terminal Cover .	2-6	operation indicators	
E5ED, E5ED-B, or E5AD		Operation Level	
mounting the Terminal Cover	2-6	output limits	
insulation block diagrams		output periods	0-49
integral time		Р	
integral/derivative time unit		<u> </u>	
K		panel cutout	
		parameter flow	
key operations	5-34	parameter initialization	
Keys	04	Parameter Mask Setting	
➤ Down Key	3-6	parameter operation lists	
Level Key		parameter structure	7-3
Mode Key		parameters	
© Shift Key (PF Key)		a	
● Up Key		Adjustment Level Display	
_ <b>~</b> ,,		Alarm 1 to 4 Hysteresis	
L		Alarm 1 to 4 Latch	
		Alarm 1 To 4 OFF Delay	
Level Key (© Key)	3-6	Alarm 1 to 4 ON Delay	
linear tuning		Alarm 1 to 4 Type	
logic operations		Alarm 1 to 4 Upper Limit	
loop burnout alarm		Alarm Lower Limit Value	
Toop burnout didim		Alarm SP Selection	
M		Alarm Upper Limit Value Alarm Value 1 to 4	
		Alarm Value Lower Limit 1 to 4	•
main functions	1-5	Alarm Value Upper Limit 1 to 4	
manual control		Alpha	
Manual Control Level		AT Calculated Gain	
manual setup		AT Calculation Gain	
MASK8		AT Execute/Cancel	
MASK		AT Hysteresis	
MC protocol (format 4)		Auto/Manual Switch	
Memory Error		Automatic Display Return Time	
Modbus		Auxiliary Output 1 to 4 Assignment	
Modbus-RTU		Auxiliary Output 1 to 4 Open in Alarm	
Mode Key ( Key)	•	Cold Junction Compensation Method	
model number legends		Communications Baud Rate	
Monitor/Setting Item Level		Communications Data Length	
mounting the Terminal Covers		Communications Parity	
E5CD	2-5	Communications Stop Bits	
E5ED		Communications Unit No	
multi-SP		Communications Wait Time	
		Communications Writing	
		Control Output 1 Assignment	
		Control Output 1 Signal	
		Control Output 2 Assignment	
		Control Period (Cooling)	
		Control Period (Heating)	

Dead Band	5-30,	6-30	MV Change Rate Limit	5-69,	6-35
Decimal Point		6-42	MV Lower Limit		6-34
Derivative Time		6-26	MV Monitor (Cooling)		6-15
Derivative Time (Cooling)4-1	4, 5-31,	6-27	MV Monitor (Heating)		6-15
Digit Shift			MV Upper Limit		6-34
Direct/Reverse Operation			Number of Multi-SP Points		
Display Brightness			Operation/Adjustment Protect		
Display Refresh Period			Parameter Initialization		
Event Input Assignment			Parameter Mask Enable		
Event Input Assignment 1 to 6			password		
event inputs			Password to Move to Protect Level		
Extraction of Square Root Enable			PF Setting		
Extraction of Square Root Low-cut Point			PID ON/OFF		
HB ON/OFF			PID ON/OFF parameter		
			Process Value Input Shift		
Heater Burnout Detection 1					
Heater Burnout Hysteresis			Process Value Slope Coefficient		
Heater Burnout Latch			Process Value/Set Point 1		
Heater Current 1 Value Monitor			Process Value/Set Point 2		
Heating/Cooling Tuning Method			Program Pattern		
HS Alarm 1			Program Start		
HS Alarm Hysteresis			Proportional Band		
HS Alarm Latch		6-77	Proportional Band (Cooling)		
HS Alarm Use	4-42,	6-76	Protocol Setting		6-97
Hysteresis		4-21	PV Rate of Change Calculation Period	4-35,	6-84
Hysteresis (Cooling)		6-31	PV Status Display Function		6-89
Hysteresis (Heating)		6-31	PV/MV (Manual MV)		6-39
Initial Setting/Communications Protect			PV/SP Display Selection		
Input Type	6-41,	A-26	PV/SP No. 1 Display Selection	4-46, 6-8,	6-88
input type			PV/SP No. 2 Display Selection		
Integral Time			RT		
Integral Time (Cooling)4-1			RT (Robust Tuning)		
Integral/Derivative Time Unit			RUN/STOP		
Integrated Alarm Assignment			Scaling Lower Limit		
LBA Band			Scaling Upper Limit		
LBA Detection Time			Set Point During SP Ramp		
LBA Level			Set Point Lower Limit		
			Set Point Upper Limit		
LCT Cooling Output Minimum ON Time Leakage Current 1 Monitor					
-			Setting Change Protect		
Limit Cycle MV Amplitude			Soak Time		
Loop Burnout Alarm (LBA)			Soak Time Remain		
Manual Control Level			Soak Time Unit		
Manual MV Initial Value			SP Lower Limit		
Manual MV Limit Enable			SP Ramp Fall Value		
Manual Output Method			SP Ramp Set Value		
Manual Reset Value			SP Ramp Time Unit		
Minimum Output ON/OFF Band		6-85	SP Upper Limit		
Monitor/Setting Item 1 to 5		6-87	SP0 to SP7		6-22
Monitor/Setting Item Display 1 to 5		6-37	Standard or Heating/Cooling		6-44
Move to Advanced Function Setting Level .		6-61	Standby Sequence Reset		6-65
Move to Calibration Level		6-96	SV Status Display Function		6-90
Move to Protect Level		6-3	Temperature Unit		
Move to Protect Level Time		6-72	Transfer Output Lower Limit		
Move to the Protect Level		5-44	Transfer Output Signal		
Moving Average Count			Transfer Output Type		
Multi-SP Set Point Selection			Transfer Output Upper Limit		
MV (Manual MV)			Wait Band		
MV at Error			Work Bit 1 to 8 OFF Delay		
MV at PV Error			Work Bit 1 to 8 ON Delay		
MV at Stop			TOTA DIE 1 to 0 OIN Doldy		0-00
1VI V at 310p	5-65,	0-00			

password	5-44, 5-45	SP0 to SP7	5-33
setting		specifications	
PF Key ((CPF Key)3-6, 3-7, 5-44		standard control	
PF setting		standby sequences	
PID constants		SV status display	
PID control		or claids display	
potentiometer input error (Position-proportion		Т	
	• •	<u>·</u>	
power supply		tomporature unit	4 12
process value/set point 1		temperature unit	
process value/set point 1process value/set point 2		terminal arrangement	2-9
program end		terminal block wiring examples	0.0
		E5CD	
program end output		E5CD-B	
programless communications		E5ED	
proportional action		E5ED-B	
proportional band		thermocouple calibration	
Protect Level		thermocouple or infrared temperature sensor	·7-15
protection		three-position control	
Initial Setting/Communications Protect .		transfer output	5-86
Operation/Adjustment Protect		transfer output signal	5-86
PF Key Protect		transfer scaling	5-87
Setting Change Protect	5-44	troubleshooting	A-20
Push-In Plus terminal blocks	2-25		
PV change rate alarm	4-35	U	
PV status display	5-73		
		Up Key ( Key)	3-6
R		USB-Serial Conversion Cable2	
		user calibration	
ratings	A-2	using the terminals	
registering calibration data			
resistance thermometer calibration		V	
RS-485		-	
run/stop control		versions	1-13
S		W	
sampling cycle	4-35. A-5	wising	2.20
sensor input setting ranges	•	wiring	
set point limiter		wiring precautions	
set points 0 to 7		work bit 1 to 8	5-78
setting levels diagram			
setting monitor/setting items			
setting output specifications			
setting output specificationssetting the input type			
setting the SP upper and lower limit values			
setting the SP upper and lower limit values			
Setup Tool ports			
Shift Key ( Key)	3-/		

 shifting input values
 5-25

 shifting inputs
 5-25

 simple program function
 5-59

 starting method
 5-60

 SP ramp
 5-41

 alarms
 5-42

 operation at startup
 5-42

 restrictions
 5-42

 SP Response Derivative Time
 6-28

 SP Response Integral Time
 6-28

 SP Response Proportional Band
 6-28

Index



## OMRON AUTOMATION AMERICAS HEADQUARTERS • Chicago, IL USA • 847.843.7900 • 800.556.6766 • www.omron247.com

#### OMRON CANADA, INC. • HEAD OFFICE

Toronto, ON, Canada • 416.286.6465 • 866.986.6766 • www.omron247.com

## **OMRON ELECTRONICS DE MEXICO • HEAD OFFICE**

México DF • 52.55.59.01.43.00 • 01-800-226-6766 • mela@omron.com

## **OMRON ELECTRONICS DE MEXICO • SALES OFFICE**

Apodaca, N.L. • 52.81.11.56.99.20 • 01-800-226-6766 • mela@omron.com

## **OMRON ELETRÔNICA DO BRASIL LTDA • HEAD OFFICE**

São Paulo, SP, Brasil • 55.11.2101.6300 • www.omron.com.br

#### **OMRON ARGENTINA • SALES OFFICE**

Cono Sur • 54.11.4783.5300

## **OMRON CHILE • SALES OFFICE**

Santiago • 56.9.9917.3920

## OTHER OMRON LATIN AMERICA SALES

54.11.4783.5300

OMRON EUROPE B.V. • Wegalaan 67-69, NL-2132 JD, Hoofddorp, The Netherlands. • +31 (0) 23 568 13 00 • www.industrial.omron.eu

Authorized Distributor:

## Controllers & I/O

- Machine Automation Controllers (MAC) Motion Controllers
- Programmable Logic Controllers (PLC) Temperature Controllers Remote I/O

## Robotics

• Industrial Robots • Mobile Robots

## **Operator Interfaces**

• Human Machine Interface (HMI)

## **Motion & Drives**

- Machine Automation Controllers (MAC) Motion Controllers Servo Systems
- Frequency Inverters

## Vision, Measurement & Identification

• Vision Sensors & Systems • Measurement Sensors • Auto Identification Systems

## Sensina

- Photoelectric Sensors Fiber-Optic Sensors Proximity Sensors
- Rotary Encoders Ultrasonic Sensors

- Safety Light Curtains Safety Laser Scanners Programmable Safety Systems
- Safety Mats and Edges Safety Door Switches Emergency Stop Devices
- Safety Switches & Operator Controls Safety Monitoring/Force-guided Relays

# **Control Components**

- Power Supplies Timers Counters Programmable Relays
- Digital Panel Meters Monitoring Products

# **Switches & Relays**

- Limit Switches Pushbutton Switches Electromechanical Relays
- Solid State Relays

## Software

• Programming & Configuration • Runtime

© 2017 Omron. All Rights Reserved.

