

# AC Current Probe

## Model JM865A

### User Manual

---

#### DESCRIPTION

The JM865A (Catalog # 2110.88) is designed for use in industrial environments. The “squared” jaws permit multiple conductor or bus bar positioning. The current output makes it the perfect tool for measurement with DMMs, recorders, power and harmonic meters. Three ranges allow you to obtain the best resolution even on low current measurement. The Model JM865A is compatible with any AC Ammeter, multimeter, or other current measuring instrument with an input impedance lower than  $2\Omega$ . To achieve the stated accuracy, use the JM865A with an Ammeter having an accuracy of 0.75%.

#### WARNING

These safety warnings are provided to ensure the safety of personnel and proper operation of the instrument.

- Read the instruction manual completely and follow all the safety information before attempting to use or service this instrument.
- Use caution on any circuit: Potentially high voltages and currents may be present and may pose a shock hazard.
- Read the Safety Specifications section prior to using the current probe. Never exceed the maximum voltage ratings given.
- Safety is the responsibility of the operator.
- ALWAYS connect the current probe to the display device before clamping the probe onto the sample being tested.
- ALWAYS inspect the instrument, probe, probe cable, and output terminals prior to use. Replace any defective parts immediately.
- NEVER use the current probe on electrical conductors rated above 600V in overvoltage category III (CAT III). Use extreme caution when clamping around bare conductors or bus bars.

#### INTERNATIONAL ELECTRICAL SYMBOLS



This symbol signifies that the current probe is protected by double or reinforced insulation. Use only factory specified replacement parts when servicing the instrument.



This symbol signifies CAUTION! and requests that the user refer to the user manual before using the instrument.



This is a type A current sensor. This symbol signifies that application around and removal from HAZARDOUS LIVE conductors is permitted.

#### DEFINITION OF MEASUREMENT CATEGORIES


**CAT II:** For measurements performed on circuits directly connected to the electrical distribution system. Examples are measurements on household appliances or portable tools.

**CAT III:** For measurements performed in the building installation at the distribution level such as on hardwired equipment in fixed installation and circuit breakers.

**CAT IV:** For measurements performed at the primary electrical supply (<1000V) such as on primary overcurrent protection devices, ripple control units, or meters.

#### RECEIVING YOUR SHIPMENT

Upon receiving your shipment, make sure that the contents are consistent with the packing list. Notify your distributor of any missing items. If the equipment appears to be damaged, file a claim immediately with the carrier and notify your distributor at once, giving a detailed description of any damage.



**ELECTRICAL SPECIFICATIONS**

**Current Range:**

- 1 to 1000A AC continuous cycle
- 1 to 2000A AC continuous cycle
- 1 to 2400A AC continuous cycle for the full temperature range.
- (3000 A if temperature <35° C or 95° F)

**Transformation Ratio:**

1000:5, 2000:5 -3000:5

**Output Signal:**

- 5mA AC/A AC (5A at 1000A)
- 2.5mA AC/A AC (5A at 2000A)
- 1.666mA AC/A AC (5A at 3000A)

**Accuracy and Phase Shift\*:**

**1000A RANGE**

Primary current	50A	200A	1000A
Accuracy %	3%	1.5%	1%
Phase shift	3°	1.5°	1°

**Load Impedance:** 0.1Ω

**Overload:** 1200A for 10 mn

**Ampere Second Product:** 15 A.s

**Accuracy:** Per IEC 185-26-27  
Class 1 (2.5VA) from 48 to 1000 Hz

**2000A RANGE**

Primary current	100 A	400A	2000A
Accuracy %	1.5%	0.75%	0.5%
Phase shift	1.5°	0.75°	0.5°

**Load Impedance:** 0.2Ω

**Overload:** 2400A for 10 mn

**Ampere Second Product:** 50 A.s

**Accuracy:** Per IEC 185-26-27  
Class 0.5 (5 VA) from 48 to 1000 Hz

**3000A RANGE**

Primary current	150 A	600A	3000A
Accuracy %	1.5%	0.75%	0.5%
Phase shift	1.5°	0.75°	0.5°

**Overload:** 3600A for 10 mn

**Ampere Second Product:** 80 A.s

**Accuracy:** Per IEC 185-26-27  
Class 0.5 (10VA) from 48 to 1000 Hz

(\*Reference conditions: 23°C±3°K, 20 to 85% RH, 45 to 65 Hz, external magnetic field < 40 A/m, no DC component, no external current carrying conductor, test sample centered.)

**Frequency Range:** 30 to 1500 Hz; current derating above 1500Hz for continuous use

**Load Impedance:** ≤ 2Ω

**Working Voltage:** 600V AC

**Common Mode Voltage:** 600V AC

**Influence of Adjacent Conductor:**  
< 0.005A/A AC

**Influence of Conductor in Jaw Opening:**

1.5% ± 0.2A on 1000:5 range

1% ± 0.2A on 2000:5 range

1% ± 0.2A on 3000:5 range

**HANICAL SPECIFICATIONS**

**Operating Temp:** 14° to 122°F (-10° to 50°C)

**Storage Temp:** -13° to 176°F (-25° to 80°C)

**Influence of Temperature:** < 0.1% per 10°K

**Jaw Opening:** 3.54" (90 mm)

**Maximum Conductor Size:**

Cable: 2.52" Ø max. (64mm)

Bus bar: 1.97 x 5.31" (50 x 135 mm)

2.52 x 3.94" (64 x 100 mm)

**Envelope Protection:** IP 20 (IEC 529)

**Drop Test:** 1 m (IEC 68-2-32)

**Mechanical Shock:** 100 g (IEC 68-2-27)

**Vibration:** 10/55/10 Hz, 0.15 mm (IEC 68-2-6)

**Polycarbonate Material:**

Handles: 10% fiberglass charged polycarbonate UL 94 V0

Jaws: ABS UL 94 V2

**Dimensions:**

4.72 x 12.40 x 1.9" (120 x 315 x 48 mm)

**Weight:** 2.65 lbs. (1200 g)

**Colors:** Dark gray handles with red jaws

**Output:**

Two standard safety banana jacks (4mm)

**SAFETY SPECIFICATIONS**



**Electrical:**

Double insulation or reinforced insulation between primary or secondary and outer case of handle upon IEC 1010-2-32

**Common Mode Voltage:**

600V CAT III, Pollution: 2

**ORDERING INFORMATION**

**Current Probe JM865A..... Cat #2110.88**

**Accessories:**

Lead, set of 2, 5ft Safety Leads

(1000V CAT IV) ..... **Cat#2152.24**

Adapter BNC (Male) –Banana (Female) (XM-BB)

(600V CAT III)..... **Cat#2118.46**

## OPERATION

Please make sure that you have already read and fully understand the WARNING section on page 1.

### Making Measurements with the AC Current Probe Model JM865A

- Connect the black and red terminals to the Ampere AC range of your DMM or current measuring instrument. Select the appropriate current range. If the current magnitude is unknown, select the highest range (3000 A AC / 5 A AC) on the switch probe located inside the handle. Clamp the probe around the conductor to be tested, with the arrow pointed toward the load. Select the lower range until you obtain the best resolution. Read the value display on the DMM and multiply it by the range selected. (If reading = 2.59 A on the 1000/5 range, the current flowing through the probe is  $2.59 \text{ A} \times 200 = 518 \text{ A AC}$ ).
- For best accuracy: carefully center the conductor inside the probe jaw, avoid if possible, the proximity of other conductors which may create noise.

### Tips for Making Precise Measurements

- When using a current probe with a meter, it is important to select the range that provides the best resolution. Failure to do this may result in measurement errors.
- Make sure that probe jaw mating surfaces are free of dust and contamination. Contaminants cause air gaps between the jaws, increasing the phase shift between primary and secondary. It is very critical for power measurement.

## MAINTENANCE:

### Warning

- For maintenance use only original replacement parts.
- To avoid electrical shock, do not attempt to perform any servicing unless you are qualified to do so.
- To avoid electrical shock and/or damage to the instrument, do not get water or other foreign agents into the probe.

### Cleaning

To ensure optimum performance, it is important to keep the probe jaw mating surfaces clean at all times. Failure to do so may result in error in readings. To clean the probe jaws, use very fine sand paper (fine 600) to avoid scratching the jaw, then gently clean with a soft oiled cloth.

## REPAIR AND CALIBRATION

You must contact our Service Center for a Customer Service Authorization number (CSA#). This will ensure that when your instrument arrives, it will be tracked and processed promptly. Please write the CSA# on the outside of the shipping container.

Chauvin Arnoux<sup>®</sup>, Inc. d.b.a. AEMC<sup>®</sup> Instruments  
15 Faraday Drive • Dover, NH 03820 USA  
(800) 945-2362 (Ext. 360) • (603) 749-6434 (Ext. 360) • [repair@aemc.com](mailto:repair@aemc.com)

(Or contact your authorized distributor)

**NOTE: All customers must obtain a CSA# before returning any instrument.**

## TECHNICAL AND SALES ASSISTANCE

If you are experiencing any technical problems, or require any assistance with the proper use or application of this instrument, please contact our technical hotline:

(800) 343-1391 • (508) 698-2115 • [techsupport@aemc.com](mailto:techsupport@aemc.com)

## LIMITED WARRANTY

The current probe is warranted to the owner for a period of two years from the date of original purchase against defects in manufacture. This limited warranty is given by AEMC<sup>®</sup> Instruments, not by the distributor from whom it was purchased. This warranty is void if the unit has been tampered with, abused or if the defect is related to service not performed by AEMC<sup>®</sup> Instruments.

**Full warranty coverage and product registration is available on our website at:  
[www.aemc.com/warranty.html](http://www.aemc.com/warranty.html).**

Please print the online Warranty Coverage Information for your records.