

# AC Clamp Meter User Manual



**Part Number: 72-14415**

## Safety

### International Safety Symbols



This symbol, adjacent to another symbol or terminal, indicates the user must refer to the manual for further information.



This symbol, adjacent to a terminal, indicates that, under normal use, hazardous voltages may be present



Double insulation

## Safety Notes

- Do not exceed the maximum allowable input range of any function
- Do not apply voltage to meter when resistance function is selected.
- Set the function switch OFF when the meter is not in use.

## Warnings

- Set function switch to the appropriate position before measuring.
- When measuring volts do not switch to current/resistance modes.
- When changing ranges using the selector switch always disconnect the test leads from the circuit under test.
- Do not exceed the maximum rated input limits.

## Cautions

Improper use of this meter can cause damage, shock, injury or death. Read and understand this user manual before operating the meter.

Always remove the test leads before replacing the battery. Inspect the condition of the test leads and the meter itself for any damage before operating the meter. Repair or replace any damage before use.

Use great care when making measurements if the voltages are greater than 25V AC rms or 35V DC. These voltages are considered a shock hazard.

Remove the battery if the meter is to be stored for long periods.

Always discharge capacitors and remove power from the device under test before performing Diode, Resistance or Continuity tests.


- Voltage checks on electrical outlets can be difficult and misleading because of the uncertainty of connection to the recessed electrical contacts. Other means should be used to ensure that the terminals are not "live".
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

Input Limits	
Function	Maximum Input
A AC	400A
V DC, V AC	600V DC/AC


Input Limits	
Function	Maximum Input
Frequency, Resistance, Diode, Continuity, Capacitance Test	600V DC/AC
Temperature (°C/°F)	600V DC/ AC

## Meter Description

1. Current clamp
2. Non-contact AC voltage indicator light
3. Clamp trigger
4. Data Hold button
5. Rotary Function swith
6. MODE select button
7. Hz% Hlod button
8. Relative button
9. LCD display
10. COM input jack
11. V ΩCAP TEMPHz jack
12. Battery Cover




- |                                |  |
|--------------------------------|--|
| 1. AC DC                       | AC (alternating current) and DC (direct current) |
| 2.                             | Minus sign                                       |
| 3. 8.8.8.8                     | 4000 count (0 to 3999) measurement reading       |
| 4. AUTO                        | Auto Range mode                                  |
| 5. REL                         | Relative mode                                    |
| 6.                             | Diode test mode                                  |
| 7. ·)))                        | Audible Continuity                               |
| 8. HOLD                        | Data Hold mode                                   |
| 9. °C, °F, μ, m, V, A, K, M, Ω | Units of measure list                            |
| 10. Hz%                        | Frequency/duty cycle mode                        |



## Specifications

Function	Range & Resolution	Accuracy (% of reading)
AC Current (50/60Hz)	40.00AAC	±(2.5 % + 8 digits)
	400.0 AAC	±(2.8 % + 8 digits)
DC Voltage	400.0mV DC	±(0.8% + 2 digits)
	4.000V DC	±(1.5% + 2digits)
	40.00V DC	
	400.0V DC	
	600.0V DC	±(2 % + 2 digits)
AC Voltage (50-400Hz)	4.000V AC	±(1.8% + 8 digits)
	40.00V AC	
	400.0V AC	
	600.0V AC	±(2.5% + 8 digits)
Resistance	400.0Ω	±(1.0% + 4 digits)
	4.000kΩ	±(1.5% + 2 digits)
	40.00kΩ	
	400.0kΩ	
	4.000MΩ	±(2.5% + 3 digits)
	40.00MΩ	±(3.5% + 5 digits)
Capacitance	40.00nF	±(4.0% reading + 20 digits)
	400.0nF	±(3% reading + 5 digits)
	4.000μF	
	40.00μF	
	100.0μF	±(4.0% reading + 10 digits)
Frequency Sensitivity: 15Vrms	10-10kHz	±(1.5% reading + 2 digits)
Temp	-20.0 to 760.0°C	±(3%rdg + 5°C)

Clamp size	Opening 1.2" (30mm) approx
Diode Test	Test current of 0.3mA typical; Open circuit voltage 1.5V DC typical.
Continuity Check	Threshold <150Ω; Test current < 0.5mA
Low Battery Indication	 is displayed
Over range Indication	"OL" is displayed
Measurements Rate	2 per second, nominal
Input Impedance	10MΩ (V DC and V AC)
Display	4000 counts LCD
AC Current	50-60Hz (AAC)
AC Voltage bandwidth	50-400Hz (VAC)
Operating Temperature	41 to 104°F (5 to 40°C)
Storage Temperature	-4 to 140°F (-20 to 60°C)
Operating Humidity	Max 80% up to 87°F (31°C) decreasing linearly to 50% at 104°F (40°C)
Storage Humidity	<80%

Operating Altitude.	7000ft. (2000meters) maximum.
Over voltage	Category III 600V
Battery	Two "AAA" 1.5V Battery
Auto OFF	approx. 30 minutes
Dimensions/Weight	200x66x37mm / 205g
Safety	For indoor use and in accordance with Overvoltage Category II, Pollution Degree 2. Category II includes local level, appliance, portable equipment, etc., with transient overvoltages less than Overvoltage Cat. III


### Operation

NOTICES: Read and understand all warning and precaution statements listed in the safety section of this operation manual prior to using this meter. Set the function select switch to the OFF position when the meter is not in use.

### AC Current Measurements

WARNING: Ensure that the test leads are disconnected from the meter before making current clamp measurements.

1. Set the Function switch to the 400 or 40A range
2. If the range of the measured is not known, select the higher range first then move to the lower range if necessary.
3. Press the trigger to open jaw. Fully enclose one conductor to be measured. The clamp meter LCD will display the reading.



### DC/AC Voltage Measurements


1. Insert the black test lead into the negative COM terminal and the red test lead into the positive V terminal.
2. Set the function switch to the V position.
3. Select AC or DC with the MODE button.
4. Connect the test leads in parallel to the circuit under test.
5. Read the voltage measurement on the LCD display.

### Resistance Measurements

1. Insert the black test lead into the negative COM terminal and the red test lead into the positive terminal.
2. Set the function switch to the  $\Omega$  (•••) position.
3. Touch the test probe tips across the circuit or component under test. It is best to disconnect one side of the device under test so the rest of the circuit will not interfere with the resistance reading.
4. For Resistance tests, read the resistance on the LCD display.

### Diode and Continuity Measurements

1. Insert the black test lead banana plug into the negative **COM** jack and the red test lead banana plug into the positive diode jack.
2. Turn the rotary switch to the  $\Omega$  (•••) position.
3. Press the **MODE** button until "•••" appears in the display.
4. Touch the test probes to the diode under test. Forward voltage will indicate 0.4V to 0.7V. Reverse voltage will indicate "OL". Shorted devices will indicate near 0mV and an open device will indicate "OL" in both polarities.



For Continuity tests, if the resistance is < 150, a tone will sound.

---

### Capacitance Measurements

**WARNING:** To avoid electric shock, disconnect power to the unit under test and discharge all capacitors before taking any capacitance measurements. Remove the batteries and unplug the line cords.

1. Set the rotary function switch to the CAP position.
2. Insert the black test lead banana plug into the negative (COM) jack. Insert the red test lead banana plug into the positive (V) jack.
3. Touch the test leads to the capacitor to be tested.
4. Read the capacitance value in the display

### Frequency or % duty cycle measurements

1. Set the rotary function switch to the "V DC/AC,Hz" position.
2. Insert the black lead banana plug into the negative COM jack and the red test lead banana plug into the positive V jack
3. Select Hz or % duty with the Hz/% button.
4. Touch the test probe tips to the circuit under test.
5. Read the frequency on the display.

### Temperature Measurements

**WARNING:** To avoid electric shock, disconnect both test probes from any source of voltage before making a temperature measurement.

1. Set the function switch to °C or °F.
2. Insert the Temperature Probe into the negative (COM) and the V jacks, making sure to observe the correct polarity.
3. Touch the Temperature Probe head to the part whose temperature you wish to measure. Keep the probe touching the part under test until the reading stabilizes (about 30 seconds).
4. Read the temperature in the display. The digital reading will indicate the proper decimal point and value.

**WARNING:** To avoid electric shock, be sure the thermocouple has been removed before changing to another measurement function

### Non-Contact AC Voltage Measurements

**WARNING:** Risk of Electrocution. Before use, always test the Voltage Detector on a known live circuit to verify proper operation

1. Touch the probe tip to the hot conductor or insert into the hot side of the electrical outlet.
2. If AC voltage is present, the detector light will illuminate.

**NOTE:** The conductors in electrical cord sets are often twisted. For best results, rub the probe tip along a length of the cord to assure placing the tip in close proximity to the live conductor.

**NOTE:** The detector is designed with high sensitivity. Static electricity or other sources of energy may randomly trip the sensor. This is normal operation

### MODE BUTTON

To select DC/ACV,OHM/ Diode/Continuity

### Data Hold Button

To freeze the LCD meter reading, press the data hold button. The data hold button is located on the left side of the meter (top button). While data hold is active, the HOLD display icon appears on the LCD. Press the data hold button again to return to normal operation.

### REL BUTTON


For Capacitance Zero & Offset adjustment.

### RANGE BUTTON

When the meter is first turned on, it automatically goes into AutoRanging. This automatically selects the best range for the measurements being made and is generally the best mode for most measurements. For measurement situations requiring that a range be manually selected, perform the following:

1. Press the RANGE button. The “Auto Range” display indicator will turn off, The “Manual Range” display indicator will turn on
2. Press the RANGE button to step through the available ranges until you select the range you want.
3. Press and hold the RANGE button for 2 seconds to exit the Manual Ranging mode and return to Auto Ranging.

### Backlight Button

The backlight function illuminates the display and is used when the ambient light is too low to permit viewing of the displayed readings. Press the  button for two seconds to turn the backlight on and press the button a second time to turn the backlight off.

### Battery Replacement

1. Remove the one rear Phillips head screw
2. Open the battery compartment
3. Replace the Requires Two “AAA” 1.5V Battery (UM4 R03)
4. Re-assemble the meter

**Important Notice :** This data sheet and its contents (the “Information”) belong to the members of the Premier Farnell group of companies (the “Group”) or are licensed to it. No licence is granted for the use of it other than for information purposes in connection with the products to which it relates. No licence of any intellectual property rights is granted. The Information is subject to change without notice and replaces all data sheets previously supplied. The Information supplied is believed to be accurate but the Group assumes no responsibility for its accuracy or completeness, any error in or omission from it or for any use made of it. Users of this data sheet should check for themselves the Information and the suitability of the products for their purpose and not make any assumptions based on information included or omitted. Liability for loss or damage resulting from any reliance on the Information or use of it (including liability resulting from negligence or where the Group was aware of the possibility of such loss or damage arising) is excluded. This will not operate to limit or restrict the Group’s liability for death or personal injury resulting from its negligence. Tenma is the registered trademark of the Group. © Premier Farnell Limited 2016.