

904-314

INSKT 8

INSTALLATION KIT FOR BOFA SYSTEM 8 EXTRACTION UNIT

CONTENTS

ITEM	QTY	DESCRIPTION
1.	5x	2.5m Long 32mm Dia Tube
2.	1x	2.5m Long 32mm Dia Flexi Tube
3.	10x	Cobra Clip
4.	10x	Screw
5.	10x	Clear Plug
6.	4x	Red End Cap
7.	3x	32mm T (one with sleeve)

INSTRUCTIONS

Fix 32mm Tube to the most convenient position on the benches, usually at the back or underneath, using 2 cobra clips (item 3) and screws (item 4) per length of tube. The tube can be cut to length using a sharp knife or hacksaw. The tube can be joined together using 100mm lengths of flexible tube cut from the 2.5m length supplied. The flex pushes over the tube to make a vacuum tight connection. The remainder of the flexible tube should be used to connect the unit to the pipe work., Open ends of pipe run should be sealed by inserting a red end cap (item 6) into the tube.

At each point along the bench where a soldering iron is to be used, a 14mm hole should be drilled in the pipe and a clear plug inserted. (Care should be taken not to enlarge the hole size as the plug needs to be a tight fit.)

Typical layout shown overleaf.

Should you experience any difficulties with the installation please call our technical help line on: 01202 896199

