



ASSEMBLY INSTRUCTION

NYS 373-* | Heavy duty Phono Plug

A Slide the boot onto the cable.

B Prepare cable as shown.

C Solder the wire ends.

D Position the chuck onto the cable and align chuck with plugfinger.

E Slide the housing onto the Plugfinger with chuck.
Attention: If using a cable with big O.D. break off marked part on the chuck.

F Finish the installation by tighten the bushing onto the connector.

NEUTRIK AG LI T: +423 / 237 24 24 F: +423 / 232 53 93
 NEUTRIK USA Inc. USA T: +1 732 / 901 9488 F: +1 732 / 901 9608
 NEUTRIK (UK) Ltd. UK T: +44 1983 / 811 441 F: +44 1983 / 811 439
 NEUTRIK Vertriebs GmbH DE/NL/AT/DK T: +49 8131 / 280 890 F: +49 8131 / 280 830

NEUTRIK France FR T: +33 1 / 4131 6750
 NEUTRIK Tokyo Ltd. JP T: +81 3 / 3663 4733
 NEUTRIK Hong Kong Ltd. HK T: +852 / 2687 6055

F: +33 1 / 4131 0511
 F: +81 3 / 3663 4796
 F: +852 / 2687 6052