
# Data Sheet | Item Number: 2002-482

Staggered jumper; 12-way; insulated; light gray

https://www.wago.com/2002-482





Color: light gray

## Electrical data

Ratings per IEC/EN	
Nominal voltage (III/3)	400 V
Rated impulse voltage (III/3)	6 kV
Rated current	25 A

## Physical data

Width	61.2 mm / 2.409 inches
Jumper assignment	1-2-3-4-5-6-7-8-9-10-11-12

Material Data	
Note (material data)	
	<u>Information on material specifications can be found here</u>
Color	light gray
Fire load	0.052 MJ
Weight	6 g

Commercial data	
Product Group	22 (TOPJOB S)
eCl@ss 10.0	27-14-11-40
eCl@ss 9.0	27-14-11-40
ETIM 8.0	EC000489
ETIM 7.0	EC000489
PU (SPU)	25 pcs
Packaging type	Bag
Country of origin	DE
GTIN	4055143692366
Customs tariff number	85366990990

# Approvals / Certificates

# Data Sheet | Item Number: 2002-482

https://www.wago.com/2002-482



### Declarations of conformity and manufacturer's declarations




Approval Standard Certificate Name

Railway - Railway Ready

WAGO GmbH & Co. KG

# Downloads Environmental Product Compliance Compliance Search Environmental Product Compliance 2002-482





# **Installation Notes**

### Commoning





Orient the staggered jumpers' red stripes on the inside.

Insert the staggered jumper and push

Insert the staggered jumper and push down until it hits the backstop.

Commoning two potentials in one single jumper slot via extremely slim staggered jumpers.

# Data Sheet | Item Number: 2002-482

https://www.wago.com/2002-482



### Commoning



Orient the staggered jumpers' red stripes on the inside.

Insert the staggered jumper and push down until it hits the backstop.

### Commoning



Removing a staggered jumper: Insert the operating tool between the staggered jumpers, then lift up the jumper.

### Commoning



Staggered jumper (seven contacts)
Breaking off contact lugs. Individual jumper contacts can be broken off by bending them. The remaining piece of insulation will meet requirements for clearances and creepage distances.



Staggered jumpers Marking with a felt-tip pen.



Staggering jumpers in a single jumper slot:

Custom staggered jumpers can be created, e.g., for bridging over a terminal block with a different potential. Make sure that only one contact lug is in contact with the terminal block.

The contact lugs of the customized staggered jumpers contact the terminal blocks via the gaps created in the second jumper. Insert and press the ready-made jumper assembly into the jumper slot until it hits the backstop.

Subject to changes. Please also observe the further product documentation!

Current addresses can be found at::  $\underline{www.wago.com}$ 

Page 3/3 Version 21.03.2023