





$\frac{.102 \pm .004}{2.60 \pm 0.1} \varnothing$   
 $\varnothing \frac{.005}{0.13} \bigcirc \bigcirc \bigcirc$   
 2 PLC

$\frac{.031 \pm .002}{0.80 \pm 0.05} \varnothing$   
 $\varnothing \frac{.005}{0.13} \bigcirc \bigcirc \bigcirc$

RECOMMENDED PC BOARD LAYOUT  $\Delta$   
 COMPONENT SIDE

T