



AVF Group Ltd. Hortonwood 30, Telford, Shropshire, TF1 7YE, England
AVF Group, Inc. 2775 Broadway, Cheektowaga, Buffalo, New York, 14227 USA
www.avfgroup.com

2

Top
Haut
Parte Supérieure

G_{x4}

A_{x4}
M4 x 16mm

B_{x4}
M5 x 16mm

C_{x4}
M6 x 16mm

D_{x4}
M8 x 16mm

E_{x4}
M5

F_{x4}
M6

A+E
B+E
C+F
D

A+E+G
B+E+G
C+F+G
D+G

3

Concrete
Béton
Cemento

65mm (2 9/16")

12.5mm (1/2") Max

Remove dust from hole
Retirez la poussière du trou
Elimine el polvo del agujero

F_{x4}

M6

H_{x4}

L_{x4}

Lubricate screw thread with soap
Lubrifiez le pas de vis avec du savon
Lubrique la rosca del tornillo con jabón

3

50mm (2")

12.5mm (1/2") Min

Ensure bracket is in the centre of the wood stud
 Assurez-vous que l'applique est au centre de la latte de bois
 Asegúrese de que el soporte está en el centro de la viga de madera

Tools and Materials:
 - Pencil
 - Power Drill
 - 3mm (1/8") Drill Bit
 - Screwdriver
 - M6 Screws

Lubricate screw thread with soap
 Lubrifiez le pas de vis avec du savon
 Lubrique la rosca del tornillo con jabón

4

i

ii

The diagram illustrates the final steps of door installation. Step i shows the door being aligned with the frame and secured with a screw. Step ii shows the door being locked into the frame with a padlock. A warning icon of two people is in the top right corner.