

Filling Norm DIN 13 157

The SÖHNGEN® Standard Norm is the German DIN 13 157. All small SÖHNGEN® first-aid kits are filled to meet the requirements of the DIN 13 157. Although SÖHNGEN® First-Aid kits meet the requirements laid down in the German Accident Regulations, we exceed these basic requirements in terms of product quantity, quality and design.

Filling Norm DIN 13 157		
1	aluderm® Dressing Sheet 40 x 60 cm	DIN 13 152-BR
1	aluderm® Dressing Sheet 60 x 80 cm	DIN 13 152-A
3	aluderm® Bandage Packet medium	DIN 13 151-M
2	aluderm® Bandage Packet large	DIN 13 151-G
2	WS-elast. Gauze Bandage 4 m x 6 cm	DIN 61 634-FB 6
2	WS-elast. Gauze Bandage 4 m x 8 cm	DIN 61 634-FB 8
1	WS-Fixing Bandage 4 m x 6 cm	DIN 61 634-FB 6
1	WS-Fixing Bandage 4 m x 8 cm	DIN 61 634-FB 8
1	WS-fix Net Bandage Size 3	
2	aluderm® Eye Compress DuOcul	
6	aluderm® Compress, Single, 10 x 10 cm	
1	SÖHNGEN® Plast 5 m x 2,5 cm	DIN 13 019
8	aluderm® aluplast elastic 10 x 6 cm	DIN 13 019
5	aluderm® aluplast Finger band 18 x 2 cm	DIN 13 019
5	aluderm® aluplast Fingertip Bandage	
10	aluderm® aluplast Strips 1,9 x 7,2 cm	
1	Triangular Bandage V	DIN 13 168-D
1	Sirius-Rescue Sheet silver/gold 160 x 210 cm	
10	Non Woven Towels 20 x 30 cm	
2	Minigrip-Bag 30 x 40 cm	
1	First-Aid Scissors 19 cm	DIN 58 279-B190
4	Vinyl Gloves	DIN-EN 455-1
1	First-Aid Guide	
1	Air-Vita® Bi-Protect Breathing Device	

Do not accept inferior quality!

Top quality is deserved by the patient and supports the healing process and guarantees optimum wound care. Do yourself and your employees a favour - you are worth the money!

The following are some examples of SÖHNGEN® top quality products: aluderm® and aluderm® aluplast, aluminium vaporized dressing containing BACTEKILLER. The WS-elastic bandage is highly elastic, air vented and does not hinder blood circulation.

Individual Set Plus  
for the Industrial Norm Filling

- 1 aluderm® aluface
- 2 aluderm® alufinger
- 1 aluderm® Cohesive Bandage
- 1 Compression Bandage
- 50 aluderm® aluplast Wound Plaster
- 4 aluderm® aluplast Finger Joint Bandage
- 1 aluderm® aluplast Sterile Bandage, small
- 1 aluderm® aluplast Sterile Bandage, large
- 1 SÖHNGEN® Cool Spray 100 ml
- 1 Hand Disinfectant 100 ml
- 1 Splinter Forceps, rust free
- 12 Safety Pins

Additional Set Plus

We offer more than the regulations require. Ready-to-use bandages for immediate usage.

Air-Vita® Bi-Protect

As an addition for your safety, there is a breathing device in every SÖHNGEN® filling.

Our additional recommendations:

AquaNIT® and OculavNIT® Immediate Eye Wash.

Ready-to-use 250 ml pump bottle of AQUA NIT® Sterile Water or oculav NIT® Sterile Solution for immediate application at the accident scene.

Extra Set Plaster Supplement

You can never have enough plasters. Plastic box with aluderm®aluplast wound bandages, individually and hygienically sealed, in addition to Silk tape for immediate usage.

Filling Norm

= 72 parts - high quality dressings  
manufactured by SÖHNGEN®  
Filling DIN 13 157

03 03 018

Filling NormPlus

= 148 parts - high quality dressings  
manufactured by SÖHNGEN®  
Filling DIN 13 157 with Additional Set Plus

03 03 019

