

# DSP 862 LEAD FREE NO CLEAN SOLDER PASTE

**CORPORATE HEADQUARTERS** USA: 315 Fairbank St. Addison, IL <sup>1</sup> 630-628-8083 or 1-800-365-3750 <sup>1</sup> FAX 630-628-6543 **EUROPE** UK: Unit 9 Apex Ct. Bassendale Rd. Bromborough, Wirral CH62 3RE <sup>1</sup> 44 151 334 0888 <sup>1</sup> FAX 44 151 346 1408 **ASIA-PACIFIC HEADQUARTERS** SINGAPORE: 6 Tuas South St. 5 Singapore 637790 <sup>1</sup> 65 6795 7757 <sup>1</sup> FAX 65 6795 7767 **PHILIPPINES:** Phase 1 Qualitek Ave. Mariveles, Bataan Philippines C-2106 <sup>1</sup> 6347 935 4163 <sup>1</sup> FAX 63475613717 **CHINA:** 3B/F, YiPa Print Bldg. 351 # JiHua Rd., Buji Shenzhen, China 518112 <sup>1</sup> 86 755 28522814 <sup>1</sup> FAX 86 755 28522787

This data is based on information that the manufacturer believed to be reliable and offered in good faith. Qualitek International, Inc. makes no warranties expressed or implied as to its accuracy and assumes no responsibilities and liabilities arising out of its use by others as conditions and methods of use of the products is beyond the control of Qualitek International, Inc. The user must determine the suitability of the product before using it on a commercial basis. The warranties extend only to the conformity of the product to the physical descriptions. In no event will Qualitek International, Inc. be responsible for special, incidental and consequential damages whether the claim is in contract, negligence or otherwise. Qualitek specifically disclaims any liability for consequential or incidental damages of any kind, including lost profits.

## **Physical Properties**

## **Solder Composition**

Qualitek Sn/Ag/Cu (Tin/Silver/Cu) is designed as a lead-free alternative for Sn/Pb alloys for electronics assembly operations. The Qualitek Sn/Ag/Cu alloy conforms and exceeds the impurity requirements of J-Std-006 and all other relevant international standards.

Typical Analysis													
Sn	Ag	Cu	Pb	Sb	Bi	In	As	Fe	Ni	Cd	Al	Zn	Au
Bal	3.6- 4.0	0.5- 0.9	0.050 Max	0.050 Max	0.050 Max	0.050 Max	0.010 Max	0.010 Max	0.005 Max	0.001 Max	0.001 Max	0.001 Max	0.002 Max

	Sn/Ag/Cu	Sn63/Pb37
Melting Point, ° C	217-221	183 E
Hardness, Brinell	15HB	14HB
Coefficient of Thermal Expansion	Pure Sn= 23.5	24.7
Tensile Strength, psi	4312	4442
Density, g/cc	7.39	8.42
Electrical Resistivity , (μohm-cm)	13.0	14.5
Electrical Conductivity, %IACS	16.6	11.9

	Sn/Ag/Cu	Sn63/Pb37
Yield Strength, psi	3724	3950
Total Elongation,%	27	48
Joint Shear Strength, at 0.1mm/min 20 C	27	23
Joint Shear Strength, at 0.1mm/min 100 C	17	14
Creep Strength, N/mm <sup>2</sup> at 0.1mm/min 20 C	13.0	3.3
Creep Strength, N/mm <sup>2</sup> at 0.1mm/min 20 C	5	1
Thermal Conductivity, W/m.K	58.7	50.9

## **Particle Size**

Sn/Ag/Cu is available in Type 2 (75-45 $\mu$ m), 3(45-25 $\mu$ m), 4(38-20 $\mu$ m), and 5 (25-15 $\mu$ m) J-STD-005 powder distribution. Solder powder distribution is measured utilizing laser diffraction, optical analysis and sieve analysis. Careful control of solder powder manufacturing processes ensures the particles' shape are 95% spherical minimum (aspect ratio < 1.5) and that the alloy contains a typical maximum oxide level of 80 ppm.

Powder Type	Fines	Majority			rse	Typical Mesh
	<10%	>80%	>90%	<1%	0%	
1	20	75-150		150	160	100/200
2	20	45-75		75	80	200/325
3	20	25-45		45	50	325/500
4	20		20-38	38	40	400/635
5	15		15-25	25	30	500
6	5		5-15	15	20	

Classification of Solder Powders by Particle Size

## **TECHNICAL SPECIFICATIONS**

Sn/Ag/Cu. 862 Rev.A

## **Metal Loading**

Typical metal loading for stencil printing application is <u>88-89%.</u> Compared to typical Sn63/Sn62 solder pastes manufactured with 90% by weight metal loading, DSP862 Lead Free provides as much as 10-12% higher metal volume than Sn63/Sn62. This increased in volume of DSP862 promotes better wetting and spreading of Sn/Ag/Cu Lead Free alloy.

## **Solder Paste**

Qualitek has developed a unique flux system designed specifically for high temperature lead free alloys. It provides the fluxing activity levels that promote thermal stability and prevents thermal degradation when reflowing under air atmosphere (normal). Since use of nitrogen is not required, DSP 862 Lead Free Solder paste will provide excellent cost savings.

In addition, DSP 862Lead Free solder paste exhibits superior joint strength, excellent wettability, extraordinary print definition and tack life. The post soldering residues of DSP862 are non-conductive, non-corrosive and highly insulated.

#### Main Features

- □ Low Voiding
- Excellent wettability
- □ Long tack time
- □ Excellent hot slump resistance
- □ Medium soft non-cracking residues
- □ Extended stencil life

	Specification	Test Method
Flux Classification	ROL0	JSTD-004
Tiux Classification	NOLU	3310-004
Copper Mirror	No removal of copper film	IPC-TM-650 2.3.32
Silver Chromate	Pass	IPC-TM-650 2.3.33
Corrosion SIR	Pass	IPC-TM-650 2.6.15
JSTD-004	1.58 x 10 <sup>11</sup> ohms	IPC-TM-650 2.6.3.3
Bellcore (Telecordia)	2.61 x 10 <sup>11</sup> ohms	Bellcore GR-78-CORE 13.1.3
Electromigration	Pass	Bellcore GR-78-CORE 13.1.4
Post Reflow Flux Residue	55%	TGA Analysis
Acid Value	168	IPC-TM-650 2.3.13
Metal Loading	88%	IPC-TM-650 2.2.20
Viscosity		
Brookfield (1), kcps	900+/-10% kcps	IPC-TM-650 2.4.34 modified
Malcom (2), poise	1700-2050	IPC-TM-650 2.4.34.3 modified
Thixotropic Index	0.50-0.60	
Slump Test		
25 C, 0.63 vertical/horizontal	No bridges all spacings	IPC-TM-650 2.4.35
150 C, 0.63 vertical/horizontal	No bridges all spacings	IPC-TM-650 2.4.35
25 C, 0.33 vertical/horizontal	0.15 /0.15	IPC-TM-650 2.4.35
150 C, 0.33 vertical/horizontal	0.06/0.06	IPC-TM-650 2.4.35
Solder Ball Test	Pass	IPC-TM-650 2.4.43
Tack		
Initial	130 gm	JIS Z 3284
Tack retention @ 24 hr	124 gm	JIS Z 3284
Tack retention @ 72 hr	57 gm	JIS Z 3284
Stencil Life	>8 hrs	QIT 3.44.5
Abandon Time	30-60 min	QIT 3.44.6

#### **Printing**

#### **Stencil**

Use of chemical etched/electroformed stencil is preferred however DSP862 has been used successfully with chemical etch, electroformed, and laser cut stencils.

## **Squeegee**

Blades: Metal (stainless steel) squeegee blades angled from 45-60° give the best print definition. Metal

(nickel) squeegee blades angled from 45-60° give the best performance. 90 durometer

polyurethane may also be used.

Pressure: Pressure should be adjusted at the point where the paste leaves a relatively clean stencil after

each print pass. Typical pressure setting 0.6-1.5lb per linear inch of blade.

Speed: Normal print speeds are 1.0-2.5 (25-50mm) per second. As print speeds increase pressure

willneed to be increased.

## **Print Definition**

DSP862 provides excellent print definition characterized by brick-like prints. Good release is seen on 12-9 mil apertures with print speeds in the range 0f 25mm -150mm per second.

#### **Open & Abandon Time**

Tests have proven that DSP862 will perform during continuous printing for up to 8 hrs. Field test have shown that an abandon time of at least 1 hr is possible, resulting in a perfect 1st pass print on resumption of printing.


#### **Paste Application**

Solder paste should be taken out of the refrigerator at least 3 to 6 hours prior to use. This will give the paste enough time to come to thermal equilibrium with the environment. Also, any fresh jar of solder paste should be gently mixed for at least one minute with a spatula. Be sure not to mix the paste too vigorously, as this will destroy the paste's viscosity characteristics and introduce entrapped air into the paste. The purpose of the mixing is to insure that the paste is smooth and consistent. If solder paste is supplied in cartridges pre-mixing is not necessary due to the shear action produced from the dispensing.

#### **Reflow**

Best results have been acheived when DSP 862 is reflowed in a *forced air convection* oven with a minimum of 8 zones (top&bottom), however reflow is possible with a 4 zone oven (top & bottom).

The following is a recommended profile for a forced air convection reflow process. The melting temperature of the solder, the heat resistance of the components, and the characteristics of the PCB (i.e. density, thickness, etc.) determine the actual reflow profile.



**Ramp Zone**- the ramp zone is used to elevate the temperature of the PCB to the desired soak temperature. In the ramp zone the temperature of the PCB is constantly rising, at a rate that should not exceed 2.5 C/sec. The oven's ramp zone should normally occupy 25-33% of the total heated tunnel length.

**The Soak Zone-** normally occupies 33-50% of the total heated tunnel length exposes the PCB to a relatively steady temperature that will allow the components of different mass to be uniform in temperature. The soak zone also allows the flux to concentrate and the volatiles to escape from the paste.

**The Reflow Zone-** or spike zone is to elevate the temperature of the PCB assembly from the activation temperature to the recommended peak temperature. The activation temperature is always somewhat below the melting point of the alloy, while the peak temperature is always above the melting point.

**The Cooling Zone** – A cool down rate of 2-4C per second is ideal for the formation of fine grain structure without risking damage to thermally sensitive components.

#### **CLEANING**

DSP 862 is a no clean formulation therefore the residues do not need to be removed for typical applications. If residue removal is desired, the use of Everkleen 2015 Buffered cleaner with a 50% concentration in hot 60 C (140 F) will aid in residue removal.

#### Sn/Ag/Cu. 862 Rev.A

#### **Storage & Shelf Life**

It is recommended that solder paste be stored at a temperature of between 35-50 F (2-10 C) to minimize solvent evaporation, flux separation, and chemical activity. If room temperature storage is necessary it should be maintain between 68-77F (20-25 C) .

Shelf life

Unopened Container (35-50F/2-10C) 9 months (from DOM) Unopened Container (68-77F/20-25 C) 3 months (from DOM)

Opened Container (68-77F/20-25 C) 24 hours

#### **Reusing Solder Paste**

This is not normally recommended, because it typically generates more problems than it is worth. If you do decide to reuse solder paste, these pointers may be helpful. First, Qualitek recommends putting any used solder paste in an empty jar, so any fresh paste will not become contaminated. This paste should be tightly sealed and refrigerated. Then, the paste may be reused at a later date, provided that the paste has not separated or thickened significantly compared to its original properties. If you have success in printing the reused paste, the paste is acceptable for use. If significant printing problems occur, discard the paste. You also may want to mix 50% "used" and 50% new to get maximum utility of the paste. This will keep the paste relatively fresh while consuming the used paste.

#### **Working Environment**

Solder paste performs best when used in a controlled environment. Maintaining ambient temperature of between 68-77 F (20-25 C) at a relative humidity of 40-65% will ensure consistent performance and maximum life of paste.

## **Cleaning Misprint Boards**

If you should have a misprinted board, the paste may be cleaned off manually with alcohol (IPA) or Qualitek stencil cleaner, SK-11. If you have a more elaborate board cleaner, the paste may be easily removed with use of a 5% saponifier solution in hot DI water. Qualitek SK-44 saponifier could be used in this process.

#### **Stencil Cleaning**

Periodic cleaning of the stencil during production is recommended to prevent any paste from being deposited in unwanted areas of the board. Without stencil cleaning, solder balling will increase. We recommend a periodic dry wipe (every 5 to 10 boards) with an occasional wet wipe (every 15 to 25 boards). When running fine pitch boards, the cleaning may need to become more frequent. The wet wipes should be performed with either alcohol or a stencil cleaner. Qualitek SK-11 stencil cleaner is designed for this purpose. When cleaning the stencil at the end of a job, the cleaning should be more thorough. If you have stencil cleaning equipment Qualitek SK-44 Stencil Cleaner Saponifier is highly recommended for stencil cleaning purposes.

## **Disposal**

DSP 862 should be stored in a sealed container and disposed of in accordance with state & local authority requirements.

#### **Packaging**

DEK Proflow Cassette 750 gm 6oz Jar 500 gm 6 oz Cartridge 500-600 gm

#### Page 7 of 8

## HANDLING & STORAGE

Sn/Ag/Cu. 862 Rev.A

12 oz Cartridge 1000-1200gm