

METEX[®]

CHAMFER TOOL



Instructions



1. Attach the male spigot into the drill chuck.



2. Clamp the pipe to be chamfered and place the tool over the end.



3. Engage the drill and rotate the tool, keeping it parallel to the pipe.



4. Apply steady pressure. Never force the tool.

- For use with 110mm PVC pipes.
- Use as guided by the directional arrows on the unit.
- Secure all loose items of clothing and keep hands away from the rotating unit.
- Chamfer blades not replaceable.
- When used correctly, the chamfer tool will provide hundreds of uses.

**SEE HOW
IT WORKS**

