DRAWIN SPL8		SHEET 1 OF 3	МО	DEL NAME NA	ISSUE 1
ISSUE	МО	DIFICATION		DRN	DATE
1	ORI	GINAL ISSUE		NJK	17.08.07

Marl International Limited

Marl Business Park, Ulverston, Cumbria, LA12 9BN, England.

tel: +44 (0)1229 582430 fax: +44 (0)1229 585155 e-mail: sales@marl.co.uk website: www.marl.co.uk

Overview

An LED light fixture requires a constant current power source. To facilitate the smooth installation of the LED fixtures available in the Soid State Lighting catalogue, a comprehensive range of constant current drivers are provided. Driver configurations can be tailored to match individual application requirements. Below is a brief explination of each driver configuration including components required.

A - Low voltage non-dimmable 1 way

This system is used to power one white LED light fixture. The components required are as follows:

Low voltage power supply - LP1060 (see accessories data sheet) External driver box - 726 series driver box (see SPL8148)

LED light fixture - See Solid State Lighting catalogue

Junction box - JUNCTIONBOX5AMP (see accessories data sheet) IP68 junction box - SL001-2WAY (see accessories data sheet)

Installation notes:

- 1. Connect AC input cable of the LP1060 to mains power. Do not turn mains power on until installation is complete. A junction box may be required.
- 2. Connect the Class 2 power output cable of the LP1060 to the input of the external driver box. See SPL8148 for external driver box installation notes. A junction box may be required.
- 3. Connect LED light fixture to LED output of external driver box. See SPL8148 for external driver box installation notes. A junction box may be required.
- 4. Turn on mains power.

B - Low voltage non-dimmable 2 to 4 way

This system is used to power 2 to 4 white LED light fixture.

The components required are as follows:

Low voltage power supply - LP1060 (see accessories data sheet)

External driver box - 726 series driver box (see SPL8148) LED light fixture - See Solid State Lighting catalogue

Optional extras:


Junction box - JUNCTIONBOX5AMP (see accessories data sheet) IP68 junction box - SL001-2WAY (see accessories data sheet)

Installation notes:


- 1. Connect AC input cable of the LP1060 to mains power. Do not turn mains power on until installation is complete. A junction box may be required.
- 2. Connect the Class 2 power output cable of the LP1060 to the input of the external driver box. See SPL8148 for external driver box installation notes. A junction box may be required.
- 3. Connect LED light fixture to LED output of external driver box. See SPL8148 for external driver box installation notes. A junction box may be required.
- 4. Repeat step 3 for each LED light fixture.
- 5. Turn on mains power.

TOLERANCE/ SCALE UOS DRN: NJK LINEAR N/A DATE: 17/08/07 **ANGULAR** N/A ALL DIMENSIONS CHK1: NO ORIGINAL SCALE CHK2: 1.1 IN MM

WIRING SCHEMATICS FOR ACHITECTURAL LIGHTING



B - Low Voltage Non-Dimmable 2 to 4 way*



DRAWIN SPL8		SHEET 2 OF 3	МО	DEL NAME NA	ISSUE 1
ISSUE	МО	DIFICATION		DRN	DATE
1	ORIGINAL ISSUE			NJK	17.08.07



Marl International Limited

Marl Business Park, Ulverston, Cumbria, LA12 9BN, England.

tel: +44 (0)1229 582430 fax: +44 (0)1229 585155 e-mail: sales@marl.co.uk website: www.marl.co.uk

WIRING SCHEMATICS FOR ACHITECTURAL LIGHTING

C - Low voltage dimmable 1 to 8 way

This system is used to power 1 to 8 white LED light fixture. The components required are as follows:

Low voltage power supply - LP1060 (see accessories data sheet) Dimmable driver unit - 726 series dimmable driver unit (see

accessories data sheet)
LED light fixture - See Solid State Lighting catalogue
Optional extras:


Junction box - JUNCTIONBOX5AMP (see accessories data sheet) IP68 junction box - SL001-2WAY (see accessories data sheet)

Installation notes:

- 1. Connect AC input cable of the LP1060 to mains power. Do not turn mains power on until installation is complete. A junction box may be required.

 2. Connect the Class 2 power output cable of the LP1060
- Connect the Class 2 power output cable of the LP1060 to the input of the dimmable driver unit and the input of the 0-10V dimmer. See data sheet for dimmable driver unit. A junction box may be required.
- 3. Connect LED light fixture to LED output of dimmable driver unit. See data sheet for dimmable driver unit.
- 4. Connect the output for the 0 10V dimmer to the input of the dimmable driver unit. A junction box may be required.
- 5. Repeat step 3 and 4 for each LED light fixture.
- 6. Turn on mains power and adjust dimmer as required.

C - Low Voltage Dimmable 1 to 8 way



TOLERANCE/ SCALE UOS
LINEAR N/A
ANGULAR N/A ALL DIMENSIONS CHK1:
ORIGINAL SCALE 1:1 IN MM CHK2:

DRAWIN SPL8		SHEET 3 OF 3	МО	DEL NAME NA	ISSUE 1
ISSUE	MODIFICATION			DRN	DATE
1	ORIGINAL ISSUE			NJK	17.08.07



Marl International Limited

Marl Business Park, Ulverston, Cumbria, LA12 9BN, England.

tel: +44 (0)1229 582430 fax: +44 (0)1229 585155 e-mail: sales@marl.co.uk website: www.marl.co.uk

WIRING SCHEMATICS FOR ACHITECTURAL LIGHTING

D - Mains voltage non-dimmable 1 way
This system is used to power one white LED light fixture.
The components required are as follows:
Mains driver unit - L07U or LP1040 (see accessories data sheet)
LED light fixture - See Solid State Lighting catalogue

Optional extras:

Junction box - JUNCTIONBOX5AMP (see accessories data sheet) IP68 junction box - SL001-2WAY (see accessories data sheet)

Installation notes:
1.Connect AC input leads of the L07U or LP1060 to mains power.
Do not turn mains power on until installation is complete. A


junction box may be required.

2. Connect LED light fixture to LED output leads of mains driver unit.

See L07U or LP1040 data sheet installation notes.

A junction box may be required. 3. Turn on mains power.

D - Mains Voltage Non-Dimmable 1 way



TOLERANCE/ SCAL	E UOS		DRN:	NJK
LINEAR	N/A		DATE:	17/08/07
ANGULAR	N/A	ALL DIMENSIONS	CHK1:	O.Molm
ORIGINAL SCALE	1:1	IN MM	CHK2:	NO