Roxtec

Product news
Roxtec RTM Software

NEW

Roxtec Cable and Pipe Transit Software
Planning has never been easier

RTM Software

A cost reducing software

Time is money! Roxtec's Transit Manager helps simplify the work of planning and installation of cable and pipe transits.

The Roxtec Transit Manager (RTM) is a software specifically developed to meet the needs of design departments within practically any type of industry and for the use of Roxtec's transit products. The traditional method of designing transits by use of CAD drawing software can be time consuming. The RTM lets you cut corners through Autoplanning, import options and other strong features to save time at all phases of a routing project.

Simple planning

Enter cables or pipes manually or import project data from external lists. Then use the Autoplanning feature to generate automatic packing plans. Once completed, print out material lists for the purchasing department and use it to order the required components. Drawings and packing plans can be exported as dxf files and the created geometries reused in CAD programs.

Installation aid

The transit plans allow each transit in the project to be well documented. Every image is shown as photographs for easy understanding. Designers can easily identify and lable each cable or pipe in the transit. Packing plans can be printed and handed to the installers for safe installation. With the materials list at hand, logistics is also simplified in bringing the right products to the location. The packing plans and materials list will in total reduce margins for error since there will be little room left for mistakes. ■

RTM Software features

■ Import external cable lists
■ Generate Automatic Packing Plans
■ Customise Project Criteria
■ Customise language
■ Generate CAD drawings
■ Export dxf files and CAD geometries

System Recommendations

■ Windows XP
■ 2 GHz processor
■ 256 MB RAM
■ 80 MB of hard drive space for program installation

The RTM software is a client – server solution and can be installed in two different ways; local installation or in a network of computers. From Version 1.0.0.0 both installation alternatives are available.

Roxtec