




# Refill Instructions - Epson T0422-T0424



## Printers

Epson C82, Cx5200, CX5300, CX5400

## Items Required

Original Epson T0422, T0423 or T0424 Cartridge, Syringe & Filling Tube, Insulation tape, Newspaper. Black Cyan Magenta Yellow Ink 9ml

## Instructions

1. Reprogramme cartridges before refilling, using a JR Inkjet Zap-It
2. Place adhesive tape over outlet hole.
3. Pierce the vent hole and the filling hole through the label with a sharp point. (Do not use the filling tube)
4. Fill the syringe and insert into the filling hole. The syringe will only enter into the Cartridge approx ½cm.
5. Inject ink very slowly allowing the ink to flow into the cartridge consistently.
6. Once ink bleeds through the vent hole and the filling hole the cartridge is full, withdraw about 1ml of ink.
7. Place strong adhesive tape over both Vent & Filling Holes.
8. Leave cartridge to stand on a protective, non-absorbent surface overnight to ensure no leakage and to give the ink time to saturate the sponge.
9. Place cartridge in printer and print test print. If streaking occurs run a cleaning cycle.

**IMPORTANT:** For best results, refill whilst ink still remains in cartridge. Empty cartridges should be refilled immediately.

For more info go to [help.jrinkjet.co.uk](http://help.jrinkjet.co.uk)