

Cord Couplers



- A range of cross wired and straight wired cord couplers designed for connecting RJ and BT terminated cords

Cross Wired - These are wired pin 1 to pin 1 etc. and are used for connecting two cables together without altering the actual configuration of the wiring.

Straight Wired - Because of the way they are wired within the coupler, they produce the following configurations:

TE05844: Pin 2-5, 3-4, 4-3, 5-2