



**MICROCHIP**

---

# FAQs – Sensor Design Guidelines



**TO OUR VALUED CUSTOMERS**

It is our intention to provide our valued customers with the best documentation possible to ensure successful use of your Microchip products. To this end, we will continue to improve our publications to better suit your needs. Our publications will be refined and enhanced as new volumes and updates are introduced.

If you have any questions or comments regarding this publication, please contact the Marketing Communications Department via E-mail at [docerrors@microchip.com](mailto:docerrors@microchip.com). We welcome your feedback.

**Most Current Tech Brief**

To obtain the most up-to-date version of this Tech Brief, please register at our Worldwide Web site at: [www.microchip.com](http://www.microchip.com)

You can determine the version of a data sheet by examining its literature number found on the bottom outside corner of any page.

The last character of the literature number is the version number, (e.g., DS30000A is version A of document DS30000).

**Customer Notification System**

Register on our web site at [www.microchip.com](http://www.microchip.com) to receive the most current information on all of our products.

**Customer Support**

Customers should contact their distributor, representative or field application engineer (FAE) for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in the back of this document. Technical support is available through the web site at: <http://support.microchip.com>

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

**Trademarks**

The Microchip name and logo, the Microchip logo, dsPIC, KEELOQ, KEELOQ logo, MPLAB, PIC, PICmicro, PICSTART, PIC32 logo, rPIC and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

FilterLab, Hampshire, HI-TECH C, Linear Active Thermistor, MXDEV, MXLAB, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Application Maestro, chipKIT, chipKIT logo, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, dsSPEAK, ECAN, ECONOMONITOR, FanSense, HI-TIDE, In-Circuit Serial Programming, ICSP, Mindi, MiWi, MPASM, MPLAB Certified logo, MPLIB, MPLINK, mTouch, Omniscient Code Generation, PICC, PICC-18, PICDEM, PICDEM.net, PICKit, PICtail, REAL ICE, rLAB, Select Mode, Total Endurance, TSHARC, UniWinDriver, WiperLock and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2012, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

Printed on recycled paper.

*Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.*

**QUALITY MANAGEMENT SYSTEM  
CERTIFIED BY DNV  
== ISO/TS 16949:2009 ==**



# TABLE OF CONTENTS

- 1. INTRODUCTION .....4**
- 2. SENSOR CONSTRUCTION.....4**
  - 2.1 SENSOR LAYERS .....4
  - 2.2 SENSOR OVERLAY .....5
    - 2.2.1 Material Type.....5
    - 2.2.2 Material Thickness .....5
    - 2.2.3 Overlay Adhesive .....5
  - 2.3 PATTERN.....6
  - 2.4 ELECTRODE GEOMETRY .....7
  - 2.5 ELECTRODE ASSIGNMENT.....7
  - 2.6 SHIELDING .....7
  - 2.7 ELECTRODE ROUTING TO CONTROLLER.....7
- 3. PCB SENSOR AND APPLICATION EXAMPLE .....8**
  - 3.1 PCB EXAMPLE - TOP LAYER .....8
  - 3.2 PCB EXAMPLE – 2<sup>ND</sup> LAYER .....9
  - 3.3 PCB EXAMPLE – 3<sup>RD</sup> LAYER.....10
  - 3.4 PCB EXAMPLE – BOTTOM LAYER .....11

# FIGURES

- Figure 1 : Sensor Layers – Cross Section .....4*
- Figure 2 : Touch Sensitivity verses Acrylic Overlay Thickness.....5*
- Figure 3 : Sensor Electrode.....6*
- Figure 4 : X & Y Axis Electrode Examples.....6*
- Figure 5 : 12 X-axis and 9 Y-axis Combined Sensor Example.....6*
- Figure 6 : Electrode Geometry.....7*
- Figure 7 : Rx & Tx Electrode Proximity Routing Cross Section.....7*
- Figure 8 : PCB Example – Top Layer Copper.....8*
- Figure 9 : PCB Example – 2<sup>nd</sup> Layer Copper.....9*
- Figure 10 : PCB Example – 3<sup>rd</sup> Layer Copper.....10*
- Figure 11 : PCB Example – Bottom Layer Copper.....11*



## 1. INTRODUCTION

Microchip's mTouch™ Projected Capacitive (Pcap) Touch Sensing technology provides a readily accessible, low cost, low power solution to facilitate implementation of projected capacitive touch user interfaces.

Microchip's *Capacitive Multi-Touch 18x13 Channel Controller # MTCH6301* is an exciting product offering, which can be purchased at microchipDIRECT [www.microchipdirect.com](http://www.microchipdirect.com).

This document is a technical brief on designing a PCB projected capacitive sensor for the # MTCH6301 *Capacitive Multi-Touch 18x13 Channel Controller*.

## 2. SENSOR CONSTRUCTION

The touch sensor is constructed on 4-layer printed circuit board (PCB), which is also used for the application circuit. A 2-layer PCB is possible for some applications.

The PCB consists of a non-conductive fiberglass/epoxy substrate called FR4 and conductors of 1.0 oz/ft<sup>2</sup> (~0.48 mΩ/sq, ~35 μm thick) copper. The total board thickness is ~1.6mm.

### 2.1 Sensor Layers

A non-scale cross sectional view of the sensor layers is shown below.




Figure 1 : Sensor Layers – Cross Section



## 2.2 Sensor Overlay

The sensor overlay is a non-conductive molded plastic or glass cover placed on top of the sensor.

### 2.2.1 Material Type

The overlay material must be non-conductive. For good touch performance, it is preferred to have a material dielectric constant greater than 3. Some commonly used materials are plastics like ABS, Acrylic, and Polycarbonate.

### 2.2.2 Material Thickness

Touch sensitivity is reduced as the overlay thickness is increased. The material thickness should be in the range of 0.1 mm to 3.0 mm.

An approximate relationship of touch sensitivity versus acrylic overlay thickness is shown below.




Figure 2 : Touch Sensitivity versus Acrylic Overlay Thickness

### 2.2.3 Overlay Adhesive

A double sided adhesive is used to mechanically join the overlay to the PCB touch sensor.

A floated overlay-to-sensor interface with no adhesive is not recommended. This can cause poor touch performance due to mechanical instability and a poor dielectric.

The adhesive thickness is typically from approximately 50  $\mu$ m to 200  $\mu$ m thick. An example adhesive is the 3M part 467MP.



### 2.3 Pattern

The sensor is a matrix of conductive electrodes on the PCB, electrically isolated from each other, arranged as rows and columns or X and Y. An electrode consists of multiple diamond shaped elements, each connected to the next with a conductive neck.



Figure 3 : Sensor Electrode

An example 12 electrode X-axis and 9 electrode Y-axis pattern are shown below.




Figure 4 : X & Y Axis Electrode Examples

The 12 electrode X-axis and a 9 electrode Y-axis are combined on the same PCB layer to create a 12x9 electrode sensor. A different PCB layer and vias are used for electrode neck cross over locations.




Figure 5 : 12 X-axis and 9 Y-axis Combined Sensor Example



MICROCHIP

## 2.4 Electrode Geometry

Diamond elements are used to maximize the exposure of sensor electrodes to a touch.

All electrodes are on the same PCB layer. Electrical isolation is achieved at X & Y axis electrode neck cross over locations by using another PCB layer. Electrode vias to another PCB layer should have approximate diameters of 0.79 mm outer, 0.64 mm inner, and 0.38 mm drill.




Figure 6 : Electrode Geometry

## 2.5 Electrode Assignment

Electrodes of one sensor axis route to the controller's Receiver (Rx) measuring pins and the other sensor axis to the controller's Transmitter (Tx) I/O pins.

If there are enough measurement pins on the controller, then a touch performance advantage may be realized by assigning the axis with the higher electrode count to be the Rx electrodes.

## 2.6 Shielding

Circuit ground shielding is implemented with both, planes and frames of copper on the PCB layers.

- Reduce affects of Electro Magnetic Interference (EMI) to the active sensor area and to controller routing to the sensor electrodes.
- Prevent touches near controller routing to the sensor electrodes from generating false touch events.
- Improve touch sensitivity with an enhanced "free space" circuit ground return path.

## 2.7 Electrode Routing to Controller

Routing from the controller to electrodes is with 0.15 mm min. traces and 0.3 mm min. spaces. Avoid long parallel routes of Tx's next to Rx's and separate them with 0.5 mm min. space.




Figure 7 : Rx & Tx Electrode Proximity Routing Cross Section



**MICROCHIP**

### 3. PCB SENSOR AND APPLICATION EXAMPLE

An example sensor design with integrated application will be shown in this section. The application schematic is not provided because it is not relevant for the scope of this sensor design layout example.

The PCB is 4-layer with overall dimensions of 78 mm wide by 89 mm high. The sensor is 12x9 electrodes with an active touch area of 70 mm wide by 53 mm high.

#### 3.1 PCB Example - Top Layer

The top PCB layer is a ground shield for the sensor and for the application circuit in the non-sensor area.

The circuit ground is ~40% pour over the full board footprint. It is constructed as a grid of ~0.38 mm lines on ~1.27 mm pitch with a pour isolation distance of ~0.25 mm.




Figure 8 : PCB Example – Top Layer Copper





**MICROCHIP**

### 3.2 PCB Example – 2<sup>nd</sup> Layer

The 2<sup>nd</sup> PCB layer is a ground shield for the sensor and for the application circuit in the non-sensor area.

The circuit ground is 100% pour in the sensor and electrode routing areas, which include the perimeter of the sensor and from the sensor to the application circuit.




Figure 9 : PCB Example – 2<sup>nd</sup> Layer Copper



MICROCHIP

### 3.3 PCB Example – 3<sup>rd</sup> Layer

The 3<sup>rd</sup> PCB layer includes a perimeter ground shield for the sensor, routing to vias going to sensor electrodes on the bottom PCB layer, necks for one sensor axis electrodes, and additional application circuit in the non-sensor area.

A circuit ground 100% pour “U” shaped perimeter is placed around the sensor at three board edges. The width of the ground varies along its perimeter path from 0.7 mm to 2.5 mm in this example. The perimeter gap from electrodes on the bottom PCB layer is ~0.3 mm.

The controller routing includes vias going to 12 X-axis electrodes on the bottom PCB layer and necks with vias going to 9 Y-axis electrodes on the bottom PCB layer.

- Routings ~0.15 mm min. traces with ~0.3 mm min. spaces
- Necks ~0.15 mm wide
- Via diameter ~0.79 mm outer, 0.64 mm inner, 0.38 mm drill




Figure 10 : PCB Example – 3<sup>rd</sup> Layer Copper



MICROCHIP

### 3.4 PCB Example – Bottom Layer

The bottom PCB layer includes a ring ground shield for the sensor, 12 X-axis sensor electrodes with necks, 9 Y-axis sensor electrodes with vias to necks on the 3<sup>rd</sup> PCB layer, and additional application circuit in the non-sensor area.

A circuit ground 100% pour ring is placed around the entire sensor perimeter, including the majority of the electrode routing to the application. The width of the ground is 2.5 mm in this example. The perimeter gap from electrodes is 0.3 mm.

The sensor electrode pattern includes X-axis sensor electrodes with their necks and Y-axis sensor electrodes with vias to their necks on the 3<sup>rd</sup> PCB layer.

- Necks ~0.15 mm wide
- Via diameter ~0.79 mm outer, 0.64 mm inner, 0.38 mm drill




Figure 11 : PCB Example – Bottom Layer Copper



MICROCHIP



MICROCHIP

---



---

**WORLDWIDE SALES AND SERVICE**


---



---

**AMERICAS**

Corporate Office  
2355 West Chandler Blvd.  
Chandler, AZ 85224-6199  
Tel: 480-792-7200  
Fax: 480-792-7277  
Technical Support:  
<http://support.microchip.com>  
Web Address:  
[www.microchip.com](http://www.microchip.com)

**Atlanta**

Duluth, GA  
Tel: 678-957-9614  
Fax: 678-957-1455

**Boston**

Westborough, MA  
Tel: 774-760-0087  
Fax: 774-760-0088

**Chicago**

Itasca, IL  
Tel: 630-285-0071  
Fax: 630-285-0075

**Cleveland**

Independence, OH  
Tel: 216-447-0464  
Fax: 216-447-0643

**Dallas**

Addison, TX  
Tel: 972-818-7423  
Fax: 972-818-2924

**Detroit**

Farmington Hills, MI  
Tel: 248-538-2250  
Fax: 248-538-2260

**Kokomo**

Kokomo, IN  
Tel: 765-864-8360  
Fax: 765-864-8387

**Los Angeles**

Mission Viejo, CA  
Tel: 949-462-9523  
Fax: 949-462-9608

**Santa Clara**

Santa Clara, CA  
Tel: 408-961-6444  
Fax: 408-961-6445

**Toronto**

Mississauga, Ontario,  
Canada  
Tel: 905-673-0699  
Fax: 905-673-6509

**ASIA/PACIFIC**

Asia Pacific Office  
Suites 3707-14, 37th Floor  
Tower 6, The Gateway  
Harbour City, Kowloon  
Hong Kong  
Tel: 852-2401-1200  
Fax: 852-2401-3431

**Australia - Sydney**

Tel: 61-2-9868-6733  
Fax: 61-2-9868-6755

**China - Beijing**

Tel: 86-10-8528-2100  
Fax: 86-10-8528-2104

**China - Chengdu**

Tel: 86-28-8665-5511  
Fax: 86-28-8665-7889

**China - Hong Kong SAR**

Tel: 852-2401-1200  
Fax: 852-2401-3431

**China - Nanjing**

Tel: 86-25-8473-2460  
Fax: 86-25-8473-2470

**China - Qingdao**

Tel: 86-532-8502-7355  
Fax: 86-532-8502-7205

**China - Shanghai**

Tel: 86-21-5407-5533  
Fax: 86-21-5407-5066

**China - Shenyang**

Tel: 86-24-2334-2829  
Fax: 86-24-2334-2393

**China - Shenzhen**

Tel: 86-755-8203-2660  
Fax: 86-755-8203-1760

**China - Wuhan**

Tel: 86-27-5980-5300  
Fax: 86-27-5980-5118

**China - Xiamen**

Tel: 86-592-2388138  
Fax: 86-592-2388130

**China - Xian**

Tel: 86-29-8833-7252  
Fax: 86-29-8833-7256

**China - Zhuhai**

Tel: 86-756-3210040  
Fax: 86-756-3210049

**ASIA/PACIFIC**

India - Bangalore  
Tel: 91-80-3090-4444  
Fax: 91-80-3090-4080

**India - New Delhi**

Tel: 91-11-4160-8631  
Fax: 91-11-4160-8632

**India - Pune**

Tel: 91-20-2566-1512  
Fax: 91-20-2566-1513

**Japan - Yokohama**

Tel: 81-45-471-6166  
Fax: 81-45-471-6122

**Korea - Daegu**

Tel: 82-53-744-4301  
Fax: 82-53-744-4302

**Korea - Seoul**

Tel: 82-2-554-7200  
Fax: 82-2-558-5932 or  
82-2-558-5934

**Malaysia - Kuala Lumpur**

Tel: 60-3-6201-9857  
Fax: 60-3-6201-9859

**Malaysia - Penang**

Tel: 60-4-227-8870  
Fax: 60-4-227-4068

**Philippines - Manila**

Tel: 63-2-634-9065  
Fax: 63-2-634-9069

**Singapore**

Tel: 65-6334-8870  
Fax: 65-6334-8850

**Taiwan - Hsin Chu**

Tel: 886-3-6578-300  
Fax: 886-3-6578-370

**Taiwan - Kaohsiung**

Tel: 886-7-536-4818  
Fax: 886-7-536-4803

**Taiwan - Taipei**

Tel: 886-2-2500-6610  
Fax: 886-2-2508-0102

**Thailand - Bangkok**

Tel: 66-2-694-1351  
Fax: 66-2-694-1350

**EUROPE**

Austria - Wels  
Tel: 43-7242-2244-39  
Fax: 43-7242-2244-393

**Denmark - Copenhagen**

Tel: 45-4450-2828  
Fax: 45-4485-2829

**France - Paris**

Tel: 33-1-69-53-63-20  
Fax: 33-1-69-30-90-79

**Germany - Munich**

Tel: 49-89-627-144-0  
Fax: 49-89-627-144-44

**Italy - Milan**

Tel: 39-0331-742611  
Fax: 39-0331-466781

**Netherlands - Drunen**

Tel: 31-416-690399  
Fax: 31-416-690340

**Spain - Madrid**

Tel: 34-91-708-08-90  
Fax: 34-91-708-08-91

**UK - Wokingham**

Tel: 44-118-921-5869  
Fax: 44-118-921-5820