

E-DRIV[®] E-Series

Electric Torque Screwdrivers
Direct Plug-In

Model	Driver Type	Item #	
		110V	220V
E180-A	Lever Start	145645	145646
E180-PS	Push-to-Start	145647	145648
E250-A	Lever Start	145649	145650
E250-PS	Push-to-Start	145651	145652

Model	Torque Ranges		
	lbf.in	cN.m	RPM
E180-A	0.9 - 15.6	10 - 176	1000
E180-PS	2.2 - 15.6	25 - 176	1000
E250-A	1.3 - 21.7	15 - 245	630
E250-PS	2.2 - 21.7	25 - 245	630

DIMENSIONS & WEIGHT

Model	Grip			
	Dia.	Length	Drive Size	Weight
E180-A	1 1/2"	10"	1/4" F/Hex	19.8 oz.
E180-PS	1 1/2"	10"	1/4" F/Hex	19.8 oz.
E250-A	1 1/2"	10"	1/4" F/Hex	19.8 oz.
E250-PS	1 1/2"	10"	1/4" F/Hex	19.8 oz.

Torque Covers

Protects from incidental or operator tampering of torque setting. Allows for color coding of specific torque values in production areas.



EZ-GLIDER

The torque arm keeps the tool perpendicular and prevents cross threading and side load.

SEE PAGES 01.35 - 01.41



POWER TOOLS

RoHS



KEY FEATURES

Various models than range from 0.9 lbf.in to 21.7 lbf.in.

Plugs directly into a power outlet. Does not require a separate power supply.

Automatic power shut off once torque is achieved.

Crafted to rest comfortably in the operators hand and reduces work fatigue with ergonomic handgrip.

External torque adjustment scale.

Push-to-Start and Lever models available.

Duty cycle tool.

110V and 220V models.

Power cord with a noise filter to reduce electronic noise (EMC).

Lightweight.



POWER BITS

SEE PAGES
02.4 - 02.5



Mountz Torque Conversion Calculator

Quickly convert torque measurement from one type of unit measurement to another. Visit www.mountztorque.com/calculator