

# DX4330

Share Moments. Share Life.™



#### Amazing picture quality

- 3.1MP for prints up to 11" x 14"
- 10X zoom with Kodak Retinar aspheric all-glass lens (3X optical zoom, 3.3X Advanced Digital Zoom)
- Multi-zone auto-focus
- Kodak color science inside

#### High performance features

- New 1.8" Indoor/Outdoor LCD
- Automatic and scene modes
- Continuous video with audio
- Auto picture rotation

#### Sophisticated simplicity

- New on-camera Share button
- 16MB internal memory with MMC/SD expansion slot
- Compatible with optional Kodak EasyShare camera dock

## Kodak EasyShare

zoom digital camera

This is one powerful camera. But don't be fooled – the Kodak EasyShare DX4330 zoom digital camera is also amazingly simple. You'll be impressed with the new Indoor/Outdoor LCD as well as the exceptional-quality prints you can create – in sizes up to 11" x 14" enlargements. Plus with creative settings such as landscape, night, and sports scene modes, you'll get the exact look you want.

### Kodak EasyShare system



**Shoot. Touch. Share.** With the Kodak EasyShare system, sharing is simple. Just place your Kodak EasyShare digital camera into the dock, touch the button, and your pictures are automatically sent to your computer. Now you're ready to e-mail pictures and share great-looking prints with the world.

D I G I T A L   M A D E   S I M P L E .   P R I N T S   M A D E   B E A U T I F U L .

# DX4330

Share Moments. Share Life.™



## Because pictures aren't taken. They're created.

There are pictures to shoot. Masterpieces to create. With the DX4330, you'll have the features you'll need to do it all.

**Big, beautiful prints**  
With the DX4330's 3.1MP, you can go from 4" x 6" to 11" x 14" and everything in between. Anyway you do it, you'll get vibrant color and crisp detail.



**Amazing color quality**  
Vivid color. Ideal lighting. Color consistency. Sharpness. You get it all with Kodak color science inside and powerful features like auto exposure with matrix metering and multi-zone auto-focus.

**Powerful 10X zoom**  
Close is an understatement with the premium all-glass Kodak Retinar 3X optical zoom lens. Incredible sharpness. Maximum depth of field. Brightness, edge to edge. Zoom in even closer with 3.3X Advanced Digital Zoom.

**Video and audio capability**  
Capture life in motion with the DX4330's continuous video with audio feature. Then play it back through the camera's LCD and built-in speaker.

**One-touch picture transfer**  
Transfer your pictures from camera to computer at the touch of a button with the optional Kodak EasyShare camera dock II. And while the DX4330 is docked, its batteries are being recharged – in 2.5 hours or less.

**One-touch sharing**  
When you know you have a picture you'll want to print or e-mail, tag it using the new on-camera Share button. When you transfer your pictures, the picture will be ready to go. Plus, you can store 32 e-mail addresses right in your camera for extra-easy e-mailing.

**Creativity made simple**  
From landscape to sports, easy-to-access scene modes take care of the details so you can consistently get the perfect shot. Use its creative modes for even more photo flair.



**Indoor/Outdoor LCD**  
Preview and review your shots easily on the DX4330's 1.8" LCD. The new Indoor/Outdoor LCD lets you maintain exceptional viewing quality even in bright sunlight.

**Auto rotation**  
Your pictures will always appear right-side-up, so you'll never have to look at a picture on its side.

**Capture a picture anytime**  
You'll never miss a shot with the DX4330. Because no matter what setting it's on, it's always ready to snap a picture.

**Ready to shoot and share**  
Your DX4330 is always ready to go with its 16MB of internal memory. Want more memory? Expand it with an MMC/SD memory card. Then share your pictures on any MMC/SD-compatible electronic device.



**Simple yet smart software**  
Make prints of incredible quality. E-mail your pictures in a click. Edit anytime. Label and organize them for simple searching. Do it all with Kodak EasyShare software. And do it with amazing ease.

**One Touch To Better Pictures**  
Get photo quality prints at home with no worry or waste. Its proprietary color algorithms match your printer to your picture for vivid colors. Plus, it's simple to use – just turn it on and it automatically adjusts your printer's settings. Use with Kodak premium and ultima picture papers.



**Print anywhere**  
It's your choice – print your pictures at home, send them to an online photofinisher, or go to an in-store Kodak picture maker kiosk. Any way you choose, you can count on this: easily getting the quality you expect from Kodak.



# D X4330

Share Moments. Share Life.™



<b>3.1</b> MEGAPIXEL	 11x14" 28x36cm MAXIMUM PRINT SIZE	<b>10X ZOOM</b> 3X OPTICAL 3.3X ADVANCED DIGITAL	 INDOOR/OUTDOOR DISPLAY	 MULTI-SCENE MODES	 VIDEO/AUDIO	<b>16MB</b> INTERNAL MEMORY	 AUTO PICTURE ROTATION	 CAPTURE "ALWAYS READY"	 MATRIX METERING
-------------------------	---	--	----------------------------	-----------------------	-----------------	--------------------------------	---------------------------	----------------------------	---------------------

## Amazing Picture Quality

CCD resolution	3.3 megapixel (2242x1473 pixels)
image resolution	3.1 megapixel (2160x1400 pixels)
image quality	3.1MP – best (print, enlargement) 2.2MP – better (small print) 0.8MP – good (e-mail)
aperture	f/2.8, f/5.1
optical zoom	3X optical (38mm-114mm)
digital zoom	3.3X Advanced Digital Zoom
focus distance	0.7m (2 ft.) to infinity
macro mode	.07-.7m (2.8-28 in.)
lens protection	lens cap tethered to body
exposure control	multi-pattern TTL/AE with program modes (auto, macro, landscape, sport, night, movie)
shutter speed	1/2-1/1700 sec.
flash mode	automatic, fill, red-eye, off
flash range	0.6-3.4m (2.0-11 ft.)
ISO equivalent	automatic (120-200)
magnify	2X and 4X in review
white balance	automatic
sharpness	automatic
multi-zone AF	automatic
matrix metering	automatic

## High Performance Features

LCD	45.6 mm (1.8 in.) Indoor/Outdoor display
scene modes	standard, landscape, night, sports, macro
movie capture	video and audio capture and playback on camera
exposure compensation	+/-2 in 0.5 stop increments
long time exposure storage	up to 4 seconds 16MB internal memory and MMC/SD removable card slot

## Sophisticated Simplicity

file format	JPEG/EXIF v2.2
capture mode	automatic - always ready

auto-orientation	on-camera picture rotation
delete	dedicated delete button
viewfinder	real-image optical viewfinder
share	Share button
software	Kodak EasyShare software
interface	USB, Kodak EasyShare camera dock compatible; audio/video connectors
video out	NTSC, PAL (user-selectable)

## Other Specifications

DC in	DC-in jack on side of camera for 3V adapter
tripod mount	1/4 in. standard
self-timer	10 seconds
power options	optional camera dock with Ni-MH rechargeable battery pack (in-camera charging); 2AA lithium or Ni-MH batteries or 1 CRV3 lithium battery, 3-volt adapter
weight	without batteries: 210 g (7.4 oz.)
dimensions	WxHxD: 110.5x66x39 mm (4.4x2.6x1.9 in.)
warranty	one year

## System Requirements

Windows:	<ul style="list-style-type: none"> <li>▪ Windows 98, 2000, millennium edition, or XP OS</li> <li>▪ 233 MHz processor or greater</li> <li>▪ 64MB RAM (128MB RAM for Windows XP)</li> <li>▪ 200MB hard drive disk space available</li> <li>▪ CD-ROM drive</li> <li>▪ Available USB port</li> <li>▪ Color monitor, 800x600 pixels (16-bit or 24-bit recommended)</li> </ul>
Macintosh:	<ul style="list-style-type: none"> <li>▪ PowerPC based Macintosh computer</li> <li>▪ Macintosh OS X (OS 8.6/9.x – Share button functions not supported – OS X is recommended for full functionality)</li> </ul>

- 128MB RAM for OS X (64MB RAM for OS 8.6/9.x)
- 200MB hard drive disk space available
- CD-ROM drive
- Built-in USB port
- Color monitor, 800x600 pixels (thousands or millions of colors recommended)

## Package Contents

- Kodak EasyShare DX4330 zoom digital camera
- CRV3 lithium battery or equivalent
- Video out cable
- USB cable
- Wrist strap
- Lens cap with strap
- Kodak EasyShare software CD
- Documentation
- Custom camera insert for optional Kodak EasyShare camera dock

## Ordering Information

CAT No.

Kodak EasyShare DX4330 zoom digital camera (US)	158 0505
Kodak EasyShare DX4330 zoom digital camera (Canada)	868 9408

## Recommended Accessories

Kodak EasyShare camera dock II	801 3815
Kodak EasyShare travel kit	131 8047
Kodak MultiMedia cards (MMC)	
32MB	802 4648
64MB	853 5692
128MB	880 2019
Kodak Ektanar digital camera lens kit	801 5877
Kodak EasyShare Ni-MH rechargeable battery pack	114 8683
Kodak EasyShare Ni-MH rapid battery charger	891 4012
Kodak MultiMedia card reader/writer	194 0824

For more information on the Kodak EasyShare DX4330 zoom digital camera, visit [www.kodak/go/easysshare](http://www.kodak/go/easysshare)

©Eastman Kodak Company, 2002. Kodak, Retinar, Ektanar, EasyShare, and Share Moments. Share Life. are trademarks of Eastman Kodak Company. One Touch To Better Pictures not available for Macintosh. Simulated LCD display image IC-949 CAT No. 133 6114



DIGITAL MADE SIMPLE. PRINTS MADE BEAUTIFUL.