

Model: 319 Replacement Knobs

Missing a knob? Replacements are available!

Whether accidentally lost, dinged or damaged, replacement knobs return your unit to "like new" status.

For use with the:

- 315 Circuit Board Holder
- 333 Rapid Assembly Circuit Board Holder
- 324 Electronic Work Center

