



TV ON DEMAND


CATCH UP ON YOUR FAVOURITE SHOWS



With Freesat you also have access to On Demand services like BBC iPlayer and ITV Player. All you need to do is connect to the internet with an Ethernet cable.

BEFORE YOU START

MAKE SURE YOU HAVE



If you require any help with your installation, just call Freesat on **0845 313 0051**.

YOUR REMOTE CONTROL



For help with installation or getting started please call Freesat on **0845 313 0051** (local call rate) or visit freesat.co.uk
For product support, call Goodmans on **08444 122 541** or visit www.goodmans.co.uk/support

HD Digital Box
Model: GS103TZH

FREE TV IN JUST A JIFFY

YOUR QUICK START GUIDE




FREESAT and the Freesat logo are registered trade marks and the Freesat logo is copyright of Freesat (UK) Ltd.


STEP ONE

BEGIN WITH A CONNECTION
HERE'S WHAT GOES WHERE

- 1 Start by connecting your box to the satellite dish. The cable from the dish screws into the port on the back of the box.
- 2 Now, connect your box to your TV using the HDMI cable supplied with your box.
- 3 Next, connect your box to the internet (more on this below).
- 4 Finally, plug the box in and switch it on.



Connect your HD Digital Box to your router.



The best way to connect is with an **Ethernet cable**. Slot one end into the Ethernet port on the back of the box, and the other end into an Ethernet port on your router. That's it - you're connected.



If your router is too far away to use a cable, try using a pair of **Betacom Powerline Homeplug Adapters**. They're a safe and convenient way to send broadband around your home using the electrical wiring. betacomdigital.co.uk

STEP TWO

FOLLOW THE ON SCREEN INSTRUCTIONS
THEN YOU'RE READY TO GO

Check signal strength

The first install screen will appear. If the signal strength is above 50% press the OK button to continue. If below 50% please call 0845 313 0051.




Enter your postcode

Use the numbers on the remote control to enter your postcode. The right arrow moves to the next space, the left arrow deletes the previous character. Press the OK button to continue. Select your TV screen size and press the OK button to continue.


Protect your children's viewing

Enter a 4-digit PIN of your choice, then press the OK button. Re-enter the PIN, then confirm it using the OK button.



STEP THREE

INTRODUCING THE PROGRAMME GUIDE
PRESS THE GUIDE BUTTON



Channel genres tab


Skip forward and back 24 hours

What's on 'Now & Next'

With Freesat it's easy to choose between different channel genres by pressing Rewind and Fast Forward and moving through the list of programmes.

STEP FOUR

MANAGING YOUR TIME
SET A REMINDER



Time tabs

Reminder set

Freesat allows you to set up a reminder by selecting a programme that will be on later and pressing the OK button. A clock will be shown next to the programme as confirmation.