TECHNICAL NOTE

Large Current External FET Controller Type Switching Regulators

Single-output Step-up, Negative Voltage, Step-down Switching Regulators (Controller type)

BD9300F/BD9300FV

Description

The BD9300F/FV 1-channel DC/DC Step-up, step-down, and inverting converter controller. This IC has a wide input voltage range of 3.6 to 35 V, providing for a variety of applications. The pin assignment is similar to that of the BA9700, facilitating a space-saving application.

Features

- 1) 1-channel PWM control DC/DC converter controller
- 2) High voltage input of 3.6 to 35 V
- 3) Reference voltage accuracy of ±1%
- 4) Oscillation frequency variable in the range of 20 to 800 kHz
- 5) Built-in UVLO (Under Voltage Lock Out) circuit and SCP (Short Circuit Prevention) circuit
- 6) Current in standby mode: 0 µA (typ.)
- 7) Switching external synchronization available (Slave operation)
- 8) SSOP-B14 Package (for BD9300FV) or SOP14 Package (for BD9300F)

Applications

- \cdot TV, power supply for liquid crystal display TV, and backlight
- DSC, DVD, printer, DVD/DVD recorder, and other consumer products



ROHM CO., LTD.



Absolute maximum ratings(Ta=25°C)

Item	Symbol	Rating	Unit
Power supply voltage	Vcc	36	V
Power dissipation	Pd	400 *	mW
Operating temperature	Topr	-40 to +85	°C
Storage temperature	Tstg	-55 to +125	°C
Output current	lo	100 **	mA
Output voltage	Vo	36	V
Maximum junction temperature	Tjmax	125	°C

* Reduce by 4 mW/ °C over 25°C, when mounted on a glass epoxy PCB of 70mmX70mmX1.6mm) ** Should not exceed Pd-value.

Recommended operating range (Ta=25°C)

ltere	Cumb al		11-24		
item	Symbol	Min	Тур	Max	Unit
Power supply voltage	Vcc	3.6	12	35	V
Output sink current	lo	-	_	30	mA
Output voltage	Vo	-	_	35	V
Timing capacitance	Ст	33	-	1000	pF
Timing resistance	RT	5	-	100	kΩ
Oscillation frequency	Fosc	20	-	800	kHz

Electrical characteristics (Unless otherwise specified, Ta=25°C, Vcc=12V, CT=200pF, RT=20kΩ)

Itom	Symbol	Limits			Lloit	Conditiona
Item	Symbol	Min	Тур	Max	Unit	Conditions
[Reference voltage block]						
Reference voltage	Vref	2.475	2.500	2.525	V	IREF=1mA
Input stability	Vdli	_	1.5	20	mV	Vcc=3.6 to 35V IREF=1mA
Load stability	Vdld	_	0.5	20	mV	IREF=0 ~ 1mA
1/2 reference voltage	1/2Vref	1.212	1.25	1.288	V	
[Triangular wave oscillator block]						
Oscillation frequency	Fosc	165	220	275	kHz	
Charge mode threshold voltage	Vosc+	_	1.95	_	V	
Discharge mode threshold voltage	Vosc-	_	1.45	_	V	
Frequency variation	Fdvo	_	1	_	%	Vcc=3.6 to 35V
[Protection circuit block]						
Threshold voltage	Vit	1.5	1.8	2.1	V	
Charge current	Iscp	_	7	11	μA	
[Rest period adjustment circuit block]	-	-		-		-
Upper limit threshold voltage	Vtн	2.05	_	-	V	Duty Cycle=0%
Lower limit threshold voltage	Vt∟	_	_	1.35	V	Duty Cycle=100%
Input bias current	lbd	_	0.1	1	μA	DTC=1.5V
Latch mode charge current	Idtc	200	500	_	μA	DTC=0V
[Under voltage lock out block]						
Threshold voltage	Vuт	_	2.8	-	V	
	•	•			•	

 \bigcirc Not designed to be radiation-resistant.

Electrical characteristics (Unless otherwise specified, Ta=25°C, Vcc=12 V, CT=200pF, RT=20 kΩ)

ltere	Symbol	Limits			Unit	Conditions
Item		Min	Тур	Max	Unit	Conditions
[Error amplifier block]						1
Input bias current	Ів	_	0.1	1	μA	
Open loop gain	AV	-	85	_	dB	Null AMP
Maximum output voltage	Vон	2.3	2.5	_	V	
Minimum output voltage	Vol	_	0.7	0.9	V	
Output sink current	Ю	0.1	1	_	mA	VFB=1.25V
Output source current	loo	40	70	_	μA	Vfb=1.25V
[Output block]						
Saturation voltage	VSAT		1.0	1.4	V	lo=30mA
Leak current	ILEAK	_	-	10	μA	OUT=35V
[Control block]						
CTL ON voltage	Von	2	-	_	V	
CTL OFF voltage	Voff	_	_	0.7	V	
CTL sink current	Ість	_	57	90	μA	Vctl=5V
[Whole device]						
Standby current	Іѕтв	_	0	10	μA	Vctl=0V
Average supply current	lcc	_	1.2	2.4	mA	RT=VREF

 $\bigcirc\,\mathsf{Not}$ designed to be radiation-resistant.

Measurement circuit diagram



Fig. 1 Typical measurement circuit



• Pin assignment

Block diagram



Fig. 11 Pin assignment / Block diagram

• Pin assignment and function

Pin No.	Pin name	Function
1	DTC	Rest period setting voltage input
2	RT	External timing resistance
3	СТ	External timing capacitance
4	FB	Error amplifier output
5	OUT	PWM output (open collector)
6	N.C.	_
7	GND	Ground
8	Vcc	Power supply
9	SCP	External timer latch setting capacitance (Ground if not used)
10	CTL	Control input
11	VREF	Reference voltage output
12	INV	Inverting input for error amplifier
13	1/2VREF	1/2 reference voltage output
14	NON	Non-inverting input for error amplifier



Fig. 12 Typical application circuit

VREF block

The VREF block is a block to output a reference voltage of 2.5 V (TYP), which is used as the operating power supply for all the Internal. The CTL pin is used to turn ON/OFF the reference voltage. Furthermore, this reference voltage has a current capacitance of 1 mA (MIN) or more, from which a high-accuracy reference voltage can be generated through dividing resistance.

ERRAMP block

The ERRAMP block is an error amplifier to amplify potential between the NON and the INV pins and then output a voltage. The FB pin output voltage determines the output pulse Duty. When the FB voltage reaches 1.95 V (TYP) or more, switching will be OFF (Duty=0%). When the FB voltage reaches 1.45 V (TYP) or less, the output NPN Tr will be FULL ON (Duty=100%).

OSC block

The OSC block is a block to determine the switching frequency through the RT and the CT pins. RT and CT voltages determine the triangular waveform.

TIMER LATCH block

The TIMER LATCH block is an output short circuit protection circuit to detect output short circuit when the output voltage from the FB pin of the error amplifier reaches 1 V (TYP) or less. When the FB voltage reaches 1 V (TYP) or less, the TIMER will starts operating to charge the SCP pin at a current capacitance of 7 μ A (TYP). When the SCP voltage reaches 1.8 V (TYP), the LATCH will be activated to shut down the circuit.

PWM/Driver block

The PWM/Driver block is a PWM comparator to determine Duty value differences between output from the error amplifier and the oscillator triangular wave. The DTC voltage determines the maximum duty ratio. When the DTC voltage reaches 1.95 V (TYP), the switching OFF is activated. FULL ON will be activated when the DTC voltage reaches 1.45 V (TYP). The DTC voltage setting should be made through dividing resistance with the VREF block.



Basic operation



Fig. 13 Basic operation

 \cdot When the short circuit protection is activated



Fig. 14 Timing when the short circuit protection is activated

- External component setting procedure
 - (1) Design of feedback resistance constant

Set step-down, step-up, and inverting feedback resistance as shown below. Set resistance in the range of 1 k Ω to 330 k Ω . Setting the resistance to 1 k Ω or less will result in degraded power efficiency, while setting it to 330 k Ω or more will increase the offset voltage due to the input bias current of 0.1µA (TYP) of the error amplifier.



(2) Setting of oscillation frequency

Connecting a resistor and capacitor to the RT pin (pin 2) and the CT pin (pin 3) will set the triangular wave oscillation frequency. The RT determines the charge/discharge current to the capacitor. Referring to Fig. 18, set RT resistor and the CT capacitor. Recommended setting ranges are 5 to 100 k Ω for the CT resistor, 33 to 1000 pF for the CT capacitor, and 20 kHz to 800 kHz for the oscillation frequency. Any setting outside of these ranges may turn OFF switching, thus impairing the operation guarantee.



(3) Setting of DTC voltage

Applying the VDTC voltage to the DTC pin (pin 1) will fix the maximum duty ratio. This will serve to prevent the power transistor (FET) from being FULL ON. Fig. 19 shows the relationship between the DTC voltage and the maximum duty ratio. Referring to this Figure, set the DTC voltage.Next, generate the VDTC by dividing the VREF voltage with resistance and then input the VDTC in the DTC pin.



Fig. 19 DTC voltage vs. Maximum duty

Furthermore, the maximum duty ratio should be designed so as not to become a maximum duty for the normal use. The following section shows ranges for the normal use.

$$\frac{\text{Step-down voltage}}{\text{ONDutyMAX}} = \frac{\text{VOMAX}}{\text{VCCMIN}}$$

$$\frac{\text{Step-up voltage}}{\text{ONDutyMAX}} = \frac{\text{VOMAX} - \text{VOMIN}}{\text{VOMAX}}$$

$$\frac{\text{VOMAX} - \text{VOMAX}}{\text{VOMAX}} = \frac{\text{VOMAX}}{\text{VOMAX} - \text{VCCMIN}}$$

(4) Setting of soft start time

Adding a capacitor to the DTC resistance divider will enable the soft start function activation.

The soft start function will be required to prevent an excessive increase in the coil current and overshoot of the output voltage, while in startup operation. Fig. 20 shows the relationship between the capacitor and the soft start time. Referring to this Figure, set the capacitor. It is recommended to set the capacitance value in the range of 0.01 to 10 µF. Setting the capacitance value to 0.01 µF or less, may cause overshoot to the output voltage, while setting it to 10 µF or more may cause an inverse current in the internal parasitic diode when the power supply is grounded, thus resulting in damage to the internal element. the internal element.



Fig. 20 Soft start capacitance vs. Delay time



Since the PNP Tr is generally slow in switching, in terms of the sat characteristics , the ON/OFF peak circuit is used as an acceleration circuit. The D1 and the C7 generate an ON peak current, while the Q1 and the C7 forms an OFF peak circuit.Set pull-up resistance to 510 Ω as a guide at VCC=12 V. It is recommended to set this resistance in the range of 100 kΩ to 10 kΩ. In order to make adjustment of the R6 and R7, however, pay attention of the points listed in table below.

NO.	Item	To reduce R6	To reduce R7
1	Efficiency	Degraded	Degraded
2	Tr Turn ON / Turn OFF	Faster Turn OFF	Faster Turn OFF
3	Switching frequency	Increasable	Increasable
4	Load current capacitance	Degraded	Degraded

Take 1000 pF as a guide for the C7 setting. If the ON/OFF peak currents are inadequate, increase the C7 capacitance value. It is recommended to set capacitance values in the range of 100 pF to 10000 pF. Setting the capacitance value to 10000 pF or more may increase the peak current and degrade the power efficiency.

(6) Phase compensation

Phase compensation setting procedure

The phase compensation setting procedure varies with the selection of output capacitors used for DC/DC converter application. In this connection, the following section describes the procedure by classifying into the two types. Furthermore, the application stability conditions are described in the Description section.

- 1. Application stability conditions
- 2. For output capacitors having high ESR, such as electrolytic capacitor
- 3. For output capacitors having low ESR, such as ceramic capacitor or OS-CON
- 1. Application stability conditions

The following section shows the stability conditions of negative feedback system.

• DSC, DVD, printer, DVD/DVD recorder, and other consumer productsAt a 1 (0-dB) gain,

the phase delay is 150° or less (i.e., the phase margin is 30° or more).

Furthermore, since the DC/DC converter application is sampled according to the switching frequency, GBW of the overall system should be set to 1/10 or less of the switching frequency. The following section summarizes the targeted characteristics of this application.

- DSC, DVD, printer, DVD/DVD recorder, and other consumer productsAt a 1 (0-dB) gain, the phase delay is 150° or less (i.e., the phase margin is 30° or more).
- DSC, DVD, printer, DVD/DVD recorder, and other consumer productsThe GBW (i.e., frequency at 0-dB gain) for this occasion is 1/10 or less of the switching frequency.

In other words, the responsiveness is determined with restrictions on the GBW. Consequently, in order to upgrade the responsiveness, higher switching frequency should be provided.

In order to ensure the stability through the phase compensation, a secondary phase delay (–180°) resulting from LC resonance should be canceled with a secondary phase lead (i.e., through inserting two phase leads). Furthermore, the GBW (i.e., frequency at 1-dB gain) is determined according to phase compensation capacitance to be provided for the error amplifier. Consequently, in order to reduce the GBW, increase the capacitance value.

(1) Typical (sun) integrator (Low pass filter)





Fig. 22 Typical integrator characteristics

Since the error amplifier is provided with (sun) or (mon) phase compensation, the low pass filter is applied. In the case of the DC/DC converter application, the R becomes a parallel resistance of the feedback resistance.

2. For output capacitors having high ESR, such as aluminum electrolytic capacitor

For output capacitors having high ESR (i.e., several ohms), the phase compensation setting procedure becomes comparatively simple. Since the DC/DC converter application has a LC resonant circuit attached to the output, a -180° phase-delay occurs in that area. If ESR component is present there, however, a $+90^{\circ}$ phase-lead occurs to shift the phase delay to -90° . Since the phase delay is desired to set within 150° , this is a very effective method but has a demerit to increase the ripple component of the output voltage.



* Same for the phase compensation of inverting and step-up voltages

Fig. 23 DC/DC converter output application

According to changes in phase characteristics due to the ESR, only one phase lead should be inserted. For this phase lead, select either of the methods shown below:



Fig. 24 Typical phase compensation circuit

To cancel the LC resonance, phase lead frequency should be set close to the LC resonant frequency.

3. For output capacitors having low ESR, such as a ceramic capacitor or OS-CON

In order to use capacitors having low ESR (i.e., several tens of mW), two phase-leads should be inserted so that a -180° phase-dela y, due to LC resonance, will be compensated. The following section shows a typical phase compensation procedure.

· Phase compensation with secondary phase lead



Fig. 25 Typical circuit after secondary compensation circuit

For the settings of phase lead frequency, insert both of the phase leads close to the LC resonant frequency.

Phase compensation on the BD9300F/FV

For BD9300F/FV, since the error amplifier input is inverted to the normal input, the phase compensation procedure is slightly different. (The BD9300F/FV returns feedback to the NON pin.)



Fig. 26 Typical circuit after phase compensation on BD9300F/FV

The BD9300F/FV feeds back on the + side input and returns the phase compensation on the - side input. Consequently, resistance of the resistance divider being used to determine the reference voltage has influence on the frequency characteristics. (The BD9300F/FV has a 1/2 VREF pin to divide resistance by 100 k Ω .)

The following section shows the phase characteristics.

Primary phase delay:
$$fp = \frac{1}{2\pi C \frac{100k\Omega}{2} (1+A)}$$
 [Hz], where A is approximately 80 dB.
Phase lead: $fz = \frac{1}{2\pi C \frac{100k\Omega}{2}}$ [Hz]

As a result, inserting a phase compensation capacitor will cause phase lead component. If any further phase lead is required, add a capacitor in parallel with the R1.

(1) DTC



(3) CT







(10) CTL



(13) 1/2VREF





(4) FB



(9) SCP



(12) INV



(14) NON



Cautions on use

1) Absolute maximum ratings

An excess in the absolute maximum ratings, such as supply voltage, temperature range of operating conditions, etc., can break down the devices, thus making impossible to identify breaking mode, such as a short circuit or an open circuit. If any over rated values will expect to exceed the absolute maximum ratings, consider adding circuit protection devices, such as fuses.

2) GND potential

Ground-GND potential should maintain at the minimum ground voltage level. Furthermore, no terminals should be lower than the GND potential voltage including an electric transients.

3) Thermal design

Use a thermal design that allows for a sufficient margin in light of the power dissipation (Pd) in actual operating conditions.

4) Inter-pin shorts and mounting errors

Use caution when positioning the IC for mounting on printed circuit boards. The IC may be damaged if there is any connection error or if positive and ground power supply terminals are reversed. The IC may also be damaged if pins are shorted together or are shorted to other circuitís power lines.

5) Operation in strong electromagnetic field

Use caution when using the IC in the presence of a strong electromagnetic field as doing so may cause the IC to malfunction. 6) Testing on application boards

When testing the IC on an application board, connecting a capacitor to a pin with low impedance subjects the IC to stress. Always

discharge capacitors after each process or step. Always turn the IC's power supply off before connecting it to, or removing it from a jig or fixture, during the inspection process. Ground the IC during assembly steps as an antistatic measure. Use similar precaution when transporting and storing the IC.

7) IC pin input

This monolithic IC contains P+ isolation and P substrate layers between adjacent elements to keep them isolated. PñN junctions are formed at the intersection of these P layers with the N layers of other elements, creating a parasitic diode or transistor. For example, the relation between each potential is as follows:

 \bigcirc When GND > Pin A and GND > Pin B, the PñN junction operates as a parasitic diode.

 \bigcirc When Pin B > GND > Pin A, the PñN junction operates as a parasitic transisto ^r.

Parasitic diodes can occur inevitably in the structure of the IC. The operation of parasitic diodes can result in mutual interference among circuits, operational faults, or physical damage. Accordingly, methods by which parasitic diodes operate, such as applying a voltage that is lower than the GND (P substrate) voltage to an input pin, should not be used.



⁸⁾ Ground wiring pattern

The power supply and ground lines must be as short and thick as possible to reduce line impedance. Fluctuating voltage on the power ground line may damage the device.

Derating curve



Fig. 29 Thermal derating characteristics

Selection of order type



Package specifications

SOP14







The contents described herein are correct as of September. 2008 The contents described herein are subject to change without notice. For updates of the latest information, please contact and confirm with ROHM CO. LTD.

The products described herein utilize silicon as the main material.
 The products described herein are not designed to be X ray proof.

Any part of this application note must not be duplicated or copied without our permission.

fuel controllers and other safety devices), please be sure to consult with our sales representative in advance.

office-automation equipment, communications devices, electrical appliances and electronic toys).

Application circuit diagrams and circuit constants contained herein are shown as examples of standard use and operation. Please pay careful attention to the peripheral conditions when designing circuits and deciding

Any data, including, but not limited to application circuit diagrams and information, described herein are intended only as illustrations of such devices and not as the specifications for such devices. ROHM CO.LTD. disclaims any warranty that any use of such devices shall be free from infringement of any third party's intellectual property rights or other proprietary rights, and further, assumes no liability of whatsoever nature in the event of any such infringement, or arising from or connected with or related to the use of such devices. • Upon the sale of any such devices, other than for buyer's right to use such devices itself, resell or otherwise dispose of the same, implied right or license to practice or commercially exploit any intellectual property rights or other proprietary rights owned or controlled by ROHM CO., LTD. is granted to any such buyer.

The products listed in this catalog are designed to be used with ordinary electronic equipment or devices (such as audio visual equipment,

Should you intend to use these products with equipment or devices which require an extremely high level of reliability and the malfunction of which would directly endanger human life (such as medical instruments, transportation equipment, aerospace machinery, nuclear-reactor controllers,

Boston Chicago Dallas Denver



upon circuit constants in the set.



ROHM CO., LTD.

21 Saiin Mizosaki-cho, Ukyo-ku, Kyoto 615-8585, Japan TEL: +81-75-311-2121 FAX: +81-75-315-0172 URL http://www.rohm.com

Published by KTC LSI Development Headquarters LSI Business Pomotion Group

Contact us	for further info	rmation about the	products.
San Diego	TEL: +1-858-625-3630	FAX: +1-858-625-3670	Tianj
Atlanta	TEL: +1-770-754-5972	FAX: +1-770-754-0691	Shan
Boston	TEL: +1-978-371-0382	FAX: +1-928-438-7164	Hang
Chicago	TEL: +1-847-368-1006	FAX: +1-847-368-1008	Nanj
Dallas	TEL: +1-469-287-5366	FAX: +1-469-362-7973	Ning
Denver	TEL: +1-303-708-0908	FAX: +1-303-708-0858	Qing
Detroit	TEL: +1-248-348-9920	FAX: +1-248-348-9942	Suzh
Nashville	TEL: +1-615-620-6700	FAX: +1-615-620-6702	Wuxi
Mexico	TEL: +52-33-3123-2001	FAX: +52-33-3123-2002	Sher
Düsseldorf	TEL: +49-2154-9210	FAX: +49-2154-921400	Dong
Munich	TEL: +49-8999-216168	FAX: +49-8999-216176	Fuzh
Stuttgart	TEL: +49-711-7272-370	FAX: +49-711-7272-3720	Guar
France	TEL: +33-1-5697-3060	FAX: +33-1-5697-3080	Huiz
United Kingdom	TEL: +44-1-908-306700	FAX: +44-1-908-235788	Xiam
Denmark	TEL: +45-3694-4739	FAX: +45-3694-4789	Zhuh
Espoo	TEL: +358-9725-54491	FAX: +358-9-7255-4499	Hong
Salo	TEL: +358-2-7332234	FAX: +358-2-7332237	Taipe
Oulu	TEL: +358-8-5372930	FAX: +358-8-5372931	Kaoł
Barcelona	TEL: +34-9375-24320	FAX: +34-9375-24410	Sing
Hungary	TEL: +36-1-4719338	FAX: +36-1-4719339	Phili
Poland	TEL: +48-22-5757213	FAX: +48-22-5757001	Thail
Russia	TEL: +7-495-739-41-74	FAX: +7-495-739-41-74	Kuala
Seoul	TEL: +82-2-8182-700	FAX: +82-2-8182-715	Pena
Masan	TEL: +82-55-240-6234	FAX: +82-55-240-6236	Kyot
Dalian	TEL: +86-411-8230-8549	FAX: +86-411-8230-8537	Yoko
Beijing	TEL: +86-10-8525-2483	FAX: +86-10-8525-2489	

Tianiin Shanahai Nangan Nanjing Ningbo Qingdao Suzhou Wuxi Shenzhen Dongguan Fuzhou Guangzhou Huizhou Xiamen Zhuhai Hong Kong Taipei Kaohsiung Singapore Philippines Thailand Kuala Lumpur Penang Kyoto Yokohama

TEL: +86-22-23029181 FAX: +86-22-23029183 FAX: +86-592-239-8380 FAX: +86-756-3232-460 TEL: +86-756-3232-480 TEL: +86-750-3232-460 TEL: +852-2-740-6262 TEL: +886-2-2500-6956 TEL: +886-7-237-0881 TEL: +65-6332-2322 FAX: +86-756-3232-460 FAX: +852-2-375-8971 FAX: +886-2-2503-2869 FAX: +886-7-238-7332 FAX: +65-6332-5662 TEL: +63-2-807-6872 FAX: +63-2-809-1422 TEL: +66-2-254-4890 FAX: +66-2-256-6334 TEL: +60-2-234-4390 TEL: +60-3-7958-8355 TEL: +60-4-2286453 TEL: +81-75-365-1218 TEL: +81-45-476-2290 FAX: +60-2-236-6334 FAX: +60-3-7958-8377 FAX: +60-4-2286452 FAX: +81-75-365-1228 FAX: +81-45-476-2295

Notice

Precaution on using ROHM Products

1. Our Products are designed and manufactured for application in ordinary electronic equipments (such as AV equipment, OA equipment, telecommunication equipment, home electronic appliances, amusement equipment, etc.). If you intend to use our Products in devices requiring extremely high reliability (such as medical equipment ^(Note 1), transport equipment, traffic equipment, aircraft/spacecraft, nuclear power controllers, fuel controllers, car equipment including car accessories, safety devices, etc.) and whose malfunction or failure may cause loss of human life, bodily injury or serious damage to property ("Specific Applications"), please consult with the ROHM sales representative in advance. Unless otherwise agreed in writing by ROHM in advance, ROHM shall not be in any way responsible or liable for any damages, expenses or losses incurred by you or third parties arising from the use of any ROHM's Products for Specific Applications.

/	1 1		
JAPAN	USA	EU	CHINA
CLASSⅢ	CLASSII	CLASS II b	
CLASSⅣ		CLASSⅢ	CLASSI

- 2. ROHM designs and manufactures its Products subject to strict quality control system. However, semiconductor products can fail or malfunction at a certain rate. Please be sure to implement, at your own responsibilities, adequate safety measures including but not limited to fail-safe design against the physical injury, damage to any property, which a failure or malfunction of our Products may cause. The following are examples of safety measures:
 - [a] Installation of protection circuits or other protective devices to improve system safety
 - [b] Installation of redundant circuits to reduce the impact of single or multiple circuit failure
- 3. Our Products are designed and manufactured for use under standard conditions and not under any special or extraordinary environments or conditions, as exemplified below. Accordingly, ROHM shall not be in any way responsible or liable for any damages, expenses or losses arising from the use of any ROHM's Products under any special or extraordinary environments or conditions. If you intend to use our Products under any special or extraordinary environments or conditions (as exemplified below), your independent verification and confirmation of product performance, reliability, etc, prior to use, must be necessary:
 - [a] Use of our Products in any types of liquid, including water, oils, chemicals, and organic solvents
 - [b] Use of our Products outdoors or in places where the Products are exposed to direct sunlight or dust
 - [C] Use of our Products in places where the Products are exposed to sea wind or corrosive gases, including Cl₂, H₂S, NH₃, SO₂, and NO₂
 - [d] Use of our Products in places where the Products are exposed to static electricity or electromagnetic waves
 - [e] Use of our Products in proximity to heat-producing components, plastic cords, or other flammable items
 - [f] Sealing or coating our Products with resin or other coating materials
 - [g] Use of our Products without cleaning residue of flux (even if you use no-clean type fluxes, cleaning residue of flux is recommended); or Washing our Products by using water or water-soluble cleaning agents for cleaning residue after soldering
 - [h] Use of the Products in places subject to dew condensation
- 4. The Products are not subject to radiation-proof design.
- 5. Please verify and confirm characteristics of the final or mounted products in using the Products.
- 6. In particular, if a transient load (a large amount of load applied in a short period of time, such as pulse. is applied, confirmation of performance characteristics after on-board mounting is strongly recommended. Avoid applying power exceeding normal rated power; exceeding the power rating under steady-state loading condition may negatively affect product performance and reliability.
- 7. De-rate Power Dissipation (Pd) depending on Ambient temperature (Ta). When used in sealed area, confirm the actual ambient temperature.
- 8. Confirm that operation temperature is within the specified range described in the product specification.
- 9. ROHM shall not be in any way responsible or liable for failure induced under deviant condition from what is defined in this document.

Precaution for Mounting / Circuit board design

- 1. When a highly active halogenous (chlorine, bromine, etc.) flux is used, the residue of flux may negatively affect product performance and reliability.
- 2. In principle, the reflow soldering method must be used; if flow soldering method is preferred, please consult with the ROHM representative in advance.

For details, please refer to ROHM Mounting specification

Precautions Regarding Application Examples and External Circuits

- 1. If change is made to the constant of an external circuit, please allow a sufficient margin considering variations of the characteristics of the Products and external components, including transient characteristics, as well as static characteristics.
- 2. You agree that application notes, reference designs, and associated data and information contained in this document are presented only as guidance for Products use. Therefore, in case you use such information, you are solely responsible for it and you must exercise your own independent verification and judgment in the use of such information contained in this document. ROHM shall not be in any way responsible or liable for any damages, expenses or losses incurred by you or third parties arising from the use of such information.

Precaution for Electrostatic

This Product is electrostatic sensitive product, which may be damaged due to electrostatic discharge. Please take proper caution in your manufacturing process and storage so that voltage exceeding the Products maximum rating will not be applied to Products. Please take special care under dry condition (e.g. Grounding of human body / equipment / solder iron, isolation from charged objects, setting of lonizer, friction prevention and temperature / humidity control).

Precaution for Storage / Transportation

- 1. Product performance and soldered connections may deteriorate if the Products are stored in the places where:
 - [a] the Products are exposed to sea winds or corrosive gases, including Cl2, H2S, NH3, SO2, and NO2
 - [b] the temperature or humidity exceeds those recommended by ROHM
 - [c] the Products are exposed to direct sunshine or condensation
 - [d] the Products are exposed to high Electrostatic
- 2. Even under ROHM recommended storage condition, solderability of products out of recommended storage time period may be degraded. It is strongly recommended to confirm solderability before using Products of which storage time is exceeding the recommended storage time period.
- 3. Store / transport cartons in the correct direction, which is indicated on a carton with a symbol. Otherwise bent leads may occur due to excessive stress applied when dropping of a carton.
- 4. Use Products within the specified time after opening a humidity barrier bag. Baking is required before using Products of which storage time is exceeding the recommended storage time period.

Precaution for Product Label

QR code printed on ROHM Products label is for ROHM's internal use only.

Precaution for Disposition

When disposing Products please dispose them properly using an authorized industry waste company.

Precaution for Foreign Exchange and Foreign Trade act

Since our Products might fall under controlled goods prescribed by the applicable foreign exchange and foreign trade act, please consult with ROHM representative in case of export.

Precaution Regarding Intellectual Property Rights

- 1. All information and data including but not limited to application example contained in this document is for reference only. ROHM does not warrant that foregoing information or data will not infringe any intellectual property rights or any other rights of any third party regarding such information or data. ROHM shall not be in any way responsible or liable for infringement of any intellectual property rights or other damages arising from use of such information or data.:
- 2. No license, expressly or implied, is granted hereby under any intellectual property rights or other rights of ROHM or any third parties with respect to the information contained in this document.

Other Precaution

- 1. This document may not be reprinted or reproduced, in whole or in part, without prior written consent of ROHM.
- 2. The Products may not be disassembled, converted, modified, reproduced or otherwise changed without prior written consent of ROHM.
- 3. In no event shall you use in any way whatsoever the Products and the related technical information contained in the Products or this document for any military purposes, including but not limited to, the development of mass-destruction weapons.
- 4. The proper names of companies or products described in this document are trademarks or registered trademarks of ROHM, its affiliated companies or third parties.

General Precaution

- 1. Before you use our Products, you are requested to care fully read this document and fully understand its contents. ROHM shall not be in an y way responsible or liable for failure, malfunction or accident arising from the use of a ny ROHM's Products against warning, caution or note contained in this document.
- 2. All information contained in this docume nt is current as of the issuing date and subject to change without any prior notice. Before purchasing or using ROHM's Products, please confirm the latest information with a ROHM sale s representative.
- 3. The information contained in this document is provided on an "as is" basis and ROHM does not warrant that all information contained in this document is accurate an d/or error-free. ROHM shall not be in an y way responsible or liable for any damages, expenses or losses incurred by you or third parties resulting from inaccuracy or errors of or concerning such information.



BD9300FV - Web Page

Distribution Inventory

Part Number	BD9300FV
Package	SSOP-B14
Unit Quantity	2500
Minimum Package Quantity	2500
Packing Type	Taping
Constitution Materials List	inquiry
RoHS	Yes