

July 10, 2017

Product Information (PI1652)
Production Change Notice
Discontinuation of Series 44
Series 44

Contact

EAO Corporation

One Parrott Drive
Shelton, CT 06484
Phone +1 203 951 4600
Fax +1 203 951 4601

Discontinuation of Series 44.

Due to expanding market demands, a major portion of EAO Series 44, 22.5mm product line will be officially discontinued at the end of 2017.

With the introduction of the new, modern and comparable Series 45, this represents the next step in the product life cycle of the Series 44, which has been in service for many years. Alternative products with similar sizes can be found in EAO Series 45, 04 and 14.

The portion of the series to be discontinued includes:

- Pushbuttons
- Emergency Stop/Stop Switches
- Selectors
- Keylocks
- Indicators

The portion of the series that will remain available:

- 2,4,& 8 Position Joysticks
- Potentiometers

The affected part numbers include and extend beyond what is listed in our current price lists.

Please refer to the list below of the affected part numbers, both discontinued and part numbers that will remain available.

- The last date we can accept orders for the discontinued items is November 15, 2017.
- Scheduled release dates for these orders are permitted up to December 31, 2017.
- After December 31, 2017, availability of the discontinued items will be limited to only "in-house" existing stock until their depletion.

DISCONTINUED ITEMS

Part no.	Description
44-111	Switching Element front mounting 1NC
44-112	Switching Element front mounting gold/silver 1NC
44-121	Switching Element front mounting 1NO
44-131	Switching Element front mounting 1NC+1NO
44-132	Switching Element front mounting gold/silver 1NC+1NO
44-141	Switching Element front mounting overlapping 1NC+1NO
44-151	Switching Element front mounting 1NC
44-152	Switching Element front mounting gold/silver 1NC
44-161	Switching Element front mounting 1NO
44-162	Switching Element front mounting gold/silver 1NO
44-211	Switching Element base mounting 1NC
44-221	Switching Element base mounting 1NO
44-524	Lamp element for front mounting
44-525	Lamp element for base mounting
44-701.20	Pushbutton-actuator black matt chrome mom
44-701.20.100	Pushbutton mom black matt chrome 1NC+1NO
44-701.22	Pushbutton-actuator red matt chrome mom
44-701.22.001	Pushbutton mom red matt chrome 1NC
44-701.22B	Pushbutton-actuator red mom without front ring
44-701.24	Pushbutton-actuator yellow matt chrome mom
44-701.24.010	Pushbutton mom yellow matt chrome 1NO
44-701.25	Pushbutton-actuator green matt chrome mom
44-701.25.010	Pushbutton mom green matt chrome 1NO
44-701.25B	Pushbutton-actuator green mom without front ring
44-701.26	Pushbutton-actuator mom blue matt chrome
44-701.27	Pushbutton-actuator mom clear matt chrome
44-701.29	Pushbutton-actuator white matt chrome mom
44-701.60	Pushbutton-actuator black mom
44-701.62	Pushbutton-actuator red mom
44-701.64	Pushbutton-actuator yellow mom
44-701.65	Pushbutton-actuator green mom
44-701.66	Pushbutton-actuator mom blue
44-701.69	Pushbutton-actuator white mom
44-702.20	Pushbutton-actuator black matt chrome main
44-702.20.100	Pushbutton main black 1NC+1NO
44-702.22	Pushbutton-actuator red matt chrome main
44-702.24	Pushbutton-actuator yellow matt chrome main
44-702.25	Pushbutton-actuator green matt chrome main
44-702.25.010	Pushbutton main green 1NO
44-702.26	Pushbutton-actuator blue matt chrome main
44-702.60	Pushbutton-actuator black main
44-702.62	Pushbutton-actuator red main
44-702.65	Pushbutton-actuator green main
44-703.20	Pushbutton-actuator mom, with front ring black matt chrome
44-703.22	Pushbutton-actuator mom, with front ring red matt chrome
44-703.24	Pushbutton-actuator mom, with front ring yellow matt chrome
44-703.25	Pushbutton-actuator mom, with front ring green matt chrome
44-703.26	Pushbutton-actuator mom, with front ring blue matt chrome
44-703.62	Pushbutton-actuator mom, with front ring red raised
44-704.22	Pushbutton-actuator mom, with raised knob red matt chrome
44-704.22B	Pushbutton-actuator mom, with raised knob red without ring
44-704.65	Pushbutton-actuator mom, with raised knob green
44-707.20	Mushroom-head pushbutton black matt chrome
44-707.22	Mushroom-head pushbutton red matt chrome
44-707.25	Mushroom-head pushbutton green matt chrome
44-707.64	Mushroom-head pushbutton yellow
44-709.27	Push Rod actuator colorless with threading M4
44-710	Switch emergency-stop-actuator red D50
44-710.001	Switch emergency-stop red D50 1NC
44-711	Switch emergency-stop-actuator red D37
44-711-C	Switch emergency-stop-actuator special
44-712	Switch emergency-stop-actuator with twist release foolproof
44-712.001	Switch emergency-stop with twist release foolproof D37 1NC
44-713	Switch emergency-stop with key release foolproof red D37
44-720.20	Selector switch-actuator 2 positions black matt chrome main
44-720.20.100	Selector switch 2 positions black matt 1NC+1NO main
44-720.22	Selector switch-actuator 2 positions red matt chrome main
44-720.62	Selector switch-actuator 2 positions red main
44-720.68	Selector switch-actuator 2 positions grey main
44-722.20	Selector switch-actuator 2 positions black matt chrome mom
44-722.68	Selector switch-actuator 2 positions grey mom
44-724.20	Selector switch-actuator 3 positions black main-0-main

Part no.	Description
44-750.65	Indicator shape 1 green
44-750.66	Indicator shape 1 blue
44-750.67	Indicator shape 1 colorless
44-751.22	Indicator shape 2 red matt chrome
44-751.22.000	Indicator shape 2 red
44-751.24	Indicator shape 2 yellow matt chrome
44-751.24.000	Indicator shape 2 yellow
44-751.25	Indicator shape 2 green matt chrome
44-751.25.000	Indicator shape 2 green
44-751.26	Indicator shape 2 blue matt chrome
44-751.29	Indicator shape 2 white matt chrome
44-751.29.000	Indicator shape 2 white
44-751.62	Indicator shape 2 red
44-751.64	Indicator shape 2 yellow
44-751.65	Indicator shape 2 green
44-751.66	Indicator shape 2 blue
44-751.69	Indicator shape 2 white
44-770.2	Double pushbutton chrome
44-771.2	Double pushbutton marking chrome
44-772.2	Double pushbutton chrome color of operation part: 2x green
44-773.2	Double pushbutton chrome color of operation part: black / white
44-774.2	Double pushbutton chrome color of operation part: black / white
44-800.A	Lever switch
44-900	Front adaptor 0
44-901	Front adaptor 1
44-902	Front adaptor 2
44-903	Front adaptor 3
44-905	Base adaptor
44-915	Blanking plate 2
44-919	Spare key lock 9500
44-919.A	Spare key brass
44-921.00	Lock cap black
44-921.08	Lock cap grey
44-925	Reducing ring
44-926.8	Fixing nut black
44-935	Mounting tool
44-940	Blank element
44-944.00	Label support black
44-944.08	Label support grey
44-945.00	Label support black with unmarked label
44-945.08	Label support grey with unmarked label
44-946	Label silver 27x18
44-946.0	Label black 27x18
44-946.01	Front bezel-set, flush mounting without label support
44-946.01-A	Front bezel-set, flush mounting round
44-946.02	Front bezel-set, flush mounting with label support
44-946.03	Front bezel-set, flush mounting flat without label support
44-946.03-A	Front bezel-set, flush mounting flat round
44-946.04	Front bezel-set, flush mounting flat with label support
44-955	Legend plate
44-960	Label 13x26
44-960-T03	Label 13x26 engraved
44-960-T27	Label 13x26 engraved
44-962.9	Marking plate white for illuminated pushbutton
44-964.3	Scale
44-964.3A	Scale dial alu with semicircular tail
44-965.2	Lens shape 1 cap red
44-965.4	Lens shape 1 cap yellow
44-965.5	Lens shape 1 cap green
44-965.6	Lens shape 1 cap blue
44-965.7	Lens shape 1 cap colorless
44-966.2	Lens red for indicator shape 2 and illuminated pushbutton actuator
44-966.4	Lens yellow for indicator shape 2 and illuminated pushbutton
44-966.5	Lens green for indicator shape 2 and illuminated pushbutton
44-966.6	Lens blue for indicator shape 2 and illuminated pushbutton actuator
44-966.7	Lens colorless for indicator shape 2 and illuminated pushbutton
44-967.2	Front ring matt chrome
44-967.6	Front ring
44-969.0	Lens black for pushbutton
44-969.2	Lens red for pushbutton
44-976	Lamp transformer 220V/24V
44-977	Lamp transformer 380V/24V

44-724.20.020	Selector switch 3 positions black matt main-0-main 2NO
44-724.60	Selector switch-actuator 3 positions black main-0-main,
44-724.68	Selector switch-actuator 3 positions grey main-0-main
44-725.20	Selector switch-actuator 3 positions black matt mom-0-mom
44-725.68	Selector switch-actuator 3 positions grey mom-0-mom
44-726.20	Selector switch-actuator 3 positions black matt main-0-mom
44-726.68	Selector switch-actuator 3 positions grey main-0-mom
44-727.20	Selector switch-actuator 3 positions black matt mom-0-main
44-730.21	Keylock switch-actuator 2 positions matt chrome main
44-730.21-A	Schlüsselschalter-Vorsatz 2-St.
44-730.21.100	Keylock switch 2 positions mat chrome main 1NC+1NO
44-730.22	Keylock switch-actuator 2 positions matt chrome main
44-730.22.100	Keylock switch 2 positions mat chrome main 1NC+1NO
44-730.61	Keylock switch-actuator 2 positions main
44-730.62	Keylock switch-actuator 2 positions main
44-732.21	Keylock switch-actuator 2 positions matt chrome mom
44-732.61	Keylock switch actuator 2 positions mom
44-740.00	Rotating knob 18/6 black/black
44-742.20	Interlocking button black matt chrome
44-742.22	Interlocking button red matt chrome
44-746.22	Illuminated pushbutton-actuator red matt chrome mom
44-746.22.001	Illuminated pushbutton red mom 1NC
44-746.24	Illuminated pushbutton-actuator yellow matt chrome mom
44-746.24.010	Illuminated pushbutton yellow mom 1NO
44-746.25	Illuminated pushbutton-actuator green matt chrome mom
44-746.25-A	Illuminated pushbutton-actuator green matt chrome mom
44-746.25.010	Illuminated pushbutton green mom 1NO
44-746.26	Illuminated pushbutton-actuator blue matt chrome mom
44-746.29	Illuminated pushbutton-actuator white matt chrome mom
44-746.29.100	Illuminated pushbutton white mom 1NC+1NO
44-746.62	Illuminated pushbutton-actuator red mom
44-746.64	Illuminated pushbutton-actuator yellow mom
44-746.65	Illuminated pushbutton-actuator green mom
44-746.66	Illuminated pushbutton-actuator blue mom
44-746.69	Illuminated pushbutton-actuator white mom
44-747.22	Illuminated pushbutton-actuator red matt chrome main
44-747.24	Illuminated pushbutton-actuator yellow matt chrome main
44-747.24.010	Illuminated pushbutton green main 1NO
44-747.25	Illuminated pushbutton-actuator green matt chrome main
44-747.25.010	Illuminated pushbutton green main 1NO
44-747.26	Illuminated pushbutton-actuator blue matt chrome main
44-747.29	Illuminated pushbutton-actuator white matt chrome main
44-747.29.100	Illuminated pushbutton white main 1NC+1NO
44-747.62	Illuminated pushbutton-actuator red main
44-747.64	Illuminated pushbutton-actuator yellow main
44-747.65	Illuminated pushbutton-actuator green main
44-747.66	Illuminated pushbutton-actuator blue main
44-747.69	Illuminated pushbutton-actuator white main
44-750.22	Indicator shape 1 red matt chrome
44-750.22.000	Indicator shape 1 red
44-750.24	Indicator shape 1 yellow matt chrome
44-750.24.000	Indicator shape 1 yellow
44-750.25	Indicator shape 1 green matt chrome
44-750.25.000	Indicator shape 1 green
44-750.26	Indicator shape 1 blue matt chrome
44-750.27	Indicator shape 1 colorless matt chrome
44-750.27.000	Indicator shape 1 colorless
44-750.62	Indicator shape 1 red
44-750.64	Indicator shape 1 yellow

44-XXX	Switches and accessories Series 44
44.131.00	Switching Element 1NC+1NO
44.701.200	Pushbutton-actuator black matt chrome mom with accessories
44.701.202	Pushbutton-actuator red matt chrome mom with accessories
44.701.204	Pushbutton-actuator yellow matt chrome mom with accessories
44.701.205	Pushbutton-actuator green matt chrome mom with accessories
44.701.206	Pushbutton-actuator mom blue matt chrome with accessories
44.701.209	Pushbutton-actuator white matt chrome mom with accessories
44.702.200	Pushbutton-actuator black matt chrome main with accessories
44.702.202	Pushbutton-actuator red matt chrome main with accessories
44.704.204	Pushbutton-actuator mom, with raised knob yellow matt chrome
44.707.202	Mushroom-head pushbutton red matt chrome with accessories
44.707.204	Mushroom-head pushbutton yellow matt chrome with accessories
44.707.205	Mushroom-head pushbutton green matt chrome with accessories
44.710.00	Switch emergency-stop-actuator red D50 with accessories
44.711.00	Switch emergency-stop-actuator red D37 with accessories
44.712.00	Switch emergency-stop-actuator with twist release foolproof red
44.713.00	Switch emergency-stop with key release foolproof red D37
44.720.200	Selector switch-actuator 2 positions black matt chrome main
44.722.200	Selector switch-actuator 2 positions matt chrome mom
44.724.200	Selector switch-actuator 3 positions black matt main-0-main
44.730.201	Keylock switch-actuator 2 positions matt chrome main
44.730.202	Keylock switch-actuator 2 positions matt chrome main
44.732.201	Keylock switch-actuator 2 positions matt chrome mom
44.734.201	Keylock switch-actuator 3 positions matt chrome main-0-main
44.734.204	Keylock switch-actuator 3 positions matt chrome main-0-main
44.734.205	Keylock switch-actuator 3 positions matt chrome main-0-main
44.737.201	Keylock switch-actuator 3 positions matt chrome mom-0-main
44.746.202	Illuminated pushbutton-actuator red matt chrome mom
44.746.204	Illuminated pushbutton-actuator yellow matt chrome mom
44.746.205	Illuminated pushbutton-actuator green matt chrome mom
44.746.206	Illuminated pushbutton-actuator blue matt chrome mom
44.746.209	Illuminated pushbutton-actuator white matt chrome mom
44.747.205	Illuminated pushbutton-actuator green matt chrome main
44.750.200	Indicator shape 1 without lens cap matt chrome
44.750.202	Indicator shape 1 red matt chrome
44.750.204	Indicator shape 1 yellow matt chrome
44.750.205	Indicator shape 1 green matt chrome
44.750.206	Indicator shape 1 blue matt chrome
44.750.207	Indicator shape 1 clear matt chrome
44.751.202	Indicator shape 2 red matt chrome
44.751.209	Indicator shape 2 white matt chrome
44.950.02	Legend plate for Emergency-Stop switch D60
EUS-44-01273	Pushbutton Assembly
EUS-44-05552	Pushbutton Assembly
EUS-44-05652	Pushbutton Assembly
EUS-44-06552	Pushbutton Assembly
EUS-44-06559	Pushbutton Assembly
EUS-44-06562	Pushbutton Assembly
EUS-44-24551	Pushbutton Assembly
EUS-44-30554	Pushbutton Assembly
EUS-44-30555	Pushbutton Assembly
EUS-44-33550	Pushbutton Assembly
EUS-44-33560	Pushbutton Assembly
EUS-44-34551	Pushbutton Assembly
EUS-44-701.26/005	Pushbutton Assembly
EUS-44-701.29/033	Pushbutton Assembly
EUS-44-771.2/003	Pushbutton Assembly
EUS-44-92502	Pushbutton Assembly

ITEMS NOT DISCONTINUED

Part no.	Description
44-744.20	Potentiometer-drive without Potentiometer matt chrome
44-744.60	Potentiometer-drive without Potentiometer
44-744.A	Potentiometer-drive Series 04 flush mounted without Pot.
44-744.C	Potentiometer-drive Series 04 flush mounted black without Pot.
44-744.D	Potentiometer-drive without Potentiometer
44-744.E	Potentiometer-drive without Potentiometer special
44-744.F	Potentiometer-drive Series 04 flush mounted without Pot.
44-744.G	Potentiometer-drive Series 04 flush mounted without Pot.
44-744.M	Potentiometer-drive Series 04 flush mounted natural without Pot.
44-744.N	Potentiometer-drive Series 04 flush mounted black without Pot.
44-745.20-10K1	Potentiometer-drive 10 kOhm lin. matt chrome
44-745.20-1K1	Potentiometer-drive 1 kOhm lin. matt chrome
44-745.20-1M1	Potentiometer-drive 1 MOhm lin. matt chrome
44-745.20-2K1	Potentiometer-drive 2,2 kOhm lin. matt chrome
44-745.20-33.1	Potentiometer-drive 33 Ohm
44-745.20-47K1	Potentiometer-drive 47 kOhm lin. matt chrome
44-745.20-4K1	Potentiometer-drive 4,7 kOhm lin. matt chrome

Part no.	Description
44-745.60-10K1	Potentiometer-drive 10 kOhm lin.
44-745.60-22K1	Potentiometer-drive 22 kOhm lin.
44-745.60-47K1	Potentiometer-drive 47 kOhm lin.
44-745.60-4K1	Potentiometer-drive 4,7 kOhm lin.
44-745.D	Potentiometer-drive Series 04 flush mounted Front ring hell 10kOhm lin
44-745.E	Potentiometer-drive Series 04 flush mounted 10kOhm lin.
44-745.G	Potentiometer-drive Series 04 flush mounted 50 Ohm lin.
44-745.P	Potentiometer-drive flush mounted 1 kOhm, special
44-745.P-3	Potentiometer-drive flush mounting, 1 k, (Vishay P30LL0FRR102MA)
44-745.S	Potentiometer actuator flush mount, 2.2kOhm pot. (SPECIAL)
44-745.T	Potentiometer-drive Series 04 flush mounted 10kOhm lin. with switch
44-745.U	Potentiometer actuator flush mount, 47kOhm pot. (SPECIAL)
44-745.V	Potentiometer-drive special flush mounting
44-800.2	Control switch 2 positions main 63mm
44-800.4	Control switch 4 positions main 63mm
44-800.8	Control switch 8 positions main 63mm
44-801.4	Control switch 4 positions main 30mm

Please note: EAO Series 45 offers many of the same features with expanded specifications and is considered the most viable alternative to the Series 44. Please contact EAO Customer Service to assist with cross referencing.