

Thanks for purchasing the **PLPTS**, a professional DJ laptop stand great for mixing it up at gig. The plastic and steel construction is durable enough to get you through any gig, any time, anywhere.



Specifications:

- Portable Laptop/Notebook Desk/Workstation
- Easily Adjustable Height
- Stand For Musicians, DJs, Based Performances
- Plastic Material Counter Construction
- Black High Gloss Finish
- Steel Frame Construction

Your kit includes one (1) set of the following items:



- 1 x tripod base
- 1 x laptop surface
- 2 x support brackets
- 4 x washers (on support brackets)
- 4 x gold screws (on support brackets)
- 4 x wing nuts (on support brackets)

Note: your stand may include different parts. If so, please check *Version 1* of this manual on www.PyleAudio.com.

1. Familiarize yourself with the tripod.



Note that knob (a) is for raising and lowering the T-bar, knob (b) is for opening and closing the tripod legs, and bar (c) secures the t-bar in place.

2. Next, prepare the support brackets. Remove the screws, washers, and nuts. Unscrew the knob. Then snap the bracket onto the t-bar.





3. Repeat this process for the next support bracket. Snap it on to the other side of the tbar. When reinserting the knob, make sure not to tighten too much, as you'll need to adjust their position to line up with the laptop plate.



4. Line up the two support brackets with the screw holes on the laptop plate. Insert each of the four screws.



5. From underneath the tripod, add a washer and wing nut to each screw to hold in place. They should look like this once installed.



6. Tighten the screws from above using a screwdriver to secure everything into place.



7. You can raise the stand by loosening knob (a) and raising the stand. Make sure to use bar (c) to secure the t-bar.



8. Congratulations - your stand is now complete!

