



FLYING EMOJI™ MINI COPTER

The Flying Emoji is controlled by hand gestures and movements made from directly underneath the ball, allowing you to play and have hours of endless fun chasing your Emoji!

The flying emoji ball is controlled by an inbuilt infra-red sensor found at the bottom of the ball.

To operate, simply wave your hand underneath the ball and the emoji will respond. By placing your hand a few inches away from the infra red light located at the bottom of the ball, you can control the movements of the emoji ball. Send the Emoji in all directions – up/down, forward/backward and even side ways!

Main Features

- Hand controlled by gesture movements
- Built in rechargeable Li-Polymer battery
- 8-10 mins flying time / 20-30 mins recharge
- Dimensions (including wing span) 20 x16 x 6cm
- Available in up to 6 different emoji designs
- Suitable for ages 5+
- Part number: BM-JY81

