

070403022

PM112xSM01

PM112/PM212

英文说明书

PULSE

零件3.11

杨松

VER1.0

1/1 杨松

PM112 & PM212

MANUAL

杨松

杨松

2016.3.14

2016.3.11

Single/Dual 12" Guitar Speaker Cabinet

IMPORTANT SAFETY SYMBOLS



The symbol is used to indicate that some hazardous live terminals are involved within this apparatus, even under the normal operating conditions, which may be sufficient to constitute the risk of electric shock or death.



The symbol is used in the service documentation to indicate that specific component shall be replaced only by the component specified in that documentation for safety reasons.



Protective grounding terminal



Alternating current/voltage



Hazardous live terminal

ON: Denotes the apparatus is turned on.

OFF: Denotes the apparatus is turned off.

WARNING: Describes precautions that should be observed to prevent the danger of injury or death to the operator.

CAUTION: Describes precautions that should be observed to prevent danger of the apparatus.



Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

IMPORTANT SAFETY INSTRUCTIONS

☐ Read these instructions. ☐ Keep these instructions.

☐ Heed all warning. ☐ Follow all instructions.

☐ Water & Moisture

The apparatus should be protected from moisture and rain, can not used near water, for example: near bathtub, kitchen sink or a swimming pool, etc.

☐ Heat

The apparatus should be located away from the heat source such as radiators, stoves or other appliances that produce heat.

Model: PM112

Speaker: 1x12"

Power: 60W

Impedance: 8 Ω

Input: 1/4" JACK

Sensitivity: 90dB

Size: 17" x 18.9" x 11.8

Weight: 26.5 lbs.



MODEL: PM212

SPEAKER: 2X12"

POWER: 120W

IMPEDANCE: 16 Ω

INPUT: 1/4" JACK

SENSITIVITY: 90dB

SIZE: 17.8" x 31.4" x 13.7"

WEIGHT: 55.2 lbs.

