

Pre Amplifier Microphone / Phono



Features

- Amplifies magnetic cartridge output for use with any amplifier.
- Use a microphone with any amplifier.
- Suitable for stereo microphones or upto 2 mono microphones.
- IC technology for high gain and low noise.
- Karaoke on any amplifier when used with mixer.
- Strong stylish steel case.
- Power supply included.

Instructions

Phono pre-amp.

Set slide switch to phono position. Connect phono output sockets to aux input of stereo amplifier. Connect turntable with magnetic cartridge to phono input sockets. Use screened phono leads.


Microphone pre-amp.

Set slide switch to mic position. Connect phono output sockets to aux input of stereo amplifier using screened phono leads. Dynamic and Condenser type microphones can be used. 1 stereo microphone or upto 2 mono microphones can be used. The sockets fitted are suitable for microphones with mono or stereo 6.3mm plugs. Adaptors are available for micro-phones fitted with 3.5mm plugs. Stereo microphones with stereo 6.3mm plug: use microphone socket marked stereo. Stereo microphones with 2 mono 6.3mm plugs: use mono socket for left channel plug, stereo socket for right channel plug. Mono microphone with 6.3mm plug: use socket mono. Output will be from both channels. Two mono microphones fitted with 6.3mm plugs. Use both mono and stereo sockets. Microphone in mono socket will be amplified on the left channel. Microphone in stereo socket will be amplified on the right channel.

Karaoke

Turn your amplifier into a karaoke amplifier: Use the product to amplify the microphone(s), connect to a Mixer connect a music source such as CD player, Tape player etc to the other input of the mixer, connect output to the aux, input of any amplify. Adjust levels accordingly.

Diagram



Part Number Table

| Description | Part Number |
|----------------------------------|-------------|
| Pre Amplifier Microphone / Phono | 555-17806 |