

Desoldering Iron

User Manual



Part Number: 21-8240





Instruction Manual

- · Plug the power cord into a power source.
- Allow the nozzle to warm up for approx. 10 min.
- · Press the knob until it clicks.
- · Place the tip of the nozzle against the solder.
- When the solder melts, press the button on the handle and the solder will be absorbed.

Cleaning

- · Lift the handle slightly in the direction of button and remove it from the grip.
- · Remove the solder waste around the cylinder.





Nozzle Replacement

Turn the nozzle counter-clock with pliers etc., and remove it from the handle.

Note: Turn the power off and wait until the unit has completely cooled before removing the solder waste or replacing the nozzle.

Caution

- · The Appliance is not a toy, and must be kept out of children's hands.
- Before cleaning the appliance or changing the filter, always remove the power lead plug from the socket. Unscrewing the housing is not permitted.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Important Notice: This data sheet and its contents (the "Information") belong to the members of the AVNET group of companies (the "Group") or are licensed to it. No licence is granted for the use of it other than for information purposes in connection with the products to which it relates. No licence of any intellectual property rights is granted. The Information is subject to change without notice and replaces all data sheets previously supplied. The Information supplied is believed to be accurate but the Group assumes no responsibility for its accuracy or completeness, any error in or omission from it or for any use made of it. Users of this data sheet should check for themselves the Information and the suitability of the products for their purpose and not make any assumptions based on information included or omitted. Liability for loss or damage resulting from any reliance on the Information or use of it (including liability resulting from negligence or where the Group was aware of the possibility of such loss or damage arising) is excluded. This will not operate to limit or restrict the Group's liability for death or personal injury resulting from its negligence. TENMA is the registered trademark of Premier Farnell Limited 2019.

Newark.com/exclusive-brands Farnell.com/exclusive-brands Element14.com/exclusive-brands

