



Solar Ground Lights Model: PELL0264

Please read these instructions carefully before use and retain for future reference.

IMPORTANT SAFETY INFORMATION

- Avoid locations of high temperature or humidity.
- The lamp is constructed to IP65 suitable for external use.

WHAT'S INCLUDED

- Lamp assembly x 4.
- User manual.

INSTALLATION

- Assemble the two parts of the ground spike by slotting the longer fin into the slot in the shorter fin.
- Engage the 4 round pins into the 4 holes in the bottom of the lamp body.
- Slide the switch into the ON position then insert the spike into the ground having
 first loosened the soil ensuring the solar panel is exposed for maximum charging
 efficiency but not in the vicinity of other strong light source or the low light
 illumination may not function.
- Do not attempt to press the lamp into solid earth.

OPERATION

· Allow at least 8hrs for the battery to fully charge initially.

NOTE: the lamp does not light except in low ambient light levels.

 When the ambient light falls below a preset level the LEDs will illuminate constantly.

CLEANING & MAINTENANCE

 Clean the unit only with a damp cloth. Do not use any chemicals, abrasives or solvents that could damage the casing or lens.

SPECIFICATION

Solar panels: Monocrystal/polycrystal 2V 120mA Battery: 1x1.2V AA 600mAh NI-MH battery

LED Type: 8 x white/warm LEDs Material: plastic+ss construction

Size: 12x12x13cm Weight: 0.15kgs







When this product has reached the end of its life it must be treated as Waste Electrical & Electronic Equipment (WEEE). Any WEEE marked products must not be mixed with general household waste, but kept separate for the treatment, recovery and recycling of the materials used. Contact your local authority for details of recycling schemes in your area.

Made in China PO Box 13362 Dublin 2 PR2 9PP

Man Rev 1.1