

Terminal block

To simplify the connection of your sensors a terminal block is available for the ADC-11. This connects to the input of the ADC-11 and provides screw terminals to allow you to quickly connect and disconnect your sensors.

