multicomp PRO





Specifications

Max. Current/Voltage Rating With Resistive Load : 400mA 32V AC - 200 mA 50V DC - 125 mA 125V AC.

Initial Contact Resistance : $50m\Omega$ max.

Insulation Resistance : 1GΩmin. at 500V DC

Dielectric Strength : 1,500V AC rms. (initial value)

Electrical Life At Full Load : 500,000 cycles.

Operating Temperature : -30°C to 85°C.

Total Travel : 1.5 mm(.059)

Operating Force : 3N~6N

Contact Bounce : 10 ms.

Mechanical Life: 1,000,000 cycles.Torque: 0.5Nm max.

Ingress Protection : IP68

Materials

Cap : Polyamide 6/6. Plunger : MPP12-6 : PC

MPP12-7: Polyamide 6/6.

Rubber : Silicone.

Bushing : Polyamide 6/6.

Case : Diallyl phthalate (DAP)(UL94v-0).
Contacts : Brass with gold over silver plated.




Switch Function

NO	MODEL	SWITCH FUNCTION		CONNECTED TERMINALS / SCHEMATIC			
NO.	MODEL NO.	POS.1	POS.2	PO	S.1	POS	5.2
					L		\
SP	MPP12-6	OFF	(ON)	OPEN	1 2	CLOSE	1 2
SP	MPP12-7	ON	(OFF)	CLOSE	1 2	OPEN	1 • • 2


^{()=}MOMENTARY

Cap Options


Flat STD









High No LED



Terminal Options

M1 Solder lug (STD)






Dimensions: Millimetres




multicomp PRO




Note: Terminal M2~M4 are only available with MPP12-6 without LED.


Panel Mounting



Dimension



Model name. MPP12-6B207MM1CAS05L00



Model name. MPP12-6B205MM1CAS05L00

Newark.com/multicomp-pro Farnell.com/multicomp-pro sg.element14.com/b/multicomp-pro

SPST




Dimensions: Millimetres




Wire Options

YXXX Wire leads 20 AWG



D001 Molding, 500mm wire leads 20 AWG *Available with flat cap type only.




multicomp PRO

Hardware

- * Standard hardware : 1 nut, 1 O-ring, 1 lockwasher
- * For further information please consult sales representative.


NUT (Std.)



Lockwasher (Std.)



O-Ring (Std.)




Rubber Hood

Transparent rubber hood (Std.)




Black rubber hood





multicomp PRO



Note: Our standard is with flat cap.

Example MPP12-6 B2 M1CAS05L00 MPP12-7 B2 M1CAS05L00

^{1.}LED is only available with flat cap.

^{2.}Round and high caps are only available with without LED.

^{**} Terminal M2~M4 are only available with MPP12-6 without LED.



Part Number Table

Description	Part Number
Pushbutton Switch, Off-On, W/O LED	MPP12-6B202MM1CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B202MM1CAS05L00-S001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B202MM1CAS05L00-Y001
Pushbutton Switch, Off-On, White LED	MPP12-6B202MM1CAS05L01
Pushbutton Switch, Off-On, White LED	MPP12-6B202MM1CAS05L01-S001
Pushbutton Switch, Off-On, White LED	MPP12-6B202MM1CAS05L01-Y001
Pushbutton Switch, Off-On, Red LED	MPP12-6B202MM1CAS05L03
Pushbutton Switch, Off-On, Red LED	MPP12-6B202MM1CAS05L03-S001
Pushbutton Switch, Off-On, Red LED	MPP12-6B202MM1CAS05L03-Y001
Pushbutton Switch, Off-On, Yellow LED	MPP12-6B202MM1CAS05L05
Pushbutton Switch, Off-On, Yellow LED	MPP12-6B202MM1CAS05L05-S001
Pushbutton Switch, Off-On, Yellow LED	MPP12-6B202MM1CAS05L05-Y001
Pushbutton Switch, Off-On, Green LED	MPP12-6B202MM1CAS05L06
Pushbutton Switch, Off-On, Green LED	MPP12-6B202MM1CAS05L06-S001
Pushbutton Switch, Off-On, Green LED	MPP12-6B202MM1CAS05L06-Y001
Pushbutton Switch, Off-On, Blue LED	MPP12-6B202MM1CAS05L07
Pushbutton Switch, Off-On, Blue LED	MPP12-6B202MM1CAS05L07-S001
Pushbutton Switch, Off-On, Blue LED	MPP12-6B202MM1CAS05L07-Y001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B202MM2CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B202MM3CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B202MM4CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B203MM1CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B203MM1CAS05L00-S001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B203MM1CAS05L00-Y001
Pushbutton Switch, Off-On, White LED	MPP12-6B203MM1CAS05L01
Pushbutton Switch, Off-On, White LED	MPP12-6B203MM1CAS05L01-S001
Pushbutton Switch, Off-On, White LED	MPP12-6B203MM1CAS05L01-Y001
Pushbutton Switch, Off-On, Red LED	MPP12-6B203MM1CAS05L03
Pushbutton Switch, Off-On, Red LED	MPP12-6B203MM1CAS05L03-S001
Pushbutton Switch, Off-On, Red LED	MPP12-6B203MM1CAS05L03-Y001
Pushbutton Switch, Off-On, Yellow LED	MPP12-6B203MM1CAS05L05
Pushbutton Switch, Off-On, Yellow LED	MPP12-6B203MM1CAS05L05-S001
Pushbutton Switch, Off-On, Yellow LED	MPP12-6B203MM1CAS05L05-Y001
Pushbutton Switch, Off-On, Green LED	MPP12-6B203MM1CAS05L06
Pushbutton Switch, Off-On, Green LED	MPP12-6B203MM1CAS05L06-S001
Pushbutton Switch, Off-On, Green LED	MPP12-6B203MM1CAS05L06-Y001
Pushbutton Switch, Off-On, Blue LED	MPP12-6B203MM1CAS05L07
Pushbutton Switch, Off-On, Blue LED	MPP12-6B203MM1CAS05L07-S001





Pushbutton Switch, Off-On, Blue LED MPP12-6B203MM1CAS05L07-Y00 Pushbutton Switch, Off-On, W/O LED MPP12-6B203MM2CAS05L00 Pushbutton Switch, Off-On, W/O LED MPP12-6B203MM3CAS05L00 Pushbutton Switch, Off-On, W/O LED MPP12-6B203MM4CAS05L00 Pushbutton Switch, Off-On, W/O LED MPP12-6B205MM1CAS05L00 Pushbutton Switch, Off-On, W/O LED MPP12-6B205MM1CAS05L00-S00 Pushbutton Switch, Off-On, W/O LED MPP12-6B205MM1CAS05L00-S00 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01-Y00 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01-S00 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01-Y00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-S00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-S00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L05-S00
Pushbutton Switch, Off-On, W/O LED Pushbutton Switch, Off-On, White LED Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-S00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L05
Pushbutton Switch, Off-On, W/O LED Pushbutton Switch, Off-On, White LED Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-S00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L05
Pushbutton Switch, Off-On, W/O LED MPP12-6B205MM1CAS05L00 Pushbutton Switch, Off-On, W/O LED MPP12-6B205MM1CAS05L00-S00 Pushbutton Switch, Off-On, W/O LED MPP12-6B205MM1CAS05L00-Y00 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01-S00 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01-Y00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-S00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L05
Pushbutton Switch, Off-On, W/O LED MPP12-6B205MM1CAS05L00-S00 Pushbutton Switch, Off-On, W/O LED MPP12-6B205MM1CAS05L00-Y00 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01-S00 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01-Y00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-S00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L05
Pushbutton Switch, Off-On, W/O LED MPP12-6B205MM1CAS05L00-Y00 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01-S00 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01-Y00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-S00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L03
Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01-S00 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01-Y00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-S00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L05
Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01-S00 Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01-Y00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-S00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L05
Pushbutton Switch, Off-On, White LED MPP12-6B205MM1CAS05L01-Y00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-S00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L05
Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-S00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L05
Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-S00 Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L05
Pushbutton Switch, Off-On, Red LED MPP12-6B205MM1CAS05L03-Y00 Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L05
Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L05
Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L05-S00
Pushbutton Switch, Off-On, Yellow LED MPP12-6B205MM1CAS05L05-Y00
Pushbutton Switch, Off-On, Green LED MPP12-6B205MM1CAS05L06
Pushbutton Switch, Off-On, Green LED MPP12-6B205MM1CAS05L06-S00
Pushbutton Switch, Off-On, Green LED MPP12-6B205MM1CAS05L06-Y00
Pushbutton Switch, Off-On, Blue LED MPP12-6B205MM1CAS05L07
Pushbutton Switch, Off-On, Blue LED MPP12-6B205MM1CAS05L07-S00
Pushbutton Switch, Off-On, Blue LED MPP12-6B205MM1CAS05L07-Y00
Pushbutton Switch, Off-On, W/O LED MPP12-6B205MM2CAS05L00
Pushbutton Switch, Off-On, W/O LED MPP12-6B205MM3CAS05L00
Pushbutton Switch, Off-On, W/O LED MPP12-6B205MM4CAS05L00
Pushbutton Switch, Off-On, W/O LED MPP12-6B206MM1CAS05L00
Pushbutton Switch, Off-On, W/O LED MPP12-6B206MM1CAS05L00-S00
Pushbutton Switch, Off-On, W/O LED MPP12-6B206MM1CAS05L00-Y00
Pushbutton Switch, Off-On, White LED MPP12-6B206MM1CAS05L01
Pushbutton Switch, Off-On, White LED MPP12-6B206MM1CAS05L01-S00
Pushbutton Switch, Off-On, White LED MPP12-6B206MM1CAS05L01-Y00
Pushbutton Switch, Off-On, Red LED MPP12-6B206MM1CAS05L03
Pushbutton Switch, Off-On, Red LED MPP12-6B206MM1CAS05L03-S00
Pushbutton Switch, Off-On, Red LED MPP12-6B206MM1CAS05L03-Y00
Pushbutton Switch, Off-On, Yellow LED MPP12-6B206MM1CAS05L05
Pushbutton Switch, Off-On, Yellow LED MPP12-6B206MM1CAS05L05-S00
Pushbutton Switch, Off-On, Yellow LED MPP12-6B206MM1CAS05L05-Y00
Pushbutton Switch, Off-On, Green LED MPP12-6B206MM1CAS05L06
Pushbutton Switch, Off-On, Green LED MPP12-6B206MM1CAS05L06-S00
Pushbutton Switch, Off-On, Green LED MPP12-6B206MM1CAS05L06-Y00





Pushbutton Switch, Off-On, Blue LED	MPP12-6B206MM1CAS05L07
Pushbutton Switch, Off-On, Blue LED	MPP12-6B206MM1CAS05L07-S001
Pushbutton Switch, Off-On, Blue LED	MPP12-6B206MM1CAS05L07-Y001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B206MM2CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B206MM3CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B206MM4CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B207MM1CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B207MM1CAS05L00-S001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B207MM1CAS05L00-Y001
Pushbutton Switch, Off-On, White LED	MPP12-6B207MM1CAS05L01
Pushbutton Switch, Off-On, White LED	MPP12-6B207MM1CAS05L01-S001
Pushbutton Switch, Off-On, White LED	MPP12-6B207MM1CAS05L01-Y001
Pushbutton Switch, Off-On, Red LED	MPP12-6B207MM1CAS05L03
Pushbutton Switch, Off-On, Red LED	MPP12-6B207MM1CAS05L03-S001
Pushbutton Switch, Off-On, Red LED	MPP12-6B207MM1CAS05L03-Y001
Pushbutton Switch, Off-On, Yellow LED	MPP12-6B207MM1CAS05L05
Pushbutton Switch, Off-On, Yellow LED	MPP12-6B207MM1CAS05L05-S001
Pushbutton Switch, Off-On, Yellow LED	MPP12-6B207MM1CAS05L05-Y001
Pushbutton Switch, Off-On, Green LED	MPP12-6B207MM1CAS05L06
Pushbutton Switch, Off-On, Green LED	MPP12-6B207MM1CAS05L06-S001
Pushbutton Switch, Off-On, Green LED	MPP12-6B207MM1CAS05L06-Y001
Pushbutton Switch, Off-On, Blue LED	MPP12-6B207MM1CAS05L07
Pushbutton Switch, Off-On, Blue LED	MPP12-6B207MM1CAS05L07-S001
Pushbutton Switch, Off-On, Blue LED	MPP12-6B207MM1CAS05L07-Y001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B207MM2CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B207MM3CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B207MM4CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A2SM1CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A2SM1CAS05L00-S001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A2SM1CAS05L00-Y001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A2SM2CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A2SM3CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A2SM4CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A3SM1CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A3SM1CAS05L00-S001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A3SM1CAS05L00-Y001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A3SM2CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A3SM3CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A3SM4CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A5SM1CAS05L00





	1
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A5SM1CAS05L00-S001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A5SM1CAS05L00-Y001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A5SM2CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A5SM3CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A5SM4CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A6SM1CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A6SM1CAS05L00-S001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A6SM1CAS05L00-Y001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A6SM2CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A6SM3CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A6SM4CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A7SM1CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A7SM1CAS05L00-S001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A7SM1CAS05L00-Y001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A7SM2CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A7SM3CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2A7SM4CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G2SM1CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G2SM1CAS05L00-S001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G2SM1CAS05L00-Y001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G2SM2CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G2SM3CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G2SM4CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G3SM1CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G3SM1CAS05L00-S001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G3SM1CAS05L00-Y001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G3SM2CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G3SM3CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G3SM4CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G5SM1CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G5SM1CAS05L00-S001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G5SM1CAS05L00-Y001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G5SM2CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G5SM3CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G5SM4CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G6SM1CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G6SM1CAS05L00-S001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G6SM1CAS05L00-Y001
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G6SM2CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G6SM3CAS05L00
Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G6SM4CAS05L00





Pushbutton Switch, Off-On, W/O LED Pushbutton Switch, On-Off, W/O LED Pushbutton Switc		
Pushbutton Switch, Off-On, W/O LED MPP12-6B2G7SM1CAS05L00-Y001 Pushbutton Switch, Off-On, W/O LED MPP12-6B2G7SM2CAS05L00 Pushbutton Switch, Off-On, W/O LED MPP12-6B2G7SM3CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-6B2G7SM4CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B202MM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B202MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B203MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B203MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B203MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B205MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B205MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B205MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2ASSM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2GSSM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2GSSM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1C	Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G7SM1CAS05L00
Pushbutton Switch, Off-On, W/O LED Pushbutton Switch, On-Off, W/O LED Pushbutton Switc	Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G7SM1CAS05L00-S001
Pushbutton Switch, Off-On, W/O LED MPP12-6B2G7SM3CAS05L00 Pushbutton Switch, Off-On, W/O LED MPP12-6B2G7SM4CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B202MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B203MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B205MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B205MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12	Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G7SM1CAS05L00-Y001
Pushbutton Switch, Off-On, W/O LED Pushbutton Switch, On-Off, W/O LED Pushbutton Switc	Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G7SM2CAS05L00
Pushbutton Switch, On-Off, W/O LED Pushbutton Switc	Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G7SM3CAS05L00
Pushbutton Switch, On-Off, W/O LED MPP12-7B202MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B203MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B203MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B205MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B205MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O	Pushbutton Switch, Off-On, W/O LED	MPP12-6B2G7SM4CAS05L00
Pushbutton Switch, On-Off, W/O LED MPP12-7B203MM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B205MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B205MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B205MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2AGSM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED	Pushbutton Switch, On-Off, W/O LED	MPP12-7B202MM1CAS05L00
Pushbutton Switch, On-Off, W/O LED MPP12-7B203MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B205MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B205MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O	Pushbutton Switch, On-Off, W/O LED	MPP12-7B202MM1CAS05L00-Y001
Pushbutton Switch, On-Off, W/O LED Pushbutton Switc	Pushbutton Switch, On-Off, W/O LED	MPP12-7B203MM1CAS05L00
Pushbutton Switch, On-Off, W/O LED MPP12-7B205MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B206MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001	Pushbutton Switch, On-Off, W/O LED	MPP12-7B203MM1CAS05L00-Y001
Pushbutton Switch, On-Off, W/O LED Pushbutton Switch, On-Off, W/O	Pushbutton Switch, On-Off, W/O LED	MPP12-7B205MM1CAS05L00
Pushbutton Switch, On-Off, W/O LED Pushbutton Switch, On-Off, W/O	Pushbutton Switch, On-Off, W/O LED	MPP12-7B205MM1CAS05L00-Y001
Pushbutton Switch, On-Off, W/O LED Pushbutton Switch, On-Off, W/O LED MPP12-7B207MM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001	Pushbutton Switch, On-Off, W/O LED	MPP12-7B206MM1CAS05L00
Pushbutton Switch, On-Off, W/O LED Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001	Pushbutton Switch, On-Off, W/O LED	MPP12-7B206MM1CAS05L00-Y001
Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001	Pushbutton Switch, On-Off, W/O LED	MPP12-7B207MM1CAS05L00
Pushbutton Switch, On-Off, W/O LED MPP12-7B2A2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001	Pushbutton Switch, On-Off, W/O LED	MPP12-7B207MM1CAS05L00-Y001
Pushbutton Switch, On-Off, W/O LED	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2A2SM1CAS05L00
Pushbutton Switch, On-Off, W/O LED Pushbutton Switch	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2A2SM1CAS05L00-Y001
Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2A3SM1CAS05L00
Pushbutton Switch, On-Off, W/O LED MPP12-7B2A5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2A3SM1CAS05L00-Y001
Pushbutton Switch, On-Off, W/O LED Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2A5SM1CAS05L00
Pushbutton Switch, On-Off, W/O LED MPP12-7B2A6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2A5SM1CAS05L00-Y001
Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2A7SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G7SM1CAS05L00	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2A6SM1CAS05L00
Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2A6SM1CAS05L00-Y001
Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2A7SM1CAS05L00
Pushbutton Switch, On-Off, W/O LED MPP12-7B2G2SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2A7SM1CAS05L00-Y001
Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G7SM1CAS05L00	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2G2SM1CAS05L00
Pushbutton Switch, On-Off, W/O LED MPP12-7B2G3SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G7SM1CAS05L00	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2G2SM1CAS05L00-Y001
Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G7SM1CAS05L00	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2G3SM1CAS05L00
Pushbutton Switch, On-Off, W/O LED MPP12-7B2G5SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G7SM1CAS05L00	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2G3SM1CAS05L00-Y001
Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G7SM1CAS05L00	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2G5SM1CAS05L00
Pushbutton Switch, On-Off, W/O LED MPP12-7B2G6SM1CAS05L00-Y001 Pushbutton Switch, On-Off, W/O LED MPP12-7B2G7SM1CAS05L00	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2G5SM1CAS05L00-Y001
Pushbutton Switch, On-Off, W/O LED MPP12-7B2G7SM1CAS05L00	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2G6SM1CAS05L00
	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2G6SM1CAS05L00-Y001
Pushbutton Switch, On-Off, W/O LED MPP12-7B2G7SM1CAS05L00-Y001	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2G7SM1CAS05L00
	Pushbutton Switch, On-Off, W/O LED	MPP12-7B2G7SM1CAS05L00-Y001

Important Notice: This data sheet and its contents (the "Information") belong to the members of the AVNET group of companies (the "Group") or are licensed to it. No licence is granted for the use of it other than for information purposes in connection with the products to which it relates. No licence of any intellectual property rights is granted. The Information is subject to change without notice and replaces all data sheets previously supplied. The Information supplied is believed to be accurate but the Group assumes no responsibility for its accuracy or completeness, any error in or omission from it or for any use made of it. Users of this data sheet should check for themselves the Information and the suitability of the products for their purpose and not make any assumptions based on information included or omitted. Liability for loss or damage resulting from any reliance on the Information or use of it (including liability resulting from negligence or where the Group was aware of the possibility of such loss or damage arising) is excluded. This will not operate to limit or restrict the Group's liability for death or personal injury resulting from its negligence. Multicomp Pro is the registered trademark of Premier Farnell Limited 2019.

