

Mi THE MASTER SERIES

Model No CX1000

Automatic Universal Lithium Ion Video/Camcorder/Digital Camera Battery Charger

This universal battery charger comes attractively packaged in a clam shell than can be hung or free standing. The unit has a built in base plate & includes additional adaptor plates that between them will fit the majority of most brand lithium Ion camcorder batteries. Charging time - standard batteries will take around an hour to charge & high capacity batteries from 2-6 hours dependant on the battery capacity.

Input: 12VDC via car cigarette lighter plug or SAA approved 240VAC power supply included.

Output: 3.6V to 7.4V (Auto Detect) @ 800mA

CE Approved.

The standard package Includes the CX1000 charger, ac/dc adapter, cigarette lighter plug cord, video battery adaptor plates, user manual.



Available from:-

Mi Master Instruments

Sydney 33-39 Sloane St Marrickville NSW 2204

Phone (02) 95191200 Fax (02) 95194604 Email sales@master-instruments.com.au

Melbourne Unit 13 107 Heatherdale Rd Ringwood VIC 3134

Phone (03) 98726422 Fax (03) 98726466 Email vic@master-instruments.com.au

The CX1000 charger comes with adaptor plates to suit most Lilon camcorder & digital camera batteries. To check compatibility please check the guide below.

Charge with	MI Battery No	Original Battery No
Base Unit	VB511	Canon BP-511, BP-522
Plate A	VB608	Canon BP-608, BP-617
Plate C	NB-1L	Canon NB-1L
Base Unit	VB915 VBL160	Canon BP-911, BP-914, BP-915, BP-924, BP-927, BP-930R, BP-941 Samsung SB-L160/L320/L480
Plate C	VB214	JVC BN-V207, BN-V214
Base Unit	VB408 VB416 VB428	JVC BN-V408, BN-V416, BN-V428
Plate C	VB514	JVC BN-V507, BN-V514
Plate B	VB607 VB615	JVC BN-V607, BN-V615, BN-V628
Plate A	VB712 NP80	JVC BN-V712, BN-V714 Fujifilm NP80, NP100 Kodak KLIC-3000
Plate B	VB907	JVC BN-V907
Plate B	VB120 VB220 VB320	Panasonic CGR-D08A, CGP-D28A, CGP-D110, CGP-D120, CGP-D210, CGP-D220, CGP-D320, CGP-D815, CGR-D08A, CGR-D16A, CGR-D28A, CGR-D110, CGR-D120, CGR-D210, CGR-D220, CGR-D815A, VSB0418
Plate C	VB610 VB620	Panasonic CGR-V610, CGR-V620, CGR-V14
Plate B	VBF10 VBFS11 VBFS21	Sony NP-F10, NP-F20, NP-F30, NP-FS11, NP-FS21, NP-FS31
Base Unit	VBF200	Sony NP-F100, NP-F200, NP-F300
Base Unit	VBF550 VBF730 VBF750 VBF950 VBFM50 VBFM70 VB812	Sony NP-F330, NP-F530, NP-F550, NP-F730, NP-F750, NP-F930, NP-F950, NP-F960, NP-FM50, NP-FM70, NP-FM90, Panasonic AGBP-15A, AGBP-25A, VW-VBD1E, VW-VBD2E, PV-DB5, CGR-D53A, CGR-B/202A, CGR-B/403A JVC BN-V812, BN-V814 Hitachi VM-BPL13L, VM-BPL27L
Plate A	VBL2 VBL22	Sharp BT-L1, BT-L2, BT-L11, BT-L12U, BT-L22U
Plate B	VB221 VB441	Sharp BT-L41, BT-L221, BT-L241, BT-L441
Also charges the following types:- RCA BB-065L (Base Unit) BB-075, BB-075L (Plate A), Sanyo VM-LC100 (Base Unit) & Toshiba PDR-BT2 (Plate A).		