




























Weller Digital Soldering Station












WSD 81 Soldering station

Tips for the WSP 80, WSP 80 FE and MPR 80 Soldering pencils:

 LT 1 Ø 0,25 mm Round tip 5 44 435 99	 LT 1L Ø 0,2 mm Round tip 5 44 423 99	 LT 1S Ø 0,2 mm Round tip 5 44 436 99	 LT AS Ø 1,6 mm Round tip 5 44 404 99	 LT CS Ø 3,2 mm Round tip 5 44 411 99	 LT H 0,8 mm Chisel tip 5 44 437 99	 LT F 1,2 mm Chisel tip 5 44 408 99	 LT K 1,2 mm Chisel tip 5 44 438 99	 LT A 1,6 mm Chisel tip 5 44 440 99
 LT L 2,0 mm Chisel tip 5 44 414 99	 LT B 2,4 mm Chisel tip 5 44 405 99	 LT C 3,2 mm Chisel tip 5 44 407 99	 LT M 3,2 mm Chisel tip 5 44 415 99	 LT D 4,6 mm Chisel tip 5 44 409 99	 LT 4 Sloped tip 5 44 439 99	 LT GW Ø 3,2 mm Sloped tip 5 44 410 99	 LT S Ø 0,4 mm Conical tip 5 44 406 99	 LT 1LX Ø 0,2 mm Bent tip 5 44 424 99
 LT HX 0,8 mm Bent tip 5 44 420 99	 LT 4X Ø 1,2 mm Bent tip 5 44 428 99	 LT AX Ø 1,6 mm Bent tip 5 44 427 99	 LT 1X Ø 2,0 mm Bent tip 5 44 425 99	 LT 1SLX Ø 2,0 mm Bent tip 5 44 426 99	 LT ALX 1,6 mm Bent tip 5 44 443 99	 LT BX 2,4 mm Bent tip 5 44 442 99	 LT Adaptor For SMD tips 5 44 417 99	 LT BB 2,4 mm sloped tip 5 44 444 99

Tips for the WSP 150 Soldering pencil:

 LT CC 3,2 mm sloped tip 5 44 445 99	 LT Measuring tip 5 44 416 99	 LHT D 5 mm Chisel tip 5 44 452 99	 LHT E 7 mm Chisel tip 5 44 451 99	 LHT F 10 mm Chisel tip 5 44 450 99	 LHT DX 5 mm Chisel tip 5 44 462 99	 LHT EX 7 mm Chisel tip 5 44 461 99	 LHT FX 10 mm Chisel tip 5 44 460 99	 LHT Calibration tip 5 44 453 99
---	---	---	---	--	--	--	---	---