

QUICK START GUIDE

SEMPER™ Evaluation Kit EVAL-S28HL512T

Get started

1. Register your kit by scanning the QR code on the back or go to softwaretools.infineon.com
2. Connect it to any host platform that supports Octal SPI
3. Visit SEMPER™ Solutions Hub to download SEMPER™ SDK Base


For more information, please visit:
www.infineon.com/semper-solutions-hub




Published by Infineon Technologies AG 81726
Munich, Germany

Document Number: 002-40007 Rev. **
Date: 06/2024

© 2024 Infineon Technologies AG.
All Rights Reserved.





SEMPER™ Evaluation Kit EVAL-S28HL512T

- EVAL-S28HL512T is Pmod compatible
- Connects to any host platform (MCU/SoC), which supports Octal SPI with 3.3 V I/Os
- Ideal for use with SEMPER™ SDK