

233201

(ETU 02)

24 HOUR ELECTRONIC TIME CONTROLLER

USES

The easy to use 24 Hour Electronic Digital Timeswitch uses the latest technology to provide you with greater security, control, economy and comfort. This product can safely switch domestic appliances on and off up to four times a day and some examples of the benefits this can offer are listed here.

BENEFIT	APPLICATION EXAMPLE
Greater Security	Switch on a table lamp, radio or TV while you are out.
Economy	Run the washing machine overnight on Economy 7.
Comfort	Switch on a fan heater while you are out and come back to a warm room in winter.
Convenience	Switch the kettle on before you wake up in the morning. And many more applications!

MAIN FEATURES

- Simple to use
- Four programmes in a 24 hour period
- Instant ON/INT (manual override)
- Programme review
- 'Power' and 'Output' safety warning lights
- Battery powered for out of socket programming
- Digital clock display

OPERATING INSTRUCTIONS

1. To prepare the timeswitch for operation you must first set the programme ON/INT times you require and then set the clock to the correct time. Clear all previous programmes by pressing all four buttons simultaneously and hold for approximately 3 seconds. The display will show '12.00 AM'.

2. Setting the Programmes

Press the 'set' button. The display will show '----' and 'ON' with '1' flashing at the right of the display. This indicates you are now ready to set the first 'ON' time. Do this by pressing the hours and minutes buttons to the time you want.

Press 'set' again and the display will show 'INT-1'. You can now use the hours and minutes buttons to set the first 'INT' time.

Repeat the process to set up further programmes. You do not have to set all four.

3. Setting the Time

Press the 'set' button until the letter 'C' flashes at the right of the display. Use the hours and minutes buttons to set the correct time.

4. To Operate

After setting the required programmes and the correct time, press the 'set' button once more. The flashing 'C' will disappear and the clock will start.

Depending on the last switching operation, the display will indicate 'ON' or 'INT'. Set the output to the required condition by pressing the 'override' button if necessary. Thereafter the switch will operate according to the programme.

Plug into a 13 amp socket and plug in the appliance via the timeswitch. The 'power' light will indicate it is plugged into a live socket and the 'output' light will indicate when power is being supplied to the appliance.

5. Reviewing the Programmes

To review the programmes you have set, press the 'set' button. The programme indicator 'ON-1', 'INT-1' and so on will appear to indicate the programme you have set.

OTHER FEATURES

1. Instant ON/INT (Override)

If you want to change the programme instantly (i.e. switch an 'on' appliance 'off' or vice versa), simply press the override button. The 'ON' or 'INT' display will flash to show 'override'.

2. Temporary Programme Change

You may suspend any programme temporarily. Press 'set' until the relevant programme ON or INT time is displayed, then press 'override'.

An 'X' indicates that this programme setting will now be inoperative until you return to it and press override again.

Remember to press the 'set' button to return to the operating condition.

SPECIFICATION

Operating Temp.	0°C to 40°C
Battery	1AAA size Alkaline Cell
Switching Current	13 amp resistive 2 amp inductive
Switching Voltage	240V AC.

NOTE: Interrupt abbreviated to 'INT' means 'OFF'.

67-055-71

24 HOUR ELECTRONIC TIME CONTROLLER

USES

The easy to use 24 Hour Electronic Digital Timeswitch uses the latest technology to provide you with greater security, control, economy and comfort. This product can safely switch domestic appliances on and off up to four times a day and some examples of the benefits this can offer are listed here.

BENEFIT	APPLICATION EXAMPLE
Greater Security	Switch on a table lamp, radio or TV while you are out.
Economy	Run the washing machine overnight on Economy 7.
Comfort	Switch on a fan heater while you are out and come back to a warm room in winter.
Convenience	Switch the kettle on before you wake up in the morning. And many more applications!

MAIN FEATURES

- Simple to use
- Four programmes in a 24 hour period
- Instant ON/INT (manual override)
- Programme review
- 'Power' and 'Output' safety warning lights
- Battery powered for out of socket programming
- Digital clock display

OPERATING INSTRUCTIONS

1. To prepare the timeswitch for operation you must first set the programme ON/INT times you require and then set the clock to the correct time. Clear all previous programmes by pressing all four buttons simultaneously and hold for approximately 3 seconds. The display will show '12.00 AM'.

2. Setting the Programmes

Press the 'set' button. The display will show '----' and 'ON' with '1' flashing at the right of the display. This indicates you are now ready to set the first 'ON' time. Do this by pressing the hours and minutes buttons to the time you want.

Press 'set' again and the display will show 'INT-1'. You can now use the hours and minutes buttons to set the first 'INT' time.

Repeat the process to set up further programmes. You do not have to set all four.

3. Setting the Time

Press the 'set' button until the letter 'C' flashes at the right of the display. Use the hours and minutes buttons to set the correct time.

4. To Operate

After setting the required programmes and the correct time, press the 'set' button once more. The flashing 'C' will disappear and the clock will start.

Depending on the last switching operation, the display will indicate 'ON' or 'INT'. Set the output to the required condition by pressing the 'override' button if necessary. Thereafter the switch will operate according to the programme.

Plug into a 13 amp socket and plug in the appliance via the timeswitch. The 'power' light will indicate it is plugged into a live socket and the 'output' light will indicate when power is being supplied to the appliance.

5. Reviewing the Programmes

To review the programmes you have set, press the 'set' button. The programme indicator 'ON-1', 'INT-1' and so on will appear to indicate the programme you have set.

OTHER FEATURES

1. Instant ON/INT (Override)

If you want to change the programme instantly (i.e. switch an 'on' appliance 'off' or vice versa), simply press the override button. The 'ON' or 'INT' display will flash to show 'override'.

2. Temporary Programme Change

You may suspend any programme temporarily. Press 'set' until the relevant programme ON or INT time is displayed, then press 'override'.

An 'X' indicates that this programme setting will now be inoperative until you return to it and press override again.

Remember to press the 'set' button to return to the operating condition.

SPECIFICATION

Operating Temp.	0°C to 40°C
Battery	1AAA size Alkaline Cell
Switching Current	13 amp resistive 2 amp inductive
Switching Voltage	240V AC.

NOTE: Interrupt abbreviated to 'INT' means 'OFF'.

67-055-71