

All cables are straight wired and are not suitable for 10 Base T networks. They can be used for modem and ADSL purposes.



**8960-2**

Stock No	Description
<i>RJ11 4 Conductor Modular Cable</i>	
<a href="#"><u>8900-0.5</u></a>	4 Pole RJ11 Male to Male Modular Cable 0.5Mtr
<a href="#"><u>8900-1</u></a>	4 Pole RJ11 Male to Male Modular Cable 1Mtr
<a href="#"><u>8900-2</u></a>	4 Pole RJ11 Male to Male Modular Cable 2Mtr
<a href="#"><u>8900-3</u></a>	4 Pole RJ11 Male to Male Modular Cable 3Mtr
<a href="#"><u>8900-5</u></a>	4 Pole RJ11 Male to Male Modular Cable 5Mtr
<a href="#"><u>8900-10</u></a>	4 Pole RJ11 Male to Male Modular Cable 10Mtr
<a href="#"><u>8900-15</u></a>	4 Pole RJ11 Male to Male Modular Cable 15Mtr
<a href="#"><u>8900-20</u></a>	4 Pole RJ11 PLG TO PLG 20m
<a href="#"><u>8900-25</u></a>	4 Pole RJ11 PLG TO PLG 25m
<a href="#"><u>8900-30</u></a>	4 Pole RJ11 Male to Male Modular Cable 30Mtr
<i>RJ11 6 Conductor Modular Cable</i>	
<a href="#"><u>8920-0.5</u></a>	6 Pole RJ11 Male to Male Modular Cable 0.5Mtr
<a href="#"><u>8920-1</u></a>	6 Pole RJ11 Male to Male Modular Cable 1Mtr
<a href="#"><u>8920-1.2</u></a>	6 POLE RJ11 PLG TO PLG 1.2M
<a href="#"><u>8920-2</u></a>	6 POLE RJ11 Male to Male Modular Cable 2Mtr
<a href="#"><u>8920-3</u></a>	6 POLE RJ11 Male to Male Modular Cable 3Mtr
<a href="#"><u>8920-5</u></a>	6 POLE RJ11 Male to Male Modular Cable 5Mtr
<a href="#"><u>8920-10</u></a>	6 POLE RJ11 Male to Male Modular Cable 10Mtr
<i>RJ45 8 Conductor Modular Cable</i>	
<a href="#"><u>8960-0.5</u></a>	8 POLE RJ45 Male to Male Modular Cable 0.5Mtr
<a href="#"><u>8960-1</u></a>	8 POLE RJ45 Male to Male Modular Cable 1Mtr
<a href="#"><u>8960-2</u></a>	8 POLE RJ45 Male to Male Modular Cable 2Mtr
<a href="#"><u>8960-3</u></a>	8 POLE RJ45 Male to Male Modular Cable 3Mtr
<a href="#"><u>8960-5</u></a>	8 POLE RJ45 Male to Male Modular Cable 5Mtr
<a href="#"><u>8960-10</u></a>	8 POLE RJ45 Male to Male Modular Cable 10Mtr