

Product Details

Model No	VB6HMH		
Selling Unit	Each		
Categories	Portable Power Product Batteries Secondary (Rechargeable) Camcorder & Video Batteries		
Description	Video Camcorder		
Application	Video & Camcorder		
Chemistry	Nickel Metal Hydride (NiMH)		
Voltage	6V		
Nominal Capacity	4000mAh		
Brand	Master (this product is a compatible alternative to that of the original brand)		
Width	46mm		
Height	45mm		
Length/Breadth/Depth	89.5mm		
Weight	301g		
Suitable For:	Blaupunkt AX-120 Blaupunkt AX-240 Blaupunkt AX-77 Blaupunkt AX-85 Blaupunkt AX-90 Curtis Mathes FV-600 Curtis Mathes FV-900 Curtis Mathes FVC-600 Curtis Mathes FVC-900 Curtis Mathes GV-600 Fisher FVC-10 Fisher FVC-1000 Fisher FVC-2000 Fisher FVC-30 Fisher FVC-4000 Fisher FVC-70 Fisher FVC-701S Fisher FVC-720 Fisher FVC-730 Fisher FVC-750 Fisher FVC-770 Fisher FVC-800 Fisher FVC-860 Fisher FVC-880 Fisher FVC-901 Fisher FVC-950 Fisher FVC-990 JVC GR-SXM Series JVC GR-SZ1 JVC GR-SZ3 JVC GR-SZ9U JVC XM-D1BK Kyocera FP-150 Kyocera FP-1501 Kyocera FP-1502 Kyocera FP-1550 Kyocera FP-170 Kyocera KD-1700U Kyocera KD-5010U Kyocera KD-5050 Kyocera KD-530 Kyocera KD-5820 Kyocera KD-H130/U Kyocera KD-H150 Kyocera KD-H170 Kyocera KD-M710 Kyocera KD-M730 Kyocera KD-M750 Kyocera KD-M770 Kyocera KD-S530 Kyocera KD-S550 Kyocera KD-S5530 Kyocera KD-S5550 Kyocera KD-ST90 Sharp VL-E41 Sharp VL-E41S Sharp VL-E42U Sharp VL-E7E Sharp VL-E8E Sharp VL-H400 Sharp VL-H400C Sharp VL-H400S Sharp VL-H400U Sharp VL-HL-1 Sharp VL-HL100U Sharp VL-HL-100U Sharp VL-HL-3 Sharp VL-HX-10U Sharp VL-L310U Sharp VL-L390 Sharp VL-L40 Sharp VL-L64U Sharp VL-M4X Sharp VL-M6C(GY) Sharp VL-M6GY Sharp VL-M6U(GY) Sharp VL-M6U(SL) Sharp VL-MX4X Sharp VL-MX6U Sharp VL-MX7 Sharp VL-MX70		

Fisher FVC-990
Fisher FVC-P2000
Fisher FVC-P701
Fisher FVC-P730
Fisher FVC-P750
Fisher FVC-P770
Fisher FVC-P880
Fisher FVC-P901
Fisher FVC-P950
Fisher FVC-P990
Fisher FVC-S2
Fisher FVP-80320
Fisher VDM6
Fujix F120SW
Fujix F122SW
Fujix F60
Fujix F610
Fujix F615
Fujix F620
Fujix F810
Fujix FF60
Fujix FF66
Fujix FH80
Fujix G806-7
Fujix G806-7-T
Fujix G901-T
Fujix H128SW
Fujix H80
Fujix M600-AF
Fujix M680
Fujix M690
Fujix M830HR
Fujix M890
Fujix P40U
Fujix P650
Fujix P660
Fujix P850
Fujix XF-60Y
Fujix XF-615
Fujix XFF-60
Fujix XFF-66
Fujix XFH-80
Fujix XH-80
Fujix XM-690
Fujix XP-40U
Fujix XP-660
Goldstar GS-E2
JVC GR-1U

Kyocera KD-S190
Kyocera KX-1
Kyocera KX-70/E
Kyocera KX-77/CV
Kyocera KX-77U
Kyocera KX-90/E
Kyocera KX-H1/U
Kyocera KX-H3
Kyocera KX-VI
Nikon VN-200
Nikon VN-300
Nikon VN-310
Nikon VN-330
Nikon VN-340
Nikon VN-350
Nikon VN-360
Nikon VN-400
Nikon VN-500
Nikon VN-5000
Nikon VN-550
Nikon VN-700
Nikon VN-720
Nikon VN-750
Nikon VN-760
Nikon VN-77
Nikon VN-820
Nikon VN-8200
Nikon VN-830
Nikon VN-8300
Nikon VN-840
Nikon VN-850
Nikon VN-860
Nikon VN-870
Nikon VN-900
Nikon VN-9000
Nikon VN-910
Nikon VN-9100
Nikon VN-950
Nikon VN-9500
Nikon VN-960
Nikon VN-9600
Olympus VC-52E
Olympus VX-43
Olympus VX-54
Olympus VX-806
Olympus VX-81
Olympus VX-82
Olympus VX-82E

Sharp VL-MX7U
Sharp VL-MX7C(GY)
Sharp VL-MX7C(SL)
Sharp VL-MX7U
Sharp VL-MX7U(GY)
Sharp VL-MX7U(SL)
Sharp VL-MX8U
Sharp VL-N1
Sharp VL-N1C
Sharp VL-N1H
Sharp VL-N1S
Sharp VL-N1U
Sharp VL-N1X
Sharp VL-N6S
Sharp VL-S6
Sony CCD-20061
Sony CCD-335E
Sony CCD-35
Sony CCD-366BR
Sony CCD-380
Sony CCD-390
Sony CCD-400
Sony CCD-50E
Sony CCD-550
Sony CCD-850
Sony CCD-EB55
Sony CCD-F1330
Sony CCD-F150
Sony CCD-F201
Sony CCD-F250
Sony CCD-F280
Sony CCD-F288BR
Sony CCD-F30
Sony CCD-F300
Sony CCD-F301
Sony CCD-F302
Sony CCD-F31
Sony CCD-F32
Sony CCD-F33
Sony CCD-F330
Sony CCD-F335
Sony CCD-F34
Sony CCD-F340
Sony CCD-F35
Sony CCD-F350
Sony CCD-F350E
Sony CCD-F355E
Sony CCD-F36

JVC GR-1UGR-AX2	Olympus VX-860E	Sony CCD-F360
JVC GR-25U	Olympus VX-C500	Sony CCD-F365
JVC GR-2U	Panasonic NV-3CCD1	Sony CCD-F370E
JVC GR-303	Panasonic NV-61	Sony CCD-F375E
JVC GR-303EG	Panasonic NV-63	Sony CCD-F38
JVC GR-303U	Panasonic NV-G1	Sony CCD-F380
JVC GR-323U	Panasonic NV-G101	Sony CCD-F385
JVC GR-35U	Panasonic NV-G101A	Sony CCD-F385E
JVC GR-40	Panasonic NV-G120	Sony CCD-F388BR
JVC GR-400	Panasonic NV-G2	Sony CCD-F390
JVC GR-40U	Panasonic NV-G200	Sony CCD-F390E
JVC GR-45	Panasonic NV-G202	Sony CCD-F40
JVC GR-450	Panasonic NV-G202A	Sony CCD-F401
JVC GR-55	Panasonic NV-G220	Sony CCD-F402
JVC GR-5505	Panasonic NV-G3	Sony CCD-F45
JVC GR-60U	Panasonic NV-G303	Sony CCD-F450
JVC GR-65EG	Panasonic NV-G3A	Sony CCD-F450E
JVC GR-707U	Panasonic NV-M810	Sony CCD-F455E
JVC GR-A30	Panasonic NV-M810PX	Sony CCD-F46
JVC GR-AS-X760U	Panasonic NV-MS70	Sony CCD-F475
JVC GR-AW1	Panasonic NV-MS95	Sony CCD-F50
JVC GR-AW1U	Panasonic NV-MS950	Sony CCD-F500
JVC GR-AX10	Panasonic NV-MS95A	Sony CCD-F500E
JVC GR-AX100	Panasonic NV-RJ16	Sony CCD-F501
JVC GR-AX1010U	Panasonic NV-RJ17	Sony CCD-F55
JVC GR-AX10U	Panasonic NV-RJ26	Sony CCD-F550
JVC GR-AX110	Panasonic NV-RJ27	Sony CCD-F550E
JVC GR-AX150	Panasonic NV-RJ36	Sony CCD-F555
JVC GR-AX155	Panasonic NV-RJ46	Sony CCD-F555E
JVC GR-AX17	Panasonic NV-RJ47	Sony CCD-F56
JVC GR-AX17U	Panasonic NV-RJ56	Sony CCD-F57
JVC GR-AX2	Panasonic NV-RJ67	Sony CCD-F70
JVC GR-AX200	Panasonic NV-S1	Sony CCD-F701
JVC GR-AX200U	Panasonic NV-S100	Sony CCD-F72
JVC GR-AX201U	Panasonic NV-S1A	Sony CCD-F73
JVC GR-AX202U	Panasonic NV-S2	Sony CCD-F75
JVC GR-AX210	Panasonic NV-S20	Sony CCD-F77
JVC GR-AX210U	Panasonic NV-S250	Sony CCD-F900
JVC GR-AX220U	Panasonic NV-S4	Sony CCD-FPKTRV8
JVC GR-AX230U	Panasonic NV-S5	Sony CCD-FTR45
JVC GR-AX25	Panasonic NV-S500	Sony CCD-FTR55
JVC GR-AX250	Panasonic NV-S500EN	Sony CCD-FTR65
JVC GR-AX255	Panasonic NV-SSA	Sony CCD-FTR75
JVC GR-AX25U	Panasonic NV-S5B	Sony CCD-FV01
JVC GR-AX26U	Panasonic NV-S5E	Sony CCD-FX200E
JVC GR-AX2U	Panasonic NV-SSEC	Sony CCD-FX210
JVC GR-AX200	Panasonic NV-S5C	Sony CCD-FX220

JVC GR-AX2U
JVC GR-AX30
JVC GR-AX300U
JVC GR-AX30U
JVC GR-AX310
JVC GR-AX310U
JVC GR-AX33
JVC GR-AX33U
JVC GR-AX34U
JVC GR-AX35
JVC GR-AX350U
JVC GR-AX35U
JVC GR-AX37
JVC GR-AX37U
JVC GR-AX40
JVC GR-AX400
JVC GR-AX400U
JVC GR-AX401U
JVC GR-AX404U
JVC GR-AX40E
JVC GR-AX410
JVC GR-AX410U
JVC GR-AX420U
JVC GR-AX430U
JVC GR-AX46U
JVC GR-AX47U
JVC GR-AX5
JVC GR-AX500
JVC GR-AX500U
JVC GR-AX50U
JVC GR-AX510U
JVC GR-AX55
JVC GR-AX55U
JVC GR-AX5EG
JVC GR-AX5U
JVC GR-AX60
JVC GR-AX606U
JVC GR-AX610U
JVC GR-AX640
JVC GR-AX640U
JVC GR-AX650U
JVC GR-AX655U
JVC GR-AX680
JVC GR-AX70
JVC GR-AX700U
JVC GR-AX70U
JVC GR-AX710U
JVC GR-AX720

Panasonic NV-S5EC
Panasonic NV-S6
Panasonic NV-S600
Panasonic NV-S600EN
Panasonic NV-S6A
Panasonic NV-S6B
Panasonic NV-S6E
Panasonic NV-S7
Panasonic NV-S700
Panasonic NV-S750
Panasonic NV-S78
Panasonic NV-S8
Panasonic NV-S800
Panasonic NV-S8A
Panasonic NV-VJ57
Panasonic NV-VJ66
Panasonic NV-VJ77
Panasonic NV-VJ78
Panasonic NV-VJ98
Panasonic PV-10
Panasonic PV-10B
Panasonic PV-10PX
Panasonic PV-14
Panasonic PV-17
Panasonic PV-18
Panasonic PV-19
Panasonic PV-20
Panasonic PV-21
Panasonic PV-22
Panasonic PV-31
Panasonic PV-32
Panasonic PV-332
Panasonic PV-333
Panasonic PV-362
Panasonic PV-40
Panasonic PV-41
Panasonic PV-42
Panasonic PV-43
Panasonic PV-50
Panasonic PV-53
Panasonic PV-5372
Panasonic PV-559
Panasonic PV-5630
Panasonic PV-A206
Panasonic PV-A207
Panasonic PV-A286
Panasonic PV-A306
Panasonic PV-A307

Sony CCD-FX210
Sony CCD-FX230
Sony CCD-FX240
Sony CCD-FX280E
Sony CCD-FX3
Sony CCD-FX300
Sony CCD-FX300E
Sony CCD-FX310
Sony CCD-FX311
Sony CCD-FX320
Sony CCD-FX330
Sony CCD-FX340
Sony CCD-FX400
Sony CCD-FX400E
Sony CCD-FX410
Sony CCD-FX411
Sony CCD-FX420
Sony CCD-FX425
Sony CCD-FX430
Sony CCD-FX435
Sony CCD-FX470
Sony CCD-FX500
Sony CCD-FX510
Sony CCD-FX510E
Sony CCD-FX511
Sony CCD-FX520
Sony CCD-FX525
Sony CCD-FX530
Sony CCD-FX600
Sony CCD-FX620
Sony CCD-FX630
Sony CCD-FX640
Sony CCD-FX700
Sony CCD-FX700E
Sony CCD-FX710
Sony CCD-FX720
Sony CCD-FX730
Sony CCD-FX730V
Sony CCD-FX810
Sony CCD-FX830VE
Sony CCD-G100ST
Sony CCD-GV200
Sony CCD-GV300
Sony CCD-M7
Sony CCD-M77
Sony CCD-M7U
Sony CCD-M7V
Sony CCD-SC6E

JVC GR-AX720U	Panasonic PV-D1000	Sony CCD-SC8E
JVC GR-AX730U	Panasonic PV-D326	Sony CCD-SP5
JVC GR-AX74U	Panasonic PV-D406	Sony CCD-SP54
JVC GR-AX750U	Panasonic PV-D407	Sony CCD-SP5G
JVC GR-AX75U	Panasonic PV-D506	Sony CCD-SP5Y
JVC GR-AX760U	Panasonic PV-D507	Sony CCD-SP7
JVC GR-AX761U	Panasonic PV-D607	Sony CCD-SP9
JVC GR-AX76U	Panasonic PV-D705	Sony CCD-TR100
JVC GR-AX77U	Panasonic PV-IQ203	Sony CCD-TR101
JVC GR-AX7EG	Panasonic PV-IQ205	Sony CCD-TR105
JVC GR-AX7U	Panasonic PV-IQ244D	Sony CCD-TR105E
JVC GR-AX80	Panasonic PV-IQ303	Sony CCD-TR150
JVC GR-AX800	Panasonic PV-IQ305	Sony CCD-TR2000
JVC GR-AX800U	Panasonic PV-IQ306	Sony CCD-TR202
JVC GR-AX808U	Panasonic PV-IQ325	Sony CCD-TR202E
JVC GR-AX810U	Panasonic PV-IQ403	Sony CCD-TR205
JVC GR-AX820U	Panasonic PV-IQ404	Sony CCD-TR21
JVC GR-AX820US	Panasonic PV-IQ404A	Sony CCD-TR23
JVC GR-AX830U	Panasonic PV-IQ405	Sony CCD-TR250E
JVC GR-AX840U	Panasonic PV-IQ503	Sony CCD-TR28
JVC GR-AX841U	Panasonic PV-IQ504	Sony CCD-TR30
JVC GR-AX84U	Panasonic PV-IQ505	Sony CCD-TR3000E
JVC GR-AX880	Panasonic PV-IQ525	Sony CCD-TR303
JVC GR-AX880US	Panasonic PV-L352	Sony CCD-TR305
JVC GR-AX890	Panasonic PV-L353	Sony CCD-TR305E
JVC GR-AX890U	Panasonic PV-L354	Sony CCD-TR30S
JVC GR-AX90	Panasonic PV-L552	Sony CCD-TR31
JVC GR-AX900U	Panasonic PV-L557	Sony CCD-TR323
JVC GR-AX90U	Panasonic PV-L606	Sony CCD-TR323E
JVC GR-AX910	Panasonic PV-L657	Sony CCD-TR33
JVC GR-AX910U	Panasonic PV-L757	Sony CCD-TR330
JVC GR-AX911U	Panasonic PV-L857	Sony CCD-TR330E
JVC GR-AX920	Panasonic PV-S332	Sony CCD-TR333
JVC GR-AX920U	Panasonic PV-S372	Sony CCD-TR333E
JVC GR-AX930U	Panasonic PV-S43	Sony CCD-TR350E
JVC GR-AX94	Panasonic PV-S53	Sony CCD-TR353E
JVC GR-AX940U	Panasonic PV-S62	Sony CCD-TR36
JVC GR-AX94U	Panasonic PV-S63	Sony CCD-TR380E
JVC GR-AX95	Panasonic PV-S630	Sony CCD-TR385E
JVC GR-AX96U	Panasonic PV-S64	Sony CCD-TR4
JVC GR-AX970U	Panasonic PV-S72	Sony CCD-TR40
JVC GR-AX97U	Panasonic PV-S770A	Sony CCD-TR400
JVC GR-AX9U	Panasonic VZ-LDS15	Sony CCD-TR403
JVC GR-AXM100U	Pentax PVC-480E	Sony CCD-TR420
JVC GR-AXM1010U	Pentax PVC-8000E	Sony CCD-TR420E
JVC GR-AXM10U	Pentax PVC-840E	Sony CCD-TR44
JVC GR-AXM151US	Pentax PVC-860E	Sony CCD-TR440
JVC GR-AXM17US	Pentax PVE-M100A	Sony CCD-TR440E

JVC GR-AXM17US
JVC GR-AXM1U
JVC GR-AXM20U
JVC GR-AXM210U
JVC GR-AXM220U
JVC GR-AXM225U
JVC GR-AXM23
JVC GR-AXM230U
JVC GR-AXM231U
JVC GR-AXM241U
JVC GR-AXM250U
JVC GR-AXM25U
JVC GR-AXM270U
JVC GR-AXM2U
JVC GR-AXM30
JVC GR-AXM300U
JVC GR-AXM30U
JVC GR-AXM310U
JVC GR-AXM341U
JVC GR-AXM407
JVC GR-AXM40U
JVC GR-AXM4U
JVC GR-AXM500
JVC GR-AXM50U
JVC GR-AXM510U
JVC GR-AXM511U
JVC GR-AXM650U
JVC GR-AXM670U
JVC GR-AXM700U
JVC GR-AXM70U
JVC GR-AXM710U
JVC GR-AXM740U
JVC GR-AXM745U
JVC GR-AXM750U
JVC GR-AXM750US
JVC GR-AXM755US
JVC GR-AXM800U
JVC GR-AXM80U
JVC GR-AXM88UM
JVC GR-AXM900U
JVC GR-AXM910U
JVC GR-AXM Series
JVC GR-AX Series
JVC GR-C11
JVC GR-C1U
JVC GR-C25□
JVC GR-C250
JVC GR-C55

Pentax PVE-M100A
Pentax PVE-M100E
RCA 151
RCA 152
RCA 16-852
RCA 16-853
RCA 188
RCA CC-1000
RCA CC-600
RCA CC-604
RCA CC-612
RCA CC-614
RCA CG-400
RCA CG-812
RCA CG-814
RCA CG-819
RCA CG-820
RCA PRO807
RCA PRO808
RCA PRO809
RCA PRO830
RCA PRO840
RCA PRO843
RCA PRO845
Ricoh R-105
Ricoh R-108H
Ricoh R-15
Ricoh R-16
Ricoh R-17C
Ricoh R-18H
Ricoh R-200
Ricoh R-260
Ricoh R-600S
Ricoh R-610
Ricoh R-612
Ricoh R-615
Ricoh R-620
Ricoh R-630
Ricoh R-66
Ricoh R-67
Ricoh R-680
Ricoh R-800H
Ricoh R-808H
Ricoh R-810
Ricoh R-830
Ricoh R-831
Ricoh R-850
Ricoh R-86

Sony CCD-TR440E
Sony CCD-TR450
Sony CCD-TR45E
Sony CCD-TR45WH
Sony CCD-TR490E
Sony CCD-TR5
Sony CCD-TR50
Sony CCD-TR501E
Sony CCD-TR502E
Sony CCD-TR503E
Sony CCD-TR505
Sony CCD-TR505K
Sony CCD-TR506
Sony CCD-TR507
Sony CCD-TR50E
Sony CCD-TR51
Sony CCD-TR514
Sony CCD-TR530
Sony CCD-TR54
Sony CCD-TR55
Sony CCD-TR550
Sony CCD-TR55E
Sony CCD-TR580E
Sony CCD-TR590E
Sony CCD-TR6
Sony CCD-TR60
Sony CCD-TR600
Sony CCD-TR606E
Sony CCD-TR60E
Sony CCD-TR61
Sony CCD-TR614
Sony CCD-TR620E
Sony CCD-TR64
Sony CCD-TR65
Sony CCD-TR66
Sony CCD-TR7
Sony CCD-TR70
Sony CCD-TR700
Sony CCD-TR705
Sony CCD-TR705E
Sony CCD-TR707
Sony CCD-TR707E
Sony CCD-TR70E
Sony CCD-TR71
Sony CCD-TR714
Sony CCD-TR72
Sony CCD-TR720E
Sony CCD-TR73

JVC GR-C55	Ricoh R-86	Sony CCD-TR73
JVC GR-C7	Ricoh R-860	Sony CCD-TR74
JVC GR-C7U	Ricoh R-861	Sony CCD-TR740E
JVC GR-C9	Ricoh R-86S	Sony CCD-TR75
JVC GR-DVA1	Ricoh R-88	Sony CCD-TR750
JVC GR-DVA1U	Ricoh R-880	Sony CCD-TR750E
JVC GR-DVF1	Ricoh R-88H	Sony CCD-TR75BR
JVC GR-DVF10	Ricoh TF-200	Sony CCD-TR75E
JVC GR-DVF10U	Ricoh VC-H815	Sony CCD-TR78
JVC GR-DVF20	Saba CMA1	Sony CCD-TR8
JVC GR-DVF20U	Samsung MH360P	Sony CCD-TR805
JVC GR-DVF25	Samsung NBG160	Sony CCD-TR805E
JVC GR-DVF3	Samsung NC120P	Sony CCD-TR808
JVC GR-DVF7	Samsung NC240P	Sony CCD-TR81
JVC GR-EX1	Samsung NH180P	Sony CCD-TR814
JVC GR-EX7	Samsung SC-A20	Sony CCD-TR82
JVC GR-EZ1U	Samsung SC-A23	Sony CCD-TR83
JVC GR-FX10	Samsung SC-A25	Sony CCD-TR84
JVC GR-FX11	Samsung SC-A30	Sony CCD-TR86
JVC GR-FX12	Samsung SC-A300	Sony CCD-TR88
JVC GR-FX14	Samsung SC-A33	Sony CCD-TR880
JVC GR-FX16	Samsung SC-A35	Sony CCD-TR880E
JVC GR-FX17	Samsung SC-A80	Sony CCD-TR9
JVC GR-FX17E	Samsung SC-A85	Sony CCD-TR900
JVC GR-FX18E	Samsung SC-H985	Sony CCD-TR91
JVC GR-FX60	Samsung SC-H996	Sony CCD-TR916
JVC GR-FXM15	Samsung SCK-60	Sony CCD-TR93
JVC GR-FXM16	Samsung SCK-70	Sony CCD-TR94
JVC GR-FXM161	Samsung SCK-75	Sony CCD-TR96
JVC GR-FXM37	Samsung SCK-80	Sony CCD-TR98
JVC GR-FXM373	Samsung SCK-85	Sony CCD-TR99
JVC GR-FXM38	Samsung SC-L100	Sony CCD-TRV10
JVC GR-FXM383	Samsung SC-L150	Sony CCD-TRV100
JVC GR-FXM40	Samsung SC-L300	Sony CCD-TRV10E
JVC GR-FXM404	Samsung SC-L330	Sony CCD-TRV11
JVC GR-FXM40E	Samsung SC-L350	Sony CCD-TRV112
JVC GR-FXM41	Samsung SC-L800	Sony CCD-TRV119
JVC GR-FXM41E	Samsung SC-L850	Sony CCD-TRV11E
JVC GR-FXM42E	Samsung SC-M3	Sony CCD-TRV12
JVC GR-FXM65	Samsung SC-X800	Sony CCD-TRV14E
JVC GR-FXM Series	Samsung SC-X804	Sony CCD-TRV19
JVC GR-FX Series	Samsung SC-X854	Sony CCD-TRV21
JVC GR-HF705U	Samsung SC-X904	Sony CCD-TRV211
JVC GR-HF805U	Samsung SC-X915	Sony CCD-TRV212
JVC GR-LT10	Samsung SC-X953	Sony CCD-TRV21E
JVC GR-LT5	Samsung SC-X954	Sony CCD-TRV22
JVC GR-LT7	Samsung SLC-90	Sony CCD-TRV24E
JVC GR-LT90	Samsung SV-E27	Sony CCD-TRV29

JVC GR-LT91	Samsung SVE-27N	Sony CCD-TRV30
JVC GR-M7U	Samsung SV-H30	Sony CCD-TRV30E
JVC GR-MV1	Samsung SV-H33	Sony CCD-TRV31
JVC GR-S27	Samsung SV-H815	Sony CCD-TRV312
JVC GR-S35	Samsung SV-X803	Sony CCD-TRV32
JVC GR-S505EG	Samsung VCE-27N	Sony CCD-TRV33
JVC GR-S505U	Samsung VC-E405P	Sony CCD-TRV34
JVC GR-S55	Samsung VC-E805P	Sony CCD-TRV40
JVC GR-S707	Samsung VCE-805P	Sony CCD-TRV44
JVC GR-S707EG	Samsung VC-E806P	Sony CCD-TRV44E
JVC GR-S70EG	Samsung VC-E807	Sony CCD-TRV512
JVC GR-S70U	Samsung VC-H815	Sony CCD-TRV52
JVC GR-S75	Samsung VCH-815	Sony CCD-TRV53
JVC GR-S77U	Samsung VP-A12	Sony CCD-TRV60
JVC GR-S99	Samsung VP-A17	Sony CCD-TRV70
JVC GR-S99EG	Samsung VP-A18	Sony CCD-TRV73
JVC GR-SV1U	Samsung VP-A20	Sony CCD-V101
JVC GR-SV3	Samsung VP-A21	Sony CCD-V11
JVC GR-SV3GR-S27	Samsung VP-A22	Sony CCD-V2006i
JVC GR-SV3U	Samsung VP-A30	Sony CCD-V22
JVC GR-SV7U	Samsung VP-A31	Sony CCD-V301
JVC GR-SX160	Samsung VP-A32	Sony CCD-V330E
JVC GR-SX19	Samsung VP-A33	Sony CCD-V340E
JVC GR-SX202	Samsung VP-A34	Sony CCD-V4
JVC GR-SX21	Samsung VP-A50	Sony CCD-V401
JVC GR-SX210A	Samsung VP-A52	Sony CCD-V4330E
JVC GR-SX21EA	Samsung VP-A55	Sony CCD-V500
JVC GR-SX22	Samsung VP-A57	Sony CCD-V5000
JVC GR-SX24	Samsung VP-A800	Sony CCD-V5000E
JVC GR-SX26	Samsung VP-A850	Sony CCD-V55
JVC GR-SX260	Samsung VP-C27H	Sony CCD-V550
JVC GR-SX26E	Samsung VP-E404	Sony CCD-V600
JVC GR-SX41	Samsung VP-E405	Sony CCD-V6000
JVC GR-SX850U	Samsung VP-E807	Sony CCD-V600E
JVC GR-SX851U	Samsung VP-E808	Sony CCD-V601
JVC GR-SX860U	Samsung VP-H65	Sony CCD-V700
JVC GR-SX907	Samsung VP-H66	Sony CCD-V700E
JVC GR-SX950U	Samsung VP-H68	Sony CCD-V701
JVC GR-SXM161	Samsung VP-J52	Sony CCD-V800
JVC GR-SXM200	Samsung VP-K60	Sony CCD-V800E
JVC GR-SXM235U	Samsung VP-K65	Sony CCD-V801
JVC GR-SXM240U	Samsung VP-K70	Sony CCD-V88
JVC GR-SXM245U	Samsung VP-K75	Sony CCD-V88E
JVC GR-SXM250US	Samsung VP-K80	Sony CCD-V9
JVC GR-SXM255	Samsung VP-K85	Sony CCD-V900
JVC GR-SXM256	Samsung VP-L220	Sony CCD-V900E
JVC GR-SXM26	Samsung VP-L300	Sony CCD-V90E

JVC GR-SXM260	Samsung VP-L320	Sony CCD-V95E
JVC GR-SXM260A	Samsung VP-L330	Sony CCD-V99
JVC GR-SXM260U	Samsung VP-L350	Sony CCD-V9E
JVC GR-SXM260US	Samsung VP-L980	Sony CCD-VX1
JVC GR-SXM265	Samsung VP-S50	Sony CCD-VX3
JVC GR-SXM26EA	Samsung VPU-10	Sony EVC-9100
JVC GR-SXM277	Samsung VP-U12	Sony EVC-X7
JVC GR-SXM278	Samsung VP-U15	Sony GV-5K
JVC GR-SXM279	Sanyo VEM-H100	Sony GV-8
JVC GR-SXM29	Sanyo VEM-S1	Sony GV-9
JVC GR-SXM30	Sanyo VEM-S2	Sony GV-9E
JVC GR-SXM300	Sanyo VM-66	Sony GV-U5
JVC GR-SXM320U	Sanyo VM-D1	Sony MVC-2000
JVC GR-SXM330U	Sanyo VM-D3	Sony MVC-5000
JVC GR-SXM335U	Sanyo VM-D44	Sony XV-M30
JVC GR-SXM340U	Sanyo VM-D5P	Sony XV-MH30
JVC GR-SXM37US	Sanyo VM-D66/P	Yashica FP-150
JVC GR-SXM46	Sanyo VM-D6P	Yashica FP-1501
JVC GR-SXM460A	Sanyo VM-D8P	Yashica FP-1502
JVC GR-SXM46EA	Sanyo VM-ES77	Yashica FP-1550
JVC GR-SXM47	Sanyo VM-ES88	Yashica FP-170
JVC GR-SXM48	Sanyo VM-ES88P	Yashica KD-1700U
JVC GR-SXM50	Sanyo VM-ES99	Yashica KD-5010U
JVC GR-SXM50E	Sanyo VM-H100P	Yashica KD-5050
JVC GR-SXM515U	Sanyo VM-P5P	Yashica KD-530
JVC GR-SXM520U	Sanyo VM-PS12	Yashica KD-5820
JVC GR-SXM525U	Sanyo VM-RZ1A	Yashica KD-H130/U
JVC GR-SXM527U	Sanyo VM-RZ1P	Yashica KD-H150
JVC GR-SXM530	Sharp GV-9	Yashica KD-H170
JVC GR-SXM535U	Sharp TWINCAM	Yashica KD-M710
JVC GR-SXM540U	Sharp VL-E100U	Yashica KD-M730
JVC GR-SXM57	Sharp VL-E30	Yashica KD-M750
JVC GR-SXM58	Sharp VL-E30C	Yashica KD-M770
JVC GR-SXM600	Sharp VL-E30S	Yashica KD-S530
JVC GR-SXM607	Sharp VL-E31	Yashica KD-S550
JVC GR-SXM720U	Sharp VL-E31E	Yashica KD-S5530
JVC GR-SXM730U	Sharp VL-E31S	Yashica KD-S5550
JVC GR-SXM735U	Sharp VL-E32U	Yashica KD-ST90
JVC GR-SXM740U	Sharp VL-E35U	Yashica KX-1
JVC GR-SXM745	Sharp VL-E36C	Yashica KX-70/E
JVC GR-SXM750U	Sharp VL-E36U	Yashica KX-77/CV
JVC GR-SXM750US	Sharp VL-E40	Yashica KX-77U
JVC GR-SXM755US	Sharp VL-E400U	Yashica KX-90/E
JVC GR-SXM915U	Sharp VL-E40C	Yashica KX-H1/U
JVC GR-SXM920U	Sharp VL-E40S	Yashica KX-H3
JVC GR-SXM930	Sharp VL-E40U	Yashica KX-VI
JVC GR-SXM930U		

	JVC GR-SXM930U JVC GR-SXM960U		
Compatible With:	Akai BPN300 Akai BPN350 Bauer BA610 Bauer BA611 Bosch BA610 Bosch BA611 Bosch BA880 Dual Voltage DV9011 Dual Voltage DV9022 Dual Voltage DV9033 Dual Voltage DV9066 Dual Voltage DV9066P Dual Voltage DV9077 Duracell DR10 Duracell DR11 G.E. 1CVA157C G.E. 1CVA158C Goldstar GS-E2 GP VD101 GP VD102 GP VD103 GP VD104 GP VD151 GP VD152 GP VD153 GP VP101 GP VP102 GP VP103 GP VP151 GP VP152 GP VP153 GP VS101 GP VS102 GP VS103 GP VS104 GP VS151 GP VS152 GP VS153 GP VT101 GP VT102 Grundig BP8-1 Grundig BP8-2 JVC BN-BP31 JVC BN-V11U	JVC BN-V25 JVC BN-V25U JVC BN-V400B JVC BN-V400U JVC BN-V50U JVC BN-V60U JVC BN-V65 Kyocera BP-150 Kyocera BP-1501 Kyocera BP-1502 Kyocera BP-1503 Kyocera BP-1550 Kyocera BP-170 Loewe BP81 Loewe BP82 Magnavox V80115BK01 Magnavox V80116BK01 Metz 9637-1 Metz 9637-20 Minolta VBP-400E Minolta VBP-401E Minolta VBP-600E Mitsubishi BY-M1 Mitsubishi BY-M2 Nikon NP66H Nikon NP77H Normende AC450 Normende AC455 Panasonic BP-12 Panasonic BP15 Panasonic BP-17 Panasonic BP-18 Panasonic HHR-V20 Panasonic HHR-V20A/1B Panasonic HHR-V214A/K Panasonic HHR-V40A Panasonic HHR-V40A/1B Panasonic PV-213A Panasonic PV-214A Panasonic P-V215A Panasonic PV-B18 Panasonic PV-BP15 Panasonic PV-BP17 Panasonic VW-VBH1	Philips SBC-5216 Philips SBC-5217 Philips SBC-5219 Quasar BP0503 Quasar BP500 RCA BB060 RCA BB120 Ricoh NP66 Ricoh NP77 Saba A8-100 Saba A8-200 Samsung NB-E60 Samsung NB-E70 Samsung NC-240 Samsung SCA-12 Samsung VP-A20 Sanyo NP66 Sanyo NP77 Sharp BT-70 Sharp BT-70BK Sharp BT-77 Sharp BT-80 Sharp BT-80BK Sharp BT-80SBK Sharp BT-BH70 Siemens FZ-114G4 Siemens FZ-115G4 Sony NP33 Sony NP-55 Sony NP-55H Sony NP66 Sony NP-66H Sony NP-67 Sony NP68 Sony NP77 Sony NP-77H Sony NP-77HD Sony NP78 Sony NP90D Sony NP98 Sony NP-98D Sony NP-C65 Sony NPS88A Telefunken VZ-824

	JVC BN-V12 JVC BN-V12U JVC BN-V140U JVC BN-V14U JVC BN-V15 JVC BN-V18U JVC BN-V20 JVC BN-V20U JVC BN-V20US JVC BN-V22 JVC BN-V22U JVC BN-V24U	Panasonic VW-VBH1E Panasonic VW-VBH2 Panasonic VW-VBH2E Panasonic VW-VBR1 Panasonic VW-VBR1E Panasonic VW-VBR2 Panasonic VW-VBR2E Panasonic VW-VBS1 Panasonic VW-VBS1E Panasonic VW-VBS2 Panasonic VW-VBS2E	Telefunken VZ-825 Varta V111 Varta V208 Varta V213 Varta V217 Varta V67 Varta V92 Yashica BP-1501 Yashica BP-1502 Yashica BP-1550 Yashica BP-170
Cell Type Used:	Sanyo Cells Used for Superior performance & extended service life.		
Comments	To view chargers suitable for this battery please click here. Some modification maybe required for old superseded Panasonic G1, G2 & G3 video cameras. Click here for more information. Cells inside this battery pack are premium quality made in Japan.		