

DigitalInnovations
Simplicity Perfected

SkipDr Motorized
Quick Start Guide



SPRAY
SkipDr® Rejuvenating Fluid lightly onto the play-side of the disc (do not spray on the label-side).



REPAIR
the disc by inserting it into the SkipDr® Disc Repair System with the play-side toward the FlexiWheel™. Press the ON/OFF button on top of the device to start the process. After the disc has made 2 full rotations, press the button again to stop.



DRY + SHINE
Dry the play side of the disc with the blue drying cloth. Then place the disc on top of the drying cloth and buff using the white buffing square. NOTE: Thorough buffing is crucial for perfect playback. It is normal for a slight, harmless radial pattern to remain on the disc after buffing. Repeat step as necessary. The Flexiwheel™ will repair up to 25 discs.

WARNING: Not for use with Blu-ray™ or Playstation® 3 discs.